FOREWORD

The dominating idea back of "Union Special" is to build the best industrial sewing machines in the world. The new high speed feed-off-the-arm machines in Class 35800, equipped with "V" type cylinder, are a pronounced achievement along these lines. All parts are made to precision gauges insuring complete interchangeability.

It is our constant aim to furnish carefully prepared information that will enable the customer to secure all possible economies and advantages from the use of Union Specials. The following pages illustrate and describe the parts for the styles in Class 35800.

Additional catalogs, containing information relative to these machines, and which will be furnished on request, are listed below:

Catalog No. 29 Third Edition List of miscellaneous accessories and transmitter parts Catalog No. 45 Needle Manual Form 357 Engineering Department Adjusting Instructions. Specify the style of machine for which the adjusting instructions are required.

In all manufacturing centers will be found Union Special representatives, who will cooperate with those who desire in planning and estimating their requirements.

> UNION SPECIAL MACHINE COMPANY Engineering Department

IDENTIFICATION OF MACHINES

Each Union Special carries a style number which is stamped in the name plate on the machine. Style numbers are classified as standard and special. Those which are standard have one or more letters suffixed, but never contain the letter "Z". Example: "35800 AC". Style numbers containing the letter "Z" are special. When only minor changes are made in a standard machine a "Z" is merely suffixed to the respective standard style number. Example: "35800 ACZ"
Styles of machines similar in construction are grouped

under a class number which differs from the style number in

that it contains no letters. Example: "35800"

APPLICATION OF CATALOG

This catalog applies only to the standard styles of machines as listed herein, which are equipped with "V" type cylinder. It can also be applied with discretion to the special machines in Class 35800.

STYLES OF MACHINES IN CLASS 35800

- Feed-Off-The-Arm Machines, With "V" Type Cylinder, For Heavy Duty Work, Double Locked Stitch Type 401
- 35800 AC For double stitch felling overalls, trousers, coats, and similar garments made from non-Sanforized materials; two needles, two loopers, left needle in front, 3/16 inch space between needles in line with feed, seam Type LSc-2, plain foot, flat throat plate, Type 128 GC needles, standard gauges Nos. 16 and 18.
- 35800 AD For double stitch felling trousers made from seersucker, khaki, and similar light weight trouser fabrics; two needles, two loopers, left needle in front, 3/16 inch space between needles in line with feed, seam Type LSc-2, tractor foot, throat plate has .025 inch step on right side, Type 128 GC needles, standard gauges Nos. 12 and 16.
- 35800 AV For double stitch felling overalls, trousers, coats, and similar garments made from 2.00 to 4.00 yard non-Sanforized materials; two needles, two loopers, left needle in front, 3/16 inch space between needles in line with feed, seam Type LSc-2, tractor foot, flat throat plate, Type 128 GC needles, standard gauges Nos. 16 and 18.
- 35800 AY For double stitch felling overalls, trousers, coats, and similar garments made from 2.20 yard to 11 ounce Sanforized and non-Sanforized materials; two needles, ounce Sanforized and non-Sanforized materials; two heedles, two loopers, left needle in front, 3/16 inch space between needles in line with feed, seam Type LSc-2, tractor foot, throat plate has .094 inch step on right side, Type 128 GC needles, standard gauges Nos. 16 and 18.

 NOTE: Style 35800 AY will be equipped with either of two feed dogs, Nos. 35805 AX-16 or 35805 AY-16. The former is used when seaming non-Sanforized materials and the latter when seaming Sanforized materials. This style is also equipped with an extra presser foot style is also equipped with an extra presser foot bottom front section No. 35830 AZ for seaming herringbone

STYLES OF MACHINES IN CLASS 35800 (Cont'a)

twill. Specify material to be sewn and the machine will be adjusted accordingly with the extra foot section tied on the side.

35800 Z A special style, similar to the standard styles in Class 35800, but differing in some of its component parts.

NEEDLES

TYPE NUMBERS AND SIZES

Each needle has a type number and size number. The former denotes the kind of shank, point, length, groove, finish, and other details. The latter denotes the largest diameter of the blade, measured in thousandths of an inch midway between the shank and eye, and is stamped in the needle shank. Collectively, the type number and size number is the complete symbol.

To have orders promptly and accurately filled, the empty package, a sample needle, or the type and size number should be given. See marks on packages. An intelligent order would read as follows "1000 Needles Type 128 H Size 036". The type numbers of the needles available for use in the styles of machines covered by this catalog are listed below. Set opposite each type number is the description of the needle.

Type No.	Description
128 C	Round shank, round point, short, double groove, ball eye, spotted, short blade 1/8 inch less than standard, width of eye and grooves undersize one step reduction, nickel plated- sizes 040, 044, 049
128 H	Same as Type 128 C, except ball point- sizes 036, 040, 044, 049
128 GC	Same as Type 128 C, except chromium plated- sizes 040, 044, 049
128 GH	Same as Type 128 C, except ball point, chromium plated- sizes 036, 040, 044, 049

APPLICATION OF TYPE NUMBERS TO MACHINES

The standard type of needle applicable to each style is listed in the description of each style. The styles of machines covered by this catalog are listed herewith. Set opposite the style numbers are the type numbers of the needles that can be used. Type numbers are arranged numerically, as the variety of the materials sewed on each machine makes it impractical to show a preference.

Machine Style		Type	of	Need	iles		
35800 AC 35800 AD 35800 AV 35800 AY	128 C 128 C 128 C 128 C	, 128 , 128	Н,	128 128	GC, GC,	128 128	GH GH

ORDERING REPAIR PARTS

PLATES

Grouped, according to scale, will be found illustrations of parts similar in appearance, and, to some extent, component parts that go in the same subdivision of the mechanism When a given design of part is made in two or more gauges or sizes, only one illustration is usually shown. In ordering these pieces, it is necessary that the additional information be furnished as requested under these illustrations.

LIST OF PARTS

Turning from the plates to the list of parts, the description of each part and its principal uses will be found. Always check the symbol against its description before ordering. It is not necessary to furnish the plate number.

When a part is used, or can be used, in all machines covered by this catalog, no specific use is mentioned in the description.

For convenience in ordering, minor parts such as screws, nuts, and similar articles are repeated after each major part.

(-) A dash in the "plate number" column of the list of

parts indicates the absence of an illustration.

(‡) A double dagger in the "symbol to order by" column indicates that the component parts cannot be furnished separately. Due to the high speed of these machines it is impossible for these associated parts to be fitted a second time and make a serviceable job.

IDENTIFYING PARTS

Where the construction permits, each part is stamped with its part number. Some of the smaller parts are stamped with an identification letter to distinguish them from parts similar in appearance.

All part numbers represent the same part, regardless of

the catalog in which they appear.

SUPPLIES

All supplies, including taps, reamers, belting, belt hooks, belt fasteners, belt punches, screw drivers, wrenches and powdered oil stone will be promptly furnished.

USE GENUINE NEEDLES AND REPAIR PARTS

Success in the operation of these machines can be secured only by the use of genuine Union Special Needles and Repair Parts as furnished by the Union Special Machine Company, its subsidiaries and authorized distributors. They are designed according to the most approved scientific principles, and are made with the utmost precision. The maximum efficiency and durability are assured.

ORDERING REPAIR PARTS (Cont'd)


USE GENUINE NEEDLES AND REPAIR PARTS (Cont'd)
Genuine needles are put up in packages marked at the top
"Trade 'UNION SPECIAL' mark". Genuine repair parts are
stamped with a reproduction of the familiar Union Special
padlocks.

Each trade mark is n materials and

your guarantee of the highest quality in materials and workmanship.


TERMS


Prices are strictly "net cash" and subject to change without notice. All shipments are forwarded at the buyer's risk F.O.B. shipping point. Parcel post shipments are insured unless otherwise directed. A charge is made to cover the postage and insurance.



From the library of: Superior Sewing Machine & Supply LLC

Plate 2 - Full Size







35805 AV Specify Gauge








35805 AD Specify Gauge




35805 AX Specify Gauge







35826D




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC





From the library of: Superior Sewing Machine & Supply LLC

Plate 10 - Full Size




From the library of: Superior Sewing Machine & Supply LLC







From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

Plate 16 - One-Half Size



From the library of: Superior Sewing Machine & Supply LLC

Plate 17 - One-Half Size







Plate 18 - One-Half Size



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

Plate 21 - One-Fourth Size




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

Plate 23 - One-Eighth Size











PL 246



ASSEMBLY Nº 21101 M-4

PL 245



ASSEMBLY Nº 21101L-4

	Man or a recipe	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
WA15	Stop Watch	5
18	Connecting Rod Nut, right thread	9
	Desagner Dump Oil Con 1 1/2 pints conceits	23
0I-19	Pressure Pump Oil Can, 1 1/2 pints capacity	20
25 B	Screw, for parallel take-up thread eyelet,	
	right; also for No. 35869 J	7
20	" for folder upper scroll; also for No.	To an in
28		~
	35870	7
36 G	Feed Rocker Connecting Rod Ball Stud Washer	11
37 R	Nut, for oil pump piston rod connection	9
	Stop Screw, for lifter lever link	8
42 A	Stop Screw, for lifter level link	
50 J-16	Needle Stop Pin	9
50 J-26	Pin, for lifter lever link connection	.9
54	Needle Lever Link	18
TA54	Hand Tally	_
	Harlu Tally	
TA55	Hand Tachometer, 300 to 12000 R.P.M	_
73 A	Screw, for folder support spring; also Nos.	
	35830 H, 35830 N	7
74	" for tension plate bracket; also for	
1.1		7
200	No. 35792 L-4	1
77	" for needle lever link pin; also for	
	Nos. 35764 Q, 35864 B, 35869 G	7
78	" for needle lever link pin	7
	Spot Screw, for main shaft coupling	7
81	Spot Screw, for main shart coupling	
86	Screw, for lifter lever link	8
88	Screw, for controller drive rod connection on	
	Styles 35800 AD, 35800 AV, 35800 AY; also	
	for Nos. 29101 G, 29730 D, 35751 F, 35845	7
00 1		7
A 88	Set Screw, for needle bar	,
89	Spot Screw, for needle holder; also for Nos.	
	29730 D, 35751 F	7
90	Screw, for top cover, middle, spring; also	
	for No. 35883 E	7
91	" for tension post; also for No. 35830	7
	Class Canan C/1C inch lang for more of car	
91 D	Clamp Screw, 7/16 inch long, for presser feet	7
93	Screw, for crank chamber cover	7
94	" for tension support	7
95	" for feed dog support; also for No.	
	35895 G	7
077		
97 -	Clamp Screw, for lifter lever link connection	-
97 A	Bearing Screw, for looper drive connecting	
	rod ball joint; also for Nos. 35837 N,	
	35841 B, 35846, 35851, 35851 A	8
98	Set Screw, for needle holder for No. 12 gauge	
	Comment of the control of the contro	1
98 A	Screw, for cylinder cover; also for No.	-
	35770 B	7
107	Tension Post Ferrule	9
108	" Nut	9
109	" Disc, small	6
	Thread Threadens	
118 B	Thread Tweezers	13
136	Screw, for tension plate bracket; also for	
,	Nos. 35892-4, 35897 AP	7
-	80	

- 3		ALDE VALUE V	
	Symbol	The figures in the last column refer only to	Plate
	To	the plates illustrating the parts and are not	No.
	Order By	to be used in ordering. Prices furnished on	
		application.	
	050	Not for food lift lower convention and hell	
	258	Nut, for feed lift lever connecting rod ball	9
	250 A	stud; also for No. 35841 B for looper drive connecting rod ball	9
	258 A	joint; also for No. 21114 W	9
	269	Connecting Rod Nut, left thread	9
	318	Screw, lower, for detachable head (washer No.	
	010	6042 A)	7
	376	" for feed dog holder	7
	413	Oil Can, complete	22
	414 A	Base, for thread stand	24
	Y501-257	Expansion Reamer, size .257 inch, for needle	
		bar bearings	21
	Y503-319	" size .319 inch, for presser	
		bar bearings	21
	531	Set Screw, for main shaft collar; also for	
		Nos. 35751 B, 35815, 35842 G, 35843, 35845	7
	Y558-250	Expansion Reamer, size .250 inch, for rear	07
	HEEG E	section of looper shaft	21
	Y558 F	Ferrule, for expansion reamer No. Y558-250	21
	Y559	Expansion Reamer, size .375 inch, for front	21
	Y561-500	section of looper shaft	21
	1361-300	" size .500 inch, length over- all 31 inches, for main	
		shaft bearings	21
	Y561 F	Ferrule, for expansion reamer No. Y561-500	21
	650 C-6	Screw, for cone support frame	24
	650 R-16	Machine Bolt, square head, 3/8 x 2 inches, for	
		light fixture rod clamp on individual power	
		table installations	8
	651 B-24	Nut, 3/8 inch, hexagonal, for cushion mounting	
	250 10	stud	9
	652-16	Washer, for sound insulator; also for No.	11
	652-24	21114 W	11
	002-24	also for No. 29469 D	11
	652 A-20	Lock Washer, for sound insulator attaching	
	000 A-00	screw	11
	652 B-24	Shake-Proof Lock Washer, 3/8 inch, for light	
		fixture rod clamp assembly	11
	652 C-9	Shake-Proof Lock Washer, for oil reservoir	11
	660-67	Oil Gun, for removing oil from cylinder	23
	660-74	Sleeve, for detachable head oiling tube	9
	660-75	Coupling, for detachable head oiling tube	9
	660-142	Cotter Pin, for oil pump piston rod connecting	5
	660 161	link pin	
	660-161	table	18
	660-162	" " Washer	18
	660-177	Check Valve, outlet, for oil pump assembly	16
	660-178	" intake, for oil pump assembly	16
	660-180	Pipe Coupling, 3/4 inch standard for thread	
		stands	24
		-33-	

	AND TO SE A SECULIA	
Symbol	The figures in the last column refer only to	Plate
The state of the s		
To	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
	application.	
660-181	Insulating End Bushing, for thread stands	24
660-184	Oil Tube Sleeve, for check valves	9
664 F-16	Taper Dowel Pin, 1 inch long, for locating	
	detachable head	5
664 F-24	" " 1 1/4 inches long, for	
	locating cylinder	5
666-46	Oil Cup, press fit, for crank chamber cover	9
666-47	Oil Wick, for feed bar	9
667 D-16	Dowel Pin, 1 inch long, for locating	9
001 D-10		-
000 1	cylinder	5
668-1	Porcelain Insert, for lead-in thread eyelet	6
668-7	" for tension thread eyelet	6
668-12	Porcelain Insert Locking Ferrule, for ten-	
	sion thread eyelet	6
668-14	Porcelain Insert Locking Ferrule, for lead-	
	in thread eyelet	6
698 BP-12		
	gauge	5
698 BP-16	" " for No. 16 gauge	5
698 BP-18	" " for No. 18 gauge	5
699 F	Test Pin	5
Y802	Taper Reamer, for needle lever link pins	21
820	Screw, for attaching cylinder (washer No.	
	6042 A)	7
1286	Needle Lever Link Pin Assembly; one each	
	Nos. 1286 A, 1286 B, 12964 C, 22560	10
1286 A	Needle Lever Link Pin (set screw for upper	
	link pin No. 77, set screw for lower link	
	pin No. 78)	10
1286 B	Needle Lever Link Pin Spring (screw No.	10
	22560)	12
1332	Hinge Pin, for presser spring regulating	12
2000	screw	8
6042 A	Washer, for cylinder attaching screws; also	0
OUTD A	for No. 74	11
11947	Feed Lift Lever Link Stud	
11947 B	" " Bushing	8
	Needle Per Pushing	10
12873	Needle Bar Bushing, lower	10
12934 A	Nut, for main frame top cover hinge; also	0
19064 0	for No. 35869 D	9
12964 C	Needle Lever Link Pin Ball	9
12982	Nut, for needle thread controller lever	
15400	attaching screw	9
15488	Looper Shaft Cross Head Link Ball Joint	
01101 7 4	Washer, right	11
21101 L-4	Spring Type Thread Stand Assembly; one each	
	Nos. 414 A, 660-180, 660-181, 21104 X-18, 21104 X-26; two No. 21114 Z; four each	
	21104 X-26; two No. 21114 Z; four each	
	Nos. 650 C-6, 652-16, 21114 W; eight No.	
	258 A; twelve No. 21114 V	24
		ME LE
	7.4	

	BIOI OF TAKES	
Symbol	The figures in the last column refer only to	Plate
To	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	110 .
	application.	
	approactor.	
21101 M-4	Disc Type Thread Stand Assembly; one each	
	Nos. 414 A, 660-180, 660-181, 21104 X-18,	
	21104 X-26; two No. 21114 Z; four each No.	
	650 C-6, 652-16, 21104 V, 21114, 21114 W;	
	eight No. 258 A	24
21104 V	Felt Pad, 5 1/4 inches diameter for spool	24
	seat disc on No. 21101 M-4	23
21104 X-18	Thread Stand Support Pipe, 18 inches long	24
21104 X-26	" " 26 inches long	24
21114	Spool Disc Seat, for disc type thread stand	24
21114 V	Cone Holder Spring, for No. 21101 L-4	24
21114 W	Spool Pin, for thread stand assembly (nut	21
	No. 258 A, washer No. 652-16)	24
21114 Z	Cone Supporting Frame, for thread stands	
	(screw No. 650 C-6)	24
21201	Screw Driver, 9/64 inch round blade, length	TO A CONTRACT OF THE PARTY OF T
	overall 7 5/8 inches	22
21202	" 7/32 inch round blade, length	
	overall 11 1/4 inches	22
21203	" " 13/64 inch round blade, length	
	overall 15 1/2 inches	22
21204	" 9/32 inch round blade, length	
01005 4	overall 15 inches	22
21205 A	5/6 Inch round brade, rength	00
21207	overall 14 inches	22
בובטו	1/04 Inch round brade, length	17
21208	overall 2 1/2 inches Screw Driver Set, three detachable blades	13
21225-9/64	Looper Adjusting Gauge, 9/64 inch measure-	22
	ment	5
21227 HH	Porcelain Insert Replacement Tool Set, for	0
	assembling 1/16 inch internal diameter	
	porcelain inserts No. 668-7 and ferrules	
	No. 668-12 in tension thread eyelet assem-	
	bly. Ferrules should always be replaced	17
21227 HK	Porcelain Insert Replacement Tool Set, for	
	assembling 1/8 inch internal diameter por-	
	celain inserts No. 668-1 and ferrules No.	
	668-14 in thread lead-in eyelet assembly.	
01 071	Ferrules should always be replaced	17
21231	Thread Meter, for recording the consumption	
	of thread in 1/10 yards as it passes into	20
21233 N	the sewing machine Connector, with BX cable for D.C. "Electro	20
-1200 H	Drives"	
21233 P	Connector, with BX cable for single and	
	three phase A.C. "Electro Drives"	_
21233 X	Light Fixture Assembly, including bulb and	
STATE OF THE SE	blue lens, table mounting, for machines	
	driven by "Electro Drive"	_
21233 Y	Light Fixture Assembly, including bulb and	
	clear lens	
	-35-	

0	The figures in the last column refer only to	Plate
Symbol		
То	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
THE RESERVE	application.	
21233 Z	Light Fixture Assembly, including bulb, but	
21200 2	without lens	_
	NOTE: When ordering light fixture assem-	
	blies to be mounted on individual power	
	tables, order as extra one set of clamps	
	No. 29469 D.	
91976	Belt Plier, for 3/8 inch and smaller round	
21236		22
21260	Emery Cord, 3/64 inch diameter, grade No.	DD .
21260	Emery Cord, 5/64 Inch diameter, grade No.	
07.000 4	120, fifty yard spool 3/64 inch diameter, grade No.	
21260 A		
01000 5	150, fifty yard spool	
21260 B	" 1/32 inch diameter, grade No.	
	180, fifty yard spool	
21260 C	" " .025 inch diameter, grade No.	
01000 5	200, fifty yard spool	_
21260 D	Emery Tape, 3/32 inch wide, grade No. 180,	
	fifty yard spool	-
21260 E	Emery Cord, .018 inch diameter, grade No.	
	200, fifty yard spool	_
21262 B-69	Leather Belt, round, 9/32 inch diameter, 69	
	inches long, including wire belt hook No.	
	21351	-
21262 H-510	"V" Belt, No. 2 size, 51 inches outside	3.0
	circumference	19
21262 H-520	DE INCHES OUTSIDE CITCUMTETERCE	19
21262 H-530	" 53 inches outside circumference	19
21262 H-540	of inches outside circumterence	19
21350	Belt Fastener, malleable iron, for 1 1/4	0
01751	inch flat belt	9
21351	Belt Hook, wire, for 9/32 inch round belt	5
21371 JT	Rubber Foot, for individual power tables	17
21372 X	Light Fixture Rod Clamp (bolt No. 650 R-16,	ma Pent
	plain washer No. 652-24, lock washer No.	10
91775 AV	652 B-24)	18
21375 AK	Wrongh single and 3/9 inch appring	23
21388 21388 N	Wrench, single end, 3/8 inch opening double end, 3/16 and 5/16 inch	13
21388 N		13
21388 R	openings double end, 3/8 and 1/2 inch	10
PT900 V	openings	13
21388 X	for main shaft bearing housing	23
21394	Utility Grinder, including emery wheel, 5	20
21094		THE SELECT
	inches diameter, 1/4 inch face, round belt drive, recommended speed 3000 R.P.M.	
21394 G	Emery Wheel, 5 inches diameter, 1/4 inch	
21034 0	face, 3/8 inch hole, grade "M" emery 60	
21394 H	Emery Wheel, 5 inches diameter, 1/2 inch	
21004 II	face, 3/8 inch hole, grade "M" emery 60	
21394 K	Utility Grinder, including emery wheel, 5	
ALUUT II	inches diameter, 1/2 inch face, round	
	belt drive, recommended speed 3000 R.P.M.	_
	-36	
	-60	

-	ALVE VE ENGINE	
Symbol	The figures in the last column refer only to	Plate
To	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
	application.	
21697 AA	Belt Take-up and Hanger Assembly, for "V"	
	belt installations	23
22513	Screw, for guide plate	7
22515 A	" for feed rocker connecting rod ball	
	joint, rear	8
22516	joint, rear	7
22516 A	" for top cover, front; also for No.	
	35887 P	7
22517	" for parallel take-up eyelet, left	7
22517 B	" for oil pump lever	7
22524	for throat plates; also for Nos.	
במטמב	35767, 35889 A, 35889 C	8
22528	" for detachable head cover, left; also	
22000	for No. 35887 R	7
22539 B	Plug Screw, for cylinder	8
22539 D		8
22539 E	" for cylinder	8
22542	Screw, for parallel take-up shield	7
22557 A	" for needle thread controller lever-	8
22560	" for needle lever link pin spring	7
22560 B	" for presser bar lifter bracket and	1
L 00033	guide	7
22561	" for oil shield; also for No. 35830 D	7
22562 A	" for looper holder	7
22564 B	for loopers; also for Nos. 35886 A	,
22004 D	and 35887 R	7
22565 C	Set Screw, for cylinder hinge cover pin	7
22569 B	Screw, for crankshaft bearing housing	7
22571 B	Plug Screw, for oil drain in main frame;	
DOO'L D	also for No. 29472 E	7
22572	Screw, for feed rocker; also for No. 35751 G	7
22574	" for belt guard	8
22574 A	" for handwheel	8
22579	Presser Spring Regulating Screw	8
22584	Screw, for presser foot stop	7
22587 B	Bearing Screw, for needle lever connecting	
	rod	8
22587 E	Screw, for feed lift, feed rocker, and	
	looper avoid eccentric bearings; also for	10-1-1
	No. 35780 D	8
22588	Feed Adjusting Screw	8
22597	Spot Screw. for pulley	7
22597 A	Set Screw. for pulley	7
22599	Screw, for presser foot bottom front section	
	equalizing spring	7
22642 K-112	" for main frame sound insulator (lock	
	washer No. 652 A-20)	8
22643 K-64	Adjusting Screw, for main frame sound	Elist of
	insulator	8
22729	Screw, for oil reservoirs; also for No.	Mark I
	35763	7
22733	Screw, for looper throw-out plunger bushing	7
	77	

The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.			
22733 A 22735 C 22736 C 22738 C 22738 C 22738 C 22747 Screw, for attaching supplementary section to feed dog Set Screw, for feed rocker connecting rod ball stud; also for Nos. 25804, 41255 B 22758 E 22758 E 22759 A 22760 A 22760 A 22760 C 22764 Screw, for detachable head Spot Screw, for lower scroll on lap seam fellers; also for No. 22768 Screw, for needle thread controller lever guide rod - presser foot connecting link Screw, for cylinder cover and oil gauge, front; also for Nos. 25766 C, 25825 D, 25835 A Serew, for readle thread for Nos. 22764 Screw, for needle thread controller lever guide rod - presser foot connecting link	To	the plates illustrating the parts and are not to be used in ordering. Prices furnished on	The state of the s
22738 C 22748 C 22748 C 22748 Screw, for attaching supplementary			
22738 C 22748 C 22748 C 22748 Screw, for attaching supplementary	22733 A	Plug Screw, for oil drain	8
Screw, for attaching supplementary			
Section to feed dog 7			0
Set Screw, for feed rocker connecting rod ball stud.	22738 0		~
Tod ball stud			7
Clamp Screw, for feed rocker connecting rod ball stud; also for Nos. 35804, 41255 B	22743	Set Screw, for feed rocker connecting	
ing rod ball stud; also for Nos. 35804, 41255 B 7 Screw, for controller drive rod connection, on Styles 35800 AD, 35800 AV, 35800 AY, also for No. 35869 D 8 22759 A 22760 A 22760 C Screw, for detachable head 8 22764 Screw, for needle thread controller lever guide rod - presser foot connecting link 8 22764 Spot Screw, for feed lift, feed rocker, and looper avoid eccentric Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge 8 22794 C Screw, for perallel take-up flange - Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 22799 L Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY 8 22829 A Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 22848 Screw, for presser foot bottoms on Styles 35800 AV, 35800 AV 8 22848 Screw, for presser foot bottoms on Styles 35800 AV, 35800 AV 8 22849 C 22840 C 23420 AY-12-3/32 23421 T-12-3/32, 23422 AY-12-3/32, 23421 T-12-3/32, 23424 F, 23424 S,		rod ball stud	7
ing rod ball stud; also for Nos. 35804, 41255 B 7 Screw, for controller drive rod connection, on Styles 35800 AD, 35800 AV, 35800 AY, also for No. 35869 D 8 22759 A 22760 A 22760 C Screw, for detachable head 8 22764 Screw, for needle thread controller lever guide rod - presser foot connecting link 8 22764 Spot Screw, for feed lift, feed rocker, and looper avoid eccentric Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge 8 22794 C Screw, for perallel take-up flange - Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 22799 L Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY 8 22829 A Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 22848 Screw, for presser foot bottoms on Styles 35800 AV, 35800 AV 8 22848 Screw, for presser foot bottoms on Styles 35800 AV, 35800 AV 8 22849 C 22840 C 23420 AY-12-3/32 23421 T-12-3/32, 23422 AY-12-3/32, 23421 T-12-3/32, 23424 F, 23424 S,	22747	Clamp Screw, for feed rocker connect-	
Serve Screw for controller drive rod connection, on Styles 35800 AD 35800 AV 35800 AV		ing rod hall stud: also for Nos.	
Screw, for controller drive rod connection, on Styles 35800 AD, 35800 AY, 35800 AY; also for No. 25869 D 8			7
Connection, on Styles 35800 AD, 35800 AV, 35800 AY, 3158 for No. 35869 D 8	DOMEO E		'
35800 AV, 35800 AY; elso for No. 35869 D	22758 E		
35869 D			
Screw, for detachable head 8		35800 AV, 35800 AY; also for No.	
22760 A Pivot Screw, for lower scroll on lap seam fellers; also for No. 23424 S Screw, for needle thread controller lever guide rod - presser foot connecting link Spot Screw, for feed lift, feed rocker, and looper avoid eccentric Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge Screw, for parallel take-up flange - Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY Screw, for looper thread shield Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AY Screw, for frame needle thread eyelet "for looper thread eyelet "for looper thread eyelet "for looper thread eyelet "for looper thread eyelet "for lower scroll support on lap seam fellers			8
22760 A Pivot Screw, for lower scroll on lap seam fellers; also for No. 23424 S Screw, for needle thread controller lever guide rod - presser foot connecting link Spot Screw, for feed lift, feed rocker, and looper avoid eccentric Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge Screw, for parallel take-up flange - Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY Screw, for looper thread shield Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AY Screw, for frame needle thread eyelet "for looper thread eyelet "for looper thread eyelet "for looper thread eyelet "for looper thread eyelet "for lower scroll support on lap seam fellers	22759 A	Screw, for detachable head	8
Seam fellers; also for No. 23424 S Screw, for needle thread controller lever guide rod - presser foot connecting link Spot Screw, for feed lift, feed rocker, and looper avoid eccentric Serew, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge Screw, for parallel take up flange - Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AV 8 Set Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 Serew, for looper thread shield Hinge Screw, for presser foot bottoms on Styles 35800 AV, 35800 AV 8 Serew, for looper thread shield For lower scroll support on lap seam fellers 7 Serew, for lower scroll support on lap seam fellers 7 For oil pump housing 7 For feed dog holder 7	22760 A	Pivot Screw, for lower scroll on lap	
Screw, for needle thread controller lever guide rod - presser foot connecting link 8			8
lever guide rod - presser foot connecting link 8	22760 C		
Connecting link	0 00133		
Spot Screw, for feed lift, feed rocker, and looper avoid eccentric		i lever guide rou - presser root	0
and looper avoid eccentric 7 Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A 7 22794 C Set Screw, for needle holders, for No. 16 and No. 18 gauge 7 22799 C Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 22799 L Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY 8 22809 A Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 22829 Screw, for looper thread shield 7 Hinge Screw, for presser foot bottoms on Styles 35800 AV, 35800 AY 7 22848 Screw, for presser foot bottoms on Styles 35800 AV - 5800 AV - 5800 AV 7 22848 Screw, for frame needle thread eyelet "for looper thread eyelet "for looper thread eyelet "for looper thread eyelet "for lower scroll support on lap seam fellers 7 22874 C C C C C C C C C C C C C C C C C C C	00001	connecting link	0
Screw, for cylinder cover and oil gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A Set Screw, for needle holders, for No. 16 and No. 18 gauge 7	22764		_
gauge, front; also for Nos. 35796 B, 35796 C, 35825 D, 35835 A 7 Set Screw, for needle holders, for Nos. 16 and No. 18 gauge 8 22799 C Screw, for parallel take-up flange 8 Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 22799 L Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY			7
35796 C, 35825 D, 35835 A	22768		
Set Screw, for needle holders, for No. 16 and No. 18 gauge			
Set Screw, for needle holders, for No. 16 and No. 18 gauge		35796 C, 35825 D, 35835 A	7
16 and No. 18 gauge	22784	Set Screw, for needle holders, for No.	
Screw, for parallel take-up flange -		16 and No. 18 gauge	7
## Hinge Screw, length overall 37/64 inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 ### Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY 8 ### ### Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 ### Screw, for looper thread shield 8 ### Screw, for looper thread shield 7 ### ### Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AY 7 ### ### Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AY 8 ### ### Screw, for frame needle thread eyelet ### for looper thread eyelet 8 ### ### ### ### ### ### ### ### ###	22794 C		10000
inch, diameter .088 inch, for presser foot bottom on Style 35800 AC 8 22799 L Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AY 8 22809 A Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AY 8 22829 Screw, for looper thread shield Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AY 7 22845 A Screw, for frame needle thread eyelet 8 22849 Screw, for frame needle thread eyelet 9 22849 A Screw, for frame needle thread eyelet 9 22874 C 23874 C 23874 C 23874 C 23874 C 23874 C 23875 C 1 for oil pump housing 7 Tor feed dog holder 7 Lap Seam Feller Assembly, for No. 12 gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23424 F, 23424 F, 23424 S,			
presser foot bottom on Style	22100 0		
35800 AC 8			11. 12. 13.
Set Screw, for presser foot yielding section on Styles 35800 AD, 35800 AV, 35800 AY			0
Section on Styles 35800 AD, 35800 AV, 35800 AV, 35800 AY	1 00000		0
35800 AV, 35800 AY 8 Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AY 8 22829 Screw, for looper thread shield 7 Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AV, 35800 AV, 7 22848 Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 7 22849 CScrew, for frame needle thread eyelet "for looper thread eyelet "for looper thread eyelet "for lower scroll support on lap seam fellers 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing 7 22874 CSCREW, for frame needle thread eyelet "for oil pump housing	22/99 L		
### Hinge Screw, for presser foot and controller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 #### Screw, for looper thread shield 7 ##############################		section on Styles 35800 AD,	
troller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 Screw, for looper thread shield 7 Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AY 7 Screw, for frame needle thread eyelet 22849 22849 22849 22874 23420 AY-12-3/32 34220 AY-12-3/32 34221 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,		35800 AV, 35800 AY	8
troller drive rod connecting link, double shoulder on Styles 35800 AD, 35800 AV, 35800 AV, 35800 AY 8 Screw, for looper thread shield 7 Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AV, 35800 AV 7 22848 22849 22849 22849 22874 22874 22874 22874 22874 22874 22874 C 23420 AY-12-3/32 23420 AY-12-3/32 23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,	22809 A	Hinge Screw, for presser foot and con-	
double shoulder on Styles 35800 AD, 35800 AV, 35800 AY 8 Screw, for looper thread shield 7 Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AY 8 22848			
22829			
Screw, for looper thread shield 7			8
# 22845 A Hinge Screw, for presser foot bottoms on Styles 35800 AD, 35800 AV, 35800 AY	22829	Screw, for looper thread shield	The state of the s
on Styles 35800 AD, 35800 AV, 35800 AY			
22848 22849 22849 A "for frame needle thread eyelet "for looper thread eyelet 8 22874 "for lower scroll support on lap seam fellers 7 22874 C "for oil pump housing 7 23420 AY-12-3/32 Lap Seam Feller Assembly, for No. 12 gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23424 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,	PEROTO R	on Styles 35800 AD 35800 AV	
Screw, for frame needle thread eyelet 8 8 8 8 8 8 8 8 8			m
## for looper thread eyelet 8 ## for looper thread eyelet 8 ## for lower scroll support on lap seam fellers 8 ## for oil pump housing 7 ## for feed dog holder 7 ## for feed dog holder 7 ## Lap Seam Feller Assembly, for No. 12 ## gauge; one each Nos. 28, 73 A, ## 23421 T-12-3/32, 23424 AY-12-3/32, ## 23424 D, 23424 E, 23424 F, 23424 S,	00040		
## for lower scroll support on lap seam fellers 8 7 22874 6 7 7 7 8 7 7 8 7 7 8 7 7		screw, for frame needle thread eyelet	
22874 c " for oil pump housing 7 22874 C " for feed dog holder 7 Lap Seam Feller Assembly, for No. 12 gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,			8
22874 c "for oil pump housing 7 7 23420 AY-12-3/32	22849 A	Tot tower scrott support on tap	-
22874 C 23420 AY-12-3/32			
23420 AY-12-3/32 Lap Seam Feller Assembly, for No. 12 gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,			7
23420 AY-12-3/32 Lap Seam Feller Assembly, for No. 12 gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,		" for feed dog holder	7
gauge; one each Nos. 28, 73 A, 23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,	23420 AY-12-3/32		
23421 T-12-3/32, 23422 AY-12-3/32, 23424 D, 23424 E, 23424 F, 23424 S,		gauge; one each Nos. 28, 73 A.	Page 1
23424 D, 23424 É, 23424 F, 23424 Ś,		23421 T-12-3/32, 23422 AY-12-3/32	
			The second
		70	

	HIDI OI IMIID	
Symbol	The figures in the last column refer only to	Plate
То	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
	application.	
	23424 T, 23425 T; two each Nos.	2011
	22561, 22760 A, 22849 A	17
23420 AY-18-1/8	Lap Seam Feller Assembly, for No. 18	
	gauge; one each Nos. 28, 73 A,	
	23421 Y-9-1/8, 23422 AY-18-1/8,	
	23424 D, 23424 E, 23424 F, 23424 S,	
	23424 D, 23424 E, 23424 F, 23424 S, 23424 T, 23425 T; two each Nos.	
	22561, 22760 A, 22849 A	17
23420 AY-18-3/32	Lap Seam Feller Assembly, for No. 16	
	gauge; one each Nos. 28, 73 A,	
	23421 Y-9-3/32, 23422 AY-18-3/32,	
	23424 D, 23424 E, 23424 F, 23424 S,	
	23424 T, 23425 T; two each Nos.	P.
	22561, 22760 A, 22849 A	17
23421 T-12-3/32	Upper Scroll, 3/32 inch capacity, for	
20121 1 15-0,05	No. 12 gauge lap seam feller	17
23421 Y-9-3/32	Upper Scroll, 3/32 inch capacity, for	
20121 1-0-0/05	No. 16 gauge	17
23421 Y-9-1/8	Upper Scroll, 1/8 inch capacity, for	11
20421 1-9-1/0		177
	No. 18 gauge	17
97499 AV 19 7/79	Upper Scroll Screw No. 28	
23422 AY-12-3/32	Lower Scroll, 3/32 inch capacity, for	200
97499 AV 10 7/79	No. 12 gauge lap seam feller	17
23422 AY-18-3/32	Lower Scroll, 3/32 inch capacity, for	7.00
97499 4W 39 3 /9	No. 16 gauge	17
23422 AY-18-1/8	1/6 Inch capacity, for	2.00
	No. 18 gauge	17
07101 7	Lower Scroll Screw No. 22760 A	THE PLANT
23424 D	Sliding Base and Support, right sec-	3.00
	tion for lap seam fellers	17
23424 E	Sliding Base and Support, left sec-	
	tion, for lap seam fellers	17
23424 F	Sliding Base and Support Spring, for	
	lap seam fellers (screw No. 73 A)	12
23424 S	Spring, for lower scroll on lap seam	
The state of the s	fellers (screw No. 22760 A)	12
23424 T	Lower Scroll Support, for lap seam	-
	fellers (screw No. 22849 A)	17
23425 T	Washer Plate, for lower scroll support	
	on lap seam fellers	11
28606-1/2	Powdered Oil Stone, 1/2 lb. package	-
28606-1	" " 1 lb. package	-
28616 E	Crankshaft Thrust Washer	11
28705	"Electro Drive", round belt, 1/2 H.P.,	
	A.C., 1 phase, 60 cycles, 105-115	
	volts, 3400 R.P.M	-
28705 D	"Electro Drive", round belt, 1/2 H.P.,	SW TIE
	A.C., 1 phase, 60 cycles, 220 volts,	
	3450 R.P.M	_
28705 V	"Electro Drive". "V" belt. 1/2 H.P	
	A.C., 1 phase, 60 cycles, 105-115	
	volts, 3400 R.P.M	
***	-39-	-

	LIBI OF PARIS	
BEALT OF BEALT		
Symbol	The figures in the last column refer only to	Plate
To	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
	application.	
	approductor.	
28705 DV	"Electro Drive", "V" belt, 1/2 H.P., A.C., 1	
20100 21	phase, 60 cycles, 220 volts, 3450 R.P.M	
28707 B	"Floatro Drive" round helt 1/2 U.D. A.C. 7	
20101 B	"Electro Drive", round belt, 1/2 H.P., A.C., 3	
28707 D	phase, 60 cycles, 210-230 volts, 3500 R.P.M. "Electro Drive", round belt, 1/2 H.P., A.C., 3	_
20101 D	"Electro Drive", round belt, 1/2 H.P., A.C., 3	
COMON DI	phase, 60 cycles, 440 volts, 3500 R.P.M	_
28707 BV	"Electro Drive", "V" belt, 1/2 H.P., A.C., 3	
20.000 TO THE RESERVE	phase, 60 cycles, 210-230 volts, 3500 R.P.M.	_
28707 DV	"Electro Drive", "V" belt, 1/2 H.P., A.C., 3	
	phase, 60 cycles, 440 volts, 3500 R.P.M	_
28708	"Electro Drive", round belt, 1/2 H.P., D.C.,	
	105-115 volts, 3000 R.P.M	
28708 A	"Electro Drive", round belt, 1/2 H.P., D.C.,	
	210-230 volts * 3000 R P M	
28708 V	210-230 volts, 3000 R.P.M "Electro Drive", "V" belt, 1/2 H.P., D.C.,	
20100 V	105 115 wolter 7000 P.D.W.	
00000 411	105-115 volts, 3000 R.P.M "Electro Drive", "V" belt, 1/2 H.P., D.C.,	_
28708 AV	"Electro Drive", "V" belt, 1/2 H.P., D.C.,	FA.
	210-230 volts, 3000 R.P.M	_
\$29101 G	Feed Lift, Feed Rocker, and Looper Avoid	
	Eccentric Assembly, includes eccentric No.	
	35847 D (set screw No. 88, spot screw No.	
	22764, bearing screw No. 22587 E)	13
29401 C	Cushion Mounting Assembly, for attaching mach-	
	ine to table; one No. 35895 R; two each Nos.	
	651 B-24, 652-24, 660-162, 35895 N, 35895 Q;	
	four No. 660 161 Chariff common and months	
	four No. 660-161. Specify component parts in	10
20460 D	ordering	18
29469 D	Light Fixture Rod Clamp Assembly, for attaching	
	light fixtures Nos. 21233 X, 21233 Y, 21233 Z	
	to table leg on individual power table in-	
	stallations; one each Nos. 650 R-16, 652-24,	
	652 B-24; two No. 21372 X	_
29472 E	Oil Pump Assembly; one each Nos. 37 R,22571 B,	
	22733 C, 35897 AB, 35897 AC, 35897 AD,	
	35897 AG, 35897 AK, 35897 AY; two each Nos.	
	660-177, 660-178; three No. 35897 AH	16
29478 BC	Main Shaft and Crankshaft Sub-assembly; one	
	each Nos. 35822 T, 35822 V, 35895 G	
29478 BD	Feed Rocker, Looper Avoid, Feed Lift Eccentric,	THE STATE OF
	and Connecting Rod Assembly; one each Nos.	CALL S
	20101 G 35841 B 35846 75040 E 47846	
	29101 G, 35841 B, 35846, 35847 E, 43246; two	10
29730 D	each Nos. 18, 258, 269, 35746 A, 41355 U	13
D3190 D	Parallel Take-up Assembly; one each Nos. 88,	
	89, 22747, 35773, 35773 A, 35798 C, 35804,	
25001 0	35823 C; two No. 22794 C	18
35721 C	Machine Pulley, grooved for No. 2 "V" belt	
	(spot screw No. 22597, set screw No. 22597 A)	19
35721 D	Machine Pulley, complete, grooved for No. 2 "V"	
	belt; one each Nos. 22597, 22597 A. 35721 C.	to Find
	35721 F, 35721 G, 35721 H; three No. 22574 A	_
35721 F	Handwheel (screw No. 22574 A)	19
35721 G	Machine Pulley Spacing Plate	18
-		10
\$See Page	6 -40-	

=			
	Symbol	The figures in the last column refer only to	Plate
	to	the plates illustrating the parts and are not	No.
	Order By	to be used in ordering. Prices furnished on	
	23	application.	
		арртгосотоп.	
	35721 H	Machine Pulley Clamping Plate	18
	35731 A	Presser Bar Connection Guide Plate (screw No.	10
	OUTOL H		=
	75777 D	22513)	5
	35731 B	Presser Bar Bushing, upper	10
	35733 B	Presser Spring Regulating Nut	9
	35736 A	Feed Rocker Bushing; also for No. 35844	10
	35736 B	" Bushing Key	5
	35746 A	Ball Stud Washer	11
	35750 A	Looper Shaft Bushing, middle, length overall	
		9/16 inch	10
	35750 D	" " front, length overall	-
	20,00 2	1 1/8 inches	10
	35751	" " Cross Head	11
		" " Guide Shaft (screw No.	11
	35751 B		14
	25053 5	531)	14
	35751 F	Looper Shaft Thrust Collar (set screw No. 88,	3.0
		spot screw No. 89)	10 -
	35751 G	Looper Shaft Cross Head Thrust Collar (screw	
		No. 22572)	5
	35759 A	Needle Bar Bushing, upper	10
	35760 B	Needle Lever Shaft Bushing, 1 3/16 inches long	10
	35760 C	" " " 13/16 inch long	10
	35761	Needle Lever Shaft	14
	35761 B	" " Bushing Cap	9
	35761 C	" " " Paper Gasket	9
		" " Connecting Rod Pin (screw No.	3
	35763		10
	SEROS D	22729)	10
	35763 F	Crankshaft Needle Bearing Roller Retaining Ring	9
	35763 G	TO OUTILITIES TITLES	6
	35764 Q	Needle Lever Thread Eyelet, for Style 35800 AC	
		(screw No. 77)	6
	35766 A	Nut, for looper shaft cross head link ball	
		joint, front	9
	35766 B	" for feed rocker connecting rod ball joint,	The second
		front	9
	35767	Detachable Head Key (screw No. 22524)	11
	35770 B	Needle Thread Take-up, for Style 35800 AC	
	201.00	(screw No. 98 A)	6
	35773	Parallel Take-up Driving Flange (set screw No.	
	00110	88, spot screw No. 89)	18
	35777 A	Parallel Take-up Flange (screw No. 22794 C)	18
	35773 A	Lifton Lover (clamp corew No. 22507 F)	13
	35780 D	Lifter Lever (clamp screw No. 22587 E)	6
	35781 D	Looper Thread Guide	0
	35789 D	Detachable Head Cover, left, for Style 35800 AC	15
		(screw No. 22528)	15
	35790 E	Crankshaft Bushing, front, length 1 3/8 inches	10
	35791 A	Crankshaft Bushing Housing (screw No. 22569 B)	19
	35792	Tension Disc, large	6
	35792 C	Tension Disc Release Shaft Spring	12
	35792 E	Tension Plate Bracket (screw, front, No. 74,	THE REST OF
		screw, rear, No. 136)	11
	35792 H	screw, rear, No. 136) Tension Post (screw No. 91)	6
		-41-	1
		-41-	

Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35792 J	Tension Thread Eyelet (porcelain insert No.	
001000	668-7, ferrule No. 668-12)	6
35792 K	Tension Release Pin	9
35792 L-4	Lead-in Thread Eyelet, with four holes	
	(screw No. 74, porcelain insert No.	1
	668-1, ferrule No. 668-14)	21
35792 M	Tension Release Shaft	20
35795 F	Bed Plug	9
35796 B 35796 C	Chain Cutter Blade (screw No. 22768) (screw No. 22768)	6
35798 C	Cast-off Plate Spring	12
35804	Cast-off Plate Spring	18
35805 AC-16	Feed Dog, for Nos. 16 and 18 gauge, Style	
	35800 AC	2
35805 AD-12	" includes supplementary section	
	No. 35826 D, for No. 12 gauge,	
35805 AD-16	Style 35800 AD includes supplementary section	2
00000 AD-10	No. 35826 D for No. 16 gauge,	
	Style 35800 AD	2
35805 AV-16	" " for Nos. 16 and 18 gauge, Style	
	35800 AV	2
35805 AX-16	" " includes supplementary section	
	No. 35826 A, for Nos. 16 and 18 gauge, Style 35800 AY	0
35805 AY-16	" " includes supplementary section	2
00000 111 10	No. 35826, for Nos. 16 and 18	
	gauge, Style 35800 AY	2
	Feed Dog Screw No. 22874 C	
35808 AY	Looper, front, marked "AU"	5
35809 AY	" back, marked "AT" Looper Screw No. 22564 B	5
35815	Needle Lever (set screw No. 531)	13
35817 D-12	Needle Bar, marked "BM-12", for No. 12	10
	gauge, Style 35800 AD (set screw No. 88 A) Needle Bar, marked "CL", for Nos. 16 and 18	14
35817 AY	Needle Bar, marked "CL", for Nos. 16 and 18	
75010 40 10	gauge (set screw No. 88 A)	14
35818 AC-16	Needle Holder, marked "T-16", for No. 16 gauge (spot screw No. 89, set screw No.	
		12
35818 AC-18	Needle Holder, marked "T-18", for No. 18	12
	gauge (spot screw No. 89, set screw No.	SER !
	22784)	12
35820 AC-16	Presser Foot Assembly, for No. 16 gauge,	
	Style 35800 AC; one each Nos. 22799 C,	3
35820 AC-18	35830, 35830 AC-16, 51930 Presser Foot Assembly, for No. 18 gauge,	0
	Style 35800 AC; one each Nos. 22799 C,	
	35830, 35830 AC-18, 51930	3
-	10	

	LIST OF PARTS	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35820 AD-12	Presser Foot Assembly, for No. 12 gauge, Style 35800 AD; one each Nos. 22561, 22599, 22799 L, 22809 A, 35830 C,35830 D, 35830 F, 35830 H, 35830 K, 35830 M, 35830 N, 35830 Y, 35830 AD-12, 35830 AE; two No. 73 A; five No. 22845 A	3
35820 AD-16	Presser Foot Assembly, for No. 16 gauge, Style 35800 AD; one each Nos. 22561, 22599, 22799 L, 22809 A, 35830 C,35830 D, 35830 F, 35830 H, 35830 K, 35830 M, 35830 N, 35830 Y, 35830 AD-16, 35830 AE;	
35820 AV-16	two No. 73 A; five No. 22845 A Presser Foot Assembly, for No. 16 gauge, Style 35800 AV; one each Nos. 73 A, 22561, 22599, 22799 L, 22809 A, 35830 B,35830 C, 35830 D, 35830 E, 35830 F, 35830 G, 35830 H, 35830 K, 35830 AV-16; five No.	3
35820 AV-18	22845 A	3
35820 AY-16	22845 A	3
35820 AY-18	two No. 73 A; five No. 22845 A Presser Foot Assembly, for No. 18 gauge, Style 35800 AY; one each Nos. 22561, 22599, 22799 L, 22809 A, 35830 C,35830 D, 35830 F, 35830 H, 35830 K, 35830 AY-18;	3
35821	two No. 73 A; five No. 22845 A Machine Pulley, complete, grooved for round belt; one each Nos. 22597, 22597 A, 35721 F, 35721 G, 35721 H, 35821 B; three	3
35821 B	No. 22574 A Machine Pulley, grooved for round belt (spot screw No. 22597, set screw No. 22597 A)	19
35822 T	Crankshaft	20
\$35822 V	Main Shaft Assembly (hinge pin No. 55241 F)	20
35823 C	Parallel Take-up	18
35824 AC-16	Throat Plate, marked "L-16", for No. 16	
	Throat Plate, marked "L-16", for No. 16 gauge, Style 35800 AC	1
35824 AC-18	Throat Plate, marked "L-18", for No. 18 gauge, Style 35800 AC	1
35824 AD-12	Throat Plate, marked "M-12", for No. 12 gauge, Style 35800 AD	1

\$See Page 6

	BIDI OI IIMID	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35824 AD-16	Throat Plate, marked "M-16", for No. 16 gauge, Style 35800 AD	1
35824 AV-16	" marked "N-16", for No. 16 gauge, Style 35800 AV	1
35824 AV-18	" " marked "N-18", for No. 18 gauge, Style 35800 AV	1
35824 AY-16	" " marked "R-16", for No. 16 gauge, Style 35800 AY	1
35824 AY-18	" " marked "R-18", for No. 18 gauge, Style 35800 AY	1
35825 D	Throat Plate Screw No. 22524 Needle Guard, marked "FN" (screw No. 22768)	12
35826	Feed Dog Supplementary Section, for Style	2
35826 A	Feed Dog Supplementary Section, for Style	2
35826 D	Feed Dog Supplementary Section, for Style 35800 AD	2
	Feed Dog Supplementary Section Screw No. 22738	2
35829 G	Cylinder (screw No. 820, washer No. 6042 A, taper pin No. 664 F-24, dowel pin No. 667 D-16) NOTE: Furnished only when repairs are made	_
35829 J	at factory Detachable Head (screw, upper, No. 22759 A,	
	screw, lower, No. 318, washer No. 6042 A, taper pin No. 664 F-16) NOTE: Furnished only when repairs are made	-
35830	at factory Presser Foot Shank, for Style 35800 AC	7
35830 B	(screw No. 91) for Style 35800 AV (screw No. 91 D)	3
35830 C	" Yoke, for Styles 35800 AD, 35800 AV, 35800 AY	0
35830 D	(hinge screw No. 22845 A) Presser Foot Spring, for Styles 35800 AD,	4
35830 E	35800 AV, 35800 AY (screw No. 22561) Presser Foot Yielding Section, for Style	3
35830 F	35800 AV (set screw No. 22799 L) Presser Foot Yielding Section Adjusting Nut,	4
35830 G	for Styles 35800 AD, 35800 AV, 35800 AY-Presser Foot Bottom, rear section, for Style	3
35830 H	35800 AV (hinge screw No. 22845 A) Presser Foot Bottom Rear Section Equalizing	4
75070 V	Spring, for Styles 35800 AD, 35800 AV, 35800 AY (screw No. 73 A)	3
35830 K	Presser Foot Bottom Front Section Equalizing Spring, for Styles 35800 AD, 35800 AV, 35800 AY (screw No. 22599)	7
	30000 AI (SCIEW NO. 22399)	3

	2201 01 1111110	
Symbol	The figures in the last column refer only to	Plate
То	the plates illustrating the parts and are not	
Order By	to be used in ordering. Prices furnished on	No.
order by	application.	
	apprication.	
35830 M	Presser Foot Shank, for Styles No.35800 AD,	
00000 11	35800 AY (screw No. 91 D)	3
35830 N	Presser Foot Bottom Front Section Spring,	0
00000 11	for Ctyles 35000 AD 35000 AV (see N	
	for Styles 35800 AD, 35800 AY (screw No. 73 A)	-
35830 Y	Program Foot Pottom moon rooting 6 - Gt 1	3
00000 1	Presser Foot Bottom, rear section, for Style	
35830 Z	35800 AD (hinge screw No. 22845 A)	4
55050 Z	Presser Foot Bottom, rear section, for Style	
75070 AC 1C	35800 AY (hinge screw No. 22845 A)	4
35830 AC-16	Presser Foot Bottom, for No. 16 gauge, Style	
75070 10 10	35800 AC (hinge screw No. 22799 C)	4
35830 AC-18	Presser Foot Bottom, for No. 18 gauge, Style	
25020 AD 12	35800 AC (hinge screw No. 22799 C)	4 ,
35830 AD-12	Presser Foot Bottom, front section, for No.	
35830 AD-16	12 gauge, Style 35800 AD	4
99990 AD-16	Presser Foot Bottom, front section, for No.	
35830 AE	16 gauge, Style 35800 AD	4
DOODU AL	Presser Foot Yielding Section, for Styles	
	35800 AD and 35800 AY (set screw No. 22799 L)	-
35830 AV-16	Proggar Foot Bottom front gooties for No	3
99990 AV-10	Presser Foot Bottom, front section, for No.	
35830 AV-18	16 gauge, Style 35800 AV	4
00000 AV-10	Presser Foot Bottom, front section, for No. 18 gauge, Style 35800 AV	1
35830 AY-16	Prosser Foot Bottom front section for No	4
00000 AI-10	Presser Foot Bottom, front section, for No. 16 gauge, Style 35800 AY	4
35830 AY-18	Presser Foot Bottom, front section, for No.	4
CCCCO AI-10	18 gauge, Style 35800 AY	4
35830 AZ-16	Presser Foot Bottom, front section, for sew-	4
CCCCC ND-10	ing herringbone twill on No. 16 gauge,	
	Style 35800 AY	4
35830 AZ-18	Presser Foot Bottom, front section, for sew-	-
00000 112 20	ing herringbone twill on No. 18 gauge,	
	Style 35800 AY	4
	Presser Foot Bottom, front section, hinge	-
	screws, right, No. 22845 A, left, No.	
	22809 A	
35831 B	Presser Bar Lifter Bracket and Guide (screw	
	No. 22560 B)	11
35831 F	Presser Foot Stop, for Styles 35800 AD.	
	35800 AV, 35800 AY (screw No. 22584)	18
35833 C	Presser Spring Plate	18
35833 D	Presser Spring. lower	14
35833 E	" upper	14
35833 F	Presser Spring Rest	5
35834 G	Feed Bar Shaft Bushing	10
35834 N	Feed Lift Lever Link Bushing, upper	10
35834 R	Feed Bar (feed dog support screw No. 95, oil	
	wick No. 666-47)	20
35834 U	Feed Dog Holder (screws Nos. 376, 22874 C)	12
35834 V-3		11

	BIOT OF THEE	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35835 A 35836 35837	Needle Guard Holder (screw No. 22768) Feed Rocker (screw No. 22572) Feed Rocker Connecting Rod Ball Joint, rear (bearing screw No. 22515 A, stud clamp screw	12 13
35837 N	No. 22747, stud set screw No. 22743) Feed Rocker Connecting Rod Ball Joint, front (bearing screw No. 97 A, ball stud washer No.	11
35841 B	36 G, ball stud nut No. 35766 A) Feed Rocker and Looper Avoid Eccentric Connecting Rod Ball Joint (bearing screw No. 97 A, ball stud washer No. 35746 A, ball stud	11
35842 35842 G	washer shim No. 41355 U, nut No. 258) Feed Drive Lever and Looper Avoid Lever Feed Drive Lever and Looper Avoid Lever Shaft	11 13
35843 35844 35844 A	(screw No. 531)	14 14 20 4
35844 B 35845	" " left	14
35846	Feed Lift Lever Connecting Rod Ball Joint (bearing screw No. 97 A, ball stud nut No. 258, ball stud washer No. 35746 A, ball stud	
35847 E	washer shim No. 41355 U) Feed Lift Eccentric Connecting Rod (nut, right thread, No. 18; nut, left thread, No. 269)	11
35848 B	Looper Holder, front, marked "A" (screw No. 22562 A)	12
35848 C 35849 B	" back, marked "B" (screw No. 22562 A)	12
35850 A	" Bushing, rear, length overall 1 1/32 inches	10
35851	Looper Shaft Cross Head Link Ball Joint, front (bearing screw No. 97 A; ball stud nut No.	11
35851 A	35766 A; ball stud washer No. 15488) Looper Shaft Cross Head Link Ball Joint, rear (bearing screw No. 97 A)	11
35851 G	Looper Shaft Cross Head Link Connecting Rod (nut, right thread, No. 18; nut, left thread, No. 269)	
‡35853 U	Looper Drive Connecting Rod Assembly (locking spring No. 55241 E; bearing screw No. 97 A)	5
35853 W 35853 X	Looper Throw-out Plunger	9
35853 Y 35853 Z	" " Spring Knob	12
35856 A 35856 T	" Thread Eyelet (screw No. 22849) " Shield and Eyelet (screw No. 22829)	6
‡See Page	10	10

	BIDI OF THEE	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35859 H 35861 35861 A	Needle Bar Connection	12 15 15
35862 35864 B	Needle Lever Connecting Rod (bearing screw No. 22587 B) Needle Lever Thread Eyelet, for Styles 35800 AD,	13
35869 C	35800 AV, 35800 AY (screw No. 77) Needle Thread Controller Lever, for Styles	6
	35800 AD, 35800 AV, 35800 AY (screw No. 22557 A; nut No. 12982)	18
35869 D	Needle Thread Controller Lever Connecting Link, for Styles 35800 AD, 35800 AV, 35800 AY	2.2
35869 E	(screw No. 22758 E; nut No. 12934 A) Needle Thread Controller Lever Drive Rod Connection, for Styles 35800 AD, 35800 AV,	11
35869 F	35800 AY (screws Nos. 88, 22758 E) Needle Thread Controller Lever Drive Rod, for	12
35869 G	Styles 35800 AD, 35800 AV, 35800 AY Needle Thread Controller Lever Drive Rod Guide,	14
75000 H	for Styles 35800 AD, 35800 AV, 35800 AY (screw No. 77)	6
35869 Н	Needle Thread Controller Lever Drive Rod - Presser Foot Connecting Link, for Styles 35800 AD, 35800 AV, 35800 AY (screw No. 22760 C)	4
35869 J	Needle Lever Thread Controller Eyelet, for Styles 35800 AD, 35800 AV, 35800 AY (screw	
35870	No. 25 B) Needle Thread Take-up, for Styles 35800 AD,	6
35871 B 35872 B	35800 AV, 35800 AY (screw No. 28) Frame Needle Thread Eyelet (screw No. 22848) Parallel Take-up Thread Eyelet, right (screw	6
35872 C	No. 25 B) Parallel Take-up Thread Eyelet, left (screw No.	6
	22517)	6
35878 A 35880	Presser Bar Lifter Lever Link (screw No. 86)	20
35880 A	" " Connection (clamp screw No. 97)	4
35880 B	Presser Bar Lifter Lever	4
35883 A 35883 B	Cylinder Cover (screw No. 98 A)	19
35883 C	" Hinged Cover	15
35883 D	" " Pin (set screw No. 22565 C)	9
35883 E	" " Spring (screw No. 90)	12
35884 A 35884 C	Cylinder Gasket	19
35884 D 35886 A	Gasket, for cylinder cover and oil gauge Cylinder Side Cover (screw No. 22564 B)	15 19
-	-47-	

	HIDT OF THEED	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
35886 B 35887 G	Gasket, for cylinder side cover Main Frame Sound Insulator (screw No. 22642 K-112; washer No. 652-16; adjusting screw No. 22643 K-64; lock washer No.	19
35887 J 35887 K 35887 L	Main Frame Top Cover, front (screw No.22516 A) Gasket, for main frame top cover, front Main Frame Top Cover, middle	22 19 19 19
35887 M 35887 P 35887 Q	Spring, for main frame top cover, middle (screw No. 90; nut No. 41071 G) Main Frame Top Cover, back (screw No. 22516 A) Gasket, for top cover, back	12 19 19
35887 Ř 35888 B	Hinge, for main frame top cover, middle (screws Nos. 22528, 22564 B; nut No. 12934 A) Crank Chamber Cover (screw No. 93; oil cup No.	15
35888 C 35889 A		19 19
35889 B 35889 C	Detachable Head Cover, front, for Styles 35800 AD, 35800 AV, 35800 AY	15
35889 D	Detachable Head Cover, left, for Styles 35800 AD, 35800 AV, 35800 AY (screw No. 22528)	15
35889 E 35889 F 35889 G 35890	Gasket, for detachable head cover, left Oil Shield, for crank chamber (screw No.22561) Baffle Plate, for crank chamber Main Shaft Bushing, front, 27/32 inch length	15 16 19
35890 A 35892-4	overall	10
35894 B	rear, No. 136)	20
35894 C 35895-3	Oil Reservoir, back (screw No. 22729; lock washer No. 652 C-9)	16 2
35895-5 35895-8 35895 G	mental sections on feed dogs Shim, .005 inch thick	2 2
35895 N 35895 Q	Cushion Spring, for attaching machines to table	18 18 18
35895 R 35897 AB 35897 AC	Cushion Stud (nut No. 651 B-24, washer No. 652-24)	18 16 16
	-48-	10

	BIDI OF THEE	
		m1 1
Symbol	The figures in the last column refer only to	Plate
To Do	the plates illustrating the parts and are not	No.
Order By	to be used in ordering. Prices furnished on	
	application.	
35897 AD	Oil Pump Piston Rod	16
35897 AG	" " " Bearing	10
35897 AH	Gasket, for oil pump piston rod bearing	11
35897 AK	Oil Pump Piston Rod Connection (nut No. 37 R)	5
35897 AL	" " " Connecting Link	4
35897 AM	" " " Connecting Link Pin(cotter	
	pin No. 660-142)	5
35897 AN	" Lever (screw No. 22517 B)	16
35897 AP	" " Bearing Bracket (screw No. 136)	5
35897 AQ	idbe, incake, for sewing head	16
35897 AR 35897 AS	outlet, for sewing nead	16
35897 AT	intake, for cylinder	19
35897 AU	" " outlet, for cylinder Detachable Head Oiling Tube (sleeve No.660-74;	16
00001 110	coupling No. 660-75)	9
35897 AV	Detachable Head Oil Wicking Hook, lower	12
35897 AW	" " " upper	12
35897 AX	Cylinder Oil Drain Hole Gasket	11
35897 AY	Oil Gauge, Lucite	8
39141	Feed Rocker Connecting Rod (nut, right thread,	
	No. 18; nut, left thread, No. 269)	14
41041 B	Main Shaft Collar (set screw No. 531)	10
41061 C	Collar, for needle thread controller lever	
	drive rod, for Styles 35800 AD, 35800 AV,	10
41071 G	35800 AY Nut, for middle top cover spring	10
41255 B	Looper Drive Connecting Rod Ball Joint Fork	9
11200 2	(screw No. 22747)	9
41355 U-4	Shim, .004 inch thick, for feed lift lever	
	connecting rod ball joint washer; also for	
	No. 35841 B	11
41355 U-5	Shim, .005 inch thick	11
41355 U-6	" .006 inch thick	11
41355 U-7	" .007 inch thick	11
41355 U-8	" .008 inch thick	11
41355 U-9 43246	" .009 inch thick Feed Rocker and Looper Avoid Connecting Rod	11
10540	(nut, right thread, No. 18; nut, left thread,	BERTHER
	No. 269)	14
51257 B	Presser Bar Bushing, lower	10
51292 F-2	Tension Spring, .022 inch diameter wire, for	
	looper threads	12
51292 F-8	" .037 inch diameter wire, for	
F1430 36		12
51418-16	Needle Holder, marked "D-16", for No. 12 gauge	2.0
51070	(spot screw No. 89, set screw No. 98)	12
51930	Presser Foot Tilting Spring, for Style	12
52887 G	Presser Spring Rest	5
55241 E	Locking Spring, for looper drive connecting	
	rod assembly	12
	40	

	LIST OF PARTS	
Symbol To Order By	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Prices furnished on application.	Plate No.
55241 F-156 55241 F-158 55241 F-160 60078 P	Looper Drive Connecting Rod Hinge Pin, .156 inch diameter	9 9 9