



LIST OF PARTS FOR STYLES IN CLASSES 6000 6200 6400 6500 6600 FLAT BED MACHINES

CATALOG No. 44

SUPPLEMENT TO CATALOG No. 44


Applying to Styles 6600 E, 6600 G and 6600 H Having Annular Take-Up

6600 E For seaming couch covers, with and without rope welt; welt guided to left of needle.

6600 G For seaming decks to quarters of auto tops; includes puller STYLE 21700 T.

6600 H For undersewing auto cushions.


| SYMBOL | |
|------------------|--|
| | Feed Rocker, floating design (screws No. 88) |
| | Feed Rocker Shaft, 525 to inches long |
| 482 | Collar, for floating design feed rocker shaft (screw No. 98) |
| | Oil Cup, for right main shaft bearing |
| 1276 | Needle Lever Stud, cone bearing design (nut No. 47, Washer No. 48) |
| 6015 B | Needle Lever, forged aluminum alloy |
| 6042 A | Needle Lever Ball Clamp Bolt Washer |
| 6060 | Renewable Bearing, left, for main shaft |
| 6090 A | Needle Lever Stud Sleeve |
| 6091 | Needle Lever Nut, front, hexagonal |
| 6091 A | Needle Lever Nut, rear, cylindrical |
| 6092 | Needle Lever Stud Sleeve Key |
| 6093 | Needle Lever Cone (set screws No. 88) |
| 6607 B | Looper, with guard (set screw No. 73) |
| 6620 E | Presser Foot, for Style 6600 E (clamp screw No. 91) |
| 6625 B | Reciprocating Needle, Rear Guard (screw No. 90) |
| 6658 B | Take-up Thread Eyelet (screws No. 605) |
| 7404 B | Cast-off (screws No. 605) |
| 7404 B | Main Shaft |
| 7422 A 7423 A | Looper Thread Annular Take-up (spot screw No. 89) |
| 7425 A 7445 A | Looper Rocker Frame, detachable cone design |
| | Looper Rock Shaft |
| 7446 A | Main Shaft Sleeve Thread Guide (screw No. 605) |
| 7457 B | Take-up Thread Eyelet Stand (screws No. 22596) |
| 7459 | Take-up Thread Eyelet Stand (screw No. 94) |
| 7459 A | |
| 7462 D | Renewable Bearing, right, for main shaft |
| 7463 B | Main Shaft Sleeve |
| 7467 B | Cast-off Support (screw No. 94) Feed Rocker Arm (clamp screws No. 93) |
| 7484 A | |
| 7499 A | Main Shaft Counterbalance (screws No. 77) |
| 7521 B | Eccentric Pulley, throw .588 inch (screws No. 22597) Cloth Plate (screws, countersunk head, No. 80; fillister head, No. 93 A) |
| 7801 A | Cloth Plate (screws, countersunk head, No. 80; hinster head, No. 85 A) |
| 8559 | Reciprocating Needle Rear Guard Holder (screws No. 90) |
| 9932 | Feed Bar Shoe (screw No. 94) |
| 11638 M | Needle Lever Cone Adjusting Nut |
| 11684 AA | Street Elbow, for oil cup |
| 12078 | Annular Take-up Eyelet Hinge Block (pin No. 20290 B-9) |
| 17142 | Feed Bar |
| 17142 A | Reciprocating Needle Rear Guard Holder Base (screws, rear, No. 25 CC, front No. 22528) |
| 20290 B-9 | Annular Take-up Evelet Hinge Block Pin |
| 21396 AC | Needle Thread Lubricator, for Styles 6600 G, 6600 H (screw No. 93) |
| 21640 AC | Tension Release Lever Stud |
| 21640 AD | Tension Release Lever |
| 23184 H | Semi-felled Lap Seam Folder, for Style 6600 G (screws No. 25 C) |
| 29072 D | Eccentric Pulley Assembly; one each Nos. 7521 B and 15430 M lapped together |
| 29169 K | Looper Rocker Assembly, for Style 6600 G; one each Nos. 6013, 15465 F 15745 B lapped together, 6038, 12987 A and two No. 88 |
| 29304 E | Needle Lever Stud Assembly, cone design; one each Nos. 1276, 6090 A, 6093 lapped together, and two each Nos. 88, 11638 M |
| OFFOO D | Tension Thread Eyelet, sheet metal |
| 35582 B | Spring Valve Oiler |



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

Catalog No. 44

LIST OF PARTS

STYLES IN CLASSES

6000 6200 6400 6500 6600

The parts listed in this catalog are furnished at list prices for repairs only.

First Edition



Printed in U.S.A.

IMPORTANT NOTICE TO CUSTOMERS

The parts listed in this catalog are furnished at list prices for repairs only.

Attention is hereby called to the fact that many of said parts are subjects of patents, or enter into patented combinations, and that in furnishing these parts at list prices we only license their use for repairing machines of our own make, in their original condition.

Notice is hereby given that the sale of such parts by the purchaser, or the use thereof for changing over machines from one style to another, or for any other than bona fide repair purposes, is an infringement, for which the seller or user will be liable to prosecution.

CONTENTS

The matter of this catalog relates only to the styles of machines in Classes 6000, 6200, 6400, 6500 and 6600, listed on the following pages, and cannot be applied to other styles. Power Transmitter parts, Pulling Machine parts and Needles are listed in separate catalogs, known as Catalog Nos. 29, 32 and 45 respectively, copies of which will be supplied on request.

| | Page |
|---|------|
| Description of Machines | 5 |
| Important Notice to Customers | 3 |
| Needles | 8 |
| Ordering Repair Parts | 11 |
| Plates or Illustrations of Parts | 16 |
| List of Parts | 57 |
| Utility Grinder, No. 21394, Illustration of | 15 |
| Style 6400 M, Group Installation, Illustration of | 13 |
| Style 6400 W, Installed, Illustration of | 14 |

DESCRIPTION OF MACHINES

All machines have both a Class Number and a Style Number. The Class Number is stamped in the name plate attached to each machine. It represents a general type of machines, which is subdivided into several styles.

The Style Number is the Class Number with a letter affixed and is only used in the catalog. It represents a machine fitted to perform a specific operation.

CLASS 6000

Flat Bed Single Needle Machines, Bed 13 Inches Long, Needle Same Length as Type 101, For Knit Underwear and Similar Garments

Style

- *6000 A—For finishing knit underwear and similar garments; feed surface on all four sides of needle, double locked stitch.
- 6000 I—For finishing knit drawers; feed surface at left and rear of needle, double locked stitch.
- 6000 K—For ornamental stitching; feed surface at left and rear of needle, double locked stitch.

CLASS 6200

Flat Bed Single Needle Machines, Bed 13 Inches Long, Needle Same Length as Type 106, for Shoe Work

Style

- 6200 B—For making linings; feed surface at left and rear of needle, flat presser foot, double locked stitch.
- 6200 C—For making linings; rolling presser foot, diameter of roller $1\frac{5}{16}$ inches unless otherwise specified, double locked stitch.
- 6200 D—For folding and stitching top bands to linings; one operation, body of lining passes to left of needle, double locked stitch.
- 6200 E—For closing shoes; under feed only, flat presser foot, double locked stitch.
- 6200 F—For closing shoes; under feed only, rolling presser foot, diameter of roller 1 \frac{5}{16} inches unless otherwise specified, double locked stitch.

CLASS 6200—Continued

- Style
- 6200 K—For closing shoes; upper and under feed, double locked stitch.
- 6200M—For closing leather shoes; upper and under feed, welt gauge No. 2603D, double locked stitch.
- 6200 Q—For folding and stitching top bands to linings; one operation, body of lining passes to right of needle, double locked stitch.
- 6200W—For binding tongues; double locked stitch.
- 6200 X—For stitching leather top bands to shoe linings; upper and under feed, body of lining passes to left of needle, double locked stitch.
- 6200 Y—For folding, stitching and reinforcing edge of cloth button hole flies; one operation, double locked stitch.
- 6200AA—For stitching soles to uppers of felt slippers; upper and under feed, double locked stitch.
- 6200AB—For closing leather gloves; upper and under feed, vibrating presser mechanism, double locked stitch.

CLASS 6400

- Flat Bed Single Needle Machines, Bed 13 Inches Long, Needle Same Length as Type 106, For *Light* Weight Woven Fabrics
- 6400 I—For binding miscellaneous work not otherwise specified; double locked stitch.
- 6400M—For seaming mattress ticks; bound seams, English binder, double locked stitch.
- 6400 N—For joinging shoulders of shirts; one operation, double edge folder, upper and lower ply of fabric turned inwardly and front of garment inserted between, double locked stitch.
- 6400 U-For seaming mattress ticks; felled seams, double locked stitch.
- 6400W—For seaming mattress ticks; plain seams, double locked stitch.
- 6400 X—For stitching rick-rack braid to house dresses, aprons and similar garments; folder for edge of body fabric and adjustable guide for braid, double locked stitch.

CLASS 6500

Flat Bed Single Needle Machines, Bed 13 Inches Long, Needle Same Length as Type 128; For *Heavy* Weight Woven Fabrics

Style

- 6500 B—For seaming trousers, coats and similar garments; double locked stitch.
- 6500 C—For seaming trousers; welt seam, one operation, double locked stitch.
- 6500 E—For making pants flies; one operation, concealed stitch folder, double locked stitch.
- 6500 H-For making canvas horse collars; double locked stitch.
- 6500 N—For armhole drawing on coats and similar garments; double locked stitch.
- 6500 P—For basting edges of coats and similar garments; chain stitch, maximum length ½ inch.

CLASS 6600

Flat Bed Single Needle Machines, Bed 13 Inches Long, For Miscellaneous Work

Style

6600 B—For tent and awning work; needle same length as Type 143, double locked stitch.

NEEDLES

Descriptions Under the present plan, which was adopted in 1920, needles are given a Type Number and a new Size number. The Type Number denotes the kind of point, shank, length, groove, finish and other details. The Size Number is stamped in the needle shank. It denotes the largest diameter of the blade, meaured in thousandths of an inch, midway between the shank and eye. The Type Number and Size Number collectively represent the complete description of the needle.

Needle Catalogue No. 45 Full information is contained in Needle Catalog No. 45.

Copy will be forwarded on request. It contains the Type Numbers, New Size Numbers, and Old Size Numbers, description and prices per M. set opposite each other in convenient form, illustrations of the needles, magnified views of their points, their incision relative to the line of stitching, desirability of the different needle points on specified kinds of material, relative sizes of needles and thread, space for recording Type Number and Size Number of needle used for each operation, and other features.

Type Number Descriptions The Type Numbers of the needles used in the Styles of machines covered by this catalog are listed below. Set opposite each Type Number is the description of the needle.

DESCRIPTION

Needle Type No.

- 101—Round point, round shank, extra short, double groove, nickel plated.
- 106—Round point, round shank, extra short, double groove, nickel plated, ball eye.
- 108—Round point, round shank, extra short, double groove, nickel plated, ball eye, spotted.
- 121—Round point, round shank, short, double groove, nickel plated.
- 126—Round point, round shank, short, double groove, nickel plated, ball eye.
- 128—Round point, round shank, short, double groove, nickel plated, ball eye, spotted.

DESCRIPTION—Continued

- 130—Round point. round shank, short, double groove, nickel plated, ball eye, government, spotted.
- 140—Round point, round shank, long, double groove, nickel plated.
- 143-Round point, round shank, No. 2 bag, nickel plated.
- 145—Round point, round shank, No. 2 bag, nickel plated, government.
- 301—Stay point, round shank, extra short, double groove.
- 501—Rocked point, round shank, extra short, double groove.
- 701—Flat point, round shank, extra short, double groove.
- 907—Spear point, round shank, extra short, double groove, nickel plated, ball eye.
- 927—Spear point, round shank, short, double groove, nickel plated, ball eye.
- 929—Spear point, round shank, short, double groove, nickel plated, ball eye, spotted.
- 943—Spear point, round shank, No. 2 Bag.
- 1543—Twist point, round shank, No. 2 Bag.
- 1701—Twist Centered point, round shank, extra short, double groove.

Application of Type Numbers The Styles of machines covered by this catalog

are listed below. Set opposite each Style Number is the Type Number of the needles or needles which can be used. Type Numbers are arranged numerically, as the wide variety of the materials sewed on each Style of machine makes it impractical to show a preference.

| Machine Style No. | Type Number of Needles Used |
|----------------------|------------------------------------|
| 6000 | A—121 |
| 6000 | I—121 |
| 6000 | K—121 |
| 6200 | B—101, 106, 301 |
| 6200 | C—101, 106, 301 |
| 6200 | D—101, 106 |
| 6200 | E —101, 301, 501, 701, 1701 |
| 6200 | F-101, 301, 501, 701, 1701 |
| | |

DESCRIPTION—Continued

| Machine Style No. | Type Number of Needles Used |
|----------------------|-----------------------------|
| 6200 | K—101, 301, 501, 701, 1701 |
| 6200 | M—301, 501, 701, 1701 |
| 6200 | Q—101, 106 |
| 6200 | W101, 106 |
| 6200 | X—101, 301 |
| 6200 | Y-101, 301 |
| 6200 | AA—101, 301, 701, 1701 |
| 6200 | AB—701, 1701 |
| 6400 | I—106, 907 |
| 6400 | M106, 108 |
| 6400 | N—106 |
| 6400 | U—106, 108 |
| 6400 | W—106, 108 |
| 6400 | X—106, 907 |
| 6500 | B—126, 128, 130, 927, 929 |
| 6500 | C—126, 128, 130, 927, 929 |
| 6500 | E—126, 128 |
| 6500 | H—126, 128, 130, 927, 929 |
| 6500 | N—126, 128 |
| 6500 | P—121, 126, 128 |
| 6600 | B—140, 143, 145, 943, 1543 |

Ordering To have orders promptly and accurately filled, the empty package, a sample needle, or the Type and Size Numbers should be given. See marks on packages. An intelligible order would read as follows:

100 Needles Type 106 Size 040

Success in the operation of these machines can be assured only by the use of genuine Union Special Needles, as furnished by the Union Special Machine Company. Obviously it is to our interest to maintain the reputation of the machines by furnishing the very best needles obtainable. The genuine needles are put up in packages marked at the top "trade UNION SPECIAL mark". All other needles are bogus.

ORDERING REPAIR PARTS

Plates Grouped according to scale will be found illustrations of parts similar in appearance and, to some extent, component parts that go together in the same subdivisions of the mechanism. The scale the illustrations bear to the actual size of parts is given on each plate.

Always refer to the description, opposite the number, in the price list pages before ordering parts. In this way only can you be assured that you are sending us the correct number.

List of Parts On pages 4, etc. will be found a full description of the Classes and Styles of machines covered by this catalog. Where a part is used on all machines listed, no specific use is mentioned in its description. In describing other parts, we use the Style Numbers, or the Class Number if the part is used on every Style of machine listed in that Class. Where the description names the part and only specifies the Style Number or the Class Number of the machine or machines on which it is used, the part is the recognised standard part for those machines. We also list a few parts with a slight differentation from the standard part of similar kind for a listed Style of machine. They are described by mentioning the name of the part, Style Number of the machine, and also the features in which the part differs. Where a part is not used on a listed Style of machine, its description is based on the Class Number of the machine to which it is applied, with a specific mention of the operation the machine performs.

The screws, nuts and washers belonging to each major part are repeated after its description. If two or more parts listed consecutively have the same name and use the same screw, nuts or washers, they are only repeated after the last major part. All part numbers represent the same part, regardless of the catalog in which they appear.


Ordering Goods For convenience in ordering, the full number is stamped in each part, where its construction will permit. Sub-assemblies, comprising a plurality of parts in convenient form, are furnished. Each component part is represented

[—] A dash in the "Plate Number" column of the parts list indicates the absence of an illustration.


[‡] A double dagger in the "Number to Order by" column indicates that the component parts cannot be furnished separately.

by its own number. The assembly, taken collectively is likewise represented by a number. Where a number representing a sub-assembly is stamped in a part, it is always preceded by an open triangle "\(\triangle\)" to distinguish between the two kinds of numbers. It is not necessary that the open triangle be used in ordering. Other parts are marked with identification letters, which are mentioned in the descriptions on the parts list pages. If customers furnish the number stamped in a piece, errors will be avoided and we will be enabled promptly to duplicate the desired part. If only an identification letter is furnished, it should be accompanied with a general description of the part. All supplies including belting, belt fasteners, taps, reamers, screw drivers, and powdered oilstone, will be promptly furnished.


Terms Attention is directed to our established practice. Prices are strictly net cash. All goods are carefully packed and forwarded at buyer's risk f. o. b. shipping point. We cannot be responsible for delivery of packages shipped by parcel post, except when they are registered or insured. Where customer requests that a mail shipment be registered or insured, it will be complied with; failing this we reserve the right to use our own discretion. Regular parcel post rates and insurance, if any, will be charged on all mail shipments. Prices are subject to change without notice.



Utility Grinder




Style 6400 M, Group Installation




Style 6400 W Installed on an Individual Power Table No. 21371 G

PLATE No. 1-FULL SIZE




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 2—FULL SIZE




From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 3-FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 6-FULL SIZE mmmmm 6505 B 6405 D 15905A 6505 E 9205 E 6205 AB 6205AA 15226B 15205 6505P 6548

From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 8—FULL SIZE 6420U 6227 B 198 X 6520 N 6520 P 6627 A 6627 C 6627 D 6235 15480C 65 AF 9634


From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 9-FULL SIZE 6280 29457E 29457A 371 1588 A 370 6220-1/4 1592 6282 372 B


From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 13—FULL SIZE




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 15-FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 16-FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC



188 D

PLATE No. 19-FULL SIZE




From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 20-FULL SIZE 8368A 1286 B (110-3) (110-4) 426 1349 A·3 64 B 1280 21185

From the library of: Superior Sewing Machine & Supply LLC

15430 H




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 23-ONE HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 25-ONE HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 27—ONE HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 28-ONE HALF SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 29—ONE HALF SIZE



From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 30-ONE HALF SIZE 399 A 410 A 409 A 406 B 139A 168 168 A 168 B 8365 A 168 X

From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 32—ONE HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 33-ONE HALF SIZE 16188 21182 B 16189 21145 21364 21388 21388 B 21355 21355 A 21355B 118 B

From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 34—ONE HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 36-ONE FOURTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 37-ONE FOURTH SIZE 416 B 416 21640 A 29402 422 6522 B

From the library of: Superior Sewing Machine & Supply LLC


PLATE No. 38-ONE FOURTH SIZE poom()() 6215 153 F 16115 6250

From the library of: Superior Sewing Machine & Supply LLC

G035 A


8373

PLATE No. 39-ONE EIGHTH SIZE




From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 40-ONE EIGHTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE No. 41—ONE EIGHTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 2 | 23 | Cloth Plate Slide, right, for machines in class 6000; also for Style 6500 B, 6500 C and 6500 N. |
| | | " " Stop Screw No. 150. |
| | | " " Stop Screw No. 92, for Style 6500 N. |
| 2 A | 23 | " " left, without screw holes. |
| 2 S | 23 | " " right, for Styles 6200 B, 6200 C, 6200 D, 6200 E, |
| | - | 6200 F, 6200 Q and 6200 W. |
| | | " " " Thumb Screw No. 25 T. |
| 2 CU | 23 | " " right, for Style 6200 Y, 6400 U, 6400 W, 6500 H and 6600 B. |
| | | " " Stop Screw No. 150. |
| 4 B | 4 | Cast-off Wire, for Style 6000 B. |
| 4 C | 4 | " for machines in Class 6000; also for Styles 6200 AA, |
| | | 6200 AB, 6500 B, 6500 C, 6500 E, 6500 H and 6500 N. |
| 4 V | 4 | " for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 K, 6200 M, 6200 Q, 6200 W, 6200 X, 6200 Y 6400 I, 6400 M, 6400 N, 6400 U, 6400 W and |
| | | 6400 X. |
| |] | " " Screw No. 22524. |
| 5 | 16 | Collar, for main shaft. |
| | ļ | " Set Screws No. 95. |
| 6 A | 28 | Looper Eccentric Fork, with shoes. |
| | | " " Set Screws No. 72. |
| | | Adjusting below 110. 65. |
| 6 B | 22 | Shoe (hardened and ground) |
| _ | | Shoe Screw 140. 54. |
| 7 | 26 | Feed Rocker, with integral arm, for machines in Classes 6000 and 6400; also for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 Q, 6200 W, 6200 Y and 6600 B. |
| 7 D | _ | " with adjustable arm (includes one each Nos. 7 E and |
| | | 7 F and two No. 22548) for Styles 6500 B, 6500 C, |
| | | 6500 E and 6500 H. |
| 7 E | 26 | " " without arm, for Styles 6500 B, 6500 C, 6500 E and 6500 H. |
| | | " Set Screws No. 88. |
| 7 F | 26 | " Arm, adjustable, for Styles 6500 B, 6500 C, 6500 E |
| | | and 6500 H. |
| | 1 | " "Arm Screws No. 22548. |
| 8 | 31 | Feed Rocker Shaft $(5\frac{3}{16}$ inches long, hardened and ground) standard sizes, .407 inch: |
| 8-408 | | " " standard size, plus .001 inch. |
| 8-410 | - | " " standard size, plus .003 inch. |
| 8-413 | - | " " standard size, plus .006 inch. |
| 8-416 | <u> </u> | " " standard size, plus .009 inch. |

| | | TEFFER TO TINK INSERT FOR PRICES |
|-----------------------|--------------|--|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 8-419 | | Feed Rocker Shaft standard size, plus .012 inch. |
| 8-422 | _ | " " standard size, plus .015 inch. |
| 9 X | 25 | Feed Bar, for machines in Classes 6000 and 6400; also for Styles |
| 10 | 32 | 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 Q, 6200 W, 6200 Y, 6500 B, 6500 C, 6500 E and 6500 H. "Set Screws No. 88. |
| | 02 | Feed Bar Prong and Sponge, for machines in Classes 6000 and 6400; also for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 Q, 6200 W, 6200 Y, 6500 B, 6500 C, 6500 E and 6500 H. " " Screws No. 94. |
| 10 A | - | " " Sponge, for machines in Classes 6000, 6200 and 6400; also for Styles 6500 B, 6500 C, 6500 E, |
| 10 X | 32 | 6500 H, 6500 N and 6600 B. " " and Sponge, for Style 6600 B. " " Screws No. 94. |
| 11 | 31 | Feed Bar Shaft $(3\frac{7}{16})$ inches long, hardened and ground) |
| 15 | 21 | Feed Crank Link (hardened) " " Adjusting Screw No. 79. |
| 16 | 12 | Feed Crank Stud Ferrule; also for No. 16190. |
| 17 | 19 | " " for machines in Classes 6000, 6200 and 6400; |
| | | also for Styles 6500 B, 6500 C, 6500 E, 6500 H and 6500 N. |
| 17 X | 19 | " " for Style 6600 B. |
| 18 | 20 | " " Nut; also for Nos. 36 R, 2396, 6037, 6039, 6251 and 6252. |
| 19 | 12 | " " Cap. |
| | ĺ | " " Cap Screws No. 77. |
| 20 | 15 | " " Washer. |
| 21 | 15 | " " Pin; also for No. 16189. |
| , | - 1 | " " " Set Screw No. 77. |
| 22 | 5 | Feed Dog, for Style 6000 I. |
| 22 D | 5 | " for Styles 6000 K, 6200 B and 6200 W. |
| 22 I | 5 | " for Styles 6000 A, 6200 D and 6200 Q. |
| 22 CC | 5 | " for closing shoes, with California welt on machines in Class 6200, without upper feed. |
| 22 VA | 5 | " under feed, for Style 6200 AB. |
| | I | " " Screw No. 93. |
| İ | | " Supporting Screw No. 97. |
| T 22 | 18 | Screw, for feed dog, on Style 6500 P. |
| 23 | 22 | Feed Bar Shoe, under feed (hardened and ground) for machines |
| | ļ | in Classes 6000, 6200 and 6400, Styles 6500 B, 6500 C |
| | - | 6500 E, 6500 H and 6600 B; also feed bar spring shoe |
| i | ļ | for Style 6200 AB. |
| | | Snoe Screw No. 94. |
| | | " Spring Shoe Screw No. 25 CC. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 24 | 28 | Gauge, for Styles 6000 A and 6500 B. |
| 24 A | 28 | " for Style 6000 I. |
| | | " Screws No. 25. |
| 24 S | 28 | " for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 K and 6200 Q. |
| | | " Screws No. 25 S. |
| 24 U | 24 | " front, for Style 6200 D. |
| | | " Screws No. 25 C. |
| 24 X | 28 | " for Style 6400 W. |
| | | " Screws No. 25. |
| 25 | 19 | Thumb Screw, for cloth plate gauges. |
| 25 B | 17 | Screw, for loop retainer; also for No. 199. |
| 25 C | 18 | " $(\frac{9}{32})$ inch long) for cloth plate attachments; also for Nos. |
| -5 -5 | | 21387 A and 21387 D. |
| 25 S | 18 | " for cloth plate slide gauges; also for No. 21163. |
| 25 CC | 17 | " for feed bar spring shoe; also for Nos. 396 B, 913, 2603 D, |
| 20 00 | - | 8372, 16603 B, 16676 A and 23322 L. |
| 25 T | 19 | Thumb Screw, for cloth plate slides; also for Nos. 21172 C and |
| 20 1 | 1 - | 21172 F. |
| 26 | 4 | Looper, for machines in Class 6000. |
| 26 VN | 4 | " with guard, for Styles 6200 E, 6200 F, 6200 K and 6200 M. |
| 20 111 | 1 * | " Set Screw No. 73. |
| A 26 | 4 | " Needle Guard (marked A) for loopers Nos. 26 VN, |
| 11 20 | 1 | 6207 B and 9507 E. |
| | İ | " Needle Guard Screw, No. 73 A. |
| 27 V | 12 | Loop Retainer, for throat plates on Styles 6200 E, 6200 F, 6200 K |
| 2. 1 | | and 6200 M. |
| | | " " Screw No. 25 B. |
| 28 B | 17 | " "Adjusting Screw, headless. |
| 30 | 26 | Looper Rocker Frame, integral cone (hardened) |
| | - | " " Set Screw, left, No. 88. |
| | | " " Set Screw, right, No. 98. |
| | | " " Spot Screw, No. 96. |
| 31 | 31 | Looper Rock Shaft ($3\frac{1}{8}$ inches long, hardened and ground) standard size .407 inch: |
| 31-408 | l _ | " " standard size, plus .001 inch. |
| 31-410 | I _ | " " standard size, plus .003 inch. |
| 31-413 | · | " " standard size, plus .006 inch. |
| 31–416 | | " " standard size, plus .009 inch. |
| 31-419 | I _ | " " standard size, plus .012 inch. |
| 31–422 | | " " standard size, plus .015 inch. |
| 32 | 31 | " " $(1\frac{1}{8})$ inches long, hardened and ground) |
| 02 | " | standard size, .407 inch. |
| | | Tomassa a many 1201 manas |
| | | |
| | | · |

REFER TO PINK INSERT FOR PRICES

| t | Number o Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|---|----------------------|--------------|--|
| | 32-408 | _ | Looper Rock Shaft, standard size, plus .001 inch. |
| | 32-410 | | " " standard size, plus .003 inch. |
| | 32-413 | l _ | " " standard size, plus .006 inch. |
| | 32-416 | l _ | " " standard size, plus .009 inch. |
| | 32-419 | l | " " standard size, plus .012 inch. |
| | 32-422 | l _ | " " standard size, plus .015 inch. |
| | 33 | 19 | Looper Rocker Stud (hardened) for use with frame No. 30. |
| | 34 | 20 | " " Nut; also for No. 12993 A. |
| t | 36 L | 13 | Looper Connecting Rod Ball Joint, left, complete, for machine |
| | 00 2 | | using rods with $\frac{1}{36}$ inch diameter threaded ends (obsolete, present as sembly includes Nos. 18, 269, 6037 6038 and 6039) |
| ‡ | 36 R | 13 | " " Ball Joint, right, complete, for machines using rods with $\frac{3}{16}$ inch diameter threaded ends (obsolete, present assembly includes Nos. 18, 269, 6037, 6038 and 6039) |
| | | | " " Ball Joint Screws No. 97 A. |
| | | 1 1 | " " Ball Joint Stud Nut No. 18. |
| | 37 L | 20 | Vibrating Lifter Connecting Rod Nut, left thread, for Style 6200 AB; also for No. 152. |
| | 37 R | 20 | " " " Nut, right thread, for Style 6200 AB; also for No. 152. |
| | 38 | 16 | Looper Eccentric (originally marked D, throw .208 inch) for machines in Class 6000; also for Styles 6200 B 6200 C, 6200 D, 6200 Q, 6400 M, 6400 U |
| | 38 V | 16 | 6400 W, 6500 B, 6500 C, 6500 H and 6500 N " (originally marked V, throw .174 inch) for Styles 6200 E, 6200 F, 6200 K, 6200 M 6200 W, 6200 X, 6200 AA, 6200 AB, 6400 I 6400 N and 6400 X. |
| | 38 X | 16 | " (originally marked X, throw .219 inch) for Style 6600 B. |
| | | | " " Screw No. 96. |
| | 40 | 12 | Looper Thread Guide, lower, right. |
| | 41 A | 13 | Hand Lifter, for machines in Classes 6000 and 6200; also for |
| | | | Styles 6400 I, 6400 M, 6400 U, 6400 W, 6400 X 6500 N and 6500 P. " " Stud No. 86. |
| | 42 A | 18 | " " Screw Pin (hardened) |
| | 43 | 28 | Feed Lift Eccentric (originally marked F, throw .062 inch, obsolete, present assembly No. 43 C) |

‡See Page 11

| Number o Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|----------------------|--------------|--|
| 43 C | 16 | Feed Lift Eccentric (originally marked C, throw .080 inch) for |
| | | machines in Classes 6000 and 6400; also |
| | | for Styles 6200 B, 6200 C, 6200 D, 6200 E |
| ! | | 6200 F, 6200 Q, 6200 W, 6200 Y, 6500 B |
| | | 6500 C, 6500 E, 6500 H and 6500 N. |
| | | " " " Screw No. 96. |
| 47 | 20 | Needle Lever Stud Nut (hardened) |
| 48 | 15 | " " Washer. |
| 50 | 31 | Needle Bar (hardened and ground) standard size .257 inch, with- |
| | | out eyelet screw hole (obsolete, present assembly |
| | | includes Nos. 50 D, 53 A and 22768) |
| 50-260 | l — | " standard size, plus .003 inch. |
| 50-263 | l — | " standard size, plus .006 inch. |
| 50-266 | l — | " standard size, plus .009 inch. |
| 50-270 | l — | " standard size, plus .013 inch. |
| 50-273 | <u> </u> | " standard size, plus .016 inch. |
| 50-276 | | " " standard size, plus .019 inch. |
| 50-280 | l _ | " standard size, plus .023 inch. |
| 50-283 | l _ | " standard size, plus .026 inch. |
| 50 D | 31 | " (hardened and ground) standard size .257 inch: |
| 50 D-260 | _ | " standard size, plus .003 inch. |
| 50 D-263 | | " standard size, plus .006 inch. |
| 50 D-266 | l | " " standard size, plus .009 inch. |
| 50 D-270 | - | " " standard size, plus .013 inch. |
| 50 D-273 | l — | " " standard size, plus .016 inch. |
| 50 D-276 | | " " standard size, plus .019 inch |
| 50 D-280 | 1 — | " " standard size, plus .023 inch. |
| 50 D-283 | _ | " " standard size, plus .026 inch. |
| | ! | " " Set Screws No. 88. |
| | | " Set Screws No. 88 A, for Style 6600 B. |
| 52 A | 12 | Needle Lever Thread Eyelet, left; also frame thread eyelet for |
| | | intermittent needle thread nipper. |
| | ļ. | " "Thread Eyelet Screw No. 98 A. |
| 5 3 | 12 | Needle Bar Thread Guide, without screw hole (obsolete, present assembly includes Nos. 50 D, 53 A and 22768) |
| 53 A | 12 | " "Thread Guide, with screw hole. |
| | | " " Thread Guide Screw No. 22768. |
| 54 | 33 | " " Link (hardened) |
| 56 | 20 | Needle Clamp Nut (hardened) |
| 57 | 22 | Looper Thread Nipper Spring, upper. |
| | | " " Spring Screw No. 90. |
| 57 WB | 21 | Needle Bar Thread Nipper Plate. |
| 57 WC | 20 | " " " Spring. |
| | | " " " Stud; also for Nos. 9634 and 15480 |

| | | REFER TO FINE INSERT FOR PRICES |
|------------------------|--------------|--|
| Number to Order_by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 58 | 22 | Looper Thread Nipper Spring, lower. |
| | | " " Screw No. 90. |
| | | " " " Operating Screw No. 97. |
| 59 S | 34 | Eccentric Pulley (originally marked M, throw .529 inch) for |
| | Į. | machines in Class 6000; also for Styles 6400 I, |
| | | 6400 M, 6400 U, 6400 W, 6400 X and 6500 E. |
| 59 V | 34 | " (originally marked N, throw .461 inch) for |
| | | machines in Class 6200; also for Style 6400 N. |
| | | " Set Screws No. 22597. |
| 60 A | 31 | Presser Bar (hardened and ground) standard size .319 inch, |
| | | adjustable presser guide bar assembly: |
| 60 A-322 | - | " standard size, plus .003 inch. |
| 60 A-325 | - | " " standard size, plus .006 inch. |
| 60 A-328 | | " " standard size, plus .009 inch. |
| 60 A-331 | _ | " " standard size, plus .012 inch. |
| 60 A-334 | _ | " standard size, plus .015 inch. |
| 60 X | 31 | " (hardened and ground) standard size .319 inch, non- |
| | | adjustable presser guide bar assembly (obsolete, |
| | | present assembly includes Nos. 60 A, 61 C and |
| 20 77 800 | | 62 C) " gtandard sign plus 002 inch |
| 60 X-322 | _ | standard size, plus .005 inch. |
| 60 X-325 | _ | standard size, plus .006 inch. |
| 60 X-328 | _ | standard size, plus .009 inch. |
| 60 X-331 60 X-334 | _ | standard size, plus .012 mcn. |
| 61 C | <u> </u> | standard size, plus .015 inch. |
| 01 0 | 21 | Presser Bar Connection, adjustable presser guide bar assembly. |
| | | ocrew, from, fro. 77. |
| 61 X | 21 | " " Screw, rear, No. 88. |
| 01 21 | 21 | " " non-adjustable presser guide bar as- |
| | | sembly (obsolete, present assembly includes Nos. 60 A, 61 C and 62 C) |
| | | " " Screw, front, No. 89. |
| | | " " Screw, rear, No. 77. |
| 62 | 31 | Presser Guide Bar (hardened and ground) standard size .319 |
| | | inch, non-adjustable (obsolete, present |
| | | assembly includes Nos. 60 A, 61 C and 62 C) |
| 62-322 | | " " standard size, plus .003 inch. |
| 62-325 | - | " " standard size, plus .006 inch. |
| 62-328 | _ | " " standard size, plus .009 inch. |
| 62-331 | - | " " standard size, plus .012 inch. |
| 62-334 | - | " " standard size, plus .015 inch. |
| 62 A | 31 | " "/ (hardened and ground) standard size .319 |
| ŀ | İ | inch, adjustable, for Styles 6200 K, 6200 M, |
| | ļ | 6200 X and 6200 AB. |
| 62 A-322 | | " " standard size, plus .003 inch. |

| | | <u></u> |
|-----------------------|--------------|---|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 62 A-325 | | Presser Guide Bar, standard size, plus .006 inch. |
| 62 A-328 | _ | " " standard size, plus .009 inch. |
| 62 A-331 | _ | " " standard size, plus .012 inch. |
| 62 A-334 | _ | " " standard size, plus .015 inch. |
| 62 C | 31 | " " (hardened and ground) standard size .319 inch, adjustable, for machines in Classes 6000, 6400 and 6500; also for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 G, 6200 W, 6200 Y, 6200 AA and 6600 B: |
| 62 C-322 | - | " " standard size, plus .003 inch. |
| 62 C-325 | _ | " " standard size, plus .006 inch. |
| 62 C-328 | _ | " " standard size, plus .009 inch. |
| 62 C-331 | _ | " " standard size, plus .012 inch. |
| 62 C-334 | l _ | " " standard size, plus .015 inch. |
| 64 A | 19 | Presser Spring Screw Regulator, for machines in Classes 6000, 6200, 6400 and 6500. |
| 64 B | 20 | " " Regulator Lock Nut. |
| 64 X | 19 | " " Regulator, for Style 6600 B. |
| 65 | 7 | Presser Foot, hinged bottom, closed front, for machines in Class |
| UU | l ' | 6000 using feed dog with feed surface on all four |
| | | sides of needle. |
| GE A | 7 | " " for Style 6000 A. |
| 65 A | ľ | " " for Style 6000 I. |
| 65 F | 7 | " hinged bottom, closed front, for finishing knit |
| 65 G | 7 | undershirts on machines in Class 6000 using feed dog No. 22 D. |
| CE II | _ | " " for Style 6000 K. |
| 65 H | 7 | " " for Styles 6200 B and 6200 E. |
| 65 T | 7 | Tot boyles dade a talk dade as |
| 65 U | 7 | for closing sides, with Cambrina welt, on machines |
| 0= 47 | | in Class 6200, without upper feed. |
| 65 AF | 8 | for Style 0200 D. |
| | | Ciginp Screw No. 91. |
| 67 | 16 | Main Shaft Sleeve, left (11/16 inches long) for double locked |
| | ł | stitch machines, without upper feed. |
| | | 1 in 140. 1502. |
| 68 | 16 | stitch machines. |
| 69 S | 41 | Spool Pin, for thread stands, using two spools |
| 69 FB | 40 | Spool Support Connection, for Style 6500 P. |
| | | " " Screw, upper, No. 22508. |
| 69 FD | 19 | " " Screw, lower; also for Nos. 21130 A-2, 21685, 21693 F and 21693 K. |
| 70 | 32 | Looper Eccentric Sponge Holder, with sponge. |
| | 1. | " Sponge Holder Screw No. 93. |
| 70 A | <u> </u> | " Sponge. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 72 | 17 | Set Screw, for looper eccentric fork; also for No. 6220-11. |
| 73 | 18 | " for looper. |
| 73 A | 17 | Screw, for looper needle guards. |
| 77 | 17 | Set Screw, fillister head, upper, for needle bar link pin; also for |
| | " | Nos. 19, 21, 61 C and 61 X. |
| 78 | 17 | " " headless, convex end, lower, for needle bar link pin. |
| 79 | 18 | Screw, for feed crank link; also for No. 16189. |
| 80 | 18 | " cone head, for cloth plates. |
| 81 | 17 | Spot Screw, for feed rocker eccentric flange holder. |
| 82 | 19 | Stitch Regulating Screw. |
| 84 B | 15 | " " Sleeve $\frac{5}{32}$ inch long. |
| 85 | 19 | Clamp Screw, for looper eccentric fork. |
| 86 | 18 | Stud, for hand lifters; also for Nos. 403, 8362 B and 8363. |
| 86 A | 18 | " large size, for hand lifters (tap No. 21513) |
| 86 X | 18 | Hinge Screw, for presser feet Nos. 198 X, 6627 C and 6627 D. |
| 87 | 17 | Screw, for throat plates and throat plate needle guards; also for |
| | | Nos. 16186 D and 21390 D. |
| 87 U | 17 | " for needle thread pull-off and take-up wires; also for Nos. 8374, 21607 and 23373. |
| 88 | 17 | " for feed rockers; also for Nos. 9 X, 30, 50 D, 61 C, 161, 198 X, 409 A, 903, 1261, 1288, 2538, 5142, 6205 X, 6220-14, 6242 A, 6246, 6282, 6627 C, 6627 D, 8361, 8362 A, 8362 D, 8363, 12865, 15447 E, 15465 F, 16170, 16187 A, 21113 B, 21147 and 21161 D. |
| 88 A | 17 | " for presser bar rack and presser spring rest; also for Nos. 50 D, 6440, 1593 B. |
| 89 | 17 | " for take-ups; also for No. 61 X. |
| 90 | 17 | " for looper thread nipper springs; also for Nos. 15447 L, 16676 A, 21172 A, 21172 B, 21172 H, 21390 E, 21640 F, 23322 K $-\frac{7}{8}$ and 23322 K -1 . |
| 91 | 17 | Clamp Screw, for presser feet; also for Nos. 1586 A, 1586 B and 6548. |
| 91 A | 17 | Screw, for knife No. 1741; also for No. 6235. |
| 92 | 18 | Stop Screw, for cloth plate slide on Style 6500 N. |
| 93 | 18 | Screw ($\frac{7}{16}$ inch long) for feed dogs; also for Nos. 70, 104, 1002 |
| | | 1592, 5150, 6548, 7638 A, 8366 A, 8367 A, 8368 B, 8370 A 15447 F, 15447 H, 15447 K and 21645. |
| 93 A | 18 | " (⁹ / ₃₂ inch long) for feed dogs on machines with feed bar needle rear guards; also for Nos. 149, 416A, 911, 912, 6001, 6201 L, 6242, 6242 B, 6501 P, 7801, 8301 M, 15447 H and 15447 K. |
| 94 | 18 | " for looper eccentric fork shoes; also for Nos. 10, 10 X, 23, 143, 202 A, 404 A, 908, 5125, 6625 A, 12835, 15447 G 16171, 16173, 21164, 21172, 21602, 21602 A and 21603 |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 95 | 17 | Screw for main shaft collar; also for Nos. 100 B, 1005, 15686 A, 21113 A and 21140. |
| 96 | 17 | Spot Screw, for eccentrics; also for Nos. 30, 1261, 6606, 21126, 21173 and 21182 M. |
| 97 | 18 | Screw ($\frac{11}{32}$ inch long) for supporting feed dogs; also for Nos. 58, 103, 403, 555, 5150, 16186 D, 16188, 16189 and 21390 F. |
| 97 A | 18 | Screw for looper connecting rod ball joints; also for Nos. 6251, 6252 and 6547. |
| 98 | 17 | Set Screw, right, for looper rocker frame; also for Nos. 30, 111, 334, 424, 2650, 6206, 6206 A, 6247 and 21161 C. |
| 98 A | 17 | Screw, for needle lever thread eyelets; also for Nos. 8371 A and 21632. |
| 100 B | 35 | Thread Wire (16 inches long) for Style C thread stand. " Coupling Screw No. 88. " Extension Screw No. 95. |
| 101 | 13 | Take-up, for looper thread on machines in Class 6000. |
| | 13 | " for looper thread on machines in Classes 6200, 6400 |
| 101 V | 19 | · |
| | | and 6500; also for Style 6600 B. |
| | | BCIEW IVO. Ob. |
| 102 | 29 | Frame. |
| | | " Frame Screws No. 22596. |
| 103 | 28 | Take-up Thread Eyelet. |
| | 1 | " " Supporting Screw No. 97. |
| 104 | 22 | " " Spring. |
| 105 | 33 | " " Spring Screw No. 93. |
| 105-13 | _ | Machine Thumb Screw (1½ inches long) |
| 105-21 | l _ | " " (2½ inches long) |
| 105-3 | _ | " " (3 inches long) |
| 105-3½ | 1 _ | " " (3½ inches long) |
| 105-32 | | " " (4 inches long) |
| | | " " $(4\frac{1}{2} \text{ inches long})$ |
| 105-42 | - | " " (5 inches long) |
| 105-5 | - | " " (5½ inches long) |
| 105-5½ | - | " " (6 inches long) |
| 105–6 | 1.5 | Tension Ferrule; also for Nos. 1000 and 21182 J. |
| 107 | 15 | " Nut; also for Nos. 1000 and 21182 J. |
| 108 | 20 | 1 |
| 109 | 15 | " Disc (hardened and lapped) |
| 110-1 | 20 | Tension Spring (.026 inch diameter wire) for looper thread. |
| 110–2 | 20 | " (.028 inch diameter wire) for needle thread; also |
| | | for looper thread and No. 1000. |
| 110–3 | 20 | (.O40 Mchi diameter who) for needle throad; also |
| | | for Nos. 21176 A, 21182 B-\frac{15}{16} and 21182 J. |
| 110 -4 | 20 | " (.048 inch diameter wire) for needle thread. |
| 111 | 12 | Tension Thread Eyelet, with two eyes. |
| | 1 | " Eyelet Set Screw No. 98. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 112 | 1 | Throat Plate, for Style 6000 A. |
| 112 E | 1 | " for Style 6000 I. |
| 112 N | 1 | " " for Style 6000 K. |
| 112 S | 1 | " without needle guard hole, for finishing knit under- |
| | | shirts on machines in Class 6000 using feed dog No. 22 D. |
| 112 CC | 1 | " for closing shoes, with California welt, on machines in Class 6200, without upper feed. |
| | | " Screws No. 87. |
| 116 | 33 | Wrench $(\frac{9}{32})$ inch) for needle clamp nut. |
| 118 | 32 | Thread Hook. |
| 118 B | 33 | " Tweezers. |
| 134 | 18 | Stud, for gauge lever on Styles 6200 AA and 6200 AB. |
| 137 | 12 | Thread Controller Thread Eyelet. |
| 138 | 17 | " "Thread Eyelet Screw; also for No. 21624. |
| ‡ 139 A | 30 | " " Lever and Washer, assembled. |
| 141 | 19 | " " Lever Screw. |
| 142 C | 29 | " "Rack and Presser Spring Rest. |
| | | " Rack Screw No. 88 A. |
| 143 | 29 | Thread Oiler and Pull-off Wire Post. |
| | | " " and Pull-off Wire Post Screw No. 94. |
| 143 A | 29 | " " Valve. |
| 143 B | 12 | Needle Thread Pull-off and Take-up Wire $(\frac{9}{32}$ inch wide) "Screw No. 87 U. |
| 148 A | 11 | Throat Plate Needle Guard (hardened, marked A) for Styles 6200 E, 6200 F, 6200 K, 6200 M, 6200 W, 6200 AA and 6200 AB. " " Guard Screw No. 87. |
| 149 | 41 | Cloth Plate, for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 Q, 6200 W, 6200 Y, 6400 N, 6500 B, 6500 C, 6500 E and 6500 H. |
| | | " Screws, cone head, No. 80. |
| | | " Screw, fillister head, No. 93 A. |
| 150 | 17 | " Slide Stop Screw, passes through slide. |
| 152 | 31 | Looper Connecting Rod, $\frac{3}{16}$ inch diameter threaded ends (obsolete, present assembly includes No. 18, 269, 6037, 6038 and 6039) |
| | | " " Nut, left thread No. 37 L. |
| 170 - | [| " " Nut, right thread No. 37 R. |
| 153 F | 38 | Needle Lever, for machines in Classes 6000 and 6400; also for Styles 6200 B, 6200 C, 6200 D, 6200 Q, 6500 B 6500 C, 6500 E, 6500 H, 6500 N and 6600 B. |
| 154 | 15 | " Washer. |
| 156 | 19 | " Ball (hardened) |
| 158 | 12 | " "Thread Eyelet, right. |
| | j | " " Screw No. 98 A. |

‡See Page 11

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 161 | 16 | Binding Holder Disc Supporting Collar, for Styles 6200 W, 6400 I and 6400 M. |
| | l | " " Supporting Collar Set Screw No. 88. |
| 162 | 21 | Needle Bar Connection. |
| 168 | 30 | Presser Spring, for machines in Classes 6000 and 6400; also for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 K, 6200 M, 6200 Q, 6200 W, 6200 X, 6200 Y, and 6200 AA and 6500 N. |
| 168 A | 30 | " for Styles 6500 B, 6500 C, 6500 E, 6500 H and 6500 P. |
| 168 B | 30 | " " for Style 6200 AB. |
| | | " Screw Regulator No. 64 A. |
| 168 X | 30 | " " for Style 6600 B. |
| | | " Screw Regulator No. 64 X. |
| 169 | 36 | Main Shaft (hardened and ground) standard size .530 inch, for machines in Classes 6000, 6200 and 6400; also for Styles 6500 B, 6500 C, 6500 E, 6500 H and 6500 N: |
| 169-531 | l — | " " standard size, plus .001 inch. |
| 169-533 | l — | " " standard size, plus .003 inch. |
| 169-536 | | " " standard size, plus .006 inch. |
| 169-539 | l | " standard size, plus .009 inch. |
| 169-542 | l _ | " standard size, plus .012 inch. |
| 170 | 36 | Screw Driver, round steel $(\frac{7}{32})$ inch diameter) |
| 177 | 4 | Looper, with guard, for Styles 6500 B, 6500 C, 6500 H, 6500 N and 6600 B. |
| 177 A | 4 | " without guard, otherwise same as No. 177. " Set Screw No. 73. |
| 179 B | 4 | " Needle Guard (marked H) for looper No. 177. " Needle Guard Screw No. 73 A. |
| 181 | 29 | " Rocker, for Styles 6200 B, 6200 C, 6200 D, 6200 E, 6200 F, 6200 K, 6200 M, 6200 Q, 6200 W, 6200 Y, 6200 AA and 6200 AB. |
| 187 A | 17 | Screw, for presser foot top band guide on Style 6200 X; also for Nos. 1741 B, 6035 B, 23182 D, 23215 AP, 23223 K, 23223 L and 23371. |
| 188 D | 18 | Thumb Screw, for rick-rack spool support cone; also for No. 21148. |
| 194 | 13 | Hand Lifter, for Styles 6500 B, 6500 C, 6500 H and 6600 B. " Stud No. 86. |
| 195 | 1 | Throat Plate, for seaming trousers, coats and similar garments on machines in Class 6500, using feed dog No. 22 I. |
| 195 D | 1 | " " for Styles 6200 D and 6200 Q. |
| 195 X | 1 | " for Styles 6600 B. |
| | | " " Screws No. 87. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 196 | 11 | Throat Plate Needle Guard (hardened, marked F) for Styles 6000 K, 6400 W, 6500 B and 6500 C. |
| 196 D | 11 | " Needle Guard (hardened, marked AE) for Styles 6200 B, 6200 C, 6200 D, 6200 Q and 6200 Y. |
| 197 X | 5 | " " Needle Guard Screw No. 87. Feed Dog, for Style 6600 B. " " Screw No. 93 A. " " Supporting Screw No. 97. |
| 198 X | 8 | Presser Foot, with needle guard, for Style 6600 B. " " Set Screws No. 88. " " Hinge Screw No. 86 X. |
| 199 | 11 | " Needle Guard, for Nos. 198 X and 6627 A. " Needle Guard Screws No. 25 B. |
| 201 A | 39 | Rick-Rack Spool Support Frame. |
| 201 C | 19 | " " Frame Pin Thumb Screw; also for 21385 B. |
| 202 A | 31 | Needle Thread Take-up and Pull-off Wire Post, for machines in Class 6400; also for Styles 6200 D, 6200 Q, 6200 W, 6500 B, 6500 C, 6500 E, 6500 N, 6500 P and 6600 B. |
| 202 B | 12 | " " and Pull-Off Wire Post Screw No. 94. Needle Thread Take-Up Wire, for Styles 6400 I, 6400 M, 6400 U, 6400 W, 6400 X, 6500 B, 6500 C, 6500 E and 6500 N. " " Screw No. 87 U. |
| 213 | 29 | Screw 140. 87 U. |
| 269 | 20 | Looper Rocker, for Styles 6200 X and 6400 N. |
| 303 | 18 | " Connecting Rod Nut, left thread; also for No. 2396. Screw, hexagon head, for upper feed bar spring. |
| 318 | 19 | " for looper rock shaft frame on Style 6500 P. |
| 334 | 12 | Tension Thread Eyelet, for Style 6500 P. |
| 001 | 12 | " " Screw No. 98. |
| 347 | 12 | Needle Thread Pull-Off and Take-Up Wire $(\frac{7}{32}$ inch wide) "Screw No. 87 U. |
| 370 | 9 | Roller (diameter $1\frac{1}{3}$ inches, width $\frac{3}{16}$ inch) for presser foot No. 1520 J- $1\frac{1}{8}$ |
| 371 | 9 | " (diameter $1\frac{5}{16}$ inches, width $\frac{3}{16}$ inch) for presser foot No. $1520 \text{ J}-1\frac{5}{16}$ |
| 372 B | 9 | " (diameter $1\frac{3}{4}$ inches, width $\frac{1}{4}$ inch) for presser foot No. 1520 K- $1\frac{3}{4}$ |
| 374 | 17 | " Hub Expanding Screw. |
| 375 | 20 | " Hub Nut. |
| 376 | 17 | " Ball Bearing Stud. |
| 377 | 20 | " Ball Bearing Stud Nut. |
| 387 | 15 | " Ball Bearing Ball. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 396 D | 30 | Base, for welt gauge No. 2603 D. " Screws No. 25 CC. |
| 399 A | 30 | Slide, for welt gauge No. 2603 D. |
| 400 | 30 | " Spring. |
| 401 | 17 | " Spring Screw. |
| 402 | 18 | " Screw-pin; also for No. 410 A. |
| 403 | 30 | " Lever. |
| | | " Lever Stud No. 86. |
| | | " Lever Stop Screw No. 97. |
| 404 A | 30 | " Lever Stop Plate. |
| | | " Lever Stop Plate Screws No. 94. |
| 406 B | 30 | Welt Guide, adjustable, for welt gauge No. 2603 D. |
| 407 A | 17 | " " Screw; also for No. 409 A. |
| 409 A | 30 | " " Tongue (inner piece) adjustable. |
| | | " " Height Adjustment Screw No. 88. |
| 410 A | 30 | Flexible Guide, for welt gauge No. 2603 D. |
| | | " " Screw Pin No. 402. |
| 413 | 40 | Oil Can, with spout. |
| 413 A | | " " Spout. |
| 416 | 37 | Lifter Lever, complete, treadle operated. |
| 416 A | 37 | " " Extension. |
| | 1 | " " Extension Screws No. 93 A. |
| 416 B | 37 | " " Casting. |
| 420 | 19 | Lifter Lever Stud. |
| 421 | 37 | " " Chain (38 inches long) |
| 422 | 37 | " "Treadle, metal. |
| 423 | 32 | " " Treadle Rest. |
| 424 | 31 | " Treadle Pin. " Treadle Pin Set Serew No. 98 |
| | | Treadle 1 in Set Screw 1vo. 35. |
| 426 | 20 | Spring. |
| 426 A | 15 | Spring I'm. |
| 430 | 13 | Disc Stud, for piping holder using $\frac{1}{2}$ inch to $1\frac{3}{16}$ inch width of strip. |
| 431 A | 22 | " Stud Washer. |
| 432 | 20 | " Tension Spring. |
| 433 | 20 | " Tension Nut. |
| 434 | 20 | " Tension Lock Nut. |
| 478 | 19 | Vibrating Lifter Connecting Rod Ball Joint, for Style 6200 AB. |
| 483 | 19 | Tension Disc Separator Lever Stud. |
| 555 | 32 | Vibrating Lifter Connecting Rod Ball Joint Clamp, for Style |
| | | 6200 AB. " " Rod Ball Joint Clamp Screw No. |
| | 1 | 97. |
| 605 | 17 | Screw, for cloth plate slide supplemental plate on Styles 6400 I |
| | <u> </u> | and 6400 X; also for Nos. 6533, 9720 and 9735. |

| ======================================= | 1 | |
|---|--------------|--|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 605 A | 17 | Screw, for gauge slide plates on Styles 6200 AA and 6200 AB. |
| 721 | 28 | Gauge, for Style 6500 N. " Screws No. 25. |
| 750 | 41 | Rick-Rack Spool Support, complete. |
| 751 | 41 | " " Frame Pin. " " Frame Pin Screw No. 201 C. |
| 752 | 41 | Rick-Rack Spool Axle (13 inches long) |
| 753 | 33 | " " Cone, adjustable. " " Cone Thumb Screw No. 188 D. |
| 900 | 23 | Cloth Plate Slide, right, for Style 6200 K. |
| 901 | 23 | " " right, for Style 6200 M. " " Thumb Screw No. 25 T. |
| 902 | 26 | Feed Rocker, with integral arm, for Styles 6200 K, 6200 M, 6200 X, 6200 AA and 6200 AB. " Set Screws No. 88. |
| 903 | 25 | Feed Bar, under feed, for Styles 6200 K, 6200 M, 6200 AA, 6200 AB. |
| 904 | 25 | " Set Screws No. 88. " upper feed, for Styles 6200 K, 6200 M, 6220 X, 6200 AA and 6200 AB. |
| 905 | 28 | Feed Bar Spring, upper feed for Styles 6200 K, 6200 M and 6200 X. " " Screw No. 303. |
| 906 | 19 | " " " Adjusting Screw. |
| 906 A | 19 | Upper Feed Dog Stop Screw, for Styles 6200 K and 6200 M. |
| 907 | 20 | " " " Lock Nut; also for No. 906. |
| 908 | 32 | Feed Bar Prong and Sponge, for Styles 6200 K, 6200 M, 6200 X 6200 AA and 6200 AB. " " Screws No. 94. |
| 910 | 5 | Feed Dog, under, for closing shoes on machines in Class 6200 using throat plate No. 921 (obsolete, present assembly includes Nos. 2605 A and 2624 A) " Screw No. 93. |
| 911 | 6 | " " upper, for Styles 6200 K and 6200 M. " " Screw, No. 93 A. |
| 912 | 22 | " Holder, upper feed, for Styles 6200 K, 6200 M and 6200 AA. |
| 913 | 22 | " "Holder Screws No. 93 A. Feed Bar Shoe and Feed Bar Spring Shoe, upper feed (hardened and ground) for Styles 6200 K, 6200 M, 6200 X and 6200 AA. " "Shoe Screw No. 94. |
| 917 | 28 | " Spring Shoe Screw No. 25 CC. Feed Eccentric (markedAC) for Styles 6200K 6200M and 6200X. " Spot Screw No. 96. " Set Screw No. 22580. |

| Number to Order by Plate No. The figures in the second column refer only to the plates illust the parts, and are not to be used in ordering. These parts are further at list prices for repairs only. See notice on Page 2. Presser Foot, for Style 6200 K. " " for Style 6200 M. " " Clamp Screw No. 91. Main Shaft Sleeve, left (\frac{3}{8} inch long) for machines with and under feed. Part Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as includes Nos. 2605 A and 2624 A) | |
|---|----------|
| 919 7 " for Style 6200 M. " " Clamp Screw No. 91. 920 16 Main Shaft Sleeve, left (\frac{3}{8} inch long) for machines with and under feed. 921 1 Throat Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as | |
| 920 16 "" Clamp Screw No. 91. Main Shaft Sleeve, left (\(\frac{3}{8}\) inch long) for machines with and under feed. 921 1 Throat Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as | |
| 920 16 Main Shaft Sleeve, left (\frac{3}{8} inch long) for machines with and under feed. 921 1 Throat Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as | |
| 921 1 Throat Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as | |
| 921 1 Throat Plate, for closing shoes on machines in Class 620 feed dog No. 910 (obsolete, present as | upper |
| " " Screws No. 87. | |
| 1000 32 Thread Oiler, complete. | |
| 1002 32 " " Cup. | |
| " " Cup Screw No. 93. | |
| 1003 32 " " Cup Pin. | |
| 1004 32 " " Cup Absorbing Felt. | |
| 1005 32 " " Cup Bracket. | |
| " " Cup Bracket Set Screw No. 95. | |
| 1007 21 " " Tension Plate, complete. | |
| 1008 21 " " Tension Felt, lower. | |
| 1054 16 Looper Eccentric (originally marked V2, throw .152 in | ch) for |
| Styles 6200 Y and 6500 E. | |
| " " Screw No. 96. | |
| 1216 — Needle Lever Connection, complete, with screw cover system (obsolete, present a No. 1216 B) | |
| 1216 B 34 " " complete, with spring valve system (distance between must measure exactly $4\frac{11}{16}$ | centers |
| 1230 34 " " Bearing, upper, for No. 1216 cludes one each Nos. 1230 A 1230 D and 22586 A) | B (in- |
| ‡ 1230 A 34 " " Bearing, upper, for No. 1216 out spring valve. | B, with- |
| " " Bearing Screws No. 22587. | |
| 1230 B 20 " " Bearing Valve Spring. | |
| " " Bearing Valve Spring Scr 22586 A. | ew No |
| 1230 C 34 " " Tube, for No. 1216 B (length | overall |
| " " " Tube Nut, upper, left thre | ad, No. |
| " " Tube Nut, lower, right thr | ead No |
| 1230 D 15 " " " Bearing Valve, for No. 1216 | В. |

[1261—1275 J-002-008]

LIST OF PARTS

| Number to Order by | Plate No. | The ing the furnish | figures i parts, a ed at lis | n the nd a t pric | second column refer only to the plates illustrat- re not to be used in ordering. These parts are see for repairs only. See notice on Page 2. |
|-----------------------|--------------|---------------------------|------------------------------------|-------------------------|--|
| 1261 | 26 | Looper | Rocke | r Fr | ame, for use with detachable cone. |
| - _ | | " | " | | " Set Screw, left, No. 88. |
| | | " | u | | " Set Screw, right, No. 98. |
| | | « | u | | Spot Screw No. 96. |
| 1275 A | 28 | Needle | Lever ! | Stud | , standard size: |
| 1275 E-001 | 1 | « | " | " | standard size, plus .001 inch on Frame |
| 1210 13 001 | | | | | end. |
| 1275 E-002 | 1 _ 1 | ^u | u | u | standard size, plus .002 inch on Frame |
| 1210 17 002 | | | | | end. |
| 1275 E-003 | _ | u | u | u | |
| 12/0 12 000 | | | | | standard size, plus .003 inch on Frame end |
| 1275 E-006 | | u | u | " | |
| 12/0 12-000 | - | | | | standard size, plus .006 inch on Frame |
| 1275 E-012 | | и | u | " | end. |
| 1210 E-012 | - | | • | •• | standard size, plus .012 inch on Frame |
| 1075 TR 010 | İ | ч | " | " | end. |
| 1275 E-018 | - | - | - | ** | standard size, plus .018 inch on Frame |
| 1057 T 001 | | и | ш | и | end. |
| 1275 F-001 | - | • | " | " | standard size, plus .001 inch on Lever |
| | | | | | end. |
| 1275 F-002 | - | u | u | u | standard size, plus .002 inch on Lever |
| | 1 1 | | | | end. |
| 1275 F-003 | - | u | " | ш | standard size, plus .003 inch on Lever |
| | 1 | | | | end. |
| 1275 F-006 | - | и | u | u | standard size, plus .006 inch on Lever |
| | 1 1 | | | | end. |
| 1275 H-001 | - | u | u | u | standard size, plus .001 inch on Both |
| | | | | | ends. |
| 1275 H-002 | 1 - 1 | " | u | u | standard size, plus .002 inch on Both |
| | 1 1 | | | | ends. |
| 1275 H-003 | | " | " | u | standard size, plus .003 inch on Both |
| | 1 1 | | | | ends. |
| 1275 H-006 | | " | u | u | standard size, plus .006 inch on Both |
| | | | | | ends. |
| 1275 J-001-002 | _ | u | u | 4 | standard size, plus .001 inch on Frame |
| | ļ | | | | ends and .002 inch on Lever end. |
| 1275 J-001-003 | _ | u | u | u | standard size, plus .001 inch on Frame |
| | | | | | end and .003 inch on Lever end. |
| 1275 J-001-006 | _ | u | u | u | standard size, plus .001 inch on Frame |
| | | | | | end and .006 inch on Lever end. |
| 1275 J-002-001 | ! _ | u | u | u | standard size, plus .002 inch on Frame |
| | | | | | end and .001 inch on Lever end. |
| 1275 J-002-003 | _ | u | и | u | |
| _=.0 0 00# 000 | [[| | | | standard size, plus .002 inch on Frame |
| 1275 J-002-006 | _ | u | u | u | end and .003 inch on Lever end. |
| 10.00 000 000 | - | | | | standard size, plus .002 inch on Frame |
| | <u> </u> | | | | end and .006 inch on Lever end. |

| Number to Order by | Plate No. | turnish | ed at III | t price | econd column refer only to the plates illustrates not to be used in ordering. These parts are so for repairs only. See notice on Page 2. |
|-----------------------|--------------|---------|-----------|---------|--|
| 1275 J-003-001 | _ | Needle | Lever | Stud, | standard size, plus .003 inch on Frame end and .001 inch on Lever end. |
| 1275 J-003-002 | 1 | u | u | и | standard size, plus .003 inch on Frame end and .002 inch on Lever end. |
| 1275 J-003-006 | | ű | и | и | standard size, plus .003 inch on Frame end and .006 inch on Lever end. |
| 1275 J-006-001 | _ | и | u | u | standard size, plus .006 inch on Frame end and .001 inch on Lever end. |
| 1275 J-006-002 | - | " | u | и | standard size, plus .006 inch on Frame end and .002 inch on Lever end. |
| 1275 J-006-003 | - | u | и | u | standard size, plus .006 inch on Frame end and .003 inch on Lever end. |
| 1275 J-012-001 | _ | u | u | u | standard size, plus .012 inch on Frame end and .001 inch on Lever end. |
| 1275 J-012-002 | _ | u | u | и | standard size, plus .012 inch on Frame end and .002 inch on Lever end. |
| 1275 J-012-003 | _ | и | u | и | standard size, plus .012 inch on Frame end and .003 inch on Lever end. |
| 1275 J-012-006 | - | " | u | u | standard size, plus .012 inch on Frame end and .006 inch on Lever end. |
| 1275 J-018-001 | - | ű | u | и | standard size, plus .018 inch on Frame end and .001 inch on Lever end. |
| 1275 J-018-002 | - | " | u | u | standard size, plus .018 inch on Frame end and .002 inch on Lever end. |
| 1275 J-018-003 | - | " | и | u | standard size, plus .018 inch on Frame end and .003 inch on Lever end. |
| 1275 J-018-006 | _ | " | " | u | standard size, plus .018 inch on Frame end and .006 inch on Lever end. |
| 1275 K-001-002 | - | u | u | u | standard size, plus .001 inch on Level end and .002 inch on Frame end. |
| 1275 K-001-003 | _ | u | ш | u | standard size, plus .001 inch on Lever end and .003 inch on Frame end. |
| 1275 K-001-006 | _ | u | u | | standard size, plus .001 inch on Level end and .006 inch on Frame end. |
| 1275 K-001-012 | - | u u | и | ш | standard size, plus .001 inch on Level end and .012 inch on Frame end. |
| 1275 K-001-018 | - | " | 4 | и | standard size, plus .001 inch on Leve end and .018 inch on Frame end. |
| 1275 K-002-001 | - | " | u | и | standard size, plus .002 inch on Leve end and .001 inch on Frame end. |
| 1275 K-002-003 | - | " | u | u | standard size, plus .002 inch on Leve end and .003 inch on Frame end. |
| 1275 K-002-006 | - | " | u | u | standard size, plus .002 inch on Leve end and .006 inch on Frame end. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 1275 K-002-012 | - | Needle Lever Stud, standard size, plus .002 inch on Lever end and .012 inch on Frame end. |
| 1275 K-002-018 | - | " " " " " " " " " " " " " " " " " " " |
| 1275 K-003-001 | - | " " " " " " " " " " " " " " " " " " " |
| 1275 K-003-002 | - | " " standard size, plus .003 inch on Lever |
| 1275 K-003-006 | – | end and .002 inch on Frame end. " " standard size, plus .003 inch on Lever |
| 1275 K-003-012 | _ | end and .006 inch on Frame end. " " standard size, plus .003 inch on Lever |
| 1275 K-003-018 | - | end and .012 inch on Frame end. "" standard size, plus .003 inch on Lever |
| 1275 K-006-001 | _ | end and .018 inch on Frame end. "" standard size, plus .008 inch on Lever |
| 1275 K-006-002 | - | end and .001 inch on Frame end. "" standard size, plus .006 inch on Lever |
| 1275 K-006-003 | – | end and .002 inch on Frame end. " " standard size, plus .006 inch on Lever |
| 1275 K-006-012 | - | end and .003 inch on Frame end. " " standard size, plus .006 inch on Lever |
| 1275 K-006-018 | _ | end and .012 inch on Frame end. " " standard size, plus .006 inch on Lever |
| 1280 | 20 | end and .018 inch on Frame end. |
| 1286 | 15 | Neddle Lever Ball Clamp Nut; also for No. 15745 B. |
| 1200 | 10 | Needle Bar Link Pin (hardened and ground) complete, internal oiling; also for Nos. 7940 and 8360. |
| | | " " Set Screw, upper, No. 77. |
| | | " " Set Screw, lower, No. 78. |
| 1286 A | 15 | " " without ball spring or screw. |
| 1000 D | | " " Ball No. 12964 C. |
| 1286 B | 20 | Ball Spring. |
| 1287 | 21 | Ban Spring Screw No. 22000. |
| 1288 | 21 | Needle Bar Thread Nipper, complete. """ Collar. |
| 1200 | 21 | " " " Collar Set Screw No. 88. |
| 1346 | 21 | Tension Post without ferrule. |
| 1347 | 15 | " Ferrule ($\frac{5}{16}$ inch long, hardened) |
| 1349 | 20 | Tension Spring (.036 inch diameter wire) for needle thread. |
| 1349 A-3 | 20 | " conical (.028 inch diameter wire) for Style 6500 P. |
| 1361 A | 15 | Pin (length overall 3 inch) for presser spring. |
| 1362 | 12 | " (length overall 1½ inches) for main shaft sleeves: |

| ì | | |
|---------------------------------------|--------------|--|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 1520 J | 10 | |
| 1520 J-1 ¹ / ₈ | _ | Presser Foot, complete, rolling (diameter 1 ¹ / ₈ inches, width ³ / ₁₆ inch) for Styles 6200 C and 6200 F. |
| 1520 J-1 ⁵ / ₁₆ | _ | " complete, rolling (diameter $1\frac{5}{16}$ inch, width $\frac{3}{16}$ |
| 1520 K−1¾ | 10 | inch) for Style 6200 C and 6200 F. " complete, rolling (diameter $1\frac{3}{4}$ inches, width $\frac{1}{4}$ inch) for Styles 6200 C and 6200 F. |
| 1524 C | 2 | Throat Plate, for Styles 6200 C and 6200 AA. "Screws No. 87. |
| 1586 A | 10 | Roller Lever, for presser feet Nos. 1520 J- $1\frac{1}{8}$ and 1520 J- $1\frac{5}{16}$. |
| 1586 B | 10 | " for presser foot No. 1520 K- $1\frac{3}{4}$. |
| 1000 | | " " Serew No. 91. |
| 1588 A | 9 | " " Spring. |
| | | " " Spring Screw No. 22564. |
| 1592 | 9 | Roller Lever Support. |
| | | " " Screws No. 93. |
| 1593 B | 10 | Presser Bar Connection, for presser feet Nos. 1520 J-18, |
| | | 1520 J-1 $\frac{5}{16}$ and 1520 K-1 $\frac{3}{4}$. |
| | | " " Screws No. 88 A. |
| 1594 | 15 | Roller Lever Hinge Pin. |
| 1724 F | 1 | Throat Plate, for closing all canvas and leather palm canvas |
| | | gloves on machines in Class 6200. |
| - | | " " Screws No. 87. |
| 1741 B | 8 | Knife, for presser feet Nos. 6227 F, 6627 A and 6627 D. |
| - | | "Screw No. 187 A See illustration on Plate No. 17. |
| 2396 | 31 | Bell Crank Connecting Rod, for Style 6200 AD. |
| | | " " " Nut, right thread, No. 18. |
| | | " " Nut, left thread, No. 269. |
| 2505 | 5 | Feed Dog, coarse teeth, ten to the inch, for use with throat plate No. 2524 B. |
| 2505 A | 5 | " coarse teeth, ten to the inch, for use with throat plates Nos. 1724 F and 6224 B. |
| 2505 B | 5 | " under, for Styles 6200 C, 6200 F and 6200 AA. |
| ļ | | " Screw No. 93. |
| ļ | | " Supporting Screw No. 97. |
| 2524 B | 2 | Throat Plate, for Style 6200 F. " " Screws No. 87. |
| 2527 | 7 | Presser Foot, for Style 6200 W. " Clamp Screw No. 91. |
| 2538 | 16 | Thread Controller Rack Supporting Collar. " " Supporting Collar Set Screw No. 88. |
| 2603 D | 30 | Welt Gauge, complete, adjustable, for Style 6200 M. "Screws No. 25 CC. |
| 2605 A | 5 | Feed Dog, under, for Styles 6200 E, 6200 K and 6200 M. "Screw No. 93. |

REFER TO PINK INSERT FOR PRICES

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. | | | |
|-----------------------|--------------|--|--|--|--|
| 2624 A | 2 | Throat Plate, for Styles 6200 E, 6200 K and 6200 M. "Screws No. 87. | | | |
| 2650 | 32 | Lifter Connection, for raising upper feed dog on Styles 6200 K, 6200 M and 6200 X. " Set Screw No. 98. | | | |
| 4937 | 18 | Knee Lifter Chain Lever Stud, for Style 6500 N. | | | |
| 4949 | 15 | Bell Crank Stud, for Style 6200 AB. | | | |
| 5125 | 11 | Feed Bar Needle Guard (hardened, marked AJ) for Style 6200 X. " " Screw No. 94. | | | |
| 5142 | 25 | Feed Bar, for Style 6600 B. " " Set Screws No. 88. | | | |
| 5143 | 26 | Differential Feed Bar, for Style 6500 N. | | | |
| 5150 | 22 | Main Feed Dog Holder, for Style 6500 N. | | | |
| | İ | " " " Screw No. 93. | | | |
| | | " " " Supporting Screw No. 97. | | | |
| 5157 | 25 | Feed Rocker Arm, for Style 6500 N. | | | |
| 5824 C | 2 | " " Screws No. 22548. Throat Plate, for Style 6200 X. | | | |
| | } | " " Screws No. 87. | | | |
| 6001 | 41 | Cloth Plate, for machines in Class 6000; also for Styles 6400 I, 6400 M, 6400 U, 6400 W and 6400 X. | | | |
| | 1 | " " Screws, cone head No. 80. | | | |
| | | " Screw, fillister head No. 93 A. | | | |
| 6013 | 29 | Looper Rocker, for machines in Class 6000; also for Styles 6400 I, 6400 M, 6400 U, 6400 W, 6400 X, 6500 B, 6500 C, 6500 E, 6500 H, 6500 N and 6600 B. | | | |
| 6035 A | 38 | Cloth Plate Guard, with cushion, for machines in Classes 6000, | | | |
| 0000 A | 00 | 6200 and 6400; also for Styles 6500 B, 6500 C, 6500 E, 6500 H, 6500 P and 6600 B. | | | |
| | } | " " Screws No. 22730. | | | |
| 6035 B | 15 | " " Cushion, felt. | | | |
| | 1 | " " Cushion Screw No. 187 A. | | | |
| 6037 | 31 | Looper Connecting Rod, diameter of threaded ends, $\frac{7}{32}$ inch. | | | |
| | | Nut, right thread, No. 18. | | | |
| ± 6038 | 13 | Nut, left thread, No. 269. | | | |
| + 0099 | 19 | using connecting red No. 6037 and | | | |
| ‡ 6038 B | 13 | looper rockers Nos. 181 or 213. "Ball Joint, left, complete, for machines using connecting rod No. 6037 and | | | |
| ‡ 6039 | 13 | looper rocker No. 6013. "Ball Joint, right, complete, for machines using connecting rod No. 6037. | | | |
| | | " " Ball Joint Screws No. 97 A. | | | |
| | 1 | " " Ball Stud Nut No. 18. | | | |

‡See Page 11

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts-are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 6042 | 19 | Needle Lever Ball Clamp Bolt. |
| 6201 L | 41 | Cloth Plate, for Styles 6200 K, 6200 M, 6200 X, 6200 AA and |
| | | 6200 AB. |
| | | " Screws, cone head, No. 80. |
| | | " "Screw, fillister head, No. 93 A. |
| 6202 X | 23 | " Slide, right, for Style 6200 X. |
| 6202 AB | 23 | Silde, right, for Styles 0200 AA and 0200 AB. |
| 0000 T | | Side Thumb Screw No. 25 1. |
| 6203 X | 24 | Gauge, for Style 6200 X. |
| 6205 X | 6 | " Screws No. 25 C. |
| 0205 A | 6 | Feed Dog, upper, for Style 6200 X. " " Screw No. 93 A. |
| | | " " Adjusting Screw No. 88. |
| 6205 Y | 6 | " " under, for Style 6200 X. |
| 0200 1 | Ů | " " Screw No. 93 A. |
| | | " " Supporting Screw No. 97. |
| 6205 AA | 6 | " upper, for Styles 6200 AA and 6200 AB. |
| 6205 AB | 6 | " upper, knurled feeding surface, for Style 6200 AB. |
| | | " " Screw No. 22528. |
| 6206 | 28 | Feed Eccentric (originally marked DA) for Style 6200 AA. |
| 6206 A | 28 | " and Cam (hardened and ground, originally |
| | | marked DD) for Style 6200 AB. |
| | | " Spot Screw No. 96. |
| | _ | " Set Screw No. 98. |
| 6207 B | 4 | Looper, with guard, for machines in Class 6400; also for Styles |
| | | 6200 B, 6200 C, 6200 D, 6200 Q, 6200 W, 6200 X, |
| 2000 D | | 6200 Y and 6500 E. |
| 6208 B | 4 | " without guard, otherwise same as No. 6207 B. " Set Screw No. 73. |
| 6215 | 38 | Needle Lever, for Style 6200 E, 6200 F, 6200 K, 6200 M, 6200 W, |
| 0-10 | • | 6200 X, 6200 Y, 6200 AA and 6200 AB. |
| 6220-11 | 9 | Presser Foot, complete, rolling (diameter $1\frac{1}{4}$ inches, width $\frac{3}{16}$ |
| . | _ | inch) for closing all canvas and leather palm |
| | | canvas gloves on machines in Class 6200. |
| | | " " Screw No. 72. |
| | | " " Screw No. 22560 B. |
| | | " Screws No. 88. |
| | | " Roller Arm No. 6281. |
| 4000 | | " Roller Arm Support No. 6282. |
| 6220 X | 11 | " complete, for Style 0200 A. |
| | | Clamp Bolow 110. 01. |
| | | " Guide Screws No. 187 A." Hinge Screw No. 22786. |
| | | " Shank, including pin and screw No. 6220 XA. |
| | | Mann, moraning pill and solon 110, 0420 227. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 6220 AA | 8 | Presser Foot, for Style 6200 AA. |
| 6220 AB | 8 | " " for Style 6200 AB. |
| | | " " Clamp Screw No. 91. |
| 6220 XA | - | " Shank, including pin and screw, for No. 6220 X. |
| 6224 B | 2 | Throat Plate, for Style 6200 B. |
| 6224 W | 2 | " " for Style 6200 W. |
| 6224 AB | 2 | " for Style 6200 AB. |
| | 1 | " " Screws No. 87. |
| 6227 B | 8 | Presser Foot, for Style 6200 Q. |
| | | " " Clamp Screw No. 91. |
| 6227 C | 7 | " with yielding spring guide, distance from center of needle hole to guide $\frac{5}{64}$ inch, for stitching eyelet stays to shoe linings on machines in Class 6200. |
| 6227 D | 11 | " with adjustable guide \$\frac{3}{8}\$ inch to 1 inch for stitching continuous top bands to shoe linings on machines in Class 6200 without upper feed. |
| 6227 F | 7 | " Complete, with thread cutter for closing all canvas |
| 0221 F | | and leather palm canvas gloves on machines in Class 6200. |
| | İ | " " Clamp Screw No. 91. |
| | | " " Knife No. 1741 B. |
| | | " Knife Screw No. 187 A See illustrations on plate |
| | | " "Knife Screw No. 91 A \ No. 17 |
| 6227 FA | - | " Bottom, including pins, for No. 6227 F. |
| 6235 | 8 | " Yielding Guide, for No. 6227 C. |
| | | " Yielding Guide Screw No. 91 A. |
| 6236 | 12 | Needle Thread Pull-Off and Take-Up Wire (3 inch wide) |
| | | " " Pull-Off Screw No. 87 U. |
| 6242 | 22 | Feed Dog Holder, upper feed, for Style 6200 X. |
| 2010 1 | | " " Screws No. 93 A. |
| 6242 A | 25 | Feed Bar, under feed, for Style 6200 X. |
| 6040 D | | " Set Screws No. 88. |
| 6242 B | 22 | Feed Dog Holder, upper feed, for Style 6200 AB. |
| 0049 | ۰ | Screws No. 95 A. |
| 6243 | 28 | Feed Bar Spring, upper feed, for Styles 6200 AA and 6200 AB. |
| | | Screw Ivo. 505. |
| | | " " Adjusting Screw No. 906. " " Adjusting Screw Lock Nut No. 907. |
| 6245 | 14 | Bell Crank, for Style 6200 AB. |
| 6246 | 16 | " " Stud Collar. |
| | - | " Stud Collar Set Screws No. 88. |
| 6247 | 29 | Lifter Connection, for raising upper feed dog on Style 6200 AB. "Set Screw No. 98. |
| 6248 | 14 | Vibrating Lifter, for Style 6200 AB. |
| 6248 A | 15 | " Buffer, wood fibre. |
| | , 10 | Dallot, Wood libits. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 6250 | 38 | Needle Lever Extension, for Style 6200 AB. |
| | | " " Screws No. 22576. |
| 6251 | 13 | Bell Crank Connecting Rod Ball Joint, right thread. |
| 6252 | 13 | " " " Ball Joint, left thread. |
| | | " " " Ball Joint Screws No. 97 A. |
| | | " " " Ball Joint Stud Nut No. 18. |
| 6280 | 9 | Roller (diameter $1\frac{1}{4}$ inches, width $\frac{3}{16}$ inch) for presser foot No. $6220-1\frac{1}{4}$. |
| 6281 | - | " Arm, adjustable. |
| | | " Arm Screw No. 22528. |
| 6282 | 9 | " Arm Support. |
| | | " Arm Support Screw No. 72. |
| | Ì | " Arm Support Screw No. 22560 B. |
| | | " Arm Support Screws No. 88. |
| 6402 F | 23 | Cloth Plate Slide, right, for Style 6400 M. |
| 6402 M | 23 | " " right, for Style 6400 I. |
| | | " " " Thumb Screw No. 25 T. |
| 6402 N | 23 | " " right, for Style 6400 X. |
| | | " " Stop Screw No. 150. |
| 6402 P | 24 | " " Supplemental Plate, right, for Style 6400 X. |
| | | " " Supplemental Plate Screws No. 605. |
| 6405 D | 6 | Feed Dog, for Style 6400 W. |
| | | " " Screw No. 93. |
| | | " " Supporting Screw No. 97. |
| 6420 L | 7 | Presser Foot, for Styles 6400 M and 6400 W. |
| 6420 P | 7 | " " for Style 6500 H. |
| 6420 U | 8 | " for Style 6400 U. |
| | İ | " " Clamp Screw No. 91. |
| 6424 D | 3 | Throat Plate, for Style 6400 W. |
| 6424 E | 3 | " for Styles 6400 M and 6400 U |
| | | " Screws No. 87. |
| 6426 | 5 | Feed Dog, for Style 6500 H. |
| 6426 A | 5 | " " for Styles 6200 Y, 6400 M and 6400 U. |
| 6426 B | 5 | " " for binding miscellaneous work on machines in Class |
| | | 6400 using throat plate No. 6428 F. |
| | | Screw No. 95. |
| | | Supporting Screw No. 37. |
| 6427 B | 7 | Presser Foot, for Styles 6200 Y and 6500 E. |
| 6427 H | 11 | " with piping folder, $\frac{13}{16}$ inch strip, for piping dresses |
| | | on machines in Class 6400 using feed dog No |
| | | 9705 and throat plate No. 9724 B. |
| | | " Swinging Folder Support No. 23371 A. |
| | | " " Swinging Folder Support Stud No. 22726. |
| | | Swinging Folder Support Stud Spring washer No |
| | 1 | 12957 E. |

| | Ī | |
|-----------------------|--------------|--|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| | | Presser Foot, Piping Guide No. 23373. |
| | 1 | " " Piping Guide Screws No. 87 U. |
| | | " Piping Guide Adjusting Plate No. 23373 A. |
| 6427 J | 7 | " for Styles 6400 I and 6400 X. |
| ·· | | " Clamp Screw No. 91. |
| 6428 A | 3 | Throat Plate, for Style 6500 H. |
| 6428 E | 2 | " " for Style 6200 Y. |
| 6428 F | 3 | " raised $\frac{9}{64}$ inch, for binding miscellaneous work on |
| | | machines in Class 6400 using feed dog No. 6426 B. |
| | | " " Screws No. 87. |
| 644 0 | 30 | Slide Stop Plate, for Styles 6400 I and 6400 M. |
| | 1 | " " Screws No. 88 A. |
| 6501 P | 41 | Cloth Plate, for Style 6500 P. |
| | | " Screws, cone head, No. 80. |
| | | " Screw, fillister head, No. 93 A. |
| .6502 P | 23 | Cloth Plate Slide, right. |
| | | " " Thumb Screw No. 25 T. |
| 6503 R | 24 | Gauge, complete, for Style 6500 P. |
| | 1 | " Screws No. 25 S. |
| | | " Screw Washers No. 9255. |
| 6503 S | - | " Edge Guide. |
| | | " Edge Guide Thumb Screw No. 22756. |
| | 1 | " Swinging Arm No. 6540. |
| | l | " Base No. 6541. |
| 6505 B | 6 | Feed Dog, coarse teeth, cut ten to the inch, for auto top work on |
| | | machines in Class 6500 using throat plate No. 195. |
| 6505 E | 6 | " (width overall $\frac{5}{16}$ inch) for Style 6500 B. |
| | | " " Screw No. 93. |
| | | " " Supporting Screw No. 97. |
| 6505 P | 6 | " " for Style 6500 P. |
| | ļ | " " Screw No. T 22. |
| | | " " Screw Nut No. 16179. |
| 6520 | 7 | Presser Foot, for Style 6500 B. |
| 6520 A | 7 | " for Style 6500 C. |
| 6520 B | 7 | " (width overall 3 inch) for Style 6500 B. |
| 6520 C | 7 | " (width overall $\frac{1}{2}$ inch) with lip on right hand side, |
| 0500 - | _ | for Style 6500 C. " (width orient) 3 in al.) for State 6500 Fi |
| 6520 E | 7 | (width overall g inch) for Style 6500 E. |
| 6520 N | 8 | for Style 0500 IV. |
| 6590 D | | Clamp Screw No. 91. |
| 6520 P | 8 | for Style 6500 P. |
| 6522 B | 977 | Set Screws No. 22570. |
| 0024 B | 37 | Main Shaft (hardened and ground) standard size .530 inch, for |
| | <u> </u> | Style 6500 P. |

REFER TO PINK INSERT FOR PRICES

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 6524 N | 2 | Throat Plate, for Style 6500 N. |
| 6524 P | 3 | " " for Style 6500 P. |
| | | " " Screws No. 87. |
| 6527 B | 7 | Presser Foot (width overall 3 inch) plain front, for Style 6500 C. |
| | | " " Clamp Screw No. 91. |
| 6533 | 8 | Spring, for presser foot No. 6520 P. |
| | 1 | " Screw No. 605. |
| 6540 | — | Gauge Swinging Arm, for Style 6500 P. |
| | | " " " Stud No. 22726. |
| | | " " Stud Spring Washer No. 12957 E. |
| 6541 | l — | Gauge Base. |
| | | " " Screws No. 25 S. |
| | ļ | " Screw Washer No. 9255. |
| 6544 B | 31 | Looper Rock Shaft, $(4\frac{15}{16}$ inches long, hardened and ground) for Style 6500 P. |
| 6544 D | 25 | " " Frame, including bushings. |
| | | " " Frame Screws No. 318. |
| 6545 | 25 | Feed Rocker Arm, for Style 6500 P. |
| | | " " Screws No. 22548. |
| 6546 | 28 | Feed Rocker Eccentric (originally marked DY) |
| | | " " Screws No. 22588. |
| ‡ 6547 | 34 | Feed Rocker Eccentric Connection. |
| | | " " Connection Screws, upper, No. 97 A. |
| | | " " Connection Screws, lower, No. 22755. |
| 6548 | 6 | Feed Dog Holder, for Style 6500 P. |
| | 1 | Screw 140. 93. |
| | 1 | Supporting Screws No. 91. |
| 6606 | 16 | Feed Lift Cam (hardened and ground, originally marked AF) for Styles 6500 P and 6600 B. |
| | | " " Screw No. 96. |
| 6624 | 2 | Throat Plate, $(\frac{11}{64}$ inch thick) short needle hole, for miscellaneous |
| | 1 | auto top work on machines in Class 6600 using |
| | İ | feed dog No. 197 X. |
| 6624 A | - | " " $(\frac{5}{32}$ inch thick) long needle hole, otherwise same |
| | | as No. 6624. |
| | | " Screws No. 87. |
| 6625 | 11 | " Needle Guard (hardened, marked AH) for Style |
| | 1 | 6500 H. |
| | | " Needle Guard Screw No. 87. |
| 6625 A | 11 | Feed Bar Needle Guard (hardened, marked BS) for Style 6600 B " " " Screw No. 94. |
| 6627 A | 8 | Presser Foot, complete $(\frac{5}{16}$ inch wide to right of needle) with |
| | | thread cutter, for under sewing leather auto |
| • | | cushions on machines in Class 6600 using feed |
| | 1 | dog No. 197 X and throat plate No. 6624. |

81

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| | 1 | Presser Foot, Knife No. 1741 B. |
| | 1 | " " Knife Serent No. 107 A) Garathand |
| | | " Knife Screw No. 187 A See illustrations on plate " Knife Screw No. 91A No. 17 |
| 6627 C | 8 | |
| 332. 0 | | " complete, with three rollers in bottom, for seaming auto decks to sides on machines in Class 6600 using feed dog No. 197 X and throat plate No. 195 X. |
| 6627 D | 8 | " complete (3/32 inch wide to right of needle) with thread cutter, for undersewing plush auto cushions on machines in Class 6600 using feed dog No. 197 X and throat plate No. 6624. " Set Screws No. 88. |
| | | " Hinge Screw No. 86 X. |
| | | " Knife No. 1741 B. |
| | 1 | " Knife Screw No. 187 A) See illustrations on plate |
| | ľ | " Knife Screw No. 91A No. 17 |
| 6627 E | 7 | " for cording upholstery work on machines in Class |
| | ļ. | 6600 using feed dog No. 6405 D and throat plate |
| | l | No. 6424 D. |
| | ļ | " " Clamp Screw No. 91. |
| 6645 | 15 | Roller, for presser foot No. 6627 C. |
| 7521 | 34 | Eccentric Pulley, (originally marked AV, throw .588 inch) for |
| | | Styles 6500 B, 6500 C, 6500 H and 6500 N. |
| 7638 A | | " "Set Screws No. 22597. |
| 7036 A | 28 | Looper Thread Deflecting Wire. |
| 7801 | 41 | wire Screw No. 93. |
| .001 | 1 11 | Cloth Plate, for Style 6600 B. |
| | | " " Screws, cone head, No. 80. " " Screw, fillister head, No. 93 A. |
| 7822 | 36 | Main Shaft (hardened and ground) standard size .530, for Style |
| _ | | 6600 B: |
| 7822-531 | _ | " standard size, plus .001 inch. |
| 7822-533 | _ | " standard size, plus .003 inch. |
| 7822-536 | | " standard size, plus .006 inch. |
| 7822-539 | _ | " standard size, plus .009 inch. |
| 7822-542 | | " standard size, plus .012 inch. |
| 7940 | 21 | Vibrating Lifter Link, for Style 6200 AB. |
| | | " Link Pin No. 1286. |
| | | " Link Pin Set Screw No. 22733. |
| 8301 M | 41 | Cloth Plate, for Style 6500 N. |
| | } | " Screws, cone head, No. 80. |
| 8355 A | | Screws, fillster head, No. 93 A. |
| | _ | Feed Rocker, with arm, for Style 6500 N (includes one each Nos. 5157 and 8356 A and two No. 22548) |
| 8356 A | 25 | " without arm. |
| | | " Set Screws No. 88. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustratin the parts, and are not to be used in ordering. These parts are furnishe at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 8360 | 14 | Differential Feed Bar Link, for Style 6500 N. " " " Pin Set Screw No. 22733. |
| 8361 | 15 | " " " Pin back. |
| 3001 | 10 | " " " Set Screw No. 88. |
| 8362 A | 14 | Differential Feed Controlling Shaft Arm, left, for Style 6500 N. " Controlling Shaft Arm Screw No. 88. |
| 8362 B | 14 | " " Controlling Shaft Arm Link. |
| | } | " Controlling Shaft Arm Link Stud No. 86. |
| 8362 C | 14 | " Controlling Lever, left. |
| 8362 D | 15 | " " Controlling Lever Pin. |
| | | " Controlling Lever Pin Set Screw No. 88. |
| 8363 | 14 | " " Controlling Lever Link. |
| | | " " Controlling Lever Link Stud No. 86. |
| | | " Controlling Lever Link Screw No. 88. |
| 8365 A | 30 | " Controlling Shaft (10½ inches long) |
| 8366 A | 14 | " " Controlling Shaft Support, left. |
| 8367 A | 14 | " " Controlling Shaft Support, right. |
| 0001 11 | ** | " Controlling Shaft Support Screws No. 93. |
| 8368 A | 20 | " Controlling Shaft Spring. |
| 8368 B | 14 | " " Controlling Shaft Spring Adjusting Arm. |
| O000 D | 14 | " " Controlling Shaft Spring Adjusting Arm Clam Screw No. 93. |
| 8369 A | 14 | Knee Lifter Chain Lever, for Style 6500 N. " " Stud No. 4937. |
| 0970 4 | 1 14 | i . |
| 8370 A | 14 | Differential Feed Indicator, for Style 6500 N. "Indicator Clamp Screw No. 93. |
| 8371 A | 14 | " " Index. |
| 00/1 A | 1.4 | " " Index. Screws No. 98 A. |
| 8372 | 21 | " " Indicator Stop. |
| 0012 | 21 | " Indicator Stop Screw No. 25 CC. |
| 0270 4 | 1 | Indicator Stop Screw 140, 25 CC. |
| 8372 A | 15 | Indicator Stop Screw Washer. |
| 8373 | 38 | Cloth Plate Guard, for Style 6500 N. " " Screws No. 22730. |
| 0074 | -00 | 1 |
| 8374 | 29 | Feed Rocker Segment Cover, for Style 6500 N. |
| 0051 | 10 | Cover Screws Ivo. of C. |
| 8651 | 12 | Needle Thread Take-Up Wire, for Style-6500 P. " " Screw No. 87 U. |
| 9205 E | 6 | Feed Dog, for Styles 6500 B and 6500 C. " " Screw No. 93. |
| | | " " Supporting Screw No. 97. |
| 9224 E | 3 | Throat Plate, for Styles 6500 B and 6500 C. |
| - | _ | " " Screws No. 87. |
| 9255 | 16 | Gauge Screw Washer, for Style 6500 P. |
| | | |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 9508 E | 4 | Looper, without guard, otherwise same as 9507 E. "Set Screw No. 73. |
| 9602 | 23 | Cloth Plate Slide. right, for Styles 6400 N and 6500 E. " " Stop Screw No. 150. |
| 9634 | 8 | Yielding Bottom Spring, for presser foot No. 9720. " " Stud No. 57 WD. |
| 9634 A | 18 | " " Pin, for presser foot No. 9720. |
| 9705 | 5 | Feed Dog, for Styles 6400 N and 6500 E " Screw No. 93. " Supporting Screw No. 97. |
| 9720 | 7 | Presser Foot, complete, for Style 6400 N. |
| | | " " Bottom No. 9733. " " Clamp Screw No. 91. |
| 9724 | 3 | Throat Plate, for Style 6400 N. |
| 9724 B | 3 | " " for Style 6500 E. |
| | | " Screws No. 87. |
| 9725 | 11 | 6400 I, 6400 M, 6400 N, 6400 U, 6400 X at 6500 E. |
| | | " " Needle Guard Screw No. 87. |
| 9733 | - | Yielding Bottom, with two pins, for presser foot No. 9720. |
| 9735 | 11 | Projection, for presser foot No. 9720. "Screws No. 605. |
| 9921 | 34 | Eccentric Pulley (originally marked BL, throw .529 inch) for Style 6500 P. |
| 10356 | 31 | Det Berews No. 22097. |
| 10300 | 31 | Vibrating Lifter Connecting Rod, for Style 6200 AB. " " Rod Nut, left thread, No. 37 L. " " Bod Nut, with the last of the style of th |
| 11721 | 34 | " " Rod Nut, right thread, No. 37 R. Eccentric Pulley (originally marked AU, throw .588 inch) for Style 6600 B. |
| 11000 | | " Set Screws No. 22597. |
| 11755 | 13 | Hand Lifter, for Styles 6400 N and 6500 E. "Stud No. 86. |
| 12534 | 12 | Needle Bar Thread Eyelet, for Styles 6200 AA, 6200 AB an 6500 P. |
| 10590 | 00 | Sciew 140. 22708. |
| 12538 12835 | 20 | Feed Rocker Arm Ball Stud Nut, for Styles 6500 P. |
| | | Feed Bar Shoe, upper feed, for Style 6200 AB. " " Screw No. 94. |
| 12865 | 16 | Vibrating Lifter Thrust Collar, for Style 6200 AB. " " " Set Screws No. 88. |
| 12873 | 16 | Bushing (35 inches long) for needle bar bearings. |
| 12957 E | 16 | Gauge Swinging Arm Stud Spring Washer, for Style 6500 P; als for Nos. 6427 H and 23371 A. |

REFER TO PINK INSERT FOR PRICES

| Numb to Order | | The figure parts, and list prices i | res in t are no for reps | he secor ot to be airs only | nd column refer only to the plates illustrating the used in ordering. These parts are furnished at . See notice on Page 2. | | | |
|------------------|--------|---|--------------------------------|-----------------------------------|--|--|--|--|
| 12964 | C 15 | Needle Ba | Needle Bar Link Pin Ball. | | | | | |
| 12987 | 1 | | | | djusting Nut. | | | |
| 12993 | - | Stop Screv | v. for l | knee lif | ter interlocking lever; also for No. 21693 K. | | | |
| 12000 | - | u u | | | No. 34. | | | |
| 14544 | 31 | Main Feed Bar Shaft ($3\frac{9}{16}$ inches long, hardened and ground) for Style 6500 N. | | | | | | |
| 15205 | 6 | " Feed | Dog, | for St | yle 6500 N. | | | |
| | | u u | | | No. 22593. | | | |
| 15226 | в 6 | Differentia | l Feed | l Dog, | for Style 6500 N. | | | |
| 10110 | - * | и | u | | Screw No. 22585. | | | |
| 15430 | C 20 | Needle Le | ver Co | | on Tube Nut, upper, left thread. | | | |
| 15430 | | u | u | u | Tube Nut, lower, right thread; also for | | | |
| 10100 | _ _~ | | | | No. 21693 J. | | | |
| ‡ 15430 3 | E 34 | u | u | a | Bearing, upper, for No. 1216 (obsolete, present assembly includes Nos. 1230 and 1230 C) | | | |
| | 1 | u . | u | u | Bearing Screws No. 22587. | | | |
| 15430 | F 34 | u u | u | u | Tube, for No. 1216 (obsolete, present assembly includes Nos. 1230 and 1230 C) | | | |
| 15430 | Н 20 | u | и | | Oil Reservoir Cover, for No. 1216 (obsolete, present assembly includes Nos. 1230 and 1230 C) | | | |
| 15430 | K 15 | u | u | u | Oil Reservoir Leather Washer. | | | |
| 15430 | 1 | u | и | u | Felt. | | | |
| ‡ 15430 | | u | u | u | Bearing, lower. | | | |
| + 10300 | M 34 | u | u | u | Bearing Screws No. 22587. | | | |
| 15447 | E 25 | Main Feed | l Bar, | | yle 6500 N. rews No. 88. | | | |
| 15447 | F 22 | u u | u | Shoe. | | | | |
| 10111 | · 22 | u u | u | | Screw No. 93. | | | |
| 15447 | G 32 | u " | u | | and Sponge. | | | |
| 10711 | G 32 | u " | u | | Screws No. 94. | | | |
| 15447 | H 29 | Differentie | ıl Fee | | Guide, non-adjustable. | | | |
| 10441 | 11 25 | Differentia | # FCC | " C | Guide Screw, front, No. 93. | | | |
| | | u | u | | Guide Screw, back, No. 93 A. | | | |
| 15447 | J 22 | u | и | | Guide, complete, adjustable (includes one | | | |
| 15447 | J 22 | | | ` | each Nos. 15447 K and 15447 L and two No. 90) | | | |
| 15447 | K 22 | u | u | " (| Guiding Plate Holder. | | | |
| 1044/ | A 22 | u | и | | Guiding Plate Holder Screw, front, No. 93. | | | |
| | | " | u | | Guiding Plate Holder Screw, back, No. 93 A. | | | |
| | j. | | | | | | | |
| 15447 | L 22 | " | u | " (| Guiding Plate, adjustable. | | | |

‡See Page 11

[15465 F—16187 A] LIST OF PARTS

| | | · · · · · · · · · · · · · · · · · · · |
|-----------------------|--------------|--|
| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
| 15465 F | 16 | Looper Rocker Cone (hardened and ground) front, adjustable, |
| | | for machines using frame No. 1261. |
| | | " " Set Screws No. 88. |
| | 1 | " " Adjusting Nut No. 12987 A. |
| 15478 B | 11 | Feed Rocker Eccentric Flange, left, for Style 6500 P. |
| | | " " " Screws No. 22589. |
| 15480 C | 8 | Spring, for presser foot No. 6520 N. |
| | 1 | " Stud No. 57 WD. |
| 15483 | 26 | Feed Rocker, without arm, for Style 6500 P. |
| 4 2 4 4 5 1 | 1 | " Set Screws No. 88. |
| 15487 | 19 | Arm Bail Stud. |
| 15400 | 1 | Arm Dan Stud Nut No. 12008. |
| 15488 | 16 | Arm Ball Stud Wasner. |
| 15686 15686 A | 28 28 | Feed Rocker Eccentric Flange, left, with holder, for Style 6500 P. |
| 10000 A | 40 | riange moider. |
| | 1 | " " Flange Holder Set Screw No. 95. " " Flange Holder Spot Screw No. 81. |
| 15745 B | 19 | Looper Rocker Stud (hardened and ground) for machines using |
| 10.10 2 | " | frame No. 1261. |
| | 1 | " " Nut No. 1280. |
| 15905 A | 6 | Feed Dog, coarse teeth, cut ten to inch, for Style 6500 B. |
| 15905 D | 5 | " " for Styles 6400 I and 6400 X. |
| | | " " Screw No. 93. |
| | | " " Supporting Screw No. 97. |
| 15924 D | 3 | Throat Plate for Styles 6400 I and 6400 X. |
| | | " " Screws No. 87. |
| 15930 | 23 | Cloth Plate Slide, left, for Styles 6400 I and 6400 X. |
| 15930 A | 24 | " " Supplemental Plate. |
| 10100 7 | ١., | " " Supplemental Plate Screws No. 605. |
| 16108 J | 4 | Looper for Style 6500 P. |
| 10115 | 20 | " Set Screw No. 73. |
| 16115 16170 | 38 26 | Needle Lever, for Style 6500 P. |
| 10170 | 20 | Feed Bar, for Style 6500 P. " Set Screws No. 88. |
| 16171 | 32 | " Prong and Sponge. |
| 101/1 | 02 | " Prong Screws No. 94. |
| 16172 | [| " Prong Sponge. |
| 16173 | 22 | " Shoe (hardened and ground) |
| | | " " Shoe Screw No. 94. |
| 16179 | 6 | Feed Dog Screw Nut, for Style 6500 P. |
| 16186 D | 14 | Looper Holder and Needle Guard, for Style 6500 P. |
| | | " " " Guard Screw, cone head, No. 87. |
| | | " " " Guard Screw, fillister head No. 97. |
| 16187 A | 16 | Looper Rock Shaft Collar, for Style 6500 P. |
| | 1 | " " Collar Set Screws No. 88. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 16188 | 33 | Looper Rock Shaft Arm. |
| 10100 | 00 | " " Arm Clamp Screws No. 97. |
| 16189 | 33 | " " Crank Link. |
| 10100 | " | " " Crank Link Adjusting Screw No. 79. |
| | | " " Crank Link Pin Clamp Screw No. 97. |
| 16190 | 19 | " " Crank Stud. |
| 16195 C | 16 | " " Frame Bushing. |
| 16602 | 23 | Cloth Plate Slide, right, for closing all canvas and leather palm |
| | | canvas gloves on machines in Class 6200, |
| | | without upper feed. |
| | | " " Thumb Screw No. 25 T. |
| 16603 B | 24 | Gauge, complete, for Styles 6200 AA and 6200 AB. |
| | | " Screws No. 25 CC. |
| 16675 | _ | " Roller, for Styles 6200 AA and 6200 AB. |
| 16676 | - | " Roller Stud. |
| 16676 A | _ | " Slide. |
| | | " Slide Plate Screw No. 25 CC. |
| | | " Slide Plate Screw No. 90. |
| | | " Slide Plate Screws No. 605 A. |
| 16676 B | _ | Gauge Slide Assembly, Nos. 16675, 16676 and 16676 A. |
| 16677 | - | " Lever. |
| | | " Lever Stud No. 134. |
| 16677 A | _ | " Spring. |
| 21102 D | 40 | Thread Stand Base; also for No. 21173 C. |
| 21113 A | 31 | Spool Stand Thread Wire Extension (6 inches long) |
| | | " " Extension Set Screw No. 95. |
| 21113 B | 16 | Coupling. |
| | | Coupling Screws No. 85. |
| 21126 | 40 | Auxilliary Piping Holder Support Horizontal Rod. |
| | | Support Horizontal Rod Set Screws |
| 01120 1 | 4, | No. 96. |
| 21130-1 | 41 | Spool Support, with pin, for one spool thread stand. "Set Screw No. 22508. |
| | | " " Pin No. 21133. |
| 21130 A-2 | 41 | " " for two-spool Style C thread stand. |
| 21100 A-2 | 41 | " Set Screw No. 69 FD. |
| 21133 | _ | " " Pin, for No. 21130-1. |
| 21134 | 39 | " Center Piece, for No. 21130-1. |
| 21139 A-2 | 41 | " for two-spool Style E thread stand. |
| | | " " Set Screw No. 22508. |
| 21140 | 41 | Thread Wire, complete (21 inches long) for Style D thread stand |
| | | (includes one each Nos. 21113 A, 21113 B, |
| i | | 21140 A and two No. 88) |
| | 1 | the contract of the contract o |
| 21140 A | 35 | " (15 inches long) for Style D thread stand. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. | | | | |
|-----------------------|--------------|--|--|--|--|--|
| 21145 | 33 | Thread Stand Wooden Cone. | | | | |
| 21146 | 31 | Small Spool Holder Axle. | | | | |
| 21147 | 16 | " " Axle Connection. | | | | |
| | - | " " Axle Set Screw No. 88. | | | | |
| 21148 | l _ | " " Collar. | | | | |
| 21110 | | " " Collar Thumb Screw No. 188 D. | | | | |
| 21149 | 32 | " " complete (includes one each No. 88, 188 21146, 21147 and 21148) | | | | |
| 21150 | 39 | Piping Holder (8-inch discs) for $\frac{1}{2}$ inch to $1\frac{13}{16}$ inch width of str | | | | |
| | 1 | includes one each Nos. 25 S, 88, 94, 430, 431 | | | | |
| | 1 | 432, 433, 434, 21161 C, 21161 D, 21163, 2116 | | | | |
| | 1 | and two each Nos. 98 and 21157) | | | | |
| 21157 | 20 | I ' | | | | |
| 21161 C | 39 | " " Disc (8 inches diameter) | | | | |
| 21101 C | 39 | rrame. | | | | |
| 01101 D | | Frame Set Screws No. 98. | | | | |
| 21161 D | 39 | Guide, adjustable. | | | | |
| 24422 | l | Guide Set Screw No. 88. | | | | |
| 21163 | 31 | Piping Holder Frame Supporting Rod. | | | | |
| | 1 | Supporting Rod Screw No. 25 S. | | | | |
| 21164 | 32 | Supporting Rod Post. | | | | |
| | 1 | " " Supporting Rod Post Screw No. 94. | | | | |
| 21169 D | 39 | Binding Holder, complete, for Styles 6200 W, 6400 I and 6400 I (includes one each Nos. 88, 161, 21169 E ar 21169 F) | | | | |
| 21169 E | 39 | " " Disc (8 inches diameter) | | | | |
| 21169 F | 39 | " Base and Spindle (6½ inches high) | | | | |
| 21109 F 21171 | | | | | | |
| 21171 | 39 | Band Spool Holder, complete, for stitching continuous top band to shoe linings on machines in Class 626 without upper feed (includes one each No 25 T, 110-3, 21172, 21172 A, 21172 D and two No. 90) | | | | |
| 21171 A | 39 | " " complete, for Style 6200 X (includes of each Nos. 21172, 21172 B, 21172 C 21172 E, 21172 F, 21172 G and 21172 | | | | |
| 21172 | | and two each Nos. 25 T and 90) | | | | |
| 21112 | _ | rost. | | | | |
| 21172 A | | FOST SCIEW NO. 94. | | | | |
| 21114 A | - | Band Guide, for No. 21171. | | | | |
| 01170 7 | | Set Screw No. 90. | | | | |
| 21172 B | - | Supporting Block, adjustable. | | | | |
| 01150 = | | Supporting Block Set Screw No. 90. | | | | |
| 21172 C | - | Band Spool Axle. | | | | |
| | | " " Thumb Screw No. 25 T. | | | | |
| 21172 D | — | " " Washer, loose, for No. 21171. | | | | |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------------------|--------------|--|
| 21172 E | _ | Band Spool Disc, right, for No. 21171 A. |
| 21172 F | | " " left, for No. 21171 A. |
| | | " " Thumb Screw No. 25 T. |
| 21172 G | _ | " " Spring, for No. 21171 A. |
| 21172 H | - | Band Guide, for No. 21171 A. |
| | | " " Set Screw No. 90. |
| 21173 | 35 | Thread Stand Spool Support Rod; also for No. 21173 C. |
| 01170 4 | 00 | " " Rod Set Screws No. 96. |
| 21173 A | 39 | Auxilliary Support Vertical Rod Connection. |
| 01170 D | 00 | vertical rod Connection Screws No. 22508. |
| 21173 B | 39 | Figing Holder Socket Connection. |
| | | " " Piping Holder Socket Connection Screws No. 22508. |
| 21173 C | 39 | " with universal adjustment, for piping holder |
| | | (includes one each Nos. 21102 D, 21126, |
| | | 21173, 21173 A, 21173 B, two No. 96 and |
| | | four No. 22508) |
| 21176 A | 39 | Lower Tape Holder, complete, for Style 6200 Y (includes one |
| | | each Nos. 110-3, 201 A, 201 C and |
| | | 21185 B and two No. 21178) |
| 21178 | 39 | " " " Disc (8 inches diameter) |
| 21182 B | 33 | · |
| $21182 \text{ B} - \frac{15}{16}$ | _ | Binding Tension, complete, for use with $\frac{15}{16}$ inch and narrower |
| | | binding on Style 6400 M. |
| 21182 J | 38 | Tension, complete, for vertical strip, 3 inch and narrower widths |
| | | (includes one each Nos. 96, 21182 K, 21182 L, 21182 M |
| | | and 21217 and two each Nos. 107, 108, 110-3, 1346 and 1347) |
| 21182 K | _ | " Plate, inner. |
| 21182 L | _ | " Plate, outer. |
| 21182 M | _ | " Plate Supporting Rod. |
| | | " Plate Supporting Rod Set Screw No. 96. |
| 21185 | 20 | Thumb Nut, for binding tension No. 21182 B- $\frac{15}{16}$. |
| 21201 | 36 | Screw Driver, round steel (diameter $\frac{5}{32}$ inch) |
| 21202 | 36 | " round steel (diameter $\frac{7}{32}$ inch, length overall 10 |
| | | inches) |
| 21203 | 36 | " round steel (diameter $\frac{7}{32}$ inch, length overall 13 |
| | | inches) |
| 21204 | 36 | " " round steel (diameter ½ inch) |
| 21205 | 36 | " " octagon steel (diameter $\frac{5}{16}$ inch) |
| 21206 | 36 | " " Wrench. |
| 21207 | 36 | " " round steel, for loop retainer adjusting screws. |
| 21210 | 15 | Looper Collar (.040 inch thick) |
| 21211 | 15 | " " (.054 inch thick) |
| 21217 | 35 | Base, for Vertical strip tension No. 21182 J. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|------------------------|--------------|--|
| $21225-\frac{1}{4}$ | 22 | Looper Adjusting Gauge, ¹ / ₄ inch measurement. |
| $21225 - \frac{1}{32}$ | 22 | " " $\frac{9}{32}$ inch measurement. |
| 21290 G | 40 | Lifter Lever Threadle, wood for Styles 6200 AA and 6200 AB. |
| 21300 A-4 | - | Carriage Bolt (§ x 4 inches) including washer, for fastening board |
| | | to under side of table where tray No. 21377 D is used with Style 6500 P. |
| 21300 A-6 | l | " (3 x 6 inches) |
| 21350 | 15 | Malleable Iron Belt Fastener, for 1-inch flat belt |
| 21351 | 15 | Wire Belt Hook, for $\frac{9}{32}$ inch round belt, per 500 ($\frac{1}{2}$ cent each in |
| 21353 | -0 | quantities less than 500) |
| | | Carriage Bolt Washer. |
| 21355 | 33 | Chain Leg Extension (4 inches long) |
| 21355 A | 33 | " " (6 inches long) |
| 21355 B | 33 | (3 inches long) |
| 21360 | - | Drive Bushing ($\frac{7}{8}$ inch long, external standard size .319 inch) |
| 24222 222 | | for needle bar bearings: |
| 21360-322 | - | externat standard size, plus .005 inch. |
| 21360-325 | _ | external standard size, plus .005 inch. |
| 21360-328 | - | external standard size, plus .009 inch. |
| 21360-331 | — | " external standard size, plus .012 inch. |
| 21361 | _ | " ($\frac{1}{2}$ inch long, external size .407 inch) for presser |
| | | guide bar bearings. |
| 21362 | - | " " $(\frac{25}{32}$ inch long, external size .407 inch) for presser |
| | | bar upper bearing. |
| 21363 | _ | " " $(1\frac{3}{16}$ inches long, external size .407 inch) for |
| | | presser bar lower bearing. |
| 21364 | 33 | Hinge Pin, detachable, for tray No. 21377. |
| 21367 | _ | Flat Head Stove Bolt ($\frac{1}{4} \times 4$ inches) including nut and washer, for fastening machines, using tray No. 21377, to table. |
| 21369-3 | _ | Clamping Bolt, including wing nut and washer, for fastening |
| | | right-hand end of tray No. 21377 C to table. |
| 21371 B | _ | Table Top, sectional, (48 inches x 16 inches x $1\frac{3}{4}$ inches) |
| 21371 D | _ | Table Board (22 inches x 15 inches x $1\frac{5}{8}$ inches) for underside of |
| | | table, where tray No. 21377 D is used with Style 6500 P. |
| 21371 E | - | " Cleat (22 inches x 15 inches x $1\frac{5}{8}$ inches) for under- |
| | | side of table where tray No. 21377 D is used with Style 6500 P and cloth plate is level with table |
| | | top. |
| 21371 G | - | Individual Power Table, without electric motor, or transmitter. |
| 21375 A | 41 | Pulley Oil Guard. |
| 21377 | 40 | Tray or Wooden Work Support, (obsolete, only used whereattach- |
| 21377 C | 40 | ments overhang front of cloth plate.) " " Support $(3\frac{1}{8})$ inches high) hinged, includ- |
| | | ing clamping bolt. |

| Number to Order by | Plate No. | The it the part at list p | igures in s. and a rices for | the second re not to be repairs only. | column refer only to the plates illustrating used in ordering. These parts are furnished. See notice on Page 2. | | |
|-----------------------|--------------|--|------------------------------------|---|---|--|--|
| 21377 D | 40 | Tray or Wooden Work Support (1½ inches high) (obsolete,) for Style 6500 P. | | | | | |
| 21385 B | 39 | Lower 7 | Гаре Но " | older Axle. | Thumb Screw No. 201 C. | | |
| 21387 A | 24 | Supplen | nental F | late, for cl | oth plate on Style 6400 U. v No. 25 C. | | |
| 21387 D | 24 | " forcloth plate on Style 6400 I. " Screws, No. 25 C. | | | | | |
| 21388 | 33 | Wrench | (3 inch | . hardened |) for looper connecting rod nuts. | | |
| 21388 B | 33 | и | (a inch | hardened |) for needle lever connecting tube nuts. | | |
| 21388 G | 36 | Sarow T | river W | Trench for | roller ball bearing stud nut No. 377. | | |
| 21390 | 29 | Needle ' | Throad | Intermitte | at Nipper, complete (includes one each | | |
| 21030 | 29 | i iveedie | ımeau | mænmæ | Nos. 87, 90, 97, 21390 A, 21390 B, 21390 D, 21390 E, 21390 F and 22564) | | |
| 21390 A | 29 | u | u | и | Nipper Spring, front. | | |
| 21390 B | 29 | u | и | и | Nipper Spring, back. | | |
| 21000 D | 20 | u | u | и | Nipper Spring Screw No. 22564. | | |
| 21390 D | 29 | u | u | u | Nipper Spring Screw No. 22004. | | |
| 21080 D | 29 | и | u | ű | Nipper Spring Support. | | |
| | | | | | Nipper Spring Support Screw No. 87. | | |
| 21390 E | 29 | u | u | u | Nipper Spring Operating Block. | | |
| | | u | u | " | Nipper Spring Operating Block Screw No. 90. | | |
| 21390 F | 29 | u | " | u | Nipper Spring Operating Block Support. | | |
| | | u | u | u | Nipper Spring Operating Block Support Screw No. 97. | | |
| 21394 | | Grinder. | includi | ng emery | wheel (5 inches diameter $\frac{1}{4}$ inch face) | | |
| | | recom | mended | speed 3000 | 0 revolutions per minute. | | |
| 21394 G | | Emery V | Wheel (| inches dis | smeter, $\frac{1}{4}$ inch face, $\frac{3}{8}$ inch hole) | | |
| 21394 H | | 4 | " (! | inches die | ameter, $\frac{1}{2}$ inch face, $\frac{3}{8}$ inch hole) | | |
| 21394 K | _ | Grinder | includi | no emery i | wheel (5 inches diameter, $\frac{1}{2}$ inch face) | | |
| | | recom | mended | sneed 300 | 0 revolutions per minute. | | |
| 21400 | 35 | - 500111 | | Specia 6000 | - 1010-unona per millute. | | |
| ‡ 21400-257 | _ | Evenanci | ion Rec | mer compl | lete (length $11\frac{1}{2}$ inches) with 4 inch | | |
| + 21100 201 | | Tava barra | ion itea | guide | e, for needle bars, sizes .257 inch to | | |
| + 01400 000 | | и | и | | inch inclusive. | | |
| ‡ 21400-266 | | | - | | te, for needle bars sizes .266 inch to inch inclusive. | | |
| ‡ 21400-276 | _ | " | и | | te, for needle bars, sizes .276 inch to inch inclusive. | | |
| ‡ 21408-319 | _ | u | u | | te (length $12\frac{3}{4}$ inches) with 4 inch | | |
| • | | | | guide | e, for presser bars and presser guide | | |
| | | | | | sizes .319 inch to .325 inch inclusive. | | |
| | <u> </u> | | | | oro mon to .ozo men menusive. | | |

\$See Page 11

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. | | | | |
|-----------------------|--------------|--|--|--|--|--|
| ‡ 21408–328 | _ | Expansion Reamer, complete, for presser bars and presser guide bars, sizes .328 inch to .334 inch inclusive | | | | |
| ‡ 21420–407 | _ | " complete (length 16 inches) with $4\frac{1}{4}$ inch guide, for rock shafts, sizes .407 inch to .413 inclusive. | | | | |
| ‡ 21420–416 | _ | " " complete, for rock shafts, sizes .416 inch to .422 inch inclusive. | | | | |
| 21426 | 35 | | | | | |
| ‡ 21426–530 | _ | " complete (length 21 inches) with 4 inches guide, for main shafts, sizes .530 inch to .536 inch inclusive. | | | | |
| ‡ 21426–536 | - | " " complete, for main shafts, sizes .533 inch to .542 inch inclusive. | | | | |
| 21440 | 35 | Taper Reamer, complete, for reaming needle lever, for plus size studs. | | | | |
| 21441 | 35 | " complete for reaming frame, for plus size needle lever studs. | | | | |
| 21442 | 35 | " " complete, for link pins. | | | | |
| 21508 | 21 | Tap (marked H2) for screw No. 22525. | | | | |
| 21509 | 21 | " (marked J2) for screw No. 22526. | | | | |
| 21513 | 21 | " (marked Q2) for screw No. 86 A. | | | | |
| 21518 | 21 | " (marked X2) for screw No. 22521. | | | | |
| 21602 | 29 | Needle Thread Pull-Off Post, for rolling thread guide construction " " Post Screw No. 94. | | | | |
| 21602 A | 29 | Bell Crank Post, for Style 6200 AB. " " Screw No. 94. | | | | |
| 21603 | 29 | Needle Thread Pull-Off Post Thread Oiler. " " Post Thread Oiler Screw No. 94. | | | | |
| 21605 | 29 | " " Rolling Sleeve, for rolling thread guide construction. | | | | |
| 21606 | 29 | " " Rolling Sleeve Axle. | | | | |
| 21607 | 29 | " " Clamp Sleeve. | | | | |
| | | " " Clamp Sleeve Set Screw No. 87 U. | | | | |
| 21608 | 29 | Needle Thread Take-Up Wire, for rolling thread guide con- struction. " " Wire Set Screw No. 87 U. | | | | |
| 21610 A | 12 | Needle Bar Thread Guide, rolling construction. " " " Screw No. 22768. | | | | |
| 21624 | 12 | Thread Controller Thread Guide, rolling construction. " " Guide Screw No. 138. | | | | |
| 21628 | 12 | " " Guide Roller. | | | | |
| 21629 | 17 | " " Guide Roller Stud. | | | | |
| 21632 | 12 | Needle Lever Thread Guide, rolling construction. " " " Screw No. 98 A. | | | | |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 21640 A | 37 | Tension Disc Separator Lever. |
| 21212 = | | Lever Stud No. 483. |
| 21640 F | 11 | Tension Disc Separator. |
| | | " " Screws No. 90. |
| 21645 | 29 | " " Lever Connection. |
| | | " " Lever Connection Screw No. 93. |
| 21685 | <u> </u> | Knee Lifter Plate. |
| | | " " Plate Set Screw No. 69 FD. |
| 21692 | 37 | " Chain (18 inches long) for Style 6500 P. |
| 21693 | 40 | " (obsolete), complete, excluding chain, where tray No. |
| 21693 A | 40 | 21377 D and under board No. 21371 D are used with Style 6500 P, drop of rear hanger $\frac{11}{16}$ inch. " " complete, exclusing chain, for Styles 6500 N and 6500 P, where tray No. 21377 C is used, drop of rear hanger $2\frac{3}{8}$ inches. |
| 21693 В | _ | " Shaft $(9\frac{7}{8}$ inches long) |
| 21693 C | | " " Frame. |
| 21693 D | | |
| 21000 15 | | " Shaft Hanger, (obsolete), rear, drop 11/16 inch, for No. 21693. |
| 21693 E | - | " Shaft Hanger, rear, drop 23 inches, for No. 21693 A. |
| 21693 F | | " " Interlocking Arm, left. |
| | | " Interlocking Arm Set Screw No. 69 FD. |
| 21693 G | - | " Interlocking Lever. |
| | | " Interlocking Lever Set Screw No. 22622. |
| | | " Interlocking Lever Stop Screw No. 12993 A. |
| | | " Interlocking Lever Stop Screw Lock Nut No. 34. |
| 21693 H | - | " Interlocking Lever Pin (15 inches long) |
| 21693 J | | " " Plate Rod. |
| | - 1 | " " Plate Rod Nut No. 15430 D. |
| 21693 K | _ | " " Chain Arm. |
| 1 | | " Chain Arm Set Screw No. 69 FD. |
| | | " Chain Arm Stop Screw No. 12993 A. |
| | ì | " Chain Arm Stop Screw Lock Nut No. 34. |
| 21693 L | | " Chain (15 inches long) for Style 6500 N. |
| 22508 | 19 | Set Screw, for spool supports Nos. 21130-1 and 21139 A-2; also |
| 00714 | | for Nos. 21173 A and 21173 B. |
| 22514 | 18 | Serew $(\frac{7}{16}$ inch long) for cloth plate attachments. |
| 22521 | 18 | " large size, for cloth plates (tap No. 21518) |
| 22524 | 17 | " for cast off wires. |
| 22525 | 17 | " large size, diameter $\frac{5}{32}$ inch, for throat plates (tap No. 21508) |
| 22526 | 17 | " large size, diameter $\frac{3}{16}$ inch, for throat plates (tap No. 21509) |
| 22528 | 18 | " $(\frac{11}{32}$ inch long) for upper feed dog on Styles 6200 AA and 6200 AB; also for No. 6281. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 22530 | 18 | Screw ($\frac{1}{8}$ inch long) for gauge on Style 6200 W. |
| 22539 | 17 | " for main shaft sponge hole. |
| 22548 | 18 | " for feed rocker arms. |
| 22560 | 17 | " headless, for needle bar link pin ball spring. |
| 22560 B | 17 | " headless $(\frac{16}{64}$ inch long) for rear end of roller arm support on rolling presser foot No. 6220-1 $\frac{1}{4}$. |
| 22561 | 17 | " for binding guide adjustment on Style 6200 W. |
| 22564 | 17 | " for needle thread intermittent nipper spring; also for No. 1588 A. |
| 22569 | 18 | Clamp Screw, for needle bar bushings. |
| 22570 | 17 | Set Screw, fillister head, for presser foot No. 6520 P. |
| 22576 | 18 | Screw, for needle lever extension on Style 6200 AB. |
| 22580 | 17 | Set Screw, for feed eccentric No. 917. |
| 22585 | 17 | Screw, for differential feed dog on Style 6500 N. |
| 22586 | 17 | " for needle lever stud. |
| 22586 A | 17 | " for needle lever connection bearing valve spring. |
| 22587 | 19 | " for needle lever connection bearings. |
| 22588 | 18 | " hexagon head, for feed rocker eccentric on Style 6500 P. |
| 22589 | 17 | " cone head, for left feed rocker eccentric flange on Style 6500 P. |
| 22593 | 18 | " for main feed dog on Style 6500 N. |
| 22594 | 18 | " $(\frac{7}{16}$ inch long) for binder on Style 6400 M. |
| 22596 | 19 | " for take-up frame. |
| 22597 | 17 | Set Screw, for eccentric pulleys. |
| 22622 | 17 | " for knee lift interlocking lever. |
| 22726 | 18 | Stud, for gauge swinging arm on Style 6500 P; also for No. 23371 A. |
| 22730 | 18 | Screw, for cloth plate guards. |
| 22733 | 17 | Set Screw, for vibrating lifter link pin on Style 6200 AB; also for No. 8360. |
| 22755 | 19 | Screw, lower, for feed rocker eccentric connection, Style 6500 P. |
| 22756 | 19 | Thumb Screw, for edge guide on Style 6500 P. |
| 22768 | 17 | Screw, for needle bar thread guides. |
| 22786 | 18 | Hinge Screw, for presser foot on Style 6200 X. |
| 23100 | 27 | Yoke Folder, for Style 6400 N. " " Screws No. 25 C. |
| 23133 B | 24 | Gauge, for Style 6200 Q. "Screws No. 25 C. |
| 23182 D | 27 | Folder and Guide, for Style 6500 E. " Scroll Screws No. 187 A. |
| 23184 | 27 | Folder and Guide, for Style 6500 C, upper ply of fabric passes to the right of the needle ($\frac{1}{8}$ inch capacity for upper ply, $\frac{1}{16}$ inch capacity for lower ply and $\frac{5}{16}$ inch overlap. " " Screws No. 25 C. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 23215 AP | 27 | English Binder, adjustable, for Style 6400 M ($\frac{5}{32}$ inch capacity for goods, uses selvage edge strip $\frac{3}{4}$ inch to |
| | | 15 inch wide) " " Screws No. 22594. |
| | ļ | " " Upper Blade Screw No. 187 A. |
| 23217 Е | 27 | Cut Edge Binder, for Style 6200 W ($\frac{1}{16}$ inch capacity for goods uses cut edge strip $\frac{3}{4}$ inch wide) |
| 23218 | 97 | Screws No. 25 C. |
| 20210 | 27 | Gauge, for Style 6200 W. " Screw No. 22530. |
| 23218 A | 24 | Binding Guide, complete, adjustable, for Style 6200 W. |
| 20210 A | 41 | " " Screw No. 25 C. |
| | | " " Adjustment Screws No. 22561. |
| 23223 C | 27 | " complete, adjustable, for Style 6400 M. |
| | | " Screws No. 25 C. |
| 23223 K | | " " Adjustment, lower. |
| 23223 L | _ | " " Adjustment, upper. |
| | | " " Adjustment Screws No. 187 A. |
| 23242 N | 27 | Folder and Tape Guide, complete, adjustable, for Style 6200 Y. " " Screws No. 25 C. |
| 23242 В | 27 | Gauge and Tape Guide, complete, adjustable, for stitching pre- folded leather flies on Style 6200 Y. |
| _ | | " " " Screws No. 25 C. |
| 23322 K-7 | _ | English Binder, for Style 6400 I (uses cut edge strip $\frac{7}{8}$ inch wide, finish $\frac{3}{32}$ inch) |
| 23322 K-1 | 24 | " for Style 6400 I (uses cut edge strip 1 inch wide finish $\frac{1}{4}$ inch) |
| | | " Screws No. 90. |
| 23322 L | 27 | " Support, for Style 6400 I. |
| | | " Support Screws No. 25 CC. |
| 23322 M | 15 | " Screw Plate, for Style 6400 I. |
| 23371 | 27 | Presser Foot Swinging Folder, for piping dresses on machines in Class 6400 using presser foot No. 6427 H. |
| 000=1 | | " " Folder Screws No. 187 A. |
| 23371 A | _ | roider support. |
| | | Folder Support Stud No. 22726. |
| 00070 | | rolder Support Stud Washer No. 12957 E |
| 23373 | _ | Presser Foot Piping Guide. |
| 23373 A | | ocrews No. 87 U. |
| 23377 | 27 | " " " Adjusting Plate. Rick-Rack Guide and Folder, complete, adjustable, for Style |
| 23011 | | 6400 X. |
| | | " " Screws No. 25 C. |
| 23377 A | _ | " " right. |
| 23377 B | _ | " " left. |

| Number to Order by | Plate No. | The figures in the second column refer only to the plates illustrating the parts, and are not to be used in ordering. These parts are furnished at list prices for repairs only. See notice on Page 2. |
|-----------------------|--------------|--|
| 23377 C | | Folder, for No. 23377. |
| 23377 D | l | Folder and Rick-Rack Guide Base, for No. 23377. |
| 20077 15 | | " " Guide Base Screws No. 25 C. |
| 29051 B | | Assembly, for pulley, one each Nos. 59 S and 15430 M. |
| 29051 C | l _ | " for pulley, needle lever ball and needle lever connec |
| 20001 0 | | ing tube; one each Nos. 59 S, 156, 1230 A, 1230 |
| | ì | 1230 C, 1230 D, 15430 C, 15430 D and 22586 A. |
| 29053 В | l | " for pulley; one each Nos. 59 V and 15430 M. |
| 29053 C | l _ | " for pulley, needle lever ball and needle lever connec |
| 20000 0 | | ing tube; one each Nos. 59 V, 156, 1230 A, 1230 |
| | l | 1230 C, 1230 D, 15430 C, 15430 D and 22586 A. |
| 29066 В | _ | " for needle lever ball; one each Nos. 156, 1230 |
| | | 1230 B and 1230 D. |
| 29066 C | _ | " for needle lever ball; one each Nos. 156 and 1230 A. |
| 29070 B | l — | " for pulley; one each Nos. 11721 and 15430 M. |
| 29072 B | l — | " for pulley; one each Nos. 7521 and 15430 M. |
| 29084 B | _ | " for pulley; one each Nos. 9921 and 15430 M. |
| 29147 | _ | " for eccentric; one each Nos. 6546, 6547, 15487 a |
| | | 15488. |
| 29154 | | " for looper rocker; one each Nos. 181, 30, 33 and 34. |
| 29158 | — | for looper rocker; one each Nos. 213, 30, 33 and 34. |
| 29158 A | _ | " for looper rocker; one each Nos. 213, 12987 A, 15465 |
| | | and 15745 B and two No. 88. |
| 29169 | - | " for looper rockers; one each Nos. 6013, 30, 33 and 3 |
| 29169 A | - | " for looper rocker; one each Nos. 6013, 12957 15465 F and 15745 B and two No. 88. |
| 29185 A | _ | " for looper rocker; one each Nos. 181, 12987 A, 15465 |
| | | and 15745 B and two No. 88. |
| 29304 B | l — | " for needle lever; one each Nos. 153 F and 1275 A. |
| 29328 | l — | " for needle lever; one each Nos. 6215 and 1275 A. |
| 29332 | l — | for needle lever; one each Nos. 16115 and 1275 A. |
| 29402 | 37 | " for treadle; one each No. 422, 98, 423 and 424. |
| 29457 A | 9 | Sub Assembly, for rolling presser foot No. 1520 J-1 ⁵ / ₁₆ ; one ea Nos. 371, 374, 375, 1586 A, 1588 A, 1592, 15 and 22564. |
| 29457 B | l _ | " for rolling presser foot No. 1520 J-1\frac{1}{8}; one es |
| 20101 D | | Nos. 370, 91, 374, 375, 1586 A, 1588 A, 159 1594 and 22564. |
| 29457 E | 9 | " for rolling presser foot No. 1520 K- $1\frac{3}{4}$; one es |
| 48¥81 E | 9 | Nos. 372 B, 91, 374, 375, 1586 B, 1588 A, 159 and 22564. |





UNION SPECIAL maintains sales and service facilities throughout the world. These offices will aid you in the selection of the right sewing equipment for your particular operation. Union Special representatives and service men are factory trained and are able to serve your needs promptly and efficiently. Whatever your location, there is a Union Special Representative to serve you. Check with him today.

ATLANTA, GA.

BOSTON, MASS.

CHICAGO, ILL.

DALLAS, TEXAS

LOS ANGELES, CAL.

NEW YORK, N. Y.

PHILADELPHIA, PA.

MONTREAL, QUEBEC

BRUSSELS, BELGIUM

LEICESTER, ENGLAND

LONDON, ENGLAND

PARIS, FRANCE

STUTTGART, GERMANY

Representatives and distributors in all important industrial cities throughout the world.



404 N. FRANKLIN ST., CHICAGO 10, ILL.