


# MODEL CM491

## **BUTTON SEWING MACHINE**








# PARTS BOOK





From the library of: Superior Sewing Machine & Supply LLC




















# HAND BUTTON SEWER 475 P




Please note: Chandler Models 401, 461, 471, 481, 472, 475P & 485P are also represented in this book.




2 BS 8-24 (475P) WHEN ORDERING ANY OF THESE UNITS COMPLETE, REFER TO NUMBER ON THIS PAGE ONLY.









#### INSTRUCTIONS FOR INSTALLING CLUTCH UNIT ON

#### 472 & 475P & 485P

Refer to parts book re: part numbers

With needle bar in highest or stop position, and stop shaft 2BS3-l84 protruding approximately 3/8", the clutch assembly is positioned on clutch shaft 2BS3-l95 so that the stop shaft is relieving tension from the clutch, allowing pulley to spin freely. Cap screw will be tightened on flat of shaft and Allen screw on bottom is also tightened. With power off, run the machine thru one cycle by hand. When stop shaft is activated, part No. 2BS-7l80, stop blade, should be under leading end of stop shaft, the needle bar should be in its highest position, and the pulley should be free of the clutch, with a minimal amount of clearance. Any adjustments for this should be made by moving stop shaft in or out which is governed by the collar inside the machine. With the machine running, the stop blade should be clearing the stop shaft by approximately 1/32 of an inch.



### MAIN office

131 W. 25th Street New York, NY 10001

Tel: 212-741-7788

Fax: 212-741-7787

### Miami, FL

4013 N.W. 79th Avenue

Miami, FL 33166

Tel: 305-471-0200

Fax: 305-471-0243

### Los Angeles, CA

2320 South Hill Street

Los Angeles, CA 90007

Tel: 213-745-8844

Fax: 213-745-8855