


**ILLUSTRATED
PARTSLIST
FOR
SINGER***


MACHINE

211U157


* A Trademark of THE SINGER COMPANY
Copyright © 1981 THE SINGER COMPANY
All Rights Reserved Throughout World




No.						Description
	212U141	442	211U157	165	166	
141566	*	*	*	*	*	Machine Pulley Position Screw
141567	*	*	*	*	*	Machine Pulley Set Screw
202253	*	*	*	*	*	Arm Shaft Connecting Belt Pulley Spring Flange (2)
202330	*	*	*	*	*	Needle Bar Connecting Stud Wick
202399	*	*	*	*	*	Take-up Lever Driving Stud with 244071
202552	*	*	*	*	*	Needle Bar Connecting Link
204329	*	*	*	*	*	Arm Shaft Bushing (front) Oil Pad (felt) (lower)
235706	*	*	*	*	*	Take-up Lever Hinge Stud Oil Wick
240139	-	-	*	-	-	Take-up Lever
244071	*	*	*	*	*	Take-up Lever Driving Stud Oil Wick
244747	*	*	*	*	*	Arm Shaft Bushing (front) with 412234
267158	*	*	*	*	*	Arm Shaft
267160	*	*	*	*	*	Arm Shaft Bushing (front) Oil Pad (felt) (upper)
267161	*	*	*	*	*	Arm Shaft Connecting Belt
267221	*	*	*	*	*	Needle Bar Connecting Link Stud with 267466
267224	*	*	*	*	*	Needle Bar Crank Friction Washer
267466	*	*	*	*	*	Needle Bar Connecting Link Stud Wick
272142	*	*	*	*	*	Machine Pulley Ball Bearing (back)
412003	*	*	*	*	*	Arm Shaft complete 267221, 412205, 544327, 544332
412004	*	*	*	*	*	Needle Bar Crank
412005	*	*	*	*	*	Arm Shaft Connecting Belt Pulley with 202253 (2), 544322, 544330
412133	-	-	*	*	*	Arm Shaft complete 202399, 202552, 240139, 412003, 412134, 412225, 412226
412134	*	*	*	-	-	Needle Bar Connecting Stud with 202330, 545295
412205	*	*	*	*	*	Arm Shaft complete 267158, 412004, 544323, 504358
412225	*	*	*	*	*	Take-up Lever Hinge Stud with 235706
412226	*	*	*	*	*	Take-up Lever Hinge Stud Wearing Washer
412234	*	*	*	*	*	Arm Shaft Bushing (front) Oil Wick
412239	*	*	*	*	*	Take-up Lever Guard
512583	*	*	*	-	-	Machine Pulley with 141566, 141567, 272142
544322	*	*	*	*	*	Arm Shaft Connecting Belt Pulley Set Screw
544323	*	*	*	*	*	Needle Bar Crank Position Screw
544324	*	*	*	*	*	Arm Shaft Bushing (front) Set Screw
544327	*	*	*	*	*	Needle Bar Connecting Link Stud Set Screw
544330	*	*	*	*	*	Arm Shaft Connecting Belt Pulley Position Screw
544332	*	*	*	*	*	Needle Bar Connecting Link Stud Set Screw
544358	*	*	*	*	*	Needle Bar Crank Check Screw
545370	*	*	*	*	*	Take-up Lever Hinge Stud Set Screw
549027	*	*	*	*	*	Take-up Lever Guard Screw (2)
549380	*	*	*	*	*	Needle Bar Connecting Stud Pinch Screw








No.	212U141	442	211U157	165	166	566	Description
223	-	-	*	*	*	*	Needle Set Screw
238	-	-	*	*	*	*	Needle Bar Thread Guide Screw
202277	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Link Hinge Screw Oil Packing (wick) (2)
240039	-	-	*	-	-	-	Needle Bar Thread Guide
267230	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Link
267231	*	*	*	-	-	-	Needle Bar Oiling Felt
267232	*	*	*	-	-	-	Needle Bar Oiling Felt Retainer (upper)
267233	*	*	*	-	-	-	Needle Bar Oiling Felt Retainer (lower)
267285	*	*	*	-	-	-	Needle Bar Rock Frame Shaft
267362	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Bushing (split) (2)
412147	-	-	*	-	-	-	Needle Bar Rock Frame Rock Shaft, Needle Bar complete 267231 267232, 267233, 412148, 412149, 544376 (4)
412148	-	-	*	-	-	-	Needle Bar with 223, 238, 240039
412149	*	*	*	-	-	-	Needle Bar Rock Frame complete 267285, 412150, 512062
412150	*	*	*	-	-	-	Needle Bar Rock Frame with 412151 (2), 544377 (4)
412151	*	*	*	-	-	-	Needle Bar Rock Frame Wear Plate (2)
412152	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Connection with 545139
412153	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank with 544322, 545139
412164	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Link Hinge Screw (2) with 202277
412176	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Connection, Crank, Link with 267230, 412152, 412153, 412164 (2), 541188-001 (2)
512062	*	*	*	-	-	-	Needle Bar Rock Frame Pin
541188-001	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Link Hinge Screw Nut (2)
544322	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Set Screw
544376	*	*	*	-	-	-	Needle Bar Oiling Felt Retainer Screw (upper) (2)
544376	*	*	*	-	-	-	Needle Bar Oiling Felt Retainer Screw (lower) (2)
544377	*	*	*	-	-	-	Needle Bar Rock Frame Wear Plate Screw (4)
545139	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Connection Pinch Screw
545139	*	*	*	-	-	-	Needle Bar Rock Frame Rock Shaft Crank Pinch Screw






No.	212U141 442 211U157 165 166 566	Description
1623	- - * - - -	Thread Lubricator Oil Socket Lock Nut
201750	- - * - - -	Thread Lubricator Oil Socket Plunger Adjusting Nut
244735	- - * - - -	Thread Lubricator Oil Reservoir Cover
244736	- - * - - -	Thread Lubricator Oil Reservoir Cover Gasket
244738	- - * - - -	Thread Lubricator Oil Socket Lock Nut Washer
244739	- - * - - -	Thread Lubricator Oil Socket Plunger
244740	- - * - - -	Thread Lubricator Oil Plunger Oil Seal (Rubber)
244741	- - * - - -	Thread Lubricator Oil Socket Release Lever
244742	- - * - - -	Thread Lubricator Oil Socket Plunger Spring
244743	- - * - - -	Thread Lubricator Oil Tube
244746	- - * - - -	Thread Lubricator Oil Socket Oil Seal (2)
244748	- - * - - -	Thread Lubricator Oil Adjusting Nut Retainer
267220	* * * * *	Oil Guard
267236	* * * - - -	Oil Reservoir Oil Wick
267399	* * * - - -	Oil Vibrator Pump Weight Spring
412058	* - * * * *	Arm Cover (side)
412135	* * * - - -	Dynamic Head-End Lubrication Device complete 267399, 412136, 412137, 412138, 545114 (5)
412136	* * * - - -	Oil Vibrator Pump Block
412137	* * * - - -	Oil Vibrator Pump Bracket
412138	* * * - - -	Oil Vibrator Pump Weight
412139	- - * - - -	Face Plate complete 412140, 412155
412140	* - * - - -	Face Plate
412155	- - * - - -	Thread Lubricator complete 1623, 201750, 244735, 244736, 244738, 244739, 244740, 244741, 244742, 244746, 244748, 412165, 543807-002, 549027
412165	- - * - - -	Thread Lubricator Oil Socket
504019	* * * * *	Arm Cover (side) Screw (2)
541176	- - * - - -	Thread Lubricator Oil Tube Nut
543807-002	- - * - - -	Thread Lubricator Oil Socket Plunger Release Lever Pin
544281	* * * - - -	Oil Vibrating Pump Bracket Screw (2)
544336	* * * - - -	Face Plate Screw (2)
545114	* * * - - -	Oil Vibrator Pump Block Screw (2)
545114	* * * - - -	Oil Vibrator Pump Weight Spring Screw (2)
545114	* * * - - -	Oil Vibrator Pump Weight Screw
545114	* * * * *	Oil Guard Screw
549027	- - * - - -	Thread Lubricator Oil Reservoir Cover Screw (6)




No.	212U141	442	211U157	165	166	566	Description
	212U141	442	211U157	165	166	566	
50429	*	*	*	*	*	*	Bobbin Winder Shaft Friction Wheel Set Screw (2)
411083	*	*	*	*	*	*	Bobbin Winder Driving Wheel with 504029 (2)
411097	*	*	*	*	*	*	Bobbin Snap Spring
411098	*	*	*	*	*	*	Bobbin Winder Shaft Friction Wheel with 50429 (2)
411108	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever (short)
411178	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Connection Lever
411179	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Bearing
412053	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) complete 411098, 411178, 412054, 412055, 508553, 508554, 547412
412054	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) with 411179
412055	*	*	*	*	*	*	Bobbin Winder Shaft with 411097
412056	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Rocking
412141	-	-	*	-	-	-	Arm Cover (Top) with 412053, 412056, 412142, 412143, 412144, 412224, 412229, 412240, 500280, 502832, 508555, 508557, 541186, 543831-001, 543832-001, 544281 (2)
412142	*	*	*	-	-	-	Arm Cover (Top) Gasket (vellumoid)
412143	*	*	*	-	-	-	Oil Lever Indicator
412144	*	*	*	*	*	*	Thread Guide (Arm Top Cover)
412208	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever (long)
412224	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Thread Guard
412229	*	*	*	*	*	*	Bobbin Winder Tension complete 412230, 541170, 541186, 547246, 547247 (2)
412230	*	*	*	*	*	*	Bobbin Winder Tension Stud
412240	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever complete 411108, 412208, 543805-002, 544211-051
500280	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever Cap Screw
502832	*	*	*	*	*	*	Arm Cover (Top) Plug
504029	*	*	*	*	*	*	Bobbin Winder Driving Wheel Set Screw (2)
508553	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Spring Shackle
508554	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Link Stud
508555	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Snap Ring
508557	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Spring
541170	*	*	*	*	*	*	Bobbin Winder Tension Nut
541186	*	*	*	*	*	*	Bobbin Winder Tension Lock Nut
541186	*	*	*	*	*	*	Thread Guide (Arm Top Cover) Lock Nut
543805-008	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever Screw Washer
543831-001	*	*	*	*	*	*	Bobbin Winder Bushing (Ecc.) Rocking Lever Stop Pin
543832-001	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Coil Spring Stud
544211-051	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Trip Lever Screw
544281	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Thread Guard Screw (2)
544336	*	*	*	*	*	*	Arm Cover (Top) Screw (6)
547246	*	*	*	*	*	*	Bobbin Winder Tension Spring
547247	*	*	*	*	*	*	Bobbin Winder Tension Disc (2)
547412	*	*	*	*	*	*	Bobbin Winder Shaft Bushing (Ecc.) Link Lock Washer (2)




No.	212U141 442 211U157 165 166 566	Description
202253	* * * * *	Safety Clutch Belt Pulley Spring
202254	* * * * *	Bed Oil Wick (2)
240245	* * * * *	Feed Regulating Stud Retaining Spring
241763	* * * * *	Feed Driving Eccentric Friction Plate Screw Set Screw Packing (Brass) (2)
244712	- - * * *	Hook Driving Shaft
244713	* * * * *	Hook Driving Shaft Ball Bearing
244715	- - * * *	Hook Driving Shaft Bushing (left)
244760	- - * * *	Safety Clutch Belt Pulley with 202253
263093	* * * * *	Bed Oil Wick
263567	* * * * *	Feed Driving Eccentric Friction Plate
267033	* * * * *	Feed Driving Eccentric Connection Friction Washer
267063	* * * * *	Hook Driving Shaft Ball Bearing Retaining Washer
267245	* * * * *	Feed Regulating Stud
268063	* * * * *	Feed Driving Eccentric Connection Needle Bearing
268064	* * * * *	Feed Driving Eccentric
268065	* * * * - -	Feed Driving Eccentric Adjusting Disc
268066	* * * * *	Feed Driving Eccentric Adjusting Disc Spring
270026	* * * * *	Feed Regulating Stud Spring
276025	- - * * *	Safety Clutch Driving Ball (7/32 in. Diameter) (3)
350440	* * * * *	Bed Oil Screw
412011	* * * * - -	Feed Driving Eccentric Adjusting Disc Spring Collar with 544325 (2)
412029	* * * * - -	Feed Driving Flange with 241763 (2), 263567, 544338 (2), 544350, 544410, 549247 (2)
412031	- - * * *	Safety Clutch complete 244760, 276025 (3), 412032, 514453, 514454 (3), 543802-014
412032	- - * * *	Safety Clutch Over Load Pulley with 544322 (2), 544331 (3)
412033	* * * * *	Hook Driving Shaft Ball Bearing Collar with 544325, 544329
412034	* * * * *	Hook Driving Gear with 544325, 544329
412092	- - * * *	Hook Driving Shaft Bushing (center)
412098	* * * * *	Hook Driving Shaft Ball Bearing Collar complete 244713, 412033
412235	* * * - - -	Feed Driving Eccentric complete 268064, 268065, 268066 412011, 412029, 508499
508499	* * * - * *	Feed Driving Eccentric Connection with 268063
514453	- - * * *	Safety Clutch Disc
514454	- - * * *	Safety Clutch Driving Ball Spring (3)
543802-014	- - * * *	Safety Clutch Over Load Pulley Retaining Ring
544322	- - * * *	Safety Clutch Over Load Pulley Set Screw (2)
544325	* * * * *	Feed Driving Eccentric Adjusting Disc Spring Collar Set Screw (2)
544325	* * * * *	Hook Driving Shaft Ball Bearing Collar Set Screw
544325	* * * * *	Hook Driving Gear Set Screw
544329	* * * * *	Hook Driving Shaft Ball Bearing Collar Position Screw
544329	* * * * *	Hook Driving Gear Position Screw
544331	- - * * *	Safety Clutch Over Load Pulley Adjusting Screw (3)
544338	* * * * *	Feed Driving Eccentric Friction Plate Screw (2)
544346	* * * * *	Hook Driving Shaft Ball Bearing Retaining Washer Screw (3)
544347	* * * * *	Feed Driving Eccentric Connection Friction Washer Screw (3)
544350	* * * * *	Feed Driving Flange Set Screw
544410	* * * * *	Feed Driving Flange Position Screw
549247	* * * * *	Feed Driving Eccentric Friction Plate Screw Set Screw (2)




No.							Description
	212U141	442	211U157	165	166	566	
154780	*	*	*	*	*	*	Feed Driving Rock Shaft Stop Collar Set Screw (4)
202254	*	*	*	*	*	*	Bed Oil Wick (front)
202254	*	*	*	*	*	*	Bed Oil Wick (center)
202254	*	*	*	*	*	*	Bed Oil Wick (back)
223655	*	*	*	*	*	*	Feed Lifting Eccentric Fork Oiling Felt
240259	-	-	*	-	-	-	Feed Dog
243744	*	*	*	*	*	*	Bed Oil Stop Screw Gasket (front)
243744	*	*	*	*	*	*	Bed Oil Stop Screw Gasket (center)
243744	*	*	*	*	*	*	Bed Oil Stop Screw Gasket (back)
244730	*	*	*	*	*	*	Feed Driving Rock Shaft Bushing (center)
244730	*	*	*	*	*	*	Feed Driving Rock Shaft Bushing (back)
350366	*	*	*	*	*	*	Bed Oil Stop Screw (front)
350366	*	*	*	*	*	*	Bed Oil Stop Screw (center)
350366	*	*	*	*	*	*	Bed Oil Stop Screw (back)
412022	*	*	*	*	*	*	Feed Driving Rock Frame with 545154 (2)
412024	-	-	*	*	*	*	Feed Bar
412026	*	*	*	*	*	*	Feed Lifting Eccentric with 544329
412089	*	*	*	*	*	*	Feed Bar Hinge Screw
412159	-	-	*	-	-	-	Feed Driving Rock Shaft complete 412022, 412089, 412160, 545405
412160	-	-	*	-	-	-	Feed Bar complete 412024, 412161, 543804-005, 544411
412161	*	*	*	-	-	-	Feed Lifting Eccentric Fork with 223655, 549075
412213	*	*	*	-	-	-	Feed Driving Rock Shaft
508304	*	*	*	*	*	*	Feed Driving Rock Shaft Bushing (front)
508327	*	*	*	*	*	*	Feed Driving Rock Shaft Stop Collar (2) with 154780 (2)
543804-005	*	*	*	*	*	*	Feed Lifting Eccentric Fork Screw Washer
544329	*	*	*	*	*	*	Feed Lifting Eccentric Set Screw
544399	*	*	*	*	*	*	Feed Dog Screw (2)
544411	*	*	*	*	*	*	Feed Lifting Eccentric Fork Screw
545154	*	*	*	*	*	*	Feed Driving Rock Frame Pinch Screw (2)
545405	*	*	*	*	*	*	Feed Bar Hinge Screw Nut
549075	*	*	*	*	*	*	Feed Lifting Eccentric Fork Oiling Felt Screw




No.	212U141 442 211U157 165 166 566	Description
202337	* * * - - -	Presser Bar Position Guide
202401	* * * - - -	Take-up Lever Oiling Felt
202671	* * * - - -	Presser Bar Lifter
206608	* * * - - -	Presser Bar Lifting Releasing Lever Bracket Spring
207072	* * * - - -	Presser Bar Bushing (upper)
240067	* * * * * *	Knee Lifter Connection Lever
240564	* * * * * *	Knee Lifter Connection Lever Lifting Rod
267238	* * * - - -	Presser Bar Lifting Releasing Lever Bracket
267251	* * * * * *	Presser Bar Spring (flat)
267289	* * * * * *	Knee Lifter Lifting Lever Spring
412102	* * * * * *	Presser Bar with 500256
411120	* * * * * *	Knee Lifter Connection Lifting Rod Stop Collar with 545205-452
412145	* * * - - -	Presser Bar Spring Bracket with 545295
412146	* * * - - -	Presser Bar Position Guide Lever with 545295
412154	* * * - - -	Knee Lifter Lifting Lever
412228	* * * - - -	Presser Bar Bushing (upper)
500256	* * * * * *	Presser Bar Screw
544341	* * * * * *	Knee Lifter Connection Lever Hinge Screw
544345	* * * * * *	Presser Bar Lifter Hinge Screw
544357	* * * * * *	Presser Bar Spring Regulating Screw
544362	* * * * * *	Knee Lifter Lifting Lever Hinge Screw
544373	* * * - - -	Knee Lifter Lifting Lever Spring Stop Screw
544375	* * * - - -	Presser Bar Lifting Releasing Lever Bracket Guide Screw
544384	* * * * * *	Presser Bar Spring Support Screw
545114	* * * - - -	Take-up Lever Oiling Felt Screw
545205-452	* * * * * *	Knee Lifter Connection Lever Lifting Rod Stop Collar Set Screw
545295	* * * - - -	Presser Bar Position Guide Lever Pinch Screw
545295	* * * - - -	Presser Bar Spring Bracket Pinch Screw
545370	* * * - - -	Presser Bar Position Guide Set Screw
545370	* * * - - -	Presser Bushing Set Screw (upper)
545370	* * * - - -	Presser Bar Bushing Set Screw (lower)





No.	212U141	442	211U157	165	166	566	Description
225585	*	*	*	*	*	*	Hook Saddle Screw Washer
244084	*	*	*	-	-	*	Hook Saddle Regulating Screw Check Screw Packing
267053	*	*	*	-	-	*	Hook Ball Bearing
267139	*	*	*	-	-	*	Pinch Sleeve (lower)
267200	*	*	*	-	-	*	Hook Saddle Oil Reservoir
267212	*	*	*	-	-	*	Hook Saddle Oil Reservoir Gasket
267351	*	*	*	-	-	-	Bobbin Case Opener
267370	*	*	*	-	-	*	Bobbin Case Opener Driving Cam Shaft Bushing (lower)
267371	*	*	*	-	-	*	Bobbin Case Opener Driving Cam Shaft Bushing (upper)
271808	*	*	*	-	-	-	Hook Shaft Oil Filter Felt Holder Seal
412112	*	*	*	-	-	*	Bobbin Case Opener Cam Shaft
412113	*	*	*	-	-	*	Bobbin Case Opener Driving Cam Shaft Gear (spiral) with 544366 (2)
412115	*	*	*	-	-	*	Pinch Sleeve (upper)
412124	*	*	*	-	-	*	Hook Saddle (right) with 267370, 267371, 412236-900 512727, 514165, 514166, 545080
412156	*	*	*	-	-	-	Hook Saddle (right) complete 244084, 267053, 267200, 267212, 412112, 412113, 412124, 412157, 412158, 412168, 412206, 504010-452(2), 514171, 514173(2), 514213, 544346 (2), 544356 (2), 544358 (3), 544367, 544379 (8)
412157	*	*	*	-	-	-	Hook Shaft with 271808, 502928, 544320
412158	*	*	*	-	-	-	Bobbin Case Opener Crank
412168	*	*	*	-	-	-	Bobbin Case Opener Crank Hinge Stud
412206	*	*	*	-	-	-	Hook Driving Pinion (spiral) with 544366 (2)
412236-900	*	*	*	-	-	*	Hook Saddle Oil Gauge Sleeve
412237	*	*	*	-	-	*	Hook Saddle Oil Gauge
502928	*	*	*	-	-	-	Hook Shaft Oil Filter Felt
504010-452	*	*	*	-	-	*	Hook Ball Bearing Retaining Screw (2)
512727	*	*	*	-	-	*	Hook Saddle Oil Wick
514165	*	*	*	-	-	*	Hook Saddle Foam Cushion
514166	*	*	*	-	-	*	Hook Shaft Bushing
514171	*	*	*	-	-	*	Hook Saddle Cover Plate
514173	*	*	*	-	-	*	Hook Ball Bearing Retainer (2)
514213	*	*	*	-	-	*	Bobbin Case Opener Link
544320	*	*	*	-	-	-	Hook Shaft Oil Filter Holder
544334	*	*	*	*	*	*	Hook Saddle Screw
544346	*	*	*	-	-	*	Hook Saddle Cover Plate Screw (2)
544356	*	*	*	-	-	*	Bobbin Case Opener Crank Cap Screw
544356	*	*	*	-	-	*	Bobbin Case Opener Link Cap Screw
544358	*	*	*	-	-	*	Hook Saddle Oil Regulating Screw Check Screw
544358	*	*	*	-	-	*	Bobbin Case Opener Crank Hinge Stud Set Screw
544358	*	*	*	-	-	*	Bobbin Case Opener Crank Hinge Stud Set Screw Check Screw
544364	*	*	*	-	-	*	Pinch Sleeve Screw
544366	*	*	*	-	-	*	Bobbin Case Opener Driving Cam Shaft Gear (spiral) Set Screw (2)
544366	*	*	*	-	-	*	Hook Driving Pinion (spiral) Set Screw (2)
544367	*	*	*	-	-	*	Hook Saddle Oil Regulating Screw
544379	*	*	*	-	-	*	Hook Saddle Oil Reservoir Screw (8)
545080	*	*	*	-	-	*	Hook Saddle Oil Stop Screw
549027	*	*	*	*	*	*	Bobbin Case Opener Screw





No.	212U141 442 211U157 165 166 566	Description
140434	* * * - - -	Hook Set Screw (2)
200591	* * * - - -	Hook Thread Guard Screw (2)
200594	* * * * * -	Bobbin Case Tension Spring Screw
200984	- - * * * -	Bobbin Case Tension Spring Regulating Screw
201253	* * * - - -	Hook Gib Screw (2)
201409	* * * * * -	Hook Needle Guard Screw (2)
202056	* * * * * -	Bobbin Case Latch Pin
203214	- - * * * -	Bobbin Case Tension Spring
203216	* * * * * -	Bobbin Case Washer (cloth)
203473	* * * * * -	Bobbin Case Latch Plunger
203474	* * * * * -	Bobbin Case Latch Spring
203648	* * * * * -	Bobbin Case Latch
235099	- - * - - -	Bobbin Case Body
235100	- - * - - -	Bobbin Case Body complete 200594, 200984, 202056, 203214, 203216, 203473, 203474, 203648, 235099, 241674, 241675, 350405 (2)
241674	- - * * * -	Bobbin Case Oiling Felt
241675	- - * * * -	Bobbin Case Oiling Felt Retainer
244711	- - * - - -	Hook and Bobbin Case with 235100, 267356
244750	* * * * * -	Bobbin
267355	* * * - - -	Hook (sewing) with 140434
267356	* * * - - -	Hook complete 200591 (2), 201253 (2), 201409 (2), 267355, 267358, 267359, 267360, 350574
267358	* * * - - -	Hook Gib
267359	* * * - - -	Hook Needle Guard
267360	* * * - - -	Hook Thread Guard
350405	- - * * * -	Bobbin Case Oiling Felt Retainer Screw (2)
350574	* * * - - -	Hook Hight Adjusting Screw




No.	212U141	442	211U157	165	166	566	Description
223438	-	-	*	*	*	*	Tension Spring
223703	*	*	*	*	*	*	Tension Release Lever
223704	*	*	*	*	*	*	Tension Release Plunger
236060	*	*	*	*	*	*	Tension Disc Position Pin
241765	-	-	*	*	*	*	Thread Lubricator Oil Pad (felt)
244729	-	-	*	*	*	*	Thread Retainer
263554	-	-	*	*	*	*	Thread Lubricator Oil Pad Holder
267262	-	-	*	*	*	*	Feed Driving Rock Shaft Bushing Oil Tube Wick
267265	*	*	*	*	*	*	Tension Release Lever Rod
267293	*	*	*	*	*	*	Bed Oil Tube Clamp
267316	*	*	*	*	*	*	Thread Guide
267322	*	*	*	*	*	*	Bed Oil Supply Tube Oil Wick
267368	*	*	*	*	*	*	Thread Controller Spring
267411	*	*	*	*	*	*	Feed Driving Rock Shaft Bushing Oil Tube Wick
412030	-	-	*	*	*	*	Tension Bracket with 236060
412043	-	-	*	*	*	*	Tension Bracket complete 223438, 223703, 223704, 267368, 412030, 412103, 412201, 412202, 412203, 412204, 541187 (2), 544343 (2), 544354 (2)
412044	-	-	*	*	*	*	Thread Lubricator Oil Pad Holder complete 241765, 263554, 412045, 544337 (2)
412045	-	-	*	*	*	*	Thread Lubricator Plate
412091	*	*	*	*	*	*	Tension Stud
412103	*	*	*	*	*	*	Thread Controller Stud
412200	*	*	*	*	*	*	Tension Release Lever Spring
412201	*	*	*	*	*	*	Thread Controller Spring Stop
412202	*	*	*	*	*	*	Thread Controller Disc
412203	*	*	*	*	*	*	Tension Disc (2)
412204	*	*	*	*	*	*	Tension Release Washer
508282	*	*	*	*	*	*	Bed Oil Tube Clamp Oiling Felt
508317	-	-	*	*	*	*	Feed Driving Rock Shaft Bushing Oil Tube with 267411
508319	-	-	*	*	*	*	Feed Driving Rock Shaft Bushing Oil Tube with 267262
508321	-	-	*	*	*	*	Hook Driving Shaft Bearing Left Oil Tube with 508323
508323	-	-	*	*	*	*	Hook Driving Shaft Bearing Left Oil Tube Wick
508324	-	-	*	*	*	*	Hook Saddle Bearing Oil Tube with 508332
508330	-	-	*	*	*	*	Bed Oil Supply Tube with 267322
508332	-	-	*	*	*	*	Hook Saddle Bearing Oil Tube Wick
508333	-	-	*	*	*	*	Feed Driving Eccentric Connection Oil Tube with 508335
508335	-	-	*	*	*	*	Feed Driving Eccentric Connection Oil Tube Wick
514117	*	*	*	*	*	*	Bed Oil Tube Clamp
541187	*	*	*	*	*	*	Tension Thumb Nut (2)
544337	-	-	*	*	*	*	Thread Lubricator Oil Pad Holder Screw (2)
544343	*	*	*	*	*	*	Tension Release Lever Hinge Stud (2)
544347	-	-	*	*	*	*	Thread Lubricator Plate Screw (2)
544347	*	*	*	*	*	*	Thread Guide Screw
544352	*	*	*	*	*	*	Bed Oil Tube Clamp Screw
544354	-	-	*	*	*	*	Thread Controller Disc Screw
549168	*	*	*	*	*	*	Thread Retainer Screw
549339	*	*	*	*	*	*	Tension Controller Stud Set Screw




No.	212U141 142 211U157 165 166 566	Description
691	* * * - * *	Feed Reversing Lever Guide Roller Position Plate Screw (2)
201829	* * * - * *	Feed Reversing Lever Guide Roller
244071	* * * - * *	Feed Driving Eccentric Connection Link Hinge Pin Oil Packing (Wick)
255168	* * * - * *	Bed Oil Cup (2)
267406	* * * - * *	Feed Driving Eccentric Connection Link
267415	* * * - * *	Feed Reversing Lever Spring
276046	* * * - * *	Feed Reversing Shaft Crank Hinge Stud Oil Packing (Wick)
276160	* * * - * *	Feed Reversing Lever Handle
276171	* * * - * *	Feed Driving Eccentric Connection Link Hinge Pin with 244071
276174	* * * - * *	Feed Reversing Mechanism Support Link Stud
412075	* * * - * -	Reverse Feed complete 267406, 276171, 412076, 412077, 412078, 412079, 508341, 544365, 545425-451
412076	* * * - * -	Feed Reversing Shaft Crank Link with 544409
412077	* * * - * -	Feed Reversing Shaft Crank with 544335, 544409
412078	* * * - * *	Feed Driving Rock Shaft Crank with 545139
412079	* * * - * -	Feed Reversing Mechanism Support Link with 544409
412080	* * * - * *	Feed Reversing Lever Spring Collar with 544412 (2)
412081	* * * - * *	Feed Reversing Shaft complete 412082, 544336
412082	* * * - * *	Feed Reversing Shaft
412083	* * * - * *	Feed Reversing Lever Guide Roller Position Plate
412107	* * * - * *	Feed Reversing Lever
412108	- - * - * *	Feed Reversing Shaft Driving Stud
508341	* * * - * *	Feed Reversing Shaft Crank Hinge Stud complete 276046, 514092
514092	* * * - * *	Feed Reversing Shaft Crank Hinge Stud
541186	* * * - * *	Feed Reversing Lever Handle Screw Nut
544321	* * * - * *	Feed Reversing Mechanism Support Link Stud Set Screw
544335	* * * - * *	Feed Reversing Shaft Crank Pinch Screw
544336	* * * - * *	Feed Reversing Shaft Driving Stud Pinch Screw
544340	* * * - * *	Feed Reversing Lever Hinge Screw
544342	* * * - * *	Feed Reversing Lever Guide Roller Screw Stud
544348	* * * - * *	Feed Reversing Lever Handle Screw
544365	* * * - * *	Feed Driving Rock Shaft Crank Hinge Screw
544409	* * * - * *	Feed Reversing Shaft Crank Hinge Stud Set Screw
544409	* * * - * *	Feed Driving Eccentric Connection Link Hinge Pin Set Screw
544409	* * * - * *	Feed Reversing Shaft Crank Hinge Stud Set Screw
544412	* * * - * *	Feed Reversing Lever Spring Collar Set Screw (2)
545139	* * * - * *	Feed Driving Rock Shaft Crank Pinch Screw
545425-451	* * * - * *	Feed Driving Rock Shaft Crank Hinge Screw Nut



No.	212U141 442 211U157 165 166 566	Description
691	* * * * *	Throat Plate Screw (2)
203013-900	- - * - - -	Presser Foot Plate
215911-900	- - * - - -	Presser Foot Shank
229882	- - * - - -	Presser Foot (Hinged) complete 203013-900, 215911-900 503979-040
240004	- - * * * *	Bed Slide (front)
412106	- - * * * *	Bed Slide (back)
503884	- - * - - -	Throat Plate
503979-040	- - * - - -	Presser Foot Hinge Pin



No.	212U141 442 211U157 165 166 566	Description
411125	* * * * *	Thread Unwinder Foot With 504029
411127	* * * * *	Thread Unwinder Rod (2)
411129	* * * * *	Thread Unwinder Rod Connection Complete 411130, 541183, 544218-056
411130	* * * * *	Thread Unwinder Rod Connection (2)
411133	* * * * *	Thread Unwinder Rod Cap
411134	* * * * *	Thread Unwinder Spool (3)
411138	* * * * *	Thread Unwinder Spool Carrier Plate (3)
411139	* * * * *	Thread Unwinder Spool Cushion (3)
411143	* * * * *	Thread Unwinder Thread Guide Bushing (3)
412069	* * * * *	Thread Unwinder Complete 411125, 411127, 411129, 411133, 411138, 411139, 412070, 412071, 544112, 546893
412070	* * * * *	Thread Unwinder Spool Carrier Arm With 541166-001, 543805-004, 544278-061
412071	* * * * *	Thread Unwinder Thread Guide With 411143, 541166-001, 543805-004, 544278-061
412198	* * * * *	Thread Unwinder Spool Carrier Arm Holder Plate
504029	* * * * *	Thread Unwinder Rod Set Screw (2)
541166-004	* * * * *	Thread Unwinder Spool Nut (3)
541166-004	* * * * *	Thread Unwinder Spool Carrier Arm Screw Nut
541166-004	* * * * *	Thread Unwinder Thread Guide Nut
541183	* * * * *	Thread Unwinder Rod Connection Screw Nut (2)
543803-007	* * * * *	Thread Unwinder Spool Washer (3)
543805-004	* * * * *	Thread Unwinder Spool Spring Washer (3)
543805-004	* * * * *	Thread Unwinder Spool Carrier Arm Screw Spring Washer
543805-004	* * * * *	Thread Unwinder Thread Guide Spring Washer (3)
544112	* * * * *	Thread Unwinder Wood Screw (3)
544112	* * * * *	Thread Unwinder Spool Carrier Arm Holder Plate Wood Screw
544218-056	* * * * *	Thread Unwinder Rod Connection Screw (2)
544278-061	* * * * *	Thread Unwinder Spool Carrier Arm Screw
544278-061	* * * * *	Thread Unwinder Thread Guide Screw
546893	* * * * *	Thread Unwinder Spool Holder (3)



No.	212U141 442 211U157 165 166 566	Description
224411	* * * * *	Knee Lifter Connection Lever Lifting Rod Roller
228363	* * * * *	Knee Lifter Rock Lever Hinge Pin
228365	* * * * *	Knee Lifter Rock Lever Rod
228367	* * * * *	Knee Lifter Rock Lever Stop Stud
228386	* * * * *	Knee Lifter Rock Lever Spring
228388	* * * * *	Knee Lifter Rock Lever Knee Plate Arm
228455	* * * * *	Knee Lifter Rock Lever Position Spring
412049	* * * * *	Wood Screw (7/8 Inch, No. 12) (3)
412061	* * * * *	Knee Lifter Rock Lever Complete 228365, 228388, 412049 (3), 412062, 412065, 412066
412062	* * * * *	Knee Lifter Rock Lever Bracket Complete 228363, 228367, 228386, 228455, 412063, 412064
412063	* * * * *	Knee Lifter Rock Lever With 504105 (2)
412064	* * * * *	Knee Lifter Rock Lever Bracket With 544395
412065	* * * * *	Knee Lifter Rock Lever Knee Plate With 504105
412066	* * * * *	Knee Lifter Rock Lever Extension With 544396
412067	* * * * *	Knee Lifter Connection Lever Lifting Rod Roller Complete 224411, 412068, 544355
412068	* * * * *	Knee Lifter Connection Lever Lifting Rod Roller Bracket With 549104
504105	* * * * *	Knee Lifter Rock Lever Extension Set Screw
504105	* * * * *	Knee Lifter Rock Lever Knee Plate Arm Set Screw
504105	* * * * *	Knee Lifter Rock Lever Knee Plate Set Screw
544355	* * * * *	Knee Lifter Connection Lever Lifting Rod Roller Hinge Screw
544395	* * * * *	Knee Lifter Rock Lever Stop Stud Set Screw
544396	* * * * *	Knee Lifter Rock Lever Rod Set Screw
549104	* * * * *	Knee Lifter Connection Lever Lifting Rod Roller Pinch Screw


1901-19




244750




548701




541514




503929




511606










503933



350708




No.	212U141 441 211U157 165 166 566	Description
1901-19 244750 350708 503929 503933 511606 541514 548701	- - * - - - * * * * * - *	Needle (135 x 7 #19) (5) Bobbin (4) Drip Pan Screw Nail (7) Knee Lifter Base Drip Pan Knee Lifter Base Wood Screw (3) Screw Driver (small) Screw Driver (long)



No.	212U141 442 211U157 165 166 566	Description
41400	* * * * *	Machine Rest Pin (Wood)
411109	* * * * *	Machine Grounding Wire
412170	* * * * *	Wrench
412181	* * * - - -	Oiler (250 cc, C-Type)
503646	* * * * *	Wrench (3/32 inch, Hexagon)
543805-003	* * * * *	Machine Grounding Wire Lock Washer
544361	- - * * * *	Bed Slide Thumb Screw
545295	* * * * *	Attachment Screw (small)
545926	- - * * * *	Machine Hinge Connection (2)

OPTIONAL PARTS



No.	212U141 442 211U157 165 166 566	Description
412215 412216 412217 412218 412219 412220 544085 544217-001 544217-001 544217-004 549184	* *	<u>OPTION</u> Belt Guard Cpl. 412216, 412217, 412218 (2), 412219, 412220, 544085 (2), 544217-001 (7), 544217-004. Belt Guard Belt Guard Plate Belt Guard Screw Stud (2) Belt Guard (lower) with 549184 Belt Guard Screw Collar Belt Guard (lower) Wood Screw (2) Belt Guard Screw (3) Belt Guard Plate Screw (4) Belt Guard Screw (long) Belt Guard (lower) Thumb Screw

Form U 3220 (781)
Part No. 543227-002
Printed in Japan