

CLINTON SERVICE GUIDE

MODEL 115VS-FOTA-KS FOR JUKI MS191,1190,1190M



CUTTER ASSEMBLY




NOTES:

- 1. REMOVE EXISTING FACE PLATE AND RETAP (3) HOLES WITH DRILL NO.21 (30-2130-21) AND TAP 10-32 (30-1875-01) SUPPLIED.
- 2. MOUNT VERTICAL SHEAR CUTTER WITH (3) SCREWS 33-3210-10.
- 3. USING HOLES MARKED "A" AS A GUIDE, DRILL (2) HOLES 3/16" DIAMETER BY 3/16" DEEP. 3/16" DRILL (30-2376-12) SUPPLIED.
- 4. INSERT DOWEL PINS (1) 33-3712-08 UPPER SIDE, AND (1) 33-3712-16 LOWER SIDE.





Clinton Industries, Inc.
700 Washington Ave.
Carlstadt, N.J. 07072
Phone: 201-935-4242
Fax: 201-935-3615
www.clintonind.com
E-mail: general@clintonind.com



INSTALLATION INSTRUCTIONS

WARNING!! TO PREVENT SERIOUS INJURY, DISCONNECT AIR SUPPLY BEFORE MAKING ANY ADJUSTMENTS.





From the library of: Superior Sewing Machine & Supply LLC