Catalog No. 63 L

LIST OF PARTS

Styles in Classes

8400 8800 8500 8900 8600 9100

The parts listed in this catalog are furnished at list prices for repairs only

First Edition
Price \$2.00

Copyright 1938
By
Union Special Machine Co.
Rights Reserved In All Countries

Union Special Machine Company Chicago U.S.A.

Printed in U.S.A.

## OFFICES, SERVICE STATIONS, FOREIGN DISTRIBUTORS

\* CHICAGO, ILL. Union Special Machine Co., 404 N. Franklin St. Main Office and Factory. T. S. Whitsel, Gen. Sales Mgr. J. W. McLain, Asst. Gen. Sales Mgr. L. C. Morris, Foreign Sales Mgr. A. E. Brauch, District Sales Mgr. T. C. Wiebers, Office

Mgr. Tel. Superior 6920.
ALLENTOWN, PA. 1749 Turner St.
P. O. Box 1253. W. L. Johnson. Tel.

2.9474

\*ATLANTA, GA. 155 Spring St. P. T. McLendon, Mgr. Tel. Main 3377. BALTIMORE, MD. 17 Guilford Ave. H.

A. McGwier. Tel. Plaza 8499.

\*\*BOSTON, MASS. 210 Lincoln St. C. E. Stevens, Mgr. Tel. Liberty 0148.

\*\*CINCINNATI, O. 422 Temple Bar Bldg. W. E. LeRoy, Mgr. Tel. Parkway 2521.

CLEVELAND, O. 308 Marion Bldg. K. D.

Bear. Tel. Main 9657 DETROIT, MICH. 2725 Boston Blvd. W. J. F. Livingston. Tel. Tyler 6-4118.

WORTH, TEX. 912 Morningside Drive. H. M. Petershagen. Tel. 4-7776. GREENSBORO, N. C. 402 S. Mendenhall

St. L. F. McGwier. Tel 6301. GREENVILLE, S. C. 405 Masonic Temple

Bldg. F. E. Hodtum. Tel. 1269.

JOHNSON CITY, N. Y. 49 Cherry St.

Wm. Browne. Tel. 7-3179.

KANSAS CITY, MO. 5014 College Ave.

T. O. Biggers. Tel. Wabash 6966. LOS ANGELES CAL. 1303 So. Main St.

C. E. Downs. Tel. Prospect 5636.

MINNEAPOLIS, MINN. 3608 27th Ave.
S. R. W. Bredahl. Tel. Drexel 3331.

MONTREAL, Que. Blvd. St. Laurent at
Prince Arthur. S. J. Storey. Tel. LA 7944.

NASHVILLE, TENN. Observatory Drive. W. J. Brauch. Tel. 7-3984.

W. J. Brauch. 1et. 73964.

NEWARK, N. J. 60 Park Place. H. K.
Lanning. Tel. Market 3·3123.

NEW HAVEN, CONN. 120 Highland
Ave., West Haven. E. W. Losty.

NEW ORLEANS, LA. 202 Godchaux
Bldg. H. A. Sims. Tel. Raymond 8137.

★ NEW YORK, N. Y. 116 E. 27th St. Wm.
Bleicher, Mgr. Tel. Murray Hill 4·4665

or 4-4666.

★ PHILADELPHIA, PA. 401 N. Broad St. T. M. Murphey, Mgr. Tel. (Bell) Walnut

3131, (Key.) Race-1078.
PITTSBURGH, PA. 247 Dilworth St. C.
L. Cunningham. Tel. Hemlock 4061.
POTTSVILLE, PA. 20 South Center St.
L. J. Perrin. Tel. 2508-J.

\*ST. LOUIS, MO. 1127 Pine St. E. E. Gratsch, Mgr. Tel. Main 1776.

★ SAN FRANCISCO, CAL. 371 4th St. J. M. Biddle, Mgr. Tel. Garfield 7999. SEATTLE WASH. 615 Terminal Sales Bldg. O. L. Atchison. Tel. Main 3864. ★ TORONTO, ONT. 137 Wellington St. W. G. A. Rundle, Mgr. Tel. Adelaide

2909.

UTICA, N. Y. 329 Jay St. P. J. Steeper, Mgr. Tel. 4-6422.

WATERFORD, N. Y. 22 Fourth St. A. J.

Brown. Tel. 467. WINNIPEG: MAN: 1065 Dominion St. Walter Baldwin. Tel. 24244.

YORK, PA. 837 Florida Ave. Wm. Denholm. Tel. 64196.

### **OVERSEAS**

AFRICA—Capetown, Durban, Johannes-burg, Port Elizabeth, South Africa. Port Louis, Mauritius.

ASIA-Hong Kong, Shanghai, and Tientsin, China, Bombay and Calcutta, India. Osaka and Tokyo, Japan. Manila, P. I.

Brisbane, AUSTRALIA -Melbourne, Perth, Sydney.

EUROPE-Vienna, Austria. Brussels, Belgium. Copenhagen, Denmark. Leicester and London, England. Helsingfors, Fin-land. Paris and Lyons, France. Berlin, Chemnitz, Ebingen, Erfurt, Frankfurt am Main, Koln, Stuttgart, Germany. Milan, Main, Koln, Stuttgart, Germany, Milan, Italy. Oslo, Norway. Oporto, Portugal.

Dundee and Glasgow, Scotland. Barcelona, Spain. Boras and Stockholm, Sweden. Zurich, Switzerland.

NEW ZEALAND — Auckland, Christ church, Dunedin, Wellington.

NORTH AMERICA — Havana, Cuba.

Mexico City and Monterey, Mexico. Ja-maica, B. W. I. San Juan, P. R. PACIFIC ISLANDS—Honolulu, Hawaii.

Sourabaya, Java.

SOUTH AMERICA—Buenos Aires, Argentina. Porto Alegre, Sao Paulo, Recife, Brazil. Santiago, Chili. Barranquilla, Bo-gota, Medellin, Colombia. Guayaquil, Ecuador. Lima, Peru. Montevideo, Uru-guay. Caracas, Venezuela.

\*MAIN OFFICES

#### FOREWORD

The one dominating idea back of "Union Special" is to build the best industrial sewing machines in the world.

All parts are made to gauges with exceedingly close limits. Repairs can be made with facility as all parts are readily accessible, and are 100% interchangeable.

It is our constant aim to furnish carefully prepared information that will enable the customer to secure all possible economies and advantages from the use of Union Specials. On the pages which follow will be found illustrations and descriptions of the parts for styles in Classes 8400, 8500, 8600, 8800, 8900, 9100.

Additional catalogs, containing information relative to these machines, and which will be furnished on request, are listed below.

Catalog No. 29 Catalog No. 45

Catalog No. 45 A Form 357 List of Transmitter Parts List and Description of Needles

Price List of Needles
Engineering Department Adjusting Instructions. Specify the
Style number of the machine
for which the Adjusting Instructions are required

In all manufacturing centers will be found Union Special representatives, who will co-operate with those who desire in planning and estimating their requirements.

UNION SPECIAL MACHINE COMPANY

Engineering Department

#### IDENTIFICATION OF MACHINES

Each Union Special carries a style number which is stamped in the name plate on the machine. Style numbers are classified as standard and special. Those which are standard have one or more letters suffixed, but never contain the letter "Z". Example: 8500 A. Style numbers containing the letter "Z" are special. When only minor changes are made in a standard machine a "Z" is merely suffixed to the respective standard style number. Example: 8500 AZ.

Styles of machines similar in construction are grouped under a class number which differs from the style numbers

in that it contains no letters. Example: 8500.

The distance between the rows of stitches is represented by a gauge number. Those which apply to machines described in this catalog are as follows:

No.	1	gauge	represents	3/32 inch
No.	2	gauge	represents	1/8 inch
No.	3	gauge	represents	5/32 inch
No.	4	gauge	represents	3/16 inch
No.	4 1/4	gauge	represents	7/32 inch
No.	4 1/2	gauge	represents	1/4 inch
No.	5	gauge	represents	9/32 inch
No.	5 1/4	gauge	represents	21/64 inch
No.	5 1/2	gauge	represents	3/8 inch
No.	6	gauge	represents	13/32 inch

On Styles in Classes 8900 and 9100 this gauge represents the distance between the two inside rows of stitches.

### APPLICATION OF CATALOG

This catalog applies only to the standard styles of machines as listed herein. It can also be applied with discretion to the special machines covered by these classes.

### STYLES OF MACHINES IN CLASS 8400

Flat Bed Two Needle Machines, Needles Abreast, One Looper, Four Motion Loop Retainer, Two Needle Double Locked Stitch Type 402

8400 A For staying shoes, hinged bottom presser foot, Type 501 needles, standard gauges 1, 2, 3 and 4.

8400 B For cording shoes and other leather work, without cord, Type 501 needles, standard gauge No. 1.

8400 Z A special style similar to the standard styles in Class 8400 but differing in one or more of its component parts.

### STYLES OF MACHINES IN CLASS 8500

- Flat Bed Two Needle Machines, For Leather Work, Needles Abreast, One Looper, Stationary Loop Retainer, Two Needle Double Locked Stitch Type 402
- 8500 A For light and medium weight shoe work; vamping, foxing, eyelet row stitching, panel stitching, tipping and similar operations, rolling presser foot, Types 601, 602, 603, 604, 605, 606, 607 and 608 needles set with the flats adjacent, standard diameter of rollers, 13/16, 1 1/8, 1 5/16, or 1 3/4 inches.
- 8500 K For extra light weight shoe work; otherwise same as 8500 A
- 8500 Z A special style similar to the standard styles in Class 8500, but differing in one or more of its component parts

#### STYLES OF MACHINES IN CLASS 8600

- Flat Bed Two Needle Machines, For Cloth Work, Needles Abreast, One Looper, Stationary Loop Retainer, Two Needle Double Locked Stitch Type 402
- 8600 C For cording operations on light weight cloth, with cord, width of needle seat .160 inch, Type 101 needles.
- 8600 D For cording operations on medium weight cloth, without cord; width of needle seat .160 inch, Type 101 needles, standard heights of tucks 1/32, 3/64, 1/16, 3/32 and 1/8 inch.
- 8600 U For cording operations on heavy weight cloth, without cord, width of needle seat .160 inch, Types 207 and 208 needles, set with the arcs adjacent standard heights of tucks 1/32, 3/64, 1/16, 3/32 and 1/8 inch.
- 8600 V For cording operations on light weight silk and similar fabric, without cord, width of needle seat .160 inch, Types 207, 208, 211 and 212 needles, set with the flats adjacent, standard heights of tucks 1/32, 3/64, 1/16 and 3/32 inch.
- 8600 Y For cording operations on side walls of mattress ticks with cord approximately 1/16 inch diameter; width of needle seat .160 inch, Type 106 needles.
- 8600 Z A special style similar to the standard Styles in Class 8600 but differing in one or more of its component parts.

#### STYLES OF MACHINES IN CLASS 8800

- Flat Bed Three Needle Machines, Needles Abreast, One Looper, Three Needle Double Locked Stitch Type 403
- 8800 A For eyelet row and panel stitching on shoes; equal space, four motion loop retainer, one .048 double slab shank needle between two single slab shank, Types 403, 404 and 440 needles, rolling presser foot, standard diameter of roller 13/16 or 1 1/8 inches.
- 8800 Z A special style similar to the standard styles in Class 8800, but differing in one or more of its component parts.

## STYLES OF MACHINES IN CLASS 8900

- Flat Bed Four and Six Needle Machines, Two Loopers, Left Set of Needles in Front, 3/16 Inch Space Between Needles in Line with Feed
- 8900 A For attaching tips to shoes; stitch Type 402, four needles, wide middle space, .056 to .068 inch single slabbed shank needles Types 601, 602, 603, 604, 605, 606, 607 and 608, flat presser foot with adjustable guide on the left side, standard gauges Nos. 1, 2, 3, 4, 4 1/4, 4 1/2, 5, 5 1/4, 5 1/2 and 6.
- 8900 B For attaching tips to shoes; with adjustable guide on right side of presser foot, otherwise same as 8900 A.
- 8900 C For attaching tips to shoes; stitch Type 403, six needles, wide middle space, .056 and .068 inch single slabbed shank and .048 inch double slabbed shank needles Types 401, 402, 403, 404, 405, 406, 407, 408 and 440, flat presser foot with adjustable guide on left side, double groove machine pulley, standard gauges Nos. 1, 2, 3, 4, 4 1/4, 4 1/2, 5, 5 1/4, 5 1/2 and 6.
- 8900 J For attaching single corded tips to shoes; stitch Type 402, four needles, wide middle space, .056 to .068 inch single slabbed shank needles Types 601, 602, 603, 604, 605, 606, 607 and 608, flat presser foot with adjustable guide on left side, standard gauge No. 1 for cord 3/64 inch diameter.

### STYLES OF MACHINES IN CLASS 8900 (Cont'd)

- 8900 L For attaching single corded tips to shoes; stitch Type 403, six needles, wide middle space, .056 to .068 inch single slabbed shank and .048 inch double slabbe shank needles Types 401, 402, 403, 404, 405, 406, 407, 408 and 440, flat presser foot with adjustable guide on left side, double groove machine pulley, standard gauges No. 1 for cord 3/64 inch diameter and No. 2 for cord 3/32 inch diameter.
- 8900 Z A special machine similar to the standard styles in Class 8900 but differing in one or more of its component parts.

### STYLES OF MACHINES IN CLASS 9100

- Flat Bed Four Needle Machines, Two Loopers, Right Set of Needles in Front, 1/8 Inch Space Between Needles in Line with Feed, Double Locked Stitch Type 402
- 9100 C For vamping, foxing, eyelet row stitching, panel stitching and similar operations on shoes; wide middle space, rolling presser foot, .056 to .068 inch single slabbed shank needles Types 601, 602, 603, 604, 605, 606, 607 and 608, standard gauges Nos. 1, 2, 3 and 4, diameter of roller 13/16, 1 1/8, 1 5/16 or 1 3/4 inches.
- 9100 Z A special machine similar to the standard styles in Class 9100 but differing in one or more of its component parts.

#### NEEDLES

#### TYPE NUMBERS AND SIZES

Each needle has a type number and size number. The former denotes the kind of shank, point, length, groove, finish, and other details. The latter denotes the largest diameter of the blade, measured in thousandths of an inch midway between the shank and eye, and is stamped in the needle shank. On the slabbed shank needles the thickness in thousandths of an inch will also be found stamped in the needle shank. Collectively the type number and size number is the complete symbol.

To have orders promptly and accurately filled, the empty package, a sample needle, or the type and size numbers should be given. See marks on packages. An intelligent order would read as follows: "1000 Needles Type 605, Size .036".

#### NEEDLES

TYPE NUMBERS AND SIZES (Cont'd)

Machine

The limitations of the blade sizes of single slabbed shank needles with respect to the slab sizes are set up below:

```
Slab .056 inch - maximum blade size 032
" .060 " - " " " " 040
" .064 " - " " " " 046
" .068 " - " " " " 054
```

APPLICATION OF TYPE NUMBERS TO MACHINES

The standard type of needle applicable to each style is listed in the description of each style. The styles of machines covered by this catalog are listed below. Set opposite each style number is the type number or numbers of the needles generally used. Type numbers are arranged numerically, as the variety of materials sewed on each machine makes it impractical to show a preference. See Needle Catalog No. 45 and Needle Price List Catalog No. 45 A for description, sizes available and prices of these needles.

Type of Needles

Style	Type of Needles
8400 A 8400 B	301, 301 G, 501, 501 G, 701, 701 G, 901, 1101, 1301, 1501, 1701, 1701 G, 2101 Same as Style 8400 A
8500 A	401, 401 G, 402, 402 G, 403, 403 G, 404, 404 G, 405, 405 G, 406, 406 G, 407, 408, 415, 416, 601, 602, 603, 604, 605, 606, 607, 608, 801, 802, 803, 803 G, 804, 804 G, 805, 806, 807, 808, 815, 816, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1215, 1216, 1401, 1402, 1403, 1404, 1405, 1405 G, 1406, 1406 G, 1407, 1408, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1615, 1616, 1801, 1802, 1803, 1804, 1805, 1806, 1807, 1808, 1815, 1816, 2201, 2201 G, 2202, 2202 G, 2203, 2203 G.
8500 K 8600 C	2204, 2204 G, 2205, 2206 Same as Style 8500 A 101, 101 G, 104, 106, 106 G, 108, 108 G
8600 U	Same as Style 8600 C 207, 208, 215, 216
8600 V	207, 208, 211, 212, 215, 216, 217, 218
8600 Y	101, 101 G, 104, 106, 106 G, 108, 108 G
8800 A	403, 403 G. 404, 404 G. 1140 G. 803 803 G
	804, 804 G, 840, 1203, 1204, 1240, 1403, 1404,
	1440, 1603, 1604, 1640, 1803, 1804, 1840, 2203, 2203 G, 2204, 2204 G, 2240, 2210 G

#### NEEDLES

## APPLICATION OF TYPE NUMBERS TO MACHINES (Cont'd)

Machine Style

401, 401 G, 402, 402 G, 403, 403 G, 404, 404 G, 405, 405 G, 406, 406 G, 407, 408, 601, 602, 603, 604, 605, 606, 607, 608, 801, 802, 803, 803 G, 804, 804 G, 805, 806, 807, 808, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1401, 1402, 1403, 1404, 1405, 1405 G, 1406, 1406 G, 1407, 1408, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1801, 1802, 1803, 1804, 1805, 1806, 1807, 1808, 2201, 2201 G, 2202, 2202 G, 2203, 2203 G, 2201, 2201 G, 2205, 2206 8900 A 2203 G, 2204, 2204 G, 2205, 2206 Same as Style 8900 A 8900 B 401, 401 G, 402, 402 G, 403, 403 G, 404, 404 G, 405, 405 G, 406, 406 G, 407, 408, 440, 440 G, 801, 802, 803, 804, 805, 806, 807, 808, 840, 1201, 1202, 1203, 1204, 1205, 1206, 1207, 1208, 1240, 1401, 1402, 1403, 1404, 1405, 1406, 1407, 1408, 1440, 1601, 1602, 1603, 1604, 1605, 1606, 1607, 1608, 1640, 1801, 1802, 1803, 1804, 1805, 1806, 1807, 1808, 1840, 2201, 2201 G, 2202, 2202 G, 2203, 2203 G, 2204, 2204 G, 2205, 2206 8900 C 2202 G, 2203, 2203 G, 2204, 2204 G, 2205, 2206, 2240, 2240 G Same as Style 8900 A 8900 J Same as Style 8900 C 8900 L Same as Style 8900 A 9100 C ORDERING REPAIR PARTS

#### PLATES

Grouped, according to scale, will be found illustrations of parts similar in appearance, and, to some extent, component parts that go in the same subdivision of the mechanism. When a given design of part is made in two or more sizes, only one illustration is usually shown. In ordering these pieces, it is necessary that the additional information be furnished as requested under these illustrations.

#### LIST OF PARTS

Turning from the plates to the list of parts, the description of each part and its principal uses will be found. Always check the symbol against its description before ordering. It is not necessary to furnish the plate number. When a part is used, or can be used, in all machines covered by this catalog, no specific use is mentioned in the description.

### ORDERING REPAIR PARTS (Cont'd)

#### LIST OF PARTS (Cont'd)

For convenience in ordering, minor parts such as screws, nuts and similar articles are repeated after each major part.

(-) A dash in the "plate number" column of the list of

parts indicates the absence of an illustration.

(1) A double dagger in the "symbol to order by" column indicates that the component parts cannot be furnished separately.

#### IDENTIFYING PARTS

Where the construction permits, each part is stamped with its part number. Some of the smaller parts are stamped with an identification letter to distinguish them from parts similar in appearance.

All part numbers represent the same part, regardless of

the catalog in which they appear.

## SUPPLIES

All supplies, including taps, reamers, belting, belt hooks, belt fasteners, screw drivers, wrenches and powdered oil stone will be promptly furnished.

### USE GENUINE NEEDLES AND REPAIR PARTS


Success in the operation of these machines can be secured only by the use of genuine Union Special Needles and Repair Parts as furnished by the Union Special Machine Company, its subsidiaries and authorized distributors. Obviously, it is to our interest to maintain the reputation of Union Specials by furnishing the very best goods obtainable. They are designed according to the most approved scientific principles, and are made with the utmost precision. The maximum efficiency and durability are assured.

Genuine needles are put up in packages marked at the top "Trade 'UNION SPECIAL' mark". Genuine repair parts are stamped with a reproduction of the well known two padlocks with a link connecting the shackles. Both trade marks are symbolic of superlative excellence. All other needles and

parts are bogus.


#### TERMS

Prices are strictly "net cash" and subject to change without notice. All shipments are forwarded at the buyer's risk f.o.b. shipping point. Parcel post shipments are insured unless otherwise directed. A charge is made to cover the postage and insurance.




21394 Utility Grinder

## Plate 1 Full Size




112V


112VA




8524K




86244




8624 Specify Height of Tuck




8624K Specify Height of Tuck






8424 Specify Gauge

## Plate 2 Full Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 3 Full Size



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

## Plate 5 Full Size






8620K 8620U Specify Height Specify Height of Tuck of Tuck





8627D




From the library of: Superior Sewing Machine & Supply LLC

# Plate 6 Full Size








From the library of: Superior Sewing Machine & Supply LLC

Plate 9 Full Size

1059	1096	28 B	280	22743	91 A	25B
150	89	73 A	28	22560	22737	88
88 B	78	77A	22564	21629	87	138
€ 187A	1059A	77	22736	96	22768	87 U
98	95	22524	73	22525	91	166
98A	88A 2	22560 B	25CC	22584	22813	72
90	22586A	22705	22585	96 A	22818	81
22575	22519	86	94	93A	<b>22730</b>	97
22597	A 2259	0 86A	22597	22528	303	22521




From the library of: Superior Sewing Machine & Supply LLC

# Plate 11 Full Size




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

Plate 13 Full Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 14 Full Size




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC

## Plate 16 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 17 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 18 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 19 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 20 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 21 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 22 One-Half Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 23 One-Third Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 24 One-Fourth Size




From the library of: Superior Sewing Machine & Supply LLC

Plate 25 One-Fourth Size



From the library of: Superior Sewing Machine & Supply LLC

Plate 26 One-Fourth Size




From the library of: Superior Sewing Machine & Supply LLC

# Plate 27 One-Eighth Size




21377














8801 A 8901B

# Plate 28 One-Eighth Size



From the library of: Superior Sewing Machine & Supply LLC

	Eloi oi rimit	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
2 2 A	Cloth Plate Slide, right, 2 9/16 inches long, for styles in Classes 8400, 8500, 8600, 8800 (stop screw No. 150) Cloth Plate Slide, left	18 18
2 CU	Cloth Plate Slide, right, 2 5/16 inches long, for styles in Classes 8900, 9100, (stop screw No. 150)	18
4 C	Cast-off Wire, for styles in Classes 8900, 9100 (screw No. 22524)	8
4 V	Cast-off Wire, for styles in Classes 8400, 8500, 8600 (screw No. 22524)	8
6 B	Main Shaft Collar (screw No. 95) Looper Avoid Eccentric Fork Shoe (screw No. 94)	8
6 E	Looper Avoid Eccentric Fork (clamp screw No. 85. set screw No. 72)	19
7 G	Feed Rocker, for styles in Classes 8400, 8500, 8800, 8900, 9100 (screw No. 88)	24
7 H	Feed Rocker Arm, for styles in Classes 8400, 8500, 8800 (screw No. 93)	24
	Feed Rocker Shaft, 5 25/32 inches long, standard diameter .407 inch Feed Rocker Shaft, standard diameter plus	17
8 A-410	.001 inch Feed Rocker Shaft, standard diameter plus	17
	Feed Rocker Shaft, standard diameter plus	17
8 A-416	Feed Rocker Shaft, standard diameter plus	17
8 A-419	.012 inch	17
8 A-422 9 X	.015 inch	17
10	9100 (screw No. 88) Feed Bar Prong and Sponge, for styles in	18
10 A	Class 8600 (screw No. 94)	21
-1	styles in Classes 8400, 8500, 8800, 8900, 9100	17
15	Feed Crank Link (shim No. 1248, screw No. 22569, nut No. 7947)	13
WA15 16 17	Stop Watch	13
18	" " Nut; also for No. 6037 Cap (screw No. 77)	11
01-19	Pressure Pump Oil Can, 1 1/2 pints capacity	28

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
20 21 22 V	Feed Crank Stud Washer	11 12
22 VA	No. 93)	3
25 B	equipped with 1 1/8, 1 5/16 and 1 3/4 inch diameter rolling presser foot (screw No. 93) Screw, 1/8 inch long, for loop retainer on	3
25 CC	styles in Class 8500 Screw, front, for needle rear guard holder	9
26 J	support on styles in Class 8600	9
26 V	Looper, without guard; otherwise same as No.	4
26 JA 26 VN	Looper, without guard; otherwise same as No.26 J Looper, with guard, for Styles 8500 A, 8500 K, 8600 V (guard No. A26, guard screw No. 73 A)	4
A26	Looper Set Screw No. 73 Looper Needle Guard, marked "A", for styles in Classes 8500, 8600 (screw No. 73 A)	7
27 V	Loop Retainer, marked "AY" for styles in Classes 8500, 8600 (screw 1/8 inch long No. 25 B,	3
28	screw 5/32 inch long No. 28) Screw, 5/32 inch long, for loop retainers on styles in Class 8600	9
28 B	Screw, 3/32 inch long, for adjusting loop retainers on styles in Class 8500	9
28 C	Screw, 1/8 inch long, for adjusting loop retainer on styles in Class 8600 Looper Rock Shaft, 1 1/8 inches long, standard	9
32 32-408	diameter .407 inch Looper Rock Shaft, standard diameter plus	17
	Looper Rock Shaft, standard diameter plus	17
32-413	standard diameter plus	17
32-416 32-419	.009 inch	17
32-422	.012 inch standard diameter plus	17
36 G 38 V	.015 inch	17
40	8600 Y (spot screw No. 96)	13 15
41 A	No. 86)	12

-	EIST OF TAKES	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
42 A	Hand Lifter Screw Pin, for styles in Class	10
43	Feed Lift Eccentric, for styles in Classes 8400, 8800, 9100 (spot screw No. 96)	13
43 C	Feed Lift Eccentric, for styles in Classes	
43 X	8500, 8600, 8900 (spot screw No. 96) Loop Retainer Rocker Cam, for styles in Classes 8400, 8800 (spot screw No. 96)	13
47	Needle Lever Stud Nut; also for No. 9961 A	13
48	" " Washer; also for No.9961 A	11
52 A	Frame Thread Eyelet, for needle thread in-	
CI.	termittent nippers (screw No. 98 A)	15
54 TA54	Needle Lever Link Hand Tally	18
TA55	Hand Tachometer, 4 speed type, 90 to 12000	
1	R.P.M	21
56 C	Needle Stop Pin, for styles in Classes 8500,	- 1
56 V	Needle Clara College for styles to Classes	16
90 V	Needle Clamp Collar, for styles in Classes 8500, 8600	16
56 VA	Needle Clamp Wedge, for Styles 8600 C,	10
	8600 U, 8600 Y (screw No. 88)	16
57	Looper Thread Nipper Spring, upper, for	
	styles in Classes 8500, 8600, 8900, 9100	12
58	(screw No. 90) Looper Thread Nipper Spring, lower, for	12
	styles in Classes 8500, 8600, 8900, 9100	
	(screw No. 90, operating screw No. 97)	12
60 A	Presser Bar, standard diameter .319 inch	17
60 A-322	" standard diameter plus .003	17
60 A-325	" standard diameter plus .006	17
	inch	17
60 A-328	" standard diameter plus .009	
60 4-221	inch	17
60 A-331	" standard diameter plus .012	17
60 A-334		-1
	inch	17
61 C	" Connection (screw, rear, No.	0
62 A	88, screw, front, No. 77) Guide Bar, standard diameter.319	8
UL A	inch, for styles in Class 8600	17
62 A-322	" Guide Bar, standard diameter plus	-
	.003 inch	17
62 A-325	" Guide Bar, standard diameter plus	10
62 A-328	.006 inch	17
	.009 inch	17
62 A-331	" Guide Bar, standard diameter plus	
	.012 inch	17

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
62 A-334 62 C	Presser Guide Bar, standard diameter plus .015 inch	17
62 C-322	8900, 9100	17 17
62 C-325		17
62 C - 328	.009 inch	17
62 C-331 62 C-334	.012 inch	17
64 A 64 B 67	.015 inch  " Spring Regulating Screw  " Lock Nut  Main Shaft Sleeve, left, 1 1/16 inches long,	17 10 11
68 B 69 S 69 FD	for styles in Classes 8500, 8600, 8900, 9100 Main Shaft Sleeve, right Spool Pin, 4 inches long, for thread stand Screw, square head, cup point, 5/16 inch diameter, 18 threads per inch, 5/8 inch long,	13 13 28
70	for thread stand seats	10
70 A 72 73 73 A 75 A	Sponge (screw No. 99)  Looper Avoid Eccentric Sponge Set Screw, for looper avoid eccentric fork	12 9 9 9
77 77 A	Screw, for feed crank stud cap; also for Nos. 21, 61 C, 5636 Screw, for loop retainer on styles in Classes	9
78 80 81	8400, 8800	9 9 10 9
82 84 A 85 86	Screw, for regulating length of stitch Stitch Regulating Ferrule	10 12 10 9
86 A 87 87 U	Hand Lifter Stud, plus size, tap No. V113 Screw, for throat plates; also for No.21390 AS  for needle thread take-up wires; also for No. 21607	9

LIST OF PARTS		
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
88	Screw, for feed rockers; also for Nos. 9 X, 56 VA, 61 C, 161, 1066, 2538, 6093, 6958, 7434 A, 8560, 8645, 8646, 8647, 8650, 9931, 9953, 9961 B, 15465 F, 21113 B	9
88 A	Set Screw, fillister head, for needle bars; also for No. 142 C	9
88 B 89		9
90	1065-5, 1065-5 1/4, 1065-6, 8718, 9030, 9130 Screw, for reciprocating needle rear guards; also for Nos. 57, 58, 8459, 8559, 8842, 8843, 9972,	9
0.3	21390 E	9
91 91 A	Clamp Screw, for presser feet	9
93	Screw, for feed dogs; also for Nos. 7 H, 70, 104, 171, 1075, 1075 A, 7484 A, 7638 A, 21396 AC	10
93 A		9
94	Screw, for looper avoid eccentric fork shoes; also for Nos. 10, 202 A, 8567, 9932, 12835, 21605	9
95	Screw, for main shaft collar; also for No. 9963	9
96	Spot Screw, 9/32 inch long, for looper avoid eccentrics; also for Nos. 43, 43 C, 43 X, 7445 A, 9967 A	9
96 A		9
97	Operating Screw, for lower looper thread nipper spring; also for Nos. 103, 103 A	9
97 A	Bearing Screw, for looper connecting rod ball joints; also for No. 9964	10
98	Set Screw, for looper rocker frames; also for No. 482	9
98 A	also for No. 9966	9
100 B	Thread Stand Wire, 16 inches long (set screw No. 22632 F-24)	26
101 V	Looper Thread Take-up (spot screw No. 89)	8
102	Looper Thread Take-up Eyelet Stand, for styles in Classes 8500, 8600, 8900, 9100 (screw No. 22596)	18
103	Looper Thread Take-up Eyelet, for styles in Classes 8400, 8500, 8600, 8800 (adjusting screw No. 97)	16
103 A	Looper Thread Take-up Eyelet, for styles in Classes 8900, 9100 (adjusting screw No. 97)	8
104	Looper Thread Take-up Eyelet Spring (screw No. 93)	12
		1
	-11:	

-		2101 01 111110	
-	C-hal	m - 0;	Plate
	Symbol	The figures in the last column refer only to the	
	to	plates illustrating the parts and are not to be	No.
	Order by	used in ordering. Refer to pink insert for prices.	
_			
	105-2 1/2		
		machine to table	14
	105-3	Thumbscrew, 3 inches long	14
	105-3 1/2	" 3 1/2 inches long	14
	107	Tension Spring Ferrule	11
	108 -	" Regulating Nut, knurled	11
	109	Tension Disc, with contact surface 5/64 inch	
		wide, for machines using needle threads the	
		equivalent in size of No. 50 and smaller-	11
	109 B	Tension Disc, with contact surface 1/8 inch	
	TELE KI	wide, for machines using needle threads the	
		equivalent in size of No. 40 and larger	11
	110-1	Tension Spring, .026 inch diameter wire, for	
		looper thread	12
	110-4	Tension Spring, .048 inch diameter wire, for	
		needle threads	12
	112 V	Throat Plate, for Style 8500 A equipped with	
		roller presser feet having a 1/8 inch	
		roller face (retainer No. 27 V, attaching	1
		screw No. 25 B, adjusting screw No. 28 B,	1
		throat plate screw No. 87)	1
	112 VA	Throat Plate, for Style 8500 A equipped with	
		roller presser feet having a 3/16 inch or	
		wider roller face (retainer No. 27 V,	
		attaching screw No. 25 B, adjusting screw	1
		No. 28 B, throat plate screw No. 87)	14
	V113	Tap, marked "Q2", for No. 86 A	22
	116	Wrench, for 9/32 inch hexagon nuts	
	116 A	needle set screws	22
	110	Thread Hook, for looper threads	22
	118	" Tweezers	22
	118 B	Tap, marked "X2", for No. 22521	14
	V118	Thread Controller Thread Eyelet, for styles	
	137	in Classes 8600, 8800; Style 8900 C	15
	138	Screw, for thread controller thread eyelet	9
	‡139 A	Needle Thread Controller Lever Assembly	18
	141	" " Screw	10
	142 C	Thread Controller Rack and Presser Spring	
		Rest (screw No. 88 A)	18
	144	Needle Guide Foot, for Styles 8500 A, 8500 K	
		(clamp screw No. 91)	5 3
	145	Needle Guide Foot Toe (screw No. 91 A)	3
	150	Stop Screw, for cloth plate slides	9
	154	Needle Lever Buffer, wood fibre	11
	156	Needle Lever Ball	13
	158	" Thread Eyelet, right (screw	1,5
		No. 98 A)	15

	DIST OF PARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
158 A 158 B	Needle Lever Thread Eyelet, left, with three holes, for Style 8800 A (screw No. 98 A) Needle Lever Thread Eyelet, left, with two	15
	holes, for styles in Class 8600 (screw No. 98 A) Needle Bar, marked "V-00", for No. 2 gauge	15
160 A-1	Style 8400 A	17
160 A-2	Style 8400 A	17
161	Needle Bar Screw No. 88 A Needle Bar Stop Collar, for styles in Classes 8600, 8900, 9100 (screw No. 88)	11
162 164-1	Needle Bar Connection	8
166	No. 88 B)	16
167 A	Eccentric Pulley, throw .481 inch, with single belt groove, for Styles 8900 A, 8900 B, 8900 J, 9100 C (spot screw No. 22597, set	
167 B	screw No. 22597 A)	20
168	screw No. 22597, set screw No. 22597 A) Presser Spring, for styles in Classes 8400, 8500, 8600, 8800	20
168 A	Presser Spring, for styles in Classes 8900,	18
169	Main Shaft, for styles in Classes 8500, 8600, 8900, 9100	24
171	Tension Bracket, for styles in Class 8800 (screw No. 93)	23
	(guard No. 179, guard screw No. 73 A, looper set screw No. 73)	4
175 A 179	Looper, front, without guard; otherwise same as No. 175 (set screw No. 73)	4
181	9100 C (screw No. 73 A) Looper Rocker, for styles in Classes 8500.	3
187 A 188 D	8600, 8800	23 9
	swinging arm on Styles 8500 A, 8500 K, 8800A, 9100 C; also for No. 753	10
201 A	Frame, for cord spool holder on Styles 8600 C, 8600 Y	28
	1.4	

-			
	Symbol	The figures in the last column refer only to the	Plate
	to	plates illustrating the parts and are not to be	No.
	Order by	used in ordering. Refer to pink insert for prices.	
-	201 C	Thumbscrew, for cord spool holder axle on	
		Styles 8600 C, 8600 Y	10
	202 A	Needle Thread Take-up Wire Post, for styles in	3.5
	202 B	Classes 8600, 8800 (screw No. 94) Needle Thread Take-up Wire, for Styles 8600 U,	15
	202 2	8800 A (screw No. 87 U)	15
	258	Nut, for loop retainer ball stud on styles in	
	0/0	Classes 8400, 8800	11
	269	Looper Connecting Rod Nut, left thread	11
	294	Adjusting Screw, for reciprocating needle rear guard frame	10
	303	Clamp Screw, for loop retainer lever fork on	10
		styles in Classes 8400, 8800	9
	330 A	Main Shaft Sleeve, left, for styles in Classes	0.3
	413	8400, 8800	21 25
	416 A	Lifter Lever Extension (screw No. 93 A)	26
	416 B	" " Casting (stud No. 420)	26
	420	" Stud	10
	421	" Chain, 38 inches long	22
	422 423	" Treadle	25
	424	" Pin (screw No. 22813)	24
	426	Lever Spring	12
	426 A	" " Pin	12
	482 Y500-257	Feed Rocker Shaft Collar (screw No. 98) Expansion Reamer, for needle bars, size .257	16
	1500-251	inch	25
	Y502-319	" for presser bars and presser	
		guide bars, size .319 inch	25
	Y502-322 Y502-325	" size .322 inch	25
	Y502-328	" size .328 inch	25
	Y502-331	" " size .331 inch	25
	Y505-407	" for feed rocker shafts and	0.5
	Y505-410	feed bar shaft, size .407 inch size .410 inch	25
	Y505-413	" size .413 inch	25 25
	Y505-416	" size .416 inch	25
	Y505-419	size .419 inch	25
	Y506-530	" " for main shafts, size .530 inch	25
	650-24	Stove Bolt, flat head, 1/4 x 3 inches	_
	650 X-18	Carriage Bolt, 5/16 x 2 1/4 inches, for attach-	
		ing "Electro Drive"	-
	650 X-22	Carriage Bolt, 5/16 x 2 3/4 inches, for attach-	Barrie I.
		ing "Electro Drive"	
			1

	LIST OF PARTS	
Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order by	used in ordering. Refer to pink insert for prices.	
650 X-32	Carriage Bolt, 5/16 x 4 inches, for attaching	
O)O h )L	"Electro Drive"	_
652-16	Washer, 1/4 inch	-
652-20	" 5/16 inch	-
652 C-9	Shake-Proof Lock Washer, for needle bar	
//0 73	eyelets	11
660-31	Ball, .0625 inch diameter, for rolling presser feet	7
660-62	Oil Cup, for right main shaft bearing	21
660-112	Spring and Catch, for tray No. 21377 C	14
660-159	Idle Pulley, set of two, for leading floor	
,,	treadle lifter chain away from transmitter	
	or line shaft on American Safety Table	
	installations	26
751 A	Cord Spool Holder Pin, for Styles 8600 C,8600Y	14
753	Cord Spool Holder Adjustable Cone (thumbscrew	21
Y802	No. 188 D)	21
. 1002	Taper Reamer, for needle lever link pins and feed crank link pins	25
907	Lock Nut, for needle lever link pin clamp	-
701	screw	11
1004	Felt, for oil cup No. 21396	21
1051-1	Feed Dog, for No. 1 gauge Style 9100 C for No. 2 gauge	3
1051-2	" " for No. 2 gauge	3333
1051-3	" " for No. 3 gauge	2
1051-4	" Screw, No. 93	)
1053 A-1	Looper, back, for No. 1 gauge Style 9100 C	4
1053 A-2	" back, for No. 2 gauge	14
1053 A-3	back, for No. 3 gauge back, for No. 4 gauge	4
1053 A-3 1053 A-4	" back, for No. 4 gauge	4
1051	" Set Screw No. 73	
1054	Looper Avoid Eccentric, for styles in Classes 8500, 8900, 9100; Styles 8600 C, 8600 D,	
	8600 V (spot screw No. 96 A)	13
1055 A	Loop Retainer, front, marked "A", for Style	
	9100 C	2
1057 D	Loop Retainer, back, for Nos. 1 and 2 gauge	
1050 = =	Style 9100 C	2
1058 E-3	Loop Retainer, back, marked "E3", for No. 3	2
1058 E-4	gauge Style 9100 C Loop Retainer, back, marked "E4", for No. 4	-
10)0 E-4	gauge Style 9100 C	2
1059	Loop Retainer Adjusting Screw, for Style 91000	9
1059 A	Loop Retainer Attaching Screw, for Style 91000	9
1060	Looper Rocker, for styles in Classes 8900,	
	9100	23
The state of the s		

	Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
	1065-2 1065-3	Needle Clamp Collar, for No. 1 gauge Styles 8900 C, 8900 L (needle set screw No. 88 B, spot screw No. 89) Needle Clamp Collar, for No. 1 gauge Style 8900 J, Nos. 1, 2 and 3 gauge Styles 8900A,	16
	1065-4 1/2	8900 B and Nos. 1, 2, 3 and 4 gauge Style 9100 C (needle set screw No. 88 B, spot screw No. 89)	16
	1065-5	spot screw No. 89)	16
	1065-5 1/4	spot screw No. 89)	16
	1065-6	No. 89)  Needle Clamp Collar, for No. 5 1/2 gauge Styles 8900 A, 8900 B, Nos. 4 1/4, 4 1/2, 5 and 5 1/4 gauge Style 8900 C (needle set screw No. 88 B for No. 5 1/2 gauge Styles 8900 A, 8900 B and Nos. 5 and 5 1/2 gauge Style 8900 C, needle set screw No. 89 for Nos. 4 1/4 and 4 1/2 gauge Style 8900 C,	16
	1065-32	Spot screw No. 89)	16
	1066	spot screw No. 22560 B) Needle Stop Collar, for Nos. 1, 2 and 3 gauge Styles 8900 A, 8900 B, No. 1 gauge Styles 8900 C, 8900 J, 8900 L and Nos. 1, 2, 3 and	
	1068 A	4 gauge Style 9100 C (set screw No. 88) Needle Lever Thread Eyelet, left, with 6 holes, for Styles 8900 C, 8900 L (screw No. 98 A)	16
	1073-1	Throat Plate, for No. 1 gauge Style 9100 C (retainer, rear, No. 1057 D)	2
	1073-2	Throat Plate, for No. 2 gauge, (retainer, rear, No. 1057 D)	2
	1073-3	Throat Plate, for No. 3 gauge (retainer, rear, No. 1058 E-3)	2
	1073-4	Throat Plate, for No. 4 gauge (retainer, rear, No. 1058 E-4)	2
		Retainer, front, No. 1055 A Retainer Adjusting Screw No. 1059 Retainer Attaching Screw No. 1059 A Throat Plate Screw No. 87	
_		-	

Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order by	used in ordering. Refer to pink insert for prices.	110.
order by	and in ordering meter to print insert to prices.	
1075	Tension Bracket, for Styles 8900 A, 8900 B,	
	8900 J, 9100 C (screw No. 93)	23
1075 A	Tension Bracket, for Styles 8900 C, 8900 L	
	(screw No. 93)	23
1077-1	Needle Guide Foot, for No. 1 gauge Style 91000	5
1077-2	" " for No. 2 gauge	5
1077-3	" " for No. 3 gauge	23 5 5 5 5 5
1077-4	" for No. 4 gauge	5
200/	" " Clamp Screw No. 91	
1096	Loop Retainer Adjusting Screw, for styles in	0
\$1230 A	Class 8900 Needle Lever Connecting Rod Upper Bearing	9
TIEJU R	(screw No. 22587)	20
1230 B	Needle Lever Connecting Rod Upper Bearing	
	Valve Spring	12
1230 C	Needle Lever Connecting Rod Tube (nut, left	
#/ No. 1	thread, No. 15430 C, nut, right thread,	
	No. 15430 D)	20
1230 D	Needle Lever Connecting Rod Upper Bearing	10
101.0	Valve (valve screw No. 22586 A)	12
1248	Feed Crank Link Shim	11
1276	Needle Lever Stud, cone bearing (nut No. 47, washer No. 48)	19
1280	Needle Lever Stud Ball Clamp Bolt Nut	11
1286	Needle Lever Link Pin Assembly; one each Nos.	New York
	1286 A, 1286 B, 12964 C, 22560	12
1286 A	Needle Lever Link Pin (set screw, lower, No.	
	78, clamp screw No. 22826, clamp screw nut	100
100/ 5	No. 907)	12
1286 B	Needle Lever Link Pin Spring (screw No.22560)	12
1346	Tension Post, 1 11/16 inches long	11
1347 1349	" Spring, .036 inch diameter wire, for	11
- )47	needle threads on Styles 8600 D,8600 V	12
1361 A	Presser Spring Pin	12
1362	Main Shaft Sleeve Pin	12
1520 L-13	Rolling Presser Foot Assembly, universal ad-	
	justment, diameter of roller 13/16 inch,	
	width of face 1/8 inch, for Style 8500 A;	
	one each Nos. 1580 F-13, 188 D, 1584, 1592 B, 1592 C, 1593 C, 1593 E, 1594 A,	
	22519, 22575, 22743, 22818; two each Nos.	
	22548, 22584; twenty-six No. 660-31	6
+0		

Symbol	The figures in the last column refer only to the plates illustrating the parts and are not to be	Plate No.
to Order by	used in ordering. Refer to pink insert for prices.	No.
1520 M-13	Rolling Presser Foot Assembly, universal adjustment, diameter of roller 13/16 inch,	
	width of face 3/16 inch, for Styles 8800 A, 9100 C; one each Nos. 1580 G-13, 188 D, 1584, 1592 B, 1592 C, 1593 C, 1593 E, 1594 A, 22519, 22575, 22743, 22818; two	
	each Nos. 22548, 22584; twenty-six No.	5
1520 M-18	Rolling Presser Foot Assembly, universal adjustment, diameter of roller 1 1/8 inches; one each Nos. 1580 G-18, 188 D, 1584.	
	1592 B, 1592 C, 1593 C, 1593 E, 1594 A, 22519, 22575, 22743, 22818; two each Nos.	_
1520 M-21	22548, 22584; twenty-six No. 660-31 Rolling Presser Foot Assembly, universal adjustment, diameter of roller 1 5/16 inches;	5
	one each Nos. 1580 G-21, 188 D, 1584, 1592 B, 1592 C, 1593 C, 1593 E, 1594 A, 22519, 22575, 22743, 22818; two each Nos.	
1520 N-28	22548, 22584; twenty-six No. 660-31 Rolling Presser Foot Assembly, universal adjustment, diameter of roller 1 3/4 inches,	5
	width of face 1/4 inch, for Styles 8500 A, 9100 C; one each Nos. 1580 H-28, 188 D,	
	1584, 1592 B, 1592 C, 1593 C, 1593 E, 1594 A, 22519, 22575, 22743, 22818; two each Nos. 22548, 22584; twenty-six No.	,
1580 F-13	Roller, diameter 13/16 inch, width of face	6
1580 G-13	Roller, diameter 13/16 inch, width of face 3/16 inch	7
1580 G-21	Roller, diameter 1 1/8 inches Roller, diameter 1 5/16 inches	7
1580 H-28	Roller, diameter 1 3/4 inches, width of face 1/4 inch	7
1580 J-13	Roller Axle Lock Screw No. 22743 Roller Assembly, diameter 13/16 inch, width	
	of face 1/8 inch; one each Nos. 1580 F-13, 1584, 22743, 22818; twenty-six No. 660-31	7
1500 K-15	Roller Assembly, diameter 13/16 inch, width of face 3/16 inch; one each Nos. 1580 G-13, 1584, 22743, 22818, twenty-six	
1580 K-18	No. 660-31 Roller Assembly, diameter 1 1/8 inches; one each Nos. 1580 G-18, 1584, 22743, 22818;	7
1580 K-21	twenty-six No. 660-31 Roller Assembly, diameter 1 5/16 inches; one	7
	each Nos. 1580 G-21, 1584, 22743, 22818; twenty-six No. 660-31	7

	BIOI OI TARTO	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
1590 T 00	Dollan Aggambly diameter 1 7/1 inches width	
	Roller Assembly, diameter 1 3/4 inches, width of face 1/4 inch; one each nos. 1580 H-28, 1584, 22743, 22818; twenty-six No. 660-31 -	7
1584	Roller Support, adjustable (set screw No. 22519)	7
1592 В	Roller Support Swinging Arm, adjustable (set screw No. 188 D, stop screw No. 22575,	
1592 C	hinge pin No. 1594 A) Roller Support Swinging Arm Bracket, lower,	7
1)72 0	adjustable (screw No. 22548) Roller Support Swinging Arm Bracket, upper	7
1593 C	Roller Support Swinging Arm Bracket, upper (set screw No. 22584)	7
1593 E	Roller Support Swinging Arm Bracket, inter-	
	mediate, adjustable (screw No. 22548)	7
1594 A	Roller Support Swinging Arm Hinge Pin	12
1835 A	Feed Rocker, for styles in Class 8600 (screw	
	No. 88)	18
1836 B	Feed Bar Shaft, 2 1/16 inches long, for	10
0570	styles in Class 8600	17
2538	Thread Controller Rack and Presser Spring	11
5474	Rest Collar (screw No. 88)	11
5636	Reciprocating Needle Rear Guard Frame Shoe,	
	for styles in Classes 8400, 8500, 8800,	0
1015 5	8900, 9100 (screw No. 77)	8
6015 B	Needle Lever, lynite, for styles in Classes 8500, 8600, 8900, 9100	24
6035 A	Cloth Plate Guard, with cushion (screw No.	-4
4	22730)	26
6035 B	Cloth Plate Guard Cushion, felt (screw No.	
	187 A)	11
6037	Looper Connecting Rod (nut, right thread, No. 18, nut, left thread, No. 269)	17
‡60 <u>3</u> 8	Looper Connecting Rod Ball Joint, left (screw	1
400)0	No. 97 A)	13
‡6039	Looper Connecting Rod Ball Joint, right (ball	-
+00))	stud washer No. 36 G, screw No. 97 A)	13
6042 A	Needle Lever Ball Clamp Bolt Washer	11
6090 A	" Stud Sleeve	19
6091 A	" Nut, front, hexagonal	11
6091 A	" " rear, cylindrical	11
6091 A	" Stud Sleeve Key	12
	" Cone (set screw No. 88)	13
6093	" Cone (set screw No. 00)	-)
6236	" Thread Pull-off Wire, for Style 8600 U (screw No. 87 U)	15
6939	" Lever Ball Clamp Bolt	10
		10
6958	Reciprocating Needle Rear Guard Frame Shaft	
	Collar, for styles in Classes 8400, 8500,	11
	8800, 8900, 9100 (screw No. 88)	11
*		The same

	Symbol to	The figures in the last column refer only to the plates illustrating the parts and are not to be	Plate No.
_	Order by	used in ordering. Refer to pink insert for prices.	
	7225	Reciprocating Needle Rear Guard, marked "BW"	
	7401 A	for styles in Class 8900 (screw No. 90) Cloth Plate, for Styles 8500 A, 8500 K,	2
	1402 1	8600 D, 8600 U, 8600 V, 9100 C (screw,	-
		countersunk head, No. 80, screw, fillister	
		head, No. 93 A)	27
	7421 A	Eccentric Pulley, throw .461 inch, for styles	
		in Classes 8400, 8500, 8600, 8800 (spot	00
	7434 A	screw No. 22597, set screw No. 22597 A) Feed Bar, for styles in Class 8600 (screw	20
	1424	No. 88)	18
	7445 A	Looper Rocker Frame, for styles in Classes	
		8500, 8600, 8900, 9100 (spot screw No. 96,	
	71.1.6 4	set screw No. 98)	19
	7446 A	Looper Rock Shaft, standard diameter .407	17
	7446 A-408	" " standard diameter plus	17
		.001 inch	17
	7446 A-410	" " standard diameter plus	
	7446 A-413	.003 inch	17
	1440 A-415	" " standard diameter plus	17
	7446 A-416	" " standard diameter plus	17
		.009 inch	17
	7446 A-419	" " standard diameter plus	
	7446 A-422	.012 inch	17
	1440 A-422	" " standard diameter plus .015 inch	17
	7448 A	Needle Thread Tension Thread Eyelet, for	17
4	-1.6-	styles in Class 8600	15
ie.	7462 D	Main Shaft Bushing, right (spot screw No.	
	7484 A	22590)	25
	1404	8900, 9100 (screw No. 93)	24
	7638 A	Looper Thread Deflecting Wire (screw No. 93)	16
	7947	Feed Crank Link Nut	11
	8225 A	Reciprocating Needle Rear Guard, marked "BX" for styles in Class 9100 (screw No. 90)	
	8405-2	Feed Dog, for Nos. 1 and 2 gauge Style	2
		8400 A (screw No. 93)	3
	8405-3	Feed Dog, for Nos. 3 and 4 gauge Style	
	8405 B	8400 A (screw No. 93)	3
	040) 1	Feed Dog, for No. 1 gauge Style 8400 B (screw No. 93)	3
	8413	Looper Rocker, for styles in Class 8400	19
	8417-1	Needle Bar, for No. 1 gauge Styles 8400 A.	,
	81.20 1	8400 B (set screw No. 88 A)	17
	8420-1	Presser Foot, for No. 1 gauge Style 8400 A	6
			1

	2101 01 11111	
Symbol to	The figures in the last column refer only to the plates illustrating the parts and are not to be	Plate
Order by	used in ordering. Refer to pink insert for prices.	
8420-2	Presser Foot, for No. 2 gauge	6
8420-3 8420-4	" " for No. 4 gauge	6
8424-1	" " Clamp Screw No. 91 Throat Plate, for No. 1 gauge Style 8400A	1
8424-2 8424-3	for No. 2 gauge	1
8424-4	" " for No. 4 gauge	1
8424 B-1-3/32	for No. 1 gauge Style 8400B	T JELT
8425	Reciprocating Needle Rear Guard, marked "CO", for Styles 8400 B, 8800 A (screw	
	No. 90)	2
8427 B-1-3/32	Presser Foot, for No. 1 gauge Style 8400 B (clamp screw No. 91)	5
8459	Reciprocating Needle Rear Guard Holder,	
8524 K	for Style 8400 B (screw No. 90) Throat Plate, for Style 8500 K (retainer	8
O)Z4 K	No. 27 V, attaching screw No. 25 B, ad-	
	justing screw No. 28 B, throat plate screw No. 87)	1
8525	Reciprocating Needle Rear Guard, marked	
	"BU" for styles in Class 8500; Style 8400 A; also feed bar needle guard for	
,	styles in Class 8600 (screw No. 90)	2
8559	Reciprocating Needle Rear Guard Holder, for styles in Classes 8500, 8800, 8900,	
	9100; Style 8400 A; also feed bar	
	needle guard holder for styles in Class 8600 (screw No. 90)	8
<b>‡8560</b>	Reciprocating Needle Rear Guard Frame,	
	including shoes, for styles in Classes 8400, 8500, 8800, 8900, 9100 (set	
	screw No. 88, adjusting screw No. 294,	2.0
8561	shoes No. 5636, shoe screw No. 77) Reciprocating Needle Rear Guard Frame	18
	Eccentric Bearing (screw No. 22768)	18
8562	Feed Bar Frong Felt, for styles in Classes 8400, 8500, 8800, 8900, 9100-	12
8563	Reciprocating Needle Rear Guard Frame	
	Felt, for styles in Classes 8400, 8500, 8800, 8900, 9100	12
8564	Reciprocating Needle Rear Guard Frame Shaft	17
8565	Reciprocating Needle Rear Guard Frame	
8567	Rocker	18
	8400, 8500, 8800, 8900, 9100 (screw	0.1
	No. 94)	21

3			
	Symbol	The figures in the last column refer only to the	Plate
	The state of the s		No.
	to	plates illustrating the parts and are not to be	NO.
	Order by	used in ordering. Refer to pink insert for prices.	
•	8601 H	Clath Dieta for Ctulos 8600 C 8600 T	
	0001 H	Cloth Plate, for Styles 8600 C, 8600 Y	
		(screw, countersunk head, No. 80, screw,	
		fillister head, No. 93 A)	27
	8605 J	Feed Dog, for Styles 8600 C, 8600 D,	
		8600 U, 8600 V, 8600 Y (screw No. 93)	3
	8617 J	Moddle Ber merked Hill for styles in	,
	0011 0	Needle Bar, marked "U", for styles in	10
	0/00 -	Classes 8500, 8600 (set screw No. 88 A)	17
	8620 J	Presser Foot, for Style 8600 C	5
	8620 K-1/32	" for 1/32 inch tuck on Style	
		8600 D	5
	8620 K-3/64	" for 3/64 inch tuck	5 5 5
	8620 K-1/16	" for 1/16 inch tuck	-
		Tot 1/10 Then cack	)
	8620 K-3/32	101 )/ JE INCH CUCK ON DUYLES	
		8600 K, 8600 V	5
	8620 K-1/8	" for 1/8 inch tuck on Styles	
		8600 K, 8600 V	5
	8620 U-3/64	" for 3/64 inch tuck on Style	
		8600 U	5
	9620 H 1/16		)
	0020 0-1/10	Presser Foot, for 1/16 inch tuck on Style	
		8600 U; also 1/16 inch cord on Style	
		8600 Y	5
	8620 U-1/8	Presser Foot, for 1/8 inch tuck on Style	
		8600 U	5
		Presser Foot Clamp Screw No. 91	
	8621-1/32	Throat Plate for 1/32 inch tuck on Style	
	8624-1/32	Throat Plate, for 1/32 inch tuck on Style	
		8600 V	1
	8624-3/64	" for 3/64 inch tuck	1
	8624-1/16	" " for 1/16 inch tuck	1
	8624-3/32	" for 3/32 inch tuck	1
	8624-1/8	" " for 1/8 inch tuck	1
	0024 1/0	" Loop Retainer No. 27 V	A STATE OF
		" " Adjusting Screw	THE TEN
		Adjubiling berem	E with
		No. 28 C	
		" Attaching Screw	
		No. 28	1975
	8624 J	Throat Plate, for Styles 8600 C, 8600 Y	TO STATE OF
		(retainer No. 27 V, attaching screw No.	
		28, adjusting screw No. 28 B)	1
	8624 K-1/32		1000
	0024 N-1/92	8600 D	1
	0/01 //	8600 D	1
	0024 K-3/64	Throat Plate, for 3/64 inch tuck on Styles	Selection.
		8600 D, 8600 U	1
	8624 K-1/16	Throat Plate, for 1/16 inch tuck on Styles	POL P
		8600 D, 8600 U	1
	8621 K-3/32	Throat Plate, for 3/32 inch tuck on Styles	BART .
	10-4 1 JI JE	8600 D, 8600 U	1
		0000 D, 0000 0	1
			1000
			100
			100000
			- Indiana - Law Co.

	LIST OF PARTS		
Symbol to Order by	to plates illustrating the parts and are not to be		
8624 K-1/8	Throat Plate, for 1/8 inch tuck on Styles 8600 D, 8600 U Loop Retainer No. 27 V	ĩ	
	" " Adjusting Screw No. 28 C		
	" " Attaching Screw No. 28		
9607 D 1 /70	" " Screw No. 87		
	Presser Foot, for 1/32 inch tuck on Style 8600 V	5 5 5	
8627 D-3/64 8627 D-1/16	" for 3/64 inch tuck for 1/16 inch tuck	2	
0021 1-1/10	" Clamp Screw No. 91	,	
8645	Quilting Guide, right, adjustable, for styles in Class 8600 (screw No. 88)	21.	
8646	Quilting Guide, left, adjustable (screw	24	
	No. 88)	24	
8647	" Support (screw No. 88)	24	
8648	Quilting Guide Assembly, for styles in Class 8600; one each Nos. 8645, 8646, 8647;		
	three No. 88 (Specify component parts in		
8650	ordering) Needle Clamp, for Styles 8500 A, 8500 K,	_	
0(5)	8600 D, 8600 V (screw No. 88)	16	
8651	Needle Thread Take-up Wire, for Styles 8600 C, 8600 D, 8600 V, 8600 Y (screw No.	3.5	
8717	Needle Bar, marked "X", for styles in Class	15	
0/11	8800 (set screw No. 88 A)	17	
8718	Needle Clamp Collar, for styles in Class		
	8800 (spot screw No. 89, needle set screw	2/	
8719	No. 88 B)	16	
0119	Needle Guide Foot, for Style 8800 A (clamp screw No. 91)	5	
8801 A	Cloth Plate, for styles in Classes 8400,		
	8800 (screw, countersunk head, No. 80,	0.00	
8805 A	screw, fillister head, No. 93 A) Feed Dog, for Style 8800 A (screw No. 93)	27	
8815 A	Needle Lever, lynite, for styles in Classes	3	
	8400, 8800	24	
8824 A	Throat Plate, for Style 8800 A (screw No.87)	i	
8842	Looper Thread Nipper Spring, upper, for	2/	
8843	styles in Classes 8400, 8800 (screw No.90) Looper Thread Nipper Spring, lower, for	16	
004)	styles in Classes 8400, 8800 (screw No.		
	90, operating screw No. 97)	16	
8860 A	Loop Retainer Lever, for styles in Classes		
	8400, 8800	19	

=			
	Comple 2	The Pinner in the last of	-
	Symbol	The figures in the last column refer only to the plates illustrating the parts and are not to be	Plate No.
	Order by	used in ordering. Refer to pink insert for prices.	
_			
	8901 B	Cloth Plate, for styles in Class 8900	
		(screw, countersunk head, No. 80, screw, fillister head, No. 93 A)	27
	8905-1	Feed Dog, for No. 1 gauge Styles 8900 C,	
	8005 3	8900 L	3
	8905-2	Feed Dog, for No. 2 gauge Styles 8900 A, 8900 B, 8900 L and Nos. 2 and 3 gauge	
		Style 8900 C	3
	8905-4	Feed Dog, for Nos. 4 and 4 1/4 gauge	
	8905-5	Styles 8900 A, 8900 B, 8900 C Feed Dog, for Nos. 4 1/2 and 5 gauge Styles	3
		8900 A, 8900 B, 8900 C Feed Dog, for No. 5 1/4 gauge Styles	3
	8905-5 1/4	Feed Dog, for No. 5 1/4 gauge Styles	
	8905-5 1/2	8900 A, 8900 B, 8900 C Feed Dog, for Nos. 5 1/2 and 6 gauge Styles	3
	-,-, , -,-	8900 A, 8900 B, 8900 C	3
	9007.0	Feed Dog Screw No. 93	1
	8907 C	Looper, front, with guard, for Styles 8900 C, 8900 L (guard No. 10410, guard	
		screw No. 73 A)	4
	8909-2	Looper, back, for No. 2 gauge Styles	I.
	8909-4	8900 A, 8900 B Looper, back, for No. 4 gauge	444444444444444444444444444444444444444
	8909-4 1/2	" back for No. 1 1/2 gauge	4
	8909-5	back, for No. 5 gauge	4
	8909-5 1/4 8909-5 1/2	back, for No. 5 gauge     back, for No. 5 1/4 gauge     back, for No. 5 1/2 gauge     back, for No. 6 gauge	4
	8909-6	" back, for No. 6 gauge	4
	8909 C-1	back, for No. 1 gauge Styles	4
	8909 C-4 1/4	8900 C, 8900 L	4
		8900 C	4
	8909 C-4 1/2 8909 C-5	back, for No. 4 1/2 gauge	4
	8909 C-5 1/4	back, for No. 5 1/4 gauge	1 4
	8909 C-5 1/2	back, for No. 5 gauge back, for No. 5 1/4 gauge back, for No. 5 1/2 gauge back, for No. 5 1/2 gauge back, for No. 6 gauge	4
	8909 C-6	" Set Screw No. 73	4
	8911-3	Loop Retainer, front, marked "G-3", for No.	
		3 gauge Styles 8900 A, 8900 B (adjusting	2
	8911 C	screw No. 1096)   Loop Retainer, front, for Nos. 3, 4, 4 1/4,	-
*		Loop Retainer, front, for Nos. 3, 4, 4 1/4, 4 1/2, 5, 5 1/4, 5 1/2 and 6 gauge Style	
	9010	8900 C (adjusting screw No. 1096)	2
	8912	Loop Retainer, back, for Nos. 3, 4, 4 1/4, 4 1/2, 5, 5 1/4, 5 1/2 and 6 gauge Style	
		8900 C	2
	ETHINE		
_	-		

	LIST OF PARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
8912 A	Loop Retainer, back, for Styles 8900 A, 8900 B; also for Nos. 1 and 2 gauge Styles 8900 C, 8900 J, 8900 L	2
8920 A-4	Loop Retainer Screw No. 22737 Presser Foot, with adjustable guide on left side, for No. 4 gauge Style 8900 A	6
8920 A-4 1/4 8920 A-4 1/2 8920 A-5	Presser Foot, for No. 4 1/4 gauge   for No. 4 1/2 gauge   for No. 5 gauge	6 6 6
8920 A-5 1/4 8920 A-5 1/2 8920 A-6	" " for No. 5 gauge	666
8920 B-2	" Guide No. 9140 B " Screw No. 22736 " with adjustable guide on	
8920 B-3	right side, for No. 2 gauge Style 8900 B	6
8920 B-4 8920 B-4 1/4 8920 B-4 1/2	" " for No. 4 gauge	6 6
8920 B-5 8920 B-5 1/4 8920 B-5 1/2	" for No. 5 gauge	66666666
8920 B-6	" " for No. 6 gauge " " Guide No. 9141 B " Screw No. 22736	6
8924-2	" " Clamp Screw No. 91 " " Hinge Screw No. 22799 B Throat Plate, for No. 2 gauge Styles	
8924-4 8924-4 1/2	8900 A, 8900 B	2 2 2
8924-5 8924-5 1/4 8924-5	" " for No. 5 gauge	2 2 2 2 2 2
8924-6	" " for No. 6 gauge Loop Retainer, front, No. 9111 " back, No. 8912 A	2
	Throat Plate, for No. 4 1/4 gauge Style	2
8924 C-4 1/2 8924 C-5 8924 C-5 1/4	Throat Plate, for No. 4 1/2 gauge	2 2 2
8924 C-5 1/2 8924 C-6		2 2
	back, No. 8912 Adjusting Screw No. 1096	
	Throat Plate Screw No. 87	
	-58-	

Symbol to Order by	plates :	illustra	the last column refer only to the sting the parts and are not to be ag.Refer to pink insert for prices.	Plate No.
8927 C-4 1/4	Presser	Foot,	with adjustable guide on left	
			. 4 1/4 gauge Style 8900 C	6
8927 C-4 1/2			for No. 1 1/2 gauge	
8927 C-5	н	11	for No. 5 gauge	6
8927 C-5 1/4	11	H	for No. 5 1/4 gauge	6
8927 C-5 1/2	11	H	for No. 5 1/2 gauge	6
8927 C-6	11	11	for No. 5 gauge	6 6 6
0,21 0 0	11	**	Guide No. 9140 B	
	н	"	" Screw No. 22736	
	11	"	Clamp Screw No. 91	
	11	н	Hinge Screw No. 22799 B	
8945-2	Needle F		ad, for No. 2 gauge Styles	
0,4)-2	Needle 1	oai nea	8900 A, 8900 B	15
8945-3	н	11 11	for No. 3 gauge Styles	1)
094)-)			8900 A, 8900 B	15
8945-4	н	# 11	for No ly source Styles	15
094)-4			for No. 4 gauge Styles 8900 A, 8900 B, 8900 C	15
8945-4 1/4	н		for No. 1 1/1 gauge Styles	15
0945-4 1/4			for No. 4 1/4 gauge Styles 8900 A, 8900 B	15
8015-1 1/2	н	11 11		1)
8945-4 1/2	***		for No. 4 1/2 gauge Styles 8900 A, 8900 B	15
8945-5	11	11 11		1)
0945-5			for No. 5 gauge Styles 8900 A, 8900 B	15
8015-5 7/1	11		for No. 5 1/4 course Styles	15
8945-5 1/4			for No. 5 1/4 gauge Styles 8900 A, 8900 B	15
8945-5 1/2	"	H H	for No. 5 1/2 course Styles	1)
0945-5 1/2			for No. 5 1/2 gauge Styles 8900 A, 8900 B	15
801.5-6			for No. 6 gauge Styles	1)
8945-6			Tot no. o gauge bojico	15
901.5 C 1. 1 /1.	11		8900 A, 8900 B, 8900 C	1)
8945 C-4 1/4			for No. 4 1/4 gauge Style 8900 C	15
901.5 C 1 1 /0	#			15 15 15 15
8945 C-4 1/2	11		for No. 4 1/2 gauge	15
8945 C-5		11 11	To: No. ) Bungo	15
8945 C-5 1/4 8945 C-5 1/2	- 11		for No. 5 1/2 gauge	15
	Mandla		ollar, for Nos. 4, 4 1/4,	-)
9030	1 1/2	5 5	1/4, 5 1/2 gauge Styles	
	8000	8000	B, Nos. 3 and 4 gauge Style	
	8900 0	(set	screw No. 89)	16
9034	Needle F	Bar Thr	read Eyelet, for styles in	
7074			screw No. 22768, washer	
		52 C-9		16
9111			front, marked "U", for	-
/	Styles	8900	A, 8900 B, 8900 J, 8900 L;	
			s. 1 and 2 gauge Style 8900 C	
			screw No. 22737, adjusting	
			096)	2
	2016#		-,-,	-
			A STATE OF THE STATE OF THE STATE OF	
 				7000

	BIST OF TAKES	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
9117-3	Needle Bar, for styles in Classes 8900, 9100	
9130	(set screw No. 88 A)	17
9140 B	Presser Foot Guide, left, for Styles 8900 A,	16
91/1 B	8900 C (screw No. 22736) Presser Foot Guide, right, for Style 8900 B	3
	(screw No. 22736)	3 16
9145-1	Needle Bar Head, for No. 1 gauge Style 9100 C	16
9145-2	" " for No. 2 gauge	16
9145-3	" " for No. 3 gauge	16
9145-4	" " for No. 4 gauge	16
9904	Cast-off Wire, for styles in Classes 8400, 8800	
	(screw No. 22524)	8
9907	Looper, with guard, for styles in Classes 8400,	
	8800 (guard No. 9910, guard screw No. 73 A)	4
9908	Looper, without guard; otherwise same as No. 9907	4
,,	Looper, without guard; otherwise same as No. 9907 "Set Screw No. 73	-
9910	Looper Needle Guard, marked "W", for styles in	
//	Classes 8400, 8800 (screw No. 73 A)	3
9911 A		,
	8400, 8800 (screw No. 77 A)	2
9921	Eccentric Pulley, throw .529 inch, for styles in	
,,	Class 8400 (spot screw No. 22597, set screw No.	
	22597 A)	20
9922	Main Shaft, for styles in Classes 8400, 8800	23
9931	Feed Bar, for styles in Classes 8400, 8800	-)
1112	(screw No. 88)	23
9932	Feed Bar Shoe, for styles in Classes 8500, 8600,	2)
777-	8900, 9100 (screw No. 94)	19
9953	Loop Retainer Rocker, for styles in Classes 8400,	-7
7777	8800 (clamp screw No. 22518, set screw No. 88)	23
9954	Loop Retainer Holder (screw No. 22528)	23 12
9956	" Shaft	17
	" " Head	10
9957 A	noua	19 18
9957 B		
9958	Support (Screw No. 22)40)	23
9961 A	" Lever Stud (nut No. 47, washer No. 48)	19
9961 B	" Lever Cone (screw No. 88)	19
9962 B		
	Fork (Clamp sciew No. Joy)-	19
9963	Eccentific (apot serew No. 51;	10
	set screw No. 95)	19
		120
		Tegr.
1		

Symbol to Order by	-		BIST OF TARTS	
19964		ALIO MANAGEMENT OF THE PARTY OF		The state of the s
front, No. 75 A, screw, rear, No. 97 A)  Loop Retainer Lever Ball Stud (nut No.258)  13  13  14  15  16  17  17  18  18  18  18  19  19  19  19  10  10  10  10  10  10				NO.
13   13   15   16   16   16   16   17   17   18   18   19   19   19   19   19   19	-	19964	Loop Retainer Lever Connecting Rod (screw,	
Loop Retainer Lever Ball Stud Washer (Screw No. 98 A)		00/5		
(screw No. 98 A)			Loop Retainer Lever Ball Stud (nut No.270)	1)
84,00, 8800 (spot screw No. 96, set screw No. 98)		,,00		11
No. 98)		9967 A		
9972   Cast-off Wire Guard, for styles in Classes 84,00, 8800 (screw No. 90)				10
8400, 8800 (screw No. 90)		9972		19
10314		//!-	8400, 8800 (screw No. 90)	8
10314		9973		
Looper Avoid Eccentric, for styles in Classes 8400, 8800 (spot screw No. 96 A) Needle Bar Thread Eyelet, for styles in Class 8600 (screw No. 22768, washer No. 652 C-9)		HE HERE		23
Classes 8400, 8800 (spot screw No. 96 A) Needle Bar Thread Eyelet, for styles in Class 8600 (screw No. 22768, washer No. 652 C-9)		10314		-
Class 8600 (screw No. 22768, washer No. 652 C-9)			Classes 8400, 8800 (spot screw No. 96 A)	13
10335   Frame Tension Thread Guide, for styles in Classes 8500, 8600   15		10334 A		
Frame Tension Thread Guide, for styles in Classes 8500, 8600				15
Looper, front, with guard, for Styles 8900 A, 8900 B, 8900 J (guard No. 10410, guard screw No. 73 A)		10335	Frame Tension Thread Guide, for styles in	
8900 A, 8900 B, 8900 J (guard No. 10410, guard screw No. 73 A)		10100	Classes 8500, 8600	15
Looper, front, without guard; otherwise same as No. 10407		10407	8000 A. 8000 B. 8000 J (guard No. 10410.	HET HE
Looper, front, without guard; otherwise same as No. 10407			guard screw No. 73 A)	4
Looper Set Screw No. 73 Looper Needle Guard, for styles in Class 8900 (screw No. 73 A) Needle Lever Cone Adjusting Nut 11684 AA 11684 AA 11684 AA 11684 AA 11684 AA 11685 Feed Dog, for No. 3 gauge Styles 8900 A, 8900 B (screw No. 93) Looper, back, for No. 3 gauge Styles 8900 A, 8900 B Looper, back, for No. 4 1/4 gauge Styles 8900 A, 8900 B Throat Plate, for No. 5 gauge Styles 8900 A, 8900 B (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87)- Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat		10408	Looper, front, without guard; otherwise	
Looper Needle Guard, for styles in Class 8900 (screw No. 73 A) 11638 M 11684 AA 11684 AA 12605  12605  12609-3  12609-4  12609-4  12624 F-3  Looper, back, for No. 3 gauge Styles 8900 A, 8900 B 12624 F-3  Looper, back, for No. 4 1/4 gauge Styles 8900 A, 8900 B Throat Plate, for No. 5 gauge Styles 8900 A, 8900 B (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 22737, throat plate screw No. 87) Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8912-3, retainer, back, No. 8912-			Jooner Set Screw No. 73	
8900 (screw No. 73 A)		10410	Looner Needle Guard, for styles in Class	
11684 AA  12605  12605  12609-3  12609-4 1/4  12624 F-3  12624 F-4 1/4  12625 F-4 1/4  12625 F-4 1/4  12626 F-3  12626 F-3  12627 F-4 1/4  12626 F-3  1			8900 (screw No. 73 A)	3
ing oil cup			Oil Cup Elbow, for right main shaft bear-	11
Feed Dog, for No. 3 gauge Styles 8900 A, 8900 B (screw No. 93)		11004 AA	ing oil cup	21
Looper, back, for No. 3 gauge Styles 8900 A, 8900 B		12605	Feed Dog, for No. 3 gauge Styles 8900 A,	7
8900 A, 8900 B 4 Looper, back, for No. 4 1/4 gauge Styles 8900 A, 8900 B		12609-3	Looper, back, for No. 3 gauge Styles	)
8900 A, 8900 B 4  Throat Plate, for No. 3 gauge Styles 8900 A, 8900 B (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87) Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat			8900 A, 8900 B	4
Throat Plate, for No. 3 gauge Styles 8900 A, 8900 B (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87)- Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat		12609-4 1/4	Looper, back, for No. 4 1/4 gauge Styles	1,
8900 A, 8900 B (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87) Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat		12624 F-3		+
justing screw No. 1096, attaching screw No. 22737, throat plate screw No. 87) 2  12624 F-4 1/4 Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat			8900 A, 8900 B (retainer, front, No.	752
No. 22737, throat plate screw No. 87) 2  12624 F-4 1/4 Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat			8911-3, retainer, back, No. 8912 A, ad-	
12624 F-4 1/4 Throat Plate, for No. 4 1/4 gauge (retainer, front, No. 8911-3, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat			No. 22737, throat plate screw No. 87)-	2
back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat		12624 F-4 1/4	Throat Plate, for No. 4 1/4 gauge (re-	
1096, attaching screw No. 22737, throat				
plate screw No. 87)2			1096, attaching screw No. 22737, throat	
			plate screw No. 87)	2
10 0 10				
				1

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.			
12835	Feed Bar Shoe, for styles in Classes 8400,			
	8800 (screw No. 94)	8		
12873	Needle Bar Bushing	13		
12964 C	" Lever Link Pin Ball	11		
12987 A	Looper Rocker Cone Adjusting Nut	11		
13148 A-14				
35170.0	Classes 8600, 8900, 9100	8		
15430 C	Needle Lever Connecting Rod Nut, left thread	11		
15430 D	" " " right	11		
151.70 T	thread	11		
15430 L \$15430 M	" " Lower Bearing	21		
+1)4)0 11	(screw No.22587)	20		
15436 A	Main Shaft Bushing, left	13		
15465 F	Looper Rocker Cone (screw No. 88, nut No.	-)		
->4->	12987 A)	13		
15745 B	" " Stud	13 13		
16191-6	Needle Bar Thread Eyelet, for Styles 8900 C,			
	8900 L (screw No. 22768, washer No.			
	652 C-9)	16		
17142 A	Needle Rear Guard Holder Support, for styles			
	in Class 8600 (screw, rear, No. 25 CC,	8		
21104 A	screw, front, No. 22528)	28		
21104 B-11	" Rod, 11 inches long	24		
21113 A	" Wire Extension, 6 inches long			
	(set screw No. 22632 F-24)	21		
21113 B	" Wire Coupling (screw No. 88)	14		
21130 A-2	" Seat, two spools	28		
21130 A-3	" " three spools	28		
21130 A-4	Tour spoots	28 28		
21130 A-6	" " six spools " Set Screw No. 69 FD .	20		
21145	Cone, wood, for thread stand	22		
21201	Screw Driver, 9/64 inch round blade, length			
	overall 7 5/8 inches	26		
21202	Screw Driver, 7/32 inch round blade, length			
01057	overall 11 1/4 inches	26		
21203	Screw Driver, 13/64 inch round blade, length	26		
21204	overall 15 1/2 inches	20		
21204	overall 15 inches	26		
21205 A	Screw Driver, 3/8 inch round blade, length			
	overall 14 inches	26		
21207	Screw Driver, 7/64 inch round blade, length			
	overall 2 1/2 inches	22		
21208	Screw Driver Set, three detachable blades	26		
4.				

- 1			
	Symbol	The figures in the last column refer only to the	Plate
	to	plates illustrating the parts and are not to be	No.
	Order by	used in ordering. Refer to pink insert for prices.	E.W
	21215	Cord Spool Holder Assembly, for Styles	Harris .
		8600 C. 8600 Y; one each Nos. 188 D. 753.	
		8600 C, 8600 Y; one each Nos. 188 D, 753, 21218; two each Nos. 201 A, 201 C, 751 A	
		(Specify component parts in ordering)	28
	21218	Cord Spool Holder Axle, for Styles 8600 C,	503.
	21225-7/32	8600 Y Looper Adjusting Gauge, 7/32 inch measure-	21
	21227 1772	ment	14
	21225-1/4	Looper Adjusting Gauge, 1/4 inch measurement	14
	21231	Thread Meter, for recording the consumption	
		of thread in yards as it passes into the	5,2
	21277	sewing machine	24
	21233 A	Light Fixture Assembly, including bulb, machine mounting, for machines driven by	
		"Electro Drive"	_
	21233 N	Connector, with BX cable, for D.C.	
		"Electro Drives"	-
	21233 P	Connector, with BX cable, for single and	
	21236	three phase "Electro Drives" Belt Plier, for 3/8 inch and smaller round	=
	212)0	belting	26
	21260	Emery Cord, 3/64 inch diameter, grade No.	
		120, fifty yard spool	_
	21260 A	Emery Cord, 3/64 inch diameter, grade No.	
	21260 B	150, fifty yard spool Emery Cord, 1/32 inch diameter, grade No.	_
	21200 D	180, fifty yard spool	
	21260 C	Emery Cord, .025 inch diameter, grade No.	
	222/2 -	200, fifty yard spool	-
	21260 D	Emery Tape, 3/32 inch wide, grade No. 180,	
	21260 E	fifty yard spool Emery Cord, .Ol8 inch diameter, grade No.	
	LILOG D	200, fifty yard spool	_
	21261	Leather Belt, flat, 1 inch wide, 63 inches	
		long, includes belt fastener No. 21350	-
	21262	Leather Belt, round, 9/32 inch diameter, 44 inches long, includes wire belt hook No.	
		21351	_
	21350	Malleable Iron Belt Fastener, for 1 inch	
		flat belt	14
	21351	Wire Belt Hook, for 9/32 inch round belt	14
	21355 21367	Chair Leg Extension, 4 inches long Stove Bolt, flat head, 1/4 x 4 inches, for	22
	21901	tray No. 21377	_
	21369-3	Clamping Bolt, includes wing nut No. 21369 A	
		and washer No. 28577, for tray No. 21377	22
	21369 A	Wing Nut, for clamping bolt No. 21369-3	-
			-
	HAT WILLIAM		

	LIST OF PARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
21369 B 21371 Q 21371 BT-42	Clamp Bolt Plate, for tray No. 21377 Table Drawer	_
21371 BT-54 21371 BT-60 21375 A	Blank Table Top, 48" long	_ _ _ 27
21377 21377 C	Tray, 3 7/8 inches high, with bottom, removable front section (clamping bolt No. 21369-3)	27 27
21384 A 21388 21388 N	Leather Plug, for cloth plate screw holes Wrench, for 3/8 inch hexagon nuts double end, 3/16 and 5/16 inch openings	22
21388 R	" double end, 3/8 and 1/2 inch open- ings	22
21390 В	front- Needle Thread Intermittent Nipper Spring, rear (screw No. 22564)	16
21390 E 21390 F	Needle Thread Intermittent Nipper Spring Operating Block (screw No. 90) Needle Thread Intermittent Nipper Spring Operating Block Support (screw No. 22585)	15 16
21390 AS 21390 AT	Needle Thread Intermittent Nipper Spring Support (screw No. 87) Needle Thread Intermittent Nipper Dowel Pin	16 12
21390 AU	Needle Thread Intermittent Nipper Assembly; one each Nos. 90, 21390 A, 21390 B, 21390 E, 21390 F, 21390 AS, 21390 AT, 22564, 22585, and two No. 87	16
21394	Utility Grinder, including emery wheel, 5 inches diameter, 1/4 inch face, round belt drive, recommended speed 3000 R.P.M	
21394 G	Emery Wheel, 5 inches diameter, 1/4 inch face, 3/8 inch hole, grade "M" emery 60-	_
21394 Н	Emery Wheel, 5 inches diameter, 1/2 inch face, 3/8 inch hole, grade "M" emery 60-	_
21394 К	Utility Grinder, including emery wheel, 5 inches diameter, 1/2 inch face, round belt drive, recommended speed 3000 R.P.M	_
21396	Oil Cup, for oiling surface of leather	22
-		

Symbol	The figures in the last column refer only to the	Plate
Order by	plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	No.
21396 AC		
	presser bar lug in place of hand lifter, thread lubricated after entering tension	
21396 AG	(screw No. 93)	21
21602	Needle Thread Pull-off Post, for styles in	
21605	Classes 8500, 8900, 9100 (screw No. 94) Needle Thread Pull-off Rolling Sleeve, for	16
	styles in Classes 8500, 9100, Styles 8900 A,	
21605 A	8900 B, 8900 J	16
	Styles 8900 C, 8900 L	16
21606	Needle Thread Pull-off Rolling Sleeve Axle, for styles in Classes 8500, 9100, Styles 8900 A,	
	8900 B, 8900 J	16
21606 A	Needle Thread Pull-off Rolling Sleeve Axle, for Styles 8900 C, 8900 L	16
21607	Needle Thread Pull-off Clamp Sleeve, for styles	
21608	in Classes 8500, 8900, 9100 (screw No. 87 U) Needle Thread Take-up Wire, for styles in	16
	Classes 8500, 9100, Styles 8900 A, 8900 B, 8900 J (screw No. 87 U)	16
21608 A	Needle Thread Take-up Wire, for Styles 8900 C,	
21610 A	8900 L (screw No. 87 U) Needle Bar Rolling Thread Guide, for styles in	16
	Classes 8400, 8500 (screw No. 22768)	15
21615 A	Needle Bar Rolling Thread Guide, for Styles 8900 A, 8900 B, 8900 J, 9100 C (screw No.	
21624	22768)	15
21024	styles in Classes 8400, 8500, 9100, Styles	
21628	8900 A, 8900 B, 8900 J (screw No. 138) Thread Controller Roller	15 15
21629	" " Stud	9
21632	Needle Lever Rolling Thread Guide, for styles in Classes 8400, 8500 (screw No. 98 A)	15
21633	Needle Lever Rolling Thread Guide, for Styles	
21698-2	8900 A, 8900 B, 8900 J (screw No. 98 A) Vibration Insulator, two inches long, for	15
21698-4	tables	21
21698-5	" five inches long	21
21698-6	" six inches long Note: Special lengths will be furnished on re-	21
	quest. Part of the table leg is shown in the	
22509	illustration for clarity. Set Screw, square head, cup point, 5/16 inch	
	diameter, 18 threads per inch, 1/2 inch long,	· ·
	for thread stand rod	10

	BIOT OF TARTE	
Symbol	The figures in the last column refer only to the	Plate
to	plates illustrating the parts and are not to be	No.
Order by	used in ordering. Refer to pink insert for prices.	
22518	Clamp Screw, for loop retainer rocker	10
22519	Set Screw, hexagonal head, for rolling	
	presser foot roller support on Styles	
	8500 A, 8500 K, 8800 A, 9100 C	9
22521	Screw, plus size, for cloth plates; tap	
	No. V118	9
22524	Screw, for cast-off wires	9
22525	" .010 inch plus size, length overall	
00500	5/16 inch; otherwise same as No. 87-	9
22528	for loop retainer holder on styles in	0
22570	Classes 8400, 8800; also for No.17142A Plug Screw, for main shaft oiling system	9
22539		10
22548	Screw, for rolling presser foot roller support swinging arm lower bracket on	
THE REAL PROPERTY.	Styles 8500 A, 8500 K, 8800 A, 9100 C; also	
	for No. 1593 E, 9958	10
22560	Screw, for link pin spring	9
22560 B	Spot Screw, for needle clamp collar on No. 6	
	gauge Styles 8900 A, 8900 B, 8900 C	9
22564	Screw, for needle thread intermittent nipper	
20560	springs	9
22569 22575	Screw, for feed crank link; also for No.12873 Screw, for rolling presser foot roller	10
22)1)	support swinging arm	9
22584	Screw, for rolling presser foot roller	1
4	support swinging arm upper bracket	9
22585	Screw, for needle thread intermittent nipper	
2050/	spring operating block support	9
22586 A	Screw, for needle lever connecting rod upper	
22587	bearing valve spring	9
22,01	Screw, for needle lever connecting rod bearings	10
22590	Spot Screw, for right main shaft bushing	9
22596	Screw, for looper thread take-up eyelet stand	10
22597	Spot Screw, for eccentric pulleys	9
22597 A	Set Screw, for eccentric pulleys	9
22632 F-24	Set Screw, square head, cup poing, 3/16 inch	122
	diameter, 3/8 inch long, 24 threads to	10
00705	inch, for thread stand wires	10
22705	Screw, capstan head, for adjusting height of back looper on styles in Classes 8900, 9100	9
22730	Screw, for cloth plate guards	9
22736	Screw, capstan head, for presser foot guide	1
	on styles in Classes 8900, 9100	9
22737	Screw, for loop retainer on styles in Classes	200
	8900, 9100	9
22743	Lock Screw, headless, for rolling presser	
22769	foot roller axle	9
22768	Screw, for needle bar thread eyelets; also	0
	for Nos. 8561, 21610 A, 21615 A	7

-		
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
22799 B	Hinge Screw, for presser feet on styles in	
221// 2		10
	Classes 8900, 9100	10
22813	Screw, headless, for lifter treadle pin	9
		,
22818	Axle Screw, button head, for rolling presser	
	foot	9
0000/		
22826	Clamp Screw, for needle lever link pin	10
28577	Washer, for clamping bolt No. 21369-3	11
	HELPOTTE Primal 1/2 H B A C 1 Thoras 60	
28705	"Electro Drive", 1/2 H.P., A.C., 1 phase, 60	
	cycles, 105-115 volts, 3400 R.P.M	-
28705 D		
2010) D	Election Bille, 1/2 miles, accept phase, or	
	cycles, 220 volts, 3450 R.P.M	-
28707 B	"Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
20101 2	avalage 210 370 malta 7500 B B M	
	cycles, 210-230 volts, 3500 R.P.M	
28707 D	"Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
	cycles IIIO volts, 3500 R.P.M.	_
	3,000,000,000	1000
28707 E	cycles, 440 volts, 3500 R.P.M "Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
	cycles, 440 volts, 1725 R.P.M	-
28707 F	"Electro Drive", 1/2 H.P., A.C., 3 phase, 60	
201011	The state of the s	
	cycles, 210-230 volts, 1725 R.P.M	
28708	"Electro Drive", 1/2 H.P., D.C., 105-115 volts,	1000
	3000 R.P.M	_
00700		The second
28708 A		
	3000 R.P.M	-
29057 B	Eccentric Pulley Assembly, for Styles 8900 A,	
-/-/1	8000 B 8000 I 0100 C: one cash Neg 167 A	· 司 / · · · ·
	8900 B, 8900 J, 9100 C; one each Nos. 167 A,	
	15430 M lapped together	20
29058 B	Eccentric Pulley Assembly, for Styles 8900 C,	
	8900 L; one each Nos. 167 B, 15430 M lapped	
	oyou E, one each Nos. 10, 1, 1)4,0 if Tapped	
	together	_
29066 B	Needle Lever Connecting Rod Upper Bearing	
	Assembly; one each Nos. 1230 A, 156 lapped	
	Abbeilibly, the clash loss and appear	17
	together, 1230 B, 1230 D, 22586 A	13
29084 В	Eccentric Pulley Assembly, for styles in Class	
	8400; one each Nos. 9921, 15430 M lapped	10,20
	1,000 the cash Nos. //21, 1949s 1appen	20
	together	20
29087 D	Eccentric Pulley Assembly, for styles in	100
	Classes 8500, 8600, 8800, one each Nos.	
	7421 A, 15430 M lapped together	20
	(421 A, 1)490 H Tapped Together	20
29115	Loop Retainer Lever Eccentric Assembly, for	1 5 5 6 6
	styles in Classes 8400, 8800; one each Nos.	
	9963, 9964, 9965 lapped together	19
00150 -	990); 9904; 990) lappod a garage	-/
29159 J	Looper Rocker Assembly, for styles in Classes	
The state of the s	8900, 9100; one each Nos. 1060, 15465 F,	
	15745 B lapped together, 6038, 12987 A and	
		10
	two No. 88	19
29180 J	Looper Rocker Assembly, for styles in Class	1 50
	8400; one each Nos. 8413, 15465 F, 15745 B	TYS
	1 d to then (079 10097 t and two 17 00	10
	lapped together, 6038, 12987 A and two No. 88-	17
		1.5

	LIST OF TARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
29185 Ј	Looper Rocker Assembly, for styles in Classes 8500, 8600, 8800; one each Nos. 181, 15465 F, 15745 B lapped together, 6038, 12987 A and two No. 88	19
29202-1	Needle Bar Assembly, for No. 3 gauge Style 8400 A; one each Nos. 160 A-1, 89, 164-1 and two No. 166	
29202-2	Needle Bar Assembly, for No. 4 gauge Style 8400 A; one each Nos. 160 A-2, 89, 164-1 and two No. 166	
29203-00	Needle Bar Assembly, for No. 2 gauge Style 8400 A; one each Nos. 160 A-00, 89, 164-1 and two No. 88 B	
29225	Needle Bar Assembly, for Styles 8600 C, 8600 U, 8600 Y; one each Nos. 8617 J, 56 V. 56 VA. 88	
29225 A	Needle Bar Assembly, for Styles 8500 A, 8500 K, 8600 D, 8600 V; one each Nos. 8617 J, 56 V, 88, 8650	
29227	Needle Bar Assembly, for styles in Class 8800; one each Nos. 8717, 88 B, 89,8718	_
29231-1	Needle Bar Assembly, for No. 1 gauge Style 9100 C; one each Nos. 9145-1, 88, 89, 1065-3, 1066, 9117-3 and two No. 88 B-	_
29231-2	Needle Bar Assembly, for No. 2 gauge; one each Nos. 9145-2, 88, 89, 1065-3, 1066, 9117-3 and two No. 88 B	
29231-3	Needle Bar Assembly, for No. 3 gauge; one each Nos. 9145-3, 88, 89, 1065-3, 1066.	
29231-4	9117-3 and two No. 88 B Needle Bar Assembly, for No. 4 gauge; one each Nos. 9145-4, 88, 89, 1065-3, 1066,	
29231 A-2	9117-3 and two No. 88 B Needle Bar Assembly, for No. 2 gauge Styles 8900 A, 8900 B; one each Nos. 8945-2, 88, 89, 1065-3, 1066, 9117-3	
29231 A-3	and two No. 88 B Needle Bar Assembly, for No. 3 gauge; one	-
29231 A-4	9117-3 and two No. 88 B Needle Bar Assembly, for No. 4 gauge Styles 8900 A, 8900 B, 8900 C; one each	-
2027) 4 1 2 4	Nos. 8945-4, 1065-5 1/4, 9030, 9117-3 and two each Nos. 88 B, 89	_
29201 A-4 1/4	Needle Bar Assembly, for No. 4 1/4 gauge Styles 8900 A, 8900 B; one each Nos. 8945-4 1/4, 1065-5 1/4, 9030, 9117-3 and two each Nos. 88 B, 89	
	and one dan hose of by of	

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pin insert for prices.	Plate No.
29231 A-4 1/2 29231 A-5	Needle Bar Assembly, for No. 4 1/2 gauge; one each Nos. 8945-4 1/2, 1065-5 1/4, 9030, 9117-3 and two each Nos. 88 B, 89 Needle Bar Assembly, for No. 5 gauge; one	-
29231 A-5 1/4	each Nos. 8945-5, 1065-5 1/4, 9030, 9117-3 and two each Nos. 88 B, 89 Needle Bar Assembly, for No. 5 1/4 gauge; one each Nos. 8945-5 1/4, 1065-5 1/4, 9030, 9117-3 and two each Nos. 88 B, 89	-
29231 A-5 1/2	Needle Bar Assembly, for No. 5 1/2 gauge; one each Nos. 8945-5 1/2, 1065-6, 9030, 9117-3 and two each Nos. 88 B, 89	
29231 A-6	Needle Bar Assembly, for No. 6 gauge Styles 8900 A, 8900 B, 8900 C; one each Nos. 8945-6, 1065-32, 9117-3, 9130.	
29231 C-4 1/4	22560 B and two No. 88 B Needle Bar Assembly, for No. 4 1/4 gauge Style 8900 C; one each Nos. 8945 C-4 1/4, 1065-6, 9117-3, 9130 and	-
29231 C-4 1/2	Needle Bar Assembly, for No. 4 1/2 gauge; one each Nos. 8945 C-4 1/2, 1065-6,	-
29231 C-5	9117-3, 9130 and four No. 89 Needle Bar Assembly, for No. 5 gauge; one each Nos. 8945 C-5, 1065-6, 9117-3, 9130 and two each Nos. 88 B, 89	_
	Needle Bar Assembly, for No. 5 1/4 gauge; one each Nos. 8945 C-5 1/4, 1065-6, 9117-3, 9130 and two each Nos. 88 B. 89	_
29240-1	Needle Bar Assembly, for No. 5 1/2 gauge; one each Nos. 8945 C-5 1/2, 1065-32, 9117-3, 9130 and two each Nos. 88 B, 89 Needle Bar Assembly, for No. 1 gauge	_
29304 E	Styles 8400 A, 8400 B; one each Nos. 8417-1, 89, 164-1 and two No. 88 B Needle Lever Cone Bearing Stud Assembly;	_
29310 D	one each Nos. 1276, 6090 A, 6093 lapped together, and two each Nos. 88, 11638 M Loop Retainer Lever Assembly; one each	19
29324	Nos. 8860 A, 9961 A, 9961 B lapped together, and two No. 89 Loop Retainer Rocker Shaft Connection Assembly; one each Nos. 9957 A, 9957 B	19
29402	lapped together Lifter Treadle Assembly; one each Nos. 422, 423, 424, 22813	<b>-</b> 25
35582 в К39915	Tension Thread Eyelet Looper, back, for No. 2 gauge Styles 8900 C, 8900 L (set screw No. 73)	15
		-

	LIST OF PARTS	
Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
к39918	Throat Plate, for No. 2 gauge Styles 8900 C, 8900 L (retainer, front, No. 9111, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87)	_
41078 в к42045	Main Shaft Bearing Spring Valve Oiler Presser Foot, with adjustable guide on left side, for No. 4 gauge Style 8900 C (guide No. 9140 B, guide screw No. 22736, clamp screw	14
к42115	No. 91) 4 gauge Style 8900 C (retainer, front, No. 8911 C, retainer, back, No. 8912, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87)	
кц2376	Needle Bar Head Assembly, for No. 1 gauge Styles 8900 A, 8900 B, 8900 J; one each Nos. K55397, 1065-3, 1066 and two each Nos. 88 B,	
к42377	Presser Foot, with adjustable guide on right side, for No. 1 gauge Style 8900 B (guide No. 9141 B, guide screw No. 22736, hinge screw No. 22799 B, clamp screw No. 91	
к42378	Throat Plate, for No. 1 gauge Styles 8900 A, 8900 B, 8900 J (retainer, front, No. 9111, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat	
к42379	plate screw No. 87)	-
K42380 K42415	Looper, back, for No. 1 gauge Styles 8900 A, 8900 B, 8900 J (set screw No. 73) Presser Foot, with guide on left side, for No.	-
	2 gauge Style 8900 L (guide No. K46372, guide screw No. 22736, clamp screw No. 91)	_
КЦ2Ц22 КЦ3309	Looper, back, for No. 4 gauge Style 8900 C (set screw No. 73) Needle Bar Assembly, for No. 1 gauge Styles	-
	8900 C, 8900 L; one each Nos. K47394, 88, 89, 1065-5, 1066, 9117-3 and two No. 88 B	-
к43310	Throat Plate, for No. 1 gauge Styles 8900 C, 8900 L (retainer, front, No. 9111, retainer, back, No. 8912 A, adjusting screw No. 1096, attaching screw No. 22737, throat plate screw No. 87)	
к43311	Presser Foot, with guide on right side, for No. 1 gauge Style 8900 L (guide screw No. 22736,	
К43408	Needle Bar Head Assembly, for No. 2 gauge Styles 8900 C, 8900 L (needle clamp collar	-
	No. 1065-4 1/2, needle clamp collar spot	
	screw No. 89, needle set screw No. 88 B)	_

Symbol to Order by	The figures in the last column refer only to the plates illustrating the parts and are not to be used in ordering. Refer to pink insert for prices.	Plate No.
K43441	Looper, front, with guard, for No. 1 gauge Style	
	8900 L (guard No. K43443, guard screw No. 73 A,	
	looper set screw No. 73)	
K/13/1/13	Looper Needle Guard, for No. 1 gauge Style	
**+>++>	8900 L (screw No. 73 A)	
VI. 7857		
14,0071	Presser Foot, with adjustable guide on left side,	
	for No. 2 gauge Style 8900 C (guide No. 9140 B,	
	guide screw No. 22736, hinge screw No. 22799 B,	
	clamp screw No. 91)	-
К44081	Looper, back, for No. 3 gauge Style 8900 C (set	
William William William	screw No. 73)	-
K44083	Throat Plate, for No. 3 gauge Style 8900 C (re-	
	tainer, front, No. 8911 C, retainer, back, No.	
	8912, adjusting screw No. 1096, attaching screw	
	No. 22737, throat plate screw No. 87)	-
K44084	Needle Bar Assembly, for No. 3 gauge Style 89000;	
	one each Nos. K44386, 88, 89, 1065-5 1/4,	
	9030, 9117-3 and two No. 88 B	-
K44329	Presser Foot, with adjustable guide on left side,	
	for No. 3 gauge Style 8900 A (guide No. 9140 A,	
	guide screw No. 22736, clamp screw No. 91)	_
Khh330	Presser Foot, with adjustable guide on left side,	
	for No. 3 gauge Style 8900 C (guide No. 9140 B,	
	guide screw No. 22736, clamp screw No. 91)	_
K/1/1332	Presser Foot, with adjustable guide on left side,	
	for No. 1 gauge Style 8900 C (guide No. 9140 B,	
	guide screw No. 22736, hinge screw No. 22799 B,	
	clamp screw No. 91)	_
KU1386	Needle Bar Head, for No. 3 gauge Style 8900 C	_
K16372	Presser Foot Guide, for No. 2 gauge Style 8900 L	
140)12	(screw No. 22736)	_
KI,7301	Needle Bar Head, for No. 1 gauge Styles 8900 C,	
141774	8900 L	-
K17810	Presser Foot, with adjustable guide on left side,	
	for No. 2 gauge Style 8900 A (guide No. 9140 B,	
	guide screw No. 22736, hinge screw No. 22799 B,	The same of
	clamp screw No. 91)	-
K17859	Presser Foot, with cord guide on left side, for	
11410))	No. 1 gauge Style 8900 J (guide No. K52391,	100
	guide screw No. 22736, clamp screw No. 91)	_
K52391	Presser Foot Cord Guide, for No. 1 gauge Style	
	8900 J (screw No. 22736)	-
K5/1/123	Presser Foot, with adjustable guide on left side,	
,4-1-)	for No. 1 gauge Style 8900 A (guide No. 9140 B,	Garage T
	guide screw No. 22736, hinge screw No. 22799 B,	8 11 2
	clamp screw No. 91)	-
K55397	Needle Bar Head, for No. 1 gauge Styles 8900 A,	
/////	8900 B, 8900 J	_

