




No. 序號	Parts No. 品 號	English Description 英文品名	Chinese Description 中文品名	Specification 規格	AMT 數量
1	DDBB0140	Pedal sensor	速度基座組		1
2	AAB00910	Pedal sensor lever arm	速度基座反向外拉臂桿		1
3	AGK00240	Pedal sensor lever arm spring	速度基座外拉臂彈簧		1
4	ACF00130	PTFE washer	耐磨華司	D22xd12x0.1T	1
5	AGA0410D	Screw +Spring washer +Washer	螺絲+彈簧華司+平華司	M4xS4xφ8x0.8Tx10L	3
6	AGE0604A	Hexagon nut	螺帽	M6xP1.0xH4	2
7	ACE00070	Pedal sensor side cover	速度基座側蓋板		1
8	AGA06200	Hexagon bolts	外六角螺絲	M6xP1.0x20L	1
9	AGK00250	Pedal sensor adjusting spring	速度基座調整彈簧	φ1.0x25L	1
10	ACF00120	Pedal sensor control pin	速度基座制動桿		1
11	ADA02100	Spring fixed tagger	彈簧固定片		1
12	AGA0408A	Hexagon socket screw	內六角沉窩螺絲	M4xP0.7x8L	1
13	AAB00920	Induction screw	速度基座感應臂		1
14	AGQ00040	Nylon pin	尼龍鉚釘	ΠP-3065(3*6.5/黑)	2
15	BDA00130	Induction cable assy.	感應連接線	120L	1
16	BBH01200	Ties Support	束帶	120L	1