

Pfaff 1441 Subclass

PFAFF[®] 1441

Unterklassen-Ausstattung

Subclass parts

Composition des sous-classes

Composición de las subclases

Unterklassen-Ausstattung

Equipement des sous-classes

Subclass organization

Dotación de las subclases

Unterklasse Subclass Sous-classe Subclase	Ausführung Model Version Tipo de maquina	Nadelstange Needle bar Barre à aiguille Barra de aguja	Stoffschieber Feed dog Griffe Transportador inferior	Stichplatte Needle plate Plaque à aiguille Placa de aguja
-2/01	BN; CN	91-165 407-91	91-059 033-04	91-058 855-04
-2/01-900/56; /61	BN; CN	91-165 407-91	91-059 033-04	91-158 801-04
-6/01	BN; CN	91-165 407-91	91-047 562-04	91-058 095-04
-6/01-900/56; /61	BN; CN	91-165 407-91	91-059 364-04	91-158 750-04

4 = Ausführung angeben
 = Indicate model
 = Préciser la version
 = Indíquese el tipo de maquina

Unterklassen-Übersicht/Table of subclasses/Table des sous-classes/Tabla de subclases

<div> <div>91-165 407-91</div> <div>91-177 357-45</div> <div>91-118 196-12</div> <div> <div>11-174 173-15</div> </div> <div> <div>11-108 033-15</div> <div>91-175 097-05</div> <div>91-173 664-15</div> <div>91-175 099-05</div> </div> </div>	<div>91-047 562-04 4</div> <div>-6/01</div>	<div>91-059 033-04 4</div> <div>-2/01 (-900/56; /61)</div>	<div>91-059 364-04 4</div> <div>-6/01 (-900/56; /61)</div>
	<div>91-058 095-04 4</div> <div>-6/01</div>	<div>91-058 855-04 4</div> <div>-2/01</div>	<div>91-158 750-04 4</div> <div>-6/01-900/56; /61</div>
	<div>91-158 801-04 4</div> <div>-2/01-900/56; /61</div>		<div>91-054 915-03 4</div> <div>-2/01 (-900/56; /61) -6/01 (-900/56; /61)</div>







Équipement des sous-classes
Unterklassen-Ausstattung

Dotación de las subclases
Subclass organization

Subclass Sous-classe Subclase	Ausführung Model Version Tipo de máquina	Nähtuß / Presser foot Pie pressateur Pie prensateelas	Lineal Edge guide Guirle-bord Guia recta	Schieber links Slide left Glissière gauche Corredora izquierdo	Schieber rechts Slide right Glissière droit Corredora derecho
/01	BN, CN	91-054 915-03	91-053 620-91	91-118 835-24 x 0,8	91-173 908-93 x 0,8
/01-900/56; /61	BN, CN	91-054 915-03	91-053 620-91	91-173 907-24 x 0,8	91-173 908-93 x 0,8
/01	BN, CN	91-054 915-03		91-118 835-24 x 0,8	91-118 844-24 x 0,8
/01-900/56; /61	BN, CN	91-054 915-03		91-173 907-24 x 0,8	91-173 906-24 x 0,8

= Ausführung angeben
= indicate model
= Préciser la version
= Indíquese el tipo de máquina

Unterklassen-Übersicht/ Table of subclasses/ Table des sous-classes/ Tabla de subclases

<p>91-118 835-24</p>  <p>-2/01 -6/01</p>	<p>91-118 844-24</p>  <p>-6/01</p>
<p>91-173 907-24</p>  <p>-2/01-900/56; /61 -6/01-900/56; /61</p>	<p>91-173 906-24</p>  <p>-6/01-900/56; /61</p>
<p>91-053 620-91</p>  <p>-2/01 (-900/56; /61)</p>	<p>91-173 289-25</p> <p>91-173 908-23</p>  <p>-2/01 (-900/56; /61)</p>