



SEIKO

PARTS LIST


THM-26B-FL




SEIKO SEWING MACHINE CO., LTD.




P1




P2




P3




P4




P5




P6




P7





P9




P10




P11





P12



P13



P14



P15

THM-26B-FL PARTS LIST

PAGE	NO	DESCRIPTIONS OF PARTS	QTY
P1	1	ARM COVER PLATE (REAR)	1
	2	SCREW	2
	7	SCREW	1
	8	FACE PLATE	1
	9	SCREW	3
	10	THROAT PLATE	1
	11	SCREW	4
	12	CENTER GUIDE	1
	13	SCREW	1
	14	SLIDE PLATE (RIGHT)	1
	15	BED	1
	16	SLIDE PLATE (LEFT)	1
	17	BED SLIDE SPRING	1
	18	SCREW	2
	19	OIL GUIDE BUSHING	4
P2	1	NEEDLE BAR CONNECTING LINK	1
	2	PIN	1
	3	CAM	1
	4	ROLLER	1
	5	HINGE PIN	1
	6	THREAD TAKE-UP LEVER	1
	7	NUT	1
	8	HINGE PIN	1
	9	SCREW	1
	10	ARM SHAFT BUSHING (FRONT)	1
	11	FEED DRIVING CAM	1
	12	SCREW	1
	13	ROCK SHAFT CONNECTING ROD	1
	14	WASHER	1
	16	COLLAR	1
	17	SCREW	1
	18	SCREW	4
	19	COVER PLATE (SMALL)	1
	20	SCREW	2
	21	CAM	1
	22	BEARING	1
	23	CLANK CONNECTING ROD	1
	24	COVER PLATE	1
	25	ARM SHAFT	1
	26	FELT	1
	27	ARM SHAFT BUSHING (REAR)	1
	28	FELT	1
	29	HAND PULLEY	1
	30	SYNCHRONIZER ADAPTER	1
	31	SCREW	3
	32	WASHER	1
P3	1	PRESSER BAR BRACKET	1
	2	SCREW	1
	3	PRESSER BAR CONNECTING PLATE	1
	4	COLLAR	1
	5	SCREW	1
	6	WASHER	1

P3	7	E-RING	1
	8	PRESSER BAR LIFTING CAM	1
	9	PRESSER BAR LIFTING LEVER	1
	10	LEVER KNOB	1
	11	PRESSER BAR THUMB SCREW	1
	12	NUT	1
	13	PRESSER BAR	1
	14	PRESSER BAR SPRING	1
	15	PRESSER BAR SLIDE BLOCK	1
	16	SCREW	2
	17	PRESSER BAR BUSHING	1
	18	ROLLER PRESSER FOOT BRACKET	1
	19	PRESSER BAR SLIDE GUIDE	1
	20	SCREW	2
	21	FOOT LIFTER LIFTING LEVER	1
	22	SPRING	1
	23	SCREW	1
	24	PIN	1
P4	1	NEEDLE BAR BUSHING (UPPER)	1
	3	NEEDLE BAR PIPE	1
	4	NEEDLE BAR CONNECTING STUD	4
	5	SCREW	2
	6	NEEDLE BAR CONNECTING LINK	1
P5	7	NEEDLE BAR BUSHING (LOWER)	1
	1	HOOK DRIVING SHAFT NUT	1
	2	SCREW	2
	3	SCREW	3
	4	HOOK DRIVING SHAFT BUSHING (REAR)	1
	5	SCREW	1
	6	HOOK DRIVING GEAR	1
	7	HOOK DRIVING SHAFT	1
	8	SCREW	2
	9	HOOK BASE UPPER PLATE	9
	10	PIN	2
	11	SCREW	8
	12	HOOK BASE COVER (LEFT)	1
	13	HOOK BASE	1
	14	STUD SCREW	2
	15	SCREW	2
	16	PIN	1
	17	SCREW	2
	18	SCREW	1
	19	HOOK DRIVING SHAFT BUSHING (FRONT)	1
	20	HOOK BASE RING (INNER)	1
	21	HOOK BASE RING (MIDDLE)	1
	22	HOOK BASE RING (OUTER)	1
	23	SHUTTLE DRIVER	1
	24	SCREW	1
	25	NUT	1
	26	HOOK RING-SPRING OPENER LEVER	1
	27	SCREW	2
	28	SCREW	1
	29	HOOK RING-SPRING BASE	1
	30	HOOK RING-SPRING	1
	31	HINGE SCREW	1
	32	SCREW	4
	33	HOOK BASE COVER (LOWER)	1

P5	34	SHUTTLE HOOK WITH BOBBIN	1
	35	BOBBIN	1
P6	1	LOWER SHAFT GEAR (LEFT)	1
	2	SCREW	3
	3	LOWER SHAFT BUSHING (LEFT)	2
	4	LOWER SHAFT (LEFT)	1
	5	LOWER SHAFT COLLAR (LEFT)	1
	6	SCREW	2
	7	COUPLING	1
	8	SCREW	2
	9	LOWER SHAFT (RIGHT)	1
	10	LOWER SHAFT COLLAR (RIGHT)	1
	11	LOWER SHAFT BUSHING (RIGHT)	1
	12	LOWER SHAFT GEAR (RIGHT)	1
	13	OSCILLATING SHAFT CRANK GEAR	1
	14	PIN	1
	15	PIN	1
	16	OSCILLATING SHAFT CRANK	1
	17	WASHER	3
	18	SCREW	3
	19	HINGE PIN	1
	20	PIN	1
P7	1	NUT	2
	2	FEED LIFTING ROCK SHAFT	1
	3	BUSHING	1
	4	COLLAR	1
	5	SCREW	2
	6	FEED LIFTING ROCK SHAFT LINK	1
	7	SCREW	1
	8	BUSHING	1
	9	NUT	1
	12	SCREW	2
	13	BALL RINK COMPLETE	1
	14	BALL RINK HOUSING	1
	15	BALL RINK BUSHING	2
	16	FEED DOG	1
	17	SCREW	2
	18	FEED BASE	1
	19	FEED BASE PIN	1
	20	RING	1
	21	OIL WICK	1
P8	1	BUSHING	1
	2	LOWER FEED SHAFT CONNECTING	1
	3	SCREW	2
	4	SCREW	5
	5	RING	1
	6	LOWER FEED SHAFT	1
	7	COLLAR	2
	8	LOWER FEED LINK	1
	9	SCREW	1
	10	SCREW	1
	11	PIN	1
P9	1	BUSHING	1
	2	FEED REGULATING SUPPORT RING	1
	3	SCREW	1
	4	NUT	1
	5	SCREW	1

P9	6	FEED REGULATING	1
	7	SLIDE BLOCK	1
	8	SPRING	1
	9	GUIDE BLOCK SUPPORT PLATE	1
	10	FEED REGULATING STOPPER	1
	11	FEED REGULATING PLATE	1
	12	SCREW	2
	13	FEED REGULATING BAR GUIDE	1
	14	FEED REGULATING BAR	1
	15	FEED REGULATING THUMB NUT	1
	16	FEED REGULATING KNOB	1
P10	1	THREAD TENSION COMP. (UPPER)	2
	2	THUMB NUT	3
	3	THUMB NUT STOPPER WASHER	3
	4	TENSION SPRING	3
	5	TENSION RELEASING WASHER	3
	6	TENSION DISC	4
	7	TENSION STUD SCREW	2
	8	NUT	2
	9	TENSION RELEASING PIN	2
	10	SCREW	2
	11	SCREW	3
	12	TENSION GUIDE (UPPER)	1
	13	THREAD TENSION (UPPER) BRACKET	1
	14	TENSION RELEASING PLATE	1
	15	THREAD GUIDE (LOWER)	1
	16	THREAD CONTROLLER SPRING STOPPER	1
	17	SCREW	1
	18	NUT	1
	19	THREAD GUIDE RING	1
	20	TENSION CONTROLLER SPRING	1
	21	TENSION CONTROLLER SUPPORT SPRING	1
	22	THREAD TENSION COMP. (LOWER)	1
	23	TENSION CONTROLLER STUD	1
	24	WASHER	2
	25	FELT	2
	26	THREAD TENSION DISK	2
P11	1	THREAD STAND COMPLETE (THREE DISC)	1
P12	1	NEEDLE POSITIONING CHANGER	1
	2	SCREW	1
	3	NEEDLE BAR PIPE	1
	4	NEEDLE CLAMP STOPPER KEY	1
	5	SCREW	2
	6	NEEDLE BAR	1
	7L	NEEDLE CLAMP (LEFT)	1
	7R	NEEDLE CLAMP (RIGHT)	1
	8	NEEDLE BAR ROTATE SHAFT	1
	9L	ROLLER PRESSER FOOT (LEFT) COMP.	1
	9R	ROLLER PRESSER FOOT (RIGHT) COMP.	1
	10	SCREW	2
	11	ROLLER PRESSER FOOT BRACKET	1
	12	NEEDLE POSITIONING CHANGER (8mm)	1
	13	NEEDLE CLAMP (8mm)	2
	14	NEEDLE SET SCREW (8mm)	2
	15	NEEDLE BAR COMP. (8mm)	1
P13	1	ARM SHAFT TIMING PULLEY	1
	2	FEED LIFTING CONNECTING BAR	1

P13	3	ROD END	1
	4	NEEDLE POSITIONING CHANGER CONNECTING BAR	1
	5	TIMING BELT	1
	6	TRANSMITTER BASE	1
	7	TRANSMITTER TIMING PULLEY	1
	8	TRANSMITTER	1
	9	FEED LIFTING CONNECTING ARM	1
	10	ROLLER	1
	11	NEEDLE POSITIONING CHANGER CONNECTING ARM	1
	12	COLLAR	1
	13	PIN	1
	14	ROD-END	1
	15	ROD-END	1
	16	ROLLER	1
P14	1	ROD-END	1
	2	NEEDLE POSITION CHANGER CONNECTING BAR	1
	3	ROD-END	1
	4	PIN	1
	5	NEEDLE POSITIONING CHANGER RACK	1
	6	RACK SUPPORT BLOCK	1
P15	1	PATTERN CAM (1)	1
	2	PATTERN CAM (2)	1
	3	PATTERN CAM (3)	1
	4	PATTERN CAM (4)	1
	5	PATTERN CAM (5)	1
	6	THUMB SCREW	1
	7	FOOT LIFTING AIR CYLINDER	1