

LIST OF PARTS



SINGER^{**}

MACHINE No. 105-9

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, "TYPE B" or "TYPE D" OIL, sold by Singer Sewing Machine Company, should be applied at least twice each day to all oil holes marked "OIL".

"TYPE D" OIL should be used when an oil is desired which will produce a minimum of stain on fabrics, even after a long period of storage.

Copyright, U. S. A., 1940, 1947 and 1954
by The Singer Manufacturing Company
All Rights Reserved for all Countries

INDEX

	Page
Accessories	12
Fittings	12
Foot Lifter Parts	12
Hemmer on Shank	12
Knee Lifter Parts	13
Machine Base	13
Machine Base Oil Drain Jar	14
Machine No. 105-9	7
Numerical List of Parts	15
Thread Unwinder	14

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A—Hardened, Polished, Nickel Plated and Buffed
- A.A—Buffed and Chromium Plated
- A.B—Hardened, Polished, Buffed and Chromium Plated
- A.C—Brown Baking Enamel Finish
- A.D—Gray Baking Enamel Finish
- A.E—Hardened, Bright Rumbled and Nickel Plated
- A.F—Hardened, Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated
- A.G—Alumilite, Plain
- A.H—Alumilite, Dyed
- A.J—Polished, Nickel Plated and Chromium Plated
- A.K—Hardened, Polished, Nickel Plated and Chromium Plated
- A.L—Heat Treated for Toughness
 - B—Polished, Nickel Plated and Buffed
 - C—Hardened Only
- C.R—Hardened and Merlized
 - D—Polished Only
 - E—Soft, Not Polished
 - F—Hardened and Polished
- F.J—Hardened, Polished and Nickel Plated
 - G—Bright Rumbled and Nickel Plated
 - H—Blued
 - J—Nickel Plated Only
 - K—Hardened and Nickel Plated
 - L—Brass Plated
 - M—Oxidized
 - N—Japanned, Dull
 - P—Japanned, Bright
- P.P—Wrinkle Finish
 - R—Merlized
 - S—Cadmium Plated
 - T—Copper Plated
- T.A—Hardened, Polished, Copper and Nickel Plated and Buffed
- T.B—Copper and Nickel Plated and Polished
- T.J—Copper and Nickel Plated Only
- T.K—Hardened, Copper and Nickel Plated
- T.L—Copper and Brass Plated
- T.M—Copper Plated and Oxidized

INSTRUCTIONS FOR ORDERING—Continued

- U—Zinc Plated
- V—Silver Plated
- W—Polished and Nickel Plated
- X—Black Oxide, for Iron and Steel
- X.C—Hardened and Black Oxide, for Iron or Steel
- Y—Black Nickel Plated Only
- Z—Chromium Plated
- Z.A—Hardened, Polished, Nickel Plated, Buffed and Chromium Plated
- Z.B—Polished, Nickel Plated, Buffed and Chromium Plated
- Z.C—Hardened and Chromium Plated
- Z.D—Polished and Chromium Plated
- Z.G—Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated
- Z.J—Nickel and Chromium Plated
- Z.T—Copper and Chromium Plated

These letters **MUST BE USED** when they appear in the list; and **AFTER** the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000 are
Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers

1801 to 2000 and 51801 to 52000 are Roller Numbers

2001 to 50000 and 52001 to 140000 and 142001 to 190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.


The figures in the second column refer only to the plates, illustrating the parts, and are **NOT TO BE USED** in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

SINGER Needles should be used
in SINGER Machines
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles. 2

LIST OF PARTS COMPLETE FOR



MACHINE No. 105-9

FOR HEMMING THE BOTTOM OF OVERALLS. ONE NEEDLE, ONE LOOPER. HIGH LIFT. STITCHES MATERIAL UP TO 5/16" THICK. LENGTH OF STITCH 6 TO 20 TO THE INCH. CYLINDRICAL SHAPED THROAT PLATE. TRIPLE HINGED PRESSER FOOT. SPEED UP TO 3200, DEPENDING ON MATERIALS USED AND OPERATIONS PERFORMED.

No.	Plate	Name
*59637		Arm, upper and lower (solid).....
59491	22581	Arm Rotary Shaft.....
59609		Arm Rotary Shaft Bushing (back).....
59610	22581	Arm Rotary Shaft Bushing (back) 59609 with 52045 and 59611.....
59611		Arm Rotary Shaft Bushing (back) Oil Wick (braided cotton).....
52045	22581	Arm Rotary Shaft Bushing (back) Packing (wick).....
50554AL	22581	Arm Rotary Shaft Bushing (back) Set Screw.....
59524	22581	Arm Rotary Shaft Bushing (front) with 52045.....
52045	22581	Arm Rotary Shaft Bushing (front) Packing (wick).....
448AL	22581	Arm Rotary Shaft Bushing (front) Set Screw.....
59612		Arm Rotary Shaft Bushing (intermediate).....
59613	22581	Arm Rotary Shaft Bushing (intermediate) 59612 with 52045 and 128571.....
128571		Arm Rotary Shaft Bushing (intermediate) Oil Wick (braided cotton).....
52045	22581	Arm Rotary Shaft Bushing (intermediate) Packing (wick).....
50554AL	22581	Arm Rotary Shaft Bushing (intermediate) Set Screw.....
59629	22581	Arm Side Cover with 59631 and 132555.....
59631	22581	Arm Side Cover Oil Tube Oil Cup.....
132555	22581	Arm Side Cover Oil Tube Oil Pad (braided cotton).....
1423J	22581	Arm Side Cover Screw (2).....
59667	22582	Feed Bar with two each 458AL and 882AL.....
59668		Feed Bar 59667 with 59670 and 59671.....
59669	22582	Feed Bar Carrier with two 882AL and four 449AL.....

No.	Plate	Name
59670		Feed Bar Carrier 59669 with 59617 and 59618.....
57234	22582	Feed Bar Carrier Hinge Pin.....
57235	22582	Feed Bar Carrier Hinge Pin Bushing (2).....
457AL	22582	Feed Bar Carrier Hinge Pin Bushing Set Screw (2).....
449AL	22582	Feed Bar Carrier Hinge Pin Set Screw (2).....
59671	22582	Feed Bar Hinge Pin.....
59617	22582	Feed Bar Hinge Pin Bushing (left).....
882AL	22582	Feed Bar Hinge Pin Bushing (left) Set Screw.....
59618	22582	Feed Bar Hinge Pin Bushing (right).....
882AL	22582	Feed Bar Hinge Pin Bushing (right) Set Screw.....
458AL	22582	Feed Bar Hinge Pin Set Screw (2).....
59640	22583	Feed Dog, 8 teeth (6 teeth to the inch).....
596J	22583	Feed Dog Screw.....
51061AL	22581	Feed Eccentric Body Set Screw (2).....
7071	22581	Feed Eccentric Clamping Washer.....
217J	22581	Feed Eccentric Clamping Washer Screw.....
59495	22581	Feed Eccentric (adjustable) complete, Nos. 217J, 7071, 50328C, 130337 and two 51061AL.....
59517		Feed Eccentric 59495 with 59216.....
59216	22582	Feed Eccentric Connection with 12002 and 139110.....
59217	22582	Feed Eccentric Connection Bar with 59218.....
59218		Feed Eccentric Connection Bar Plug.....
449AL	22582	Feed Eccentric Connection Bar Set Screw (2).....
139110	22582	Feed Eccentric Connection Oil Wick.....
12002	22582	Feed Eccentric Connection Oil Wick Retaining Pin.....
130337		Feed Eccentric Lubricating Pad (wood).....
59513	22581	Feed Lifting Eccentric with two 50150AL.....
59514		Feed Lifting Eccentric 59513 with 59220.....
59220	22582	Feed Lifting Eccentric Connection.....
59221	22582	Feed Lifting Eccentric Connection Bar with 59218.....
59635	22581	Feed Lifting Eccentric Connection Bar Oil Tube with Bracket complete, Nos. 59631 and 130901.....
190J	22581	Feed Lifting Eccentric Connection Bar Oil Tube Bracket Screw.....
59631	22581	Feed Lifting Eccentric Connection Bar Oil Tube Oil Cup.....
130901	22581	Feed Lifting Eccentric Connection Bar Oil Tube Oil Pad (wick).....
59218		Feed Lifting Eccentric Connection Bar Plug.....
882AL	22582	Feed Lifting Eccentric Connection Bar Set Screw (2).....
42727	22581	Feed Lifting Eccentric Position Pin.....
50150AL	22581	Feed Lifting Eccentric Set Screw (2).....
50328C	22581	Feed Regulating Screw.....
59487	22583	Looper.....
59381	22582	Looper Carrier with 50395AL.....
59224	22582	Looper Carrier Driver with two 1186E.....
1186E	22582	Looper Carrier Driver Clamping Screw (2).....
207J	22581	Looper Carrier Driver Timing Screw.....
59225	22582	Looper Carrier Hole Plug.....
59226	22582	Looper Carrier Shaft.....
59227	22582	Looper Carrier Shaft Crank with 1143AL.....
1143AL	22582	Looper Carrier Shaft Crank Clamping Screw.....
59663	22584	Looper Cover with two 1602E.....
59664	22584	Looper Cover complete, Nos. 59230, 59663 and two 330J.....
1602E	22584	Looper Cover Screw Bushing (2).....
59230	22584	Looper Cover Holder.....
59231	22584	Looper Cover Holder Sleeve with 457AL.....
457AL	22584	Looper Cover Holder Sleeve Set Screw.....
59232	22584	Looper Cover Lock Stud.....
59233	22584	Looper Cover Lock Stud Spring.....
50300E	22584	Looper Cover Lock Stud Spring Cap Screw.....
330J	22584	Looper Cover Screw (2).....
50395AL	22582	Looper Set Screw.....
59686	22581	Machine Driving Pulley, "V" belt groove (outside diam. of belt groove 2.9 in.) with 424C and 1354C.....

No.	Plate	Name
1354C	22581	Machine Driving Pulley Position Screw.....
424C	22581	Machine Driving Pulley Set Screw.....
59683	22585	Needle Bar (hollow) with 1072F.....
59666	22585	Needle Bar Bushing (lower).....
457AL	22585	Needle Bar Bushing (lower) Set Screw.....
59469	22585	Needle Bar Bushing (upper).....
457AL	22585	Needle Bar Bushing (upper) Set Screw.....
59672	22585	Needle Bar Connecting Bracket with 175E and 460AL.....
175E	22585	Needle Bar Connecting Bracket Clamping Screw.....
59237	22585	Needle Bar Connecting Link.....
40247	22585	Needle Bar Connecting Link Hinge Pin (lower).....
208AL	22585	Needle Bar Connecting Link Hinge Pin (lower) Set Screw....
40247	22585	Needle Bar Connecting Link Hinge Pin (upper).....
460AL	22585	Needle Bar Connecting Link Hinge Pin (upper) Set Screw....
59471	22585	Needle Bar Lever with 208AL, 448AL and 51407AL.....
59684		Needle Bar Lever 59471 with 59237, 59672 and two 40247
59603	22581	Needle Bar Lever Connecting Rod with 2089, 54969 and two each 141E and 647E.....
59604		Needle Bar Lever Connecting Rod 59603 with 59240 and 59636.....
59240	22581	Needle Bar Lever Connecting Rod Ball Stud.....
51407AL	22585	Needle Bar Lever Connecting Rod Ball Stud Set Screw.....
141E	22581	Needle Bar Lever Connecting Rod Cap (lower) Screw (2)...
647E	22581	Needle Bar Lever Connecting Rod Cap (upper) Screw (2)...
59636	22581	Needle Bar Lever Connecting Rod Eccentric with 448AL, 1299AL and two 59606.....
59606		Needle Bar Lever Connecting Rod Eccentric Lubricating Pad (wood) (2).....
54969	22581	Needle Bar Lever Connecting Rod Eccentric Oil Pad.....
1299AL	22581	Needle Bar Lever Connecting Rod Eccentric Position Screw..
448AL	22581	Needle Bar Lever Connecting Rod Eccentric Set Screw.....
42077	22581	Needle Bar Lever Connecting Rod Guide.....
59273	22581	Needle Bar Lever Connecting Rod Guide Bracket.....
176J	22581	Needle Bar Lever Connecting Rod Guide Bracket Screw.....
187E	22581	Needle Bar Lever Connecting Rod Guide Screw.....
59245	22585	Needle Bar Lever Connecting Rod Guide Stud.....
59246	22585	Needle Bar Lever Connecting Rod Guide Stud Bracket with 59245.....
193E	22585	Needle Bar Lever Connecting Rod Guide Stud Bracket Screw.....
2089	22581	Needle Bar Lever Connecting Rod Oil Pad Pin.....
59247	22585	Needle Bar Lever Hinge Pin.....
59248	22585	Needle Bar Lever Hinge Pin Bushing (back).....
624AL	22585	Needle Bar Lever Hinge Pin Bushing (back) Set Screw.....
59249	22585	Needle Bar Lever Hinge Pin Bushing (front).....
465AL	22585	Needle Bar Lever Hinge Pin Bushing (front) Set Screw.....
448AL	22585	Needle Bar Lever Hinge Pin Set Screw.....
59394	22585	Needle Bar Thread Retainer Bracket.....
228J	22585	Needle Bar Thread Retainer Bracket Screw.....
17718	22585	Needle Bar Thread Retainer Bracket Screw Washer.....
42483	22585	Needle Bar Thread Retainer Disc (2).....
93AL	22585	Needle Bar Thread Retainer Screw.....
10107	22585	Needle Bar Thread Retainer Spring.....
59395		Needle Bar Thread Retainer complete, Nos. 93AL, 10107, 59394 and two 42483.....
59673	22582	Needle Guard (movable).....
59674	22582	Needle Guard Clamp.....
1072F	22585	Needle Set Screw.....
59544	22585	Presser Bar.....
59472	22585	Presser Bar Bushing (lower).....
457AL	22585	Presser Bar Bushing (lower) Set Screw.....
42253	22585	Presser Bar Bushing (upper).....
457AL	22585	Presser Bar Bushing (upper) Set Screw.....

No.	Plate	Name
59368	22585	Presser Bar Lifter.....
89F	22585	Presser Bar Lifter Hinge Screw.....
51815	22585	Presser Bar Lifter Roller and Stud.....
50138E	22585	Presser Bar Lifter Stop Screw.....
59505	22585	Presser Bar Lifting Bracket with 391E, 1143AL, 51810, 51811 and 51815.....
391E	22585	Presser Bar Lifting Bracket Adjusting Screw.....
59506	22585	Presser Bar Lifting Bracket Guide.....
624AL	22585	Presser Bar Lifting Bracket Guide Set Screw.....
1143AL	22585	Presser Bar Lifting Bracket Set Screw.....
59675	22586	Presser Bar Spring.....
59676	22586	Presser Bar Spring Block.....
51810	22585	Presser Bar Spring Roller and Stud.....
59645	22583	Presser Foot Plate.....
59652	22583	Presser Foot Plate Hinge Stud (2).....
665J	22583	Presser Foot Plate Hinge Stud Position Screw (2).....
59646	22583	Presser Foot Shank.....
59647	22583	Presser Foot Yielding Heel.....
59648	22583	Presser Foot Yielding Heel Connection with 62527.....
62527	22583	Presser Foot Yielding Heel Connection Hinge Pin.....
39443	22583	Presser Foot Yielding Heel Connection Spring.....
62527	22583	Presser Foot Yielding Heel Connection Spring Position Pin.....
62527	22583	Presser Foot Yielding Heel Hinge Pin.....
59649	22583	Presser Foot (triple hinged) complete, Nos. 39443, 59645, 59646, 59647, 59648 and two each 665J, 59652 and 62527.....
185X	22583	Presser Foot Screw.....
1317D	22586	Pressure Regulating Thumb Screw.....
1547J	22586	Pressure Regulating Thumb Screw Lock Nut.....
59266	22585	Slack Thread Regulator.....
59267	22585	Slack Thread Regulator Holder with 465AL.....
59268	22585	Slack Thread Regulator Holder Crank with two 465AL.....
51811	22585	Slack Thread Regulator Holder Crank Roller and Stud.....
465AL	22585	Slack Thread Regulator Holder Crank Set Screw (2).....
465AL	22585	Slack Thread Regulator Set Screw.....
2102	22586	Tension (under thread) Disc (2).....
51570C	22586	Tension (under thread) Regulating Thumb Nut.....
50326C	22586	Tension (under thread) Screw Stud.....
59539		Tension (under thread) Screw Stud 50326C with 51570C.....
59534	22586	Tension (under thread) Spring.....
59537	22586	Tension (under thread) Spring Bushing (large).....
59538	22586	Tension (under thread) Spring Bushing (small).....
131696	22586	Tension (under thread) Thread Guide.....
59650	22586	Tension (upper thread) Bracket.....
51192E	22586	Tension (upper thread) Bracket Screw.....
2102	22586	Tension (upper thread) Disc (2).....
51570C	22586	Tension (upper thread) Regulating Thumb Nut.....
32572	22586	Tension (upper thread) Releasing Disc.....
54988	22586	Tension (upper thread) Releasing Pin.....
54046	22586	Tension (upper thread) Releasing Shaft.....
54047	22586	Tension (upper thread) Releasing Shaft Crank with 624AL.....
59651	22586	Tension (upper thread) Releasing Shaft Crank Link.....
624AL	22586	Tension (upper thread) Releasing Shaft Crank Set Screw.....
316C	22586	Tension (upper thread) Releasing Shaft Stop Screw.....
1547J	22586	Tension (upper thread) Releasing Shaft Stop Screw Nut.....
50326C	22586	Tension (upper thread) Screw Stud.....
59539		Tension (upper thread) Screw Stud 50326C with 51570C.....
59535	22586	Tension (upper thread) Spring.....
59537	22586	Tension (upper thread) Spring Bushing (large).....
59538	22586	Tension (upper thread) Spring Bushing (small).....
131696	22586	Tension (upper thread) Thread Guide.....
59270	22586	Thread (under) Eyelet.....
1423W	22586	Thread (under) Eyelet Screw.....

No.	Plate	Name
59276	22586	Thread (under) Protector.....
240F	22586	Thread (under) Protector Set Screw.....
59277	22581	Thread (under) Take-up (left).....
59278	22581	Thread (under) Take-up (right).....
190J	22581	Thread (under) Take-up Screw (2).....
59280	22586	Thread (under) Take-up Staple.....
59281	22586	Thread (under) Take-up Staple Holder with 904AL.....
59282	22586	Thread (under) Take-up Staple Holder Collar with 460AL.....
460AL	22586	Thread (under) Take-up Staple Holder Collar Set Screw.....
59283	22586	Thread (under) Take-up Staple Holder Collar Spring.....
236F	22586	Thread (under) Take-up Staple Holder Collar Spring Screw.....
904AL	22586	Thread (under) Take-up Staple Set Screw.....
59284	22586	Thread (under) Take-up Stripper.....
59285	22586	Thread (under) Take-up Stripper Bracket with 240F.....
140050C	22586	Thread (under) Take-up Stripper Bracket Screw.....
207F	22586	Thread (under) Take-up Stripper Screw.....
59677	22585	Thread (upper) Eyelet (side of arm).....
50014AL	22585	Thread (upper) Eyelet (side of arm) Set Screw.....
59678	22585	Thread (upper) Take-up with 460AL.....
460AL	22585	Thread (upper) Take-up Set Screw.....
59665	22583	Throat Plate for 59640.....
59661	22584	Throat Plate Packing (left) with 59292.....
59292	22584	Throat Plate Packing (left) Position Stud.....
1149AL	22584	Throat Plate Packing (left) Screw.....
59662	22584	Throat Plate Packing (right).....
1149AL	22584	Throat Plate Packing (right) Screw.....
1011F	22583	Throat Plate Screw (2).....
59294	22584	Throat Plate Steady Pin.....

SINGER Needles should be used
 in **SINGER** Machines
 These Needles and their Containers
 are marked with the
 Company's Trade Mark "**SIMANCO.****" ¹

Needles in Containers marked
 "**FOR SINGER MACHINES**"
 are **NOT SINGER** made needles. ²

ACCESSORIES

No.	Plate	Name
120344	22588	Oiler (copper plated) with 120345.....
120345	22588	Oiler Spout, 4-1/2 in. long.....
26026	22588	Screw Driver (large).....
26485	22588	Screw Driver (small).....
120341	22588	Tweezers (curved).....
4822	22588	Wrench for 1547.....
8908	22588	Wrench.....
19079	22588	Wrench.....

FITTINGS

FOR HEAVY OVERALL WORK

59687	22587	Feed Dog, 11 teeth (6 teeth to the inch).....
59645	22587	Presser Foot Plate.....
59652	22587	Presser Foot Plate Hinge Stud (2).....
665J	22587	Presser Foot Plate Hinge Stud Position Screw (2).....
59646	22587	Presser Foot Shank.....
59688	22587	Presser Foot Yielding Heel.....
59689	22587	Presser Foot Yielding Heel Connection with 62527.....
62527	22587	Presser Foot Yielding Heel Connection Hinge Pin.....
8282	22587	Presser Foot Yielding Heel Connection Spring (lower).....
39443	22587	Presser Foot Yielding Heel Connection Spring (upper).....
62527	22587	Presser Foot Yielding Heel Connection Spring Position Pin.....
62527	22587	Presser Foot Yielding Heel Hinge Pin.....
59690	22587	Presser Foot (triple hinged) complete, Nos. 8282, 39443, 59645, 59646, 59688, 59689 and two each 665J, 59652 and 62527.....
59691	22587	Throat Plate.....

FOOT LIFTER PARTS

13351	22589	Chain, 46 in. to 55 in. long, with 56864 and 56865.....
	NOTE: When ordering No. 13351, state length required.	
4879	22589	Chain Connecting Link.....
56864	22589	Chain Hook (large).....
56865	22589	Chain Hook (small).....
4881	22589	Treadle.....
4882	22589	Treadle Shaft.....
4883	22589	Treadle Spring.....
4884	22589	Treadle Stand.....
4885	22589	Treadle complete, Nos. 4879, 4881, 4882, 4883, 4884 and two wood screws 1 in. No. 16.....

HEMMER ON SHANK

(Adjustable)

121544	22584	Hemmer on Shank.....
121545	22584	Hemmer Plate.....
217J	22584	Hemmer Plate Screw (2).....
7071	22584	Hemmer Plate Screw Washer (2).....
121543	22584	Hemmer on Shank (adjustable) complete, Nos. 121544, 121545 and two each 217J and 7071.....
190J	22584	Hemmer Screw (2).....
7071	22584	Hemmer Screw Washer (2).....

KNEE LIFTER PARTS

No.	Plate	Name
32040	22589	Chain, 12-3/4 in. long, with 56864 and 56865.....
56864	22589	Chain Hook (large).....
56865	22589	Chain Hook (small).....
59679	22586	Lifting Lever.....
59680	22586	Lifting Lever Extension.....
190J	22586	Lifting Lever Extension Screw (2).....
21D	22586	Lifting Lever Hinge Screw.....
59681	22586	Lifting Lever Spring.....
59511	22586	Lifting Lever Stop.....
219J	22586	Lifting Lever Stop Screw.....
7124	22589	Rock Shaft.....
2764	22589	Rock Shaft Hanger (back) with two wood screws 1 in. No. 10.....
16128	22589	Rock Shaft Hanger (front) with two wood screws 1 in. No. 10.....
16646	22589	Rock Shaft Knee Arm with 1509J.....
16647		Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 16646.....
2766	22589	Rock Shaft Knee Arm Hub with 356C.....
356C	22589	Rock Shaft Knee Arm Hub Set Screw.....
1509J	22589	Rock Shaft Knee Arm Lock Nut.....
2767	22589	Rock Shaft Knee Arm Plate with 356C.....
356C	22589	Rock Shaft Knee Arm Plate Set Screw.....
6337	22589	Rock Shaft Lifting Bracket with two 356C.....
6338	22589	Rock Shaft Lifting Bracket Hook.....
356C	22589	Rock Shaft Lifting Bracket Hook Set Screw.....
356C	22589	Rock Shaft Lifting Bracket Set Screw.....
32134	22589	Rock Shaft Spring.....
2770	22589	Rock Shaft Spring Adjusting Dog with 140219C.....
140219C	22589	Rock Shaft Spring Adjusting Dog Set Screw.....
2770	22589	Rock Shaft Stop Dog with 140219C (2).....
140219C	22589	Rock Shaft Stop Dog Set Screw (2).....
32135	22589	Rock Shaft complete, Nos. 2764, 6337, 6338, 7124, 16128, 16647, 32134, and three 2770.....
59682		Knee Lifter complete, Nos. 21D, 219J, 32040, 32135, 59511, 59679, 59680, 59681 and two 190J.....

MACHINE BASE

59697	22590	Machine Base.....
51081E	22590	Machine Base Bolt with 51581E, to fasten base to table (4).....
51581E	22590	Machine Base Bolt Nut (4).....
6055	22590	Machine Base Bolt Nut Washer (4).....
59296	22590	Machine Base Cover.....
36006	22590	Machine Base Cover Friction Washer.....
100J	22590	Machine Base Cover Hinge Screw.....
840E	22590	Machine Base Screw (3).....
59297	22590	Machine Cushion (felt) (3).....
59698	22590	Machine Base complete, Nos. 100J, 36006, 59296, 59697, three each 840E, 59297 and four each 6055 and 51081E.....
59699	22590	Machine Base and Oil Drain Jar (swinging type) complete, Nos. 59698 and 131268.....

MACHINE BASE OIL DRAIN JAR

(Swinging Type)

No.	Plate	Name
131961	22590	Jar (glass).....
131962	22590	Jar Cap.....
131188	22590	Jar Clamp.....
131217		Jar Clamp 131188 with 131189.....
131189	22590	Jar Clamp Lever.....
1247C	22590	Jar Clamp Lever Hinge Screw (2).....
131265	22590	Nipple (long) (2).....
131266	22590	Nipple (short).....
131267	22590	Nipple Elbow (2).....
131268	22590	Machine Base Oil Drain Jar (swinging type) complete, Nos. 131217, 131266, 131961, 131962 and two each 1247C, 131265 and 131267.....

THREAD UNWINDER

(For Two Spools or Two Large Cones of Thread)

228692	23289	Spool Pin (2).....
201528X	23289	Spool Pin Nut (2).....
228693	23289	Spool Pin Washer (2).....
225257	23289	Spool Rest with 201018C and two each 201528X, 228692 and 228693.....
150203	23289	Spool Rest Cushion (felt) (2).....
225388	23289	Spool Rest Rod.....
200383C	23289	Spool Rest Rod Set Screw.....
201018C	23289	Spool Rest Set Screw.....
259658	23289	Spool Stand with 200383C.....
225391	23289	Thread Guide (2).....
201696J	23289	Thread Guide Lock Nut.....
225326	23289	Thread Guide Position Cup.....
225324	23289	Thread Guide Rod with 208AL and 225322.....
208AL	23289	Thread Guide Rod Screw.....
225322	23289	Thread Guide Rod Washer.....
225258	23289	Thread Unwinder complete, Nos. 201696J, 225257, 225324, 225326, 225388, 259658, two each 150203, 225391 and three wood screws 7/8 in. No. 12 F.H.....
27739	23289	Thread Cone (wood) for large cones.....
225390	23289	Thread Cone Holder, for inverted cones.....
NOTE: Nos. 27739 and 225390 are used with, but not included in 225258.		

NUMERICAL LIST OF PARTS

No.	Plate	Name
21D	22586	Knee Lifter Lifting Lever Hinge Screw for 59682.....
89F	22585	Presser Bar Lifter Hinge Screw.....
93AL	22585	Needle Bar Thread Retainer Screw for 59395.....
100J	22590	Machine Base Cover Hinge Screw for 59698.....
141E	22581	Needle Bar Lever Connecting Rod Cap (lower) Screw for 59603.....
175E	22585	Needle Bar Connecting Bracket Clamping Screw for 59672.....
176J	22581	Needle Bar Lever Connecting Rod Guide Bracket Screw.....
185X	22583	Presser Foot Screw.....
187E	22581	Needle Bar Lever Connecting Rod Guide Screw.....
190J	22581	Feed Lifting Eccentric Connection Bar Oil Tube Bracket Screw.....
190J	22584	Hemmer Screw.....
190J	22586	Knee Lifting Lever Extension Screw for 59682.....
190J	22581	Thread (under) Take-up Screw.....
193E	22585	Needle Bar Lever Connecting Rod Guide Stud Bracket Screw.....
207J	22581	Looper Carrier Driver Timing Screw.....
207F	22586	Thread (under) Take-up Stripper Screw.....
208AL	22585	Needle Bar Connecting Link Hinge Pin (lower) Set Screw for 59471.....
208AL	23289	Thread Unwinder Thread Guide Rod Screw for 225324.....
217J	22581	Feed Eccentric Clamping Washer Screw for 59495.....
217J	22584	Hemmer Plate Screw for 121543.....
219J	22586	Knee Lifter Lifting Lever Stop Screw for 59682.....
228J	22585	Needle Bar Thread Retainer Bracket Screw.....
236F	22586	Thread (under) Take-up Staple Holder Collar Spring Screw.....
240F	22586	Thread (under) Protector Set Screw for 59285.....
316C	22586	Tension (upper thread) Releasing Shaft Stop Screw.....
330J	22584	Looper Cover Screw for 59664.....
356C	22589	Knee Lifter Rock Shaft Knee Arm Hub Set Screw for 2766.....
356C	22589	Knee Lifter Rock Shaft Knee Arm Plate Set Screw for 2767.....
356C	22589	Knee Lifter Rock Shaft Lifting Bracket Hook Set Screw for 6337.....
356C	22589	Knee Lifter Rock Shaft Lifting Bracket Set Screw for 6337.....
391E	22585	Presser Bar Lifting Bracket Adjusting Screw for 59505.....
424C	22581	Machine Driving Pulley Set Screw for 59686.....
448AL	22581	Arm Rotary Shaft Bushing (front) Set Screw.....
448AL	22581	Needle Bar Lever Connecting Rod Eccentric Set Screw for 59636.....
448AL	22585	Needle Bar Lever Hinge Pin Set Screw for 59471.....
449AL	22582	Feed Bar Carrier Hinge Pin Set Screw for 59669.....
449AL	22582	Feed Eccentric Connection Bar Set Screw for 59669.....
457AL	22582	Feed Bar Carrier Hinge Pin Bushing Set Screw.....
457AL	22584	Looper Cover Holder Sleeve Set Screw for 59231.....
457AL	22585	Needle Bar Bushing (lower) Set Screw.....
457AL	22585	Needle Bar Bushing (upper) Set Screw.....
457AL	22585	Presser Bar Bushing (lower) Set Screw.....
457AL	22585	Presser Bar Bushing (upper) Set Screw.....
458AL	22582	Feed Bar Hinge Pin Set Screw for 59667.....
460AL	22585	Needle Bar Connecting Link Hinge Pin (upper) Set Screw for 59672.....
460AL	22586	Thread (under) Take-up Staple Holder Collar Set Screw for 59282.....
460AL	22585	Thread (upper) Take-up Set Screw for 59678.....
465AL	22585	Needle Bar Lever Hinge Pin Bushing (front) Set Screw.....
465AL	22585	Slack Thread Regulator Holder Crank Set Screw for 59268.....
465AL	22585	Slack Thread Regulator Set Screw for 59267.....

No.	Plate	Name
596J	22583	Feed Dog Screw.....
624AL	22585	Needle Bar Lever Hinge Pin Bushing (back) Set Screw.....
624AL	22585	Presser Bar Lifting Bracket Guide Set Screw.....
624AL	22586	Tension (upper thread) Releasing Shaft Crank Set Screw for 54047.....
647E	22581	Needle Bar Lever Connecting Rod Cap (upper) Screw for 59603.....
665J	22583	Presser Foot Plate Hinge Stud Position Screw for 59649 and 59690.....
840E	22590	Machine Base Screw for 59698.....
882AL	22582	Feed Bar Hinge Pin Bushing (left) Set Screw for 59669.....
882AL	22582	Feed Bar Hinge Pin Bushing (right) Set Screw for 59669.....
882AL	22582	Feed Lifting Eccentric Connection Bar Set Screw for 59667.....
904AL	22586	Thread (under) Take-up Staple Set Screw for 59281.....
1011F	22583	Throat Plate Screw.....
1072F	22585	Needle Set Screw for 59683.....
1143AL	22582	Looper Carrier Shaft Crank Clamping Screw for 59227.....
1143AL	22585	Presser Bar Lifting Bracket Set Screw for 59505.....
1149AL	22584	Throat Plate Packing (left) Screw.....
1149AL	22584	Throat Plate Packing (right) Screw.....
1186E	22582	Looper Carrier Driver Clamping Screw for 59224.....
1247C	22590	Machine Base Oil Drain Jar Clamp Lever Hinge Screw for 131268.....
1299AL	22581	Needle Bar Lever Connecting Rod Eccentric Position Screw for 59636.....
1317D	22586	Pressure Regulating Thumb Screw.....
1354C	22581	Machine Driving Pulley Position Screw for 59686.....
1423J	22581	Arm Side Cover Screw.....
1423W	22586	Thread (under) Eyelet Screw.....
1509J	22589	Knee Lifter Rock Shaft Knee Arm Lock Nut for 16646.....
1547J	22586	Pressure Regulating Thumb Screw Lock Nut.....
1547J	22586	Tension (upper thread) Releasing Shaft Stop Screw Nut.....
1602E	22584	Looper Cover Screw Bushing for 59663.....
2089	22581	Needle Bar Lever Connecting Rod Oil Pad Pin for 59603.....
2102	22586	Tension (under thread) Disc.....
2102	22586	Tension (upper thread) Disc.....
2764	22589	Knee Lifter Rock Shaft Hanger (back) with two wood screws 1 in. No. 10, for 32135.....
2766	22589	Knee Lifter Rock Shaft Knee Arm Hub with 356C, for 16647.....
2767	22589	Knee Lifter Rock Shaft Knee Arm Plate with 356C, for 16647.....
2770	22589	Knee Lifter Rock Shaft Spring Adjusting Dog with 140219C, for 32135.....
2770	22589	Knee Lifter Rock Shaft Stop Dog with 140219C, for 32135.....
4822	22588	Wrench for 1547 (Accessories).....
4879	22589	Foot Lifter Chain Connecting Link for 4885.....
4881	22589	Foot Lifter Treadle for 4885.....
4882	22589	Foot Lifter Treadle Shaft for 4885.....
4883	22589	Foot Lifter Treadle Spring for 4885.....
4884	22589	Foot Lifter Treadle Stand for 4885.....
4885	22589	Foot Lifter Treadle complete, Nos. 4879, 4881, 4882, 4883, 4884 and two wood screws 1 in. No. 16.....
6055	22590	Machine Base Bolt Nut Washer for 59698.....
6337	22589	Knee Lifter Rock Shaft Lifting Bracket with two 356C, for 32135.....
6338	22589	Knee Lifter Rock Shaft Lifting Bracket Hook for 32135.....
7071	22581	Feed Eccentric Clamping Washer for 59495.....
7071	22584	Hemmer Plate Screw Washer for 121543.....
7071	22584	Hemmer Screw Washer.....
7124	22589	Knee Lifter Rock Shaft for 32135.....
8282	22587	Presser Foot Yielding Heel Connection Spring (lower) for 59690.....

NUMERICAL LIST OF PARTS

17

No.	Plate	Name
8908	22588	Wrench (Accessories).....
10107	22585	Needle Bar Thread Retainer Spring for 59395.....
12002	22582	Feed Eccentric Connection Oil Wick Retaining Pin for 59216.....
13351	22589	Foot Lifter Chain, 46 in. to 55 in. long, with 56864 and 56865.....
		NOTE: When ordering No. 13351, state length required.
16128	22589	Knee Lifter Rock Shaft Hanger (front) with two wood screws 1 in. No. 10, for 32135.....
16646	22589	Knee Lifter Rock Shaft Knee Arm with 1509J, for 16647.....
16647		Knee Lifter Rock Shaft Knee Arm complete, for 32135, Nos. 2766, 2767 and 16646.....
17718	22585	Needle Bar Thread Retainer Bracket Screw Washer.....
19079	22588	Wrench (Accessories).....
26026	22588	Screw Driver (large) Accessories.....
26485	22588	Screw Driver (small) Accessories.....
27739	23289	Thread Unwinder Thread Cone (wood) for large cones.....
		NOTE: No. 27739 is used with, but not included in 225258.
32040	22589	Knee Lifter Chain, 12-3/4 in. long, with 56864 and 56865, for 59682.....
32134	22589	Knee Lifter Rock Shaft Spring for 32135.....
32135	22589	Knee Lifter Rock Shaft complete, for 59682, Nos. 2764, 6337, 6338, 7124, 16128, 16647, 32134 and three 2770.....
32572	22586	Tension (upper thread) Releasing Disc.....
36006	22590	Machine Base Cover Friction Washer for 59698.....
39443	22583	Presser Foot Yielding Heel Connection Spring for 59649.....
39443	22587	Presser Foot Yielding Heel Connection Spring (upper) for 59690.....
40247	22585	Needle Bar Connecting Link Hinge Pin (lower) for 59684.....
40247	22585	Needle Bar Connecting Link Hinge Pin (upper) for 59684.....
42077	22581	Needle Bar Lever Connecting Rod Guide.....
42253	22585	Presser Bar Bushing (upper).....
42483	22585	Needle Bar Thread Retainer Disc for 59395.....
42727	22581	Feed Lifting Eccentric Position Pin.....
50014AL	22585	Thread (upper) Eyelet (side of arm) Set Screw.....
50138E	22585	Presser Bar Lifter Stop Screw.....
50150AL	22581	Feed Lifting Eccentric Set Screw for 59513.....
50300E	22584	Looper Cover Lock Stud Spring Cap Screw.....
50326C	22586	Tension (under thread) Screw Stud for 59539.....
50326C	22586	Tension (upper thread) Screw Stud for 59539.....
50328C	22581	Feed Regulating Screw for 59495.....
50395AL	22582	Looper Set Screw for 59381.....
50554AL	22581	Arm Rotary Shaft Bushing (back) Set Screw.....
50554AL	22581	Arm Rotary Shaft Bushing (intermediate) Set Screw.....
51061AL	22581	Feed Eccentric Body Set Screw for 59495.....
51081E	22590	Machine Base Bolt with 51581E, to fasten base to table, for 59698.....
51192E	22586	Tension (upper thread) Bracket Screw.....
51407AL	22585	Needle Bar Lever Connecting Rod Ball Stud Set Screw for 59471.....
51570C	22586	Tension (under thread) Regulating Thumb Nut for 59539.....
51570C	22586	Tension (upper thread) Regulating Thumb Nut for 59539.....
51581E	22590	Machine Base Bolt Nut for 51081E.....
51810	22585	Presser Bar Spring Roller and Stud for 59505.....
51811	22585	Slack Thread Regulator Holder Crank Roller and Stud for 59505.....
51815	22585	Presser Bar Lifter Roller and Stud for 59505.....
52045	22581	Arm Rotary Shaft Bushing (back) Packing (wick) for 59610.....
52045	22581	Arm Rotary Shaft Bushing (front) Packing (wick) for 59524.....
52045	22581	Arm Rotary Shaft Bushing (intermediate) Packing (wick) for 59613.....

No.	Plate	Name
54046	22586	Tension (upper thread) Releasing Shaft.....
54047	22586	Tension (upper thread) Releasing Shaft Crank with 624AL.....
54969	22581	Needle Bar Lever Connecting Rod Eccentric Oil Pad for 59603.....
54988	22586	Tension (upper thread) Releasing Pin.....
56864	22589	Foot Lifter Chain Hook (large) for 13351.....
56864	22589	Knee Lifter Chain Hook (large) for 32040.....
56865	22589	Foot Lifter Chain Hook (small) for 13351.....
56865	22589	Knee Lifter Chain Hook (small) for 32040.....
57234	22582	Feed Bar Carrier Hinge Pin.....
57235	22582	Feed Bar Carrier Hinge Pin Bushing.....
59216	22582	Feed Eccentric Connection with 12002 and 139110, for 59517.....
59217	22582	Feed Eccentric Connection Bar with 59218.....
59218		Feed Eccentric Connection Bar Plug for 59217.....
59218		Feed Lifting Eccentric Connection Bar Plug for 59221.....
59220	22582	Feed Lifting Eccentric Connection for 59514.....
59221	22582	Feed Lifting Eccentric Connection Bar with 59218.....
59224	22582	Looper Carrier Driver with two 1186E.....
59225	22582	Looper Carrier Hole Plug.....
59226	22582	Looper Carrier Shaft.....
59227	22582	Looper Carrier Shaft Crank with 1143AL.....
59230	22584	Looper Cover Holder for 59664.....
59231	22584	Looper Cover Holder Sleeve with 457AL.....
59232	22584	Looper Cover Lock Stud.....
59233	22584	Looper Cover Lock Stud Spring.....
59237	22585	Needle Bar Connecting Link for 59684.....
59240	22581	Needle Bar Lever Connecting Rod Ball Stud for 59604.....
59245	22585	Needle Bar Lever Connecting Rod Guide Stud for 59246.....
59246	22585	Needle Bar Lever Connecting Rod Guide Stud Bracket with 59245.....
59247	22585	Needle Bar Lever Hinge Pin.....
59248	22585	Needle Bar Lever Hinge Pin Bushing (back).....
59249	22585	Needle Bar Lever Hinge Pin Bushing (front).....
59266	22585	Slack Thread Regulator.....
59267	22585	Slack Thread Regulator Holder with 465AL.....
59268	22585	Slack Thread Regulator Holder Crank with two 465AL.....
59270	22586	Thread (under) Eyelet.....
59273	22581	Needle Bar Lever Connecting Rod Guide Bracket.....
59276	22586	Thread (under) Protector.....
59277	22581	Thread (under) Take-up (left).....
59278	22581	Thread (under) Take-up (right).....
59280	22586	Thread (under) Take-up Staple.....
59281	22586	Thread (under) Take-up Staple Holder with 904AL.....
59282	22586	Thread (under) Take-up Staple Holder Collar with 460AL.....
59283	22586	Thread (under) Take-up Staple Holder Collar Spring.....
59284	22586	Thread (under) Take-up Stripper.....
59285	22586	Thread (under) Take-up Stripper Bracket with 240F.....
59292	22584	Throat Plate Packing (left) Position Stud for 59661.....
59294	22584	Throat Plate Steady Pin.....
59296	22590	Machine Base Cover for 59698.....
59297	22590	Machine Cushion (felt) for 59698.....
59368	22585	Presser Bar Lifter.....
59381	22582	Looper Carrier with 50395AL.....
59394	22585	Needle Bar Thread Retainer Bracket for 59395.....
59395		Needle Bar Thread Retainer complete, Nos. 93AL, 10107, 59394 and two 42483.....
59469	22585	Needle Bar Bushing (upper).....
59471	22585	Needle Bar Lever with 208AL, 448AL and 51407AL, for 59684.....
59472	22585	Presser Bar Bushing (lower).....
59487	22583	Looper.....
59491	22581	Arm Rotary Shaft.....

No.	Plate	Name
59495	22581	Feed Eccentric (adjustable) complete, for 59517, Nos. 217J, 7071, 50328C, 130337 and two 51061AL.....
59505	22585	Presser Bar Lifting Bracket with 391E, 1143AL, 51810, 51811 and 51815.....
59506	22585	Presser Bar Lifting Bracket Guide.....
59511	22586	Knee Lifter Lifting Lever Stop for 59682.....
59513	22581	Feed Lifting Eccentric with two 50150AL, for 59514.....
59514		Feed Lifting Eccentric 59513 with 59220.....
59517		Feed Eccentric 59495 with 59216.....
59524	22581	Arm Rotary Shaft Bushing (front) with 52045.....
59534	22586	Tension (under thread) Spring.....
59535	22586	Tension (upper thread) Spring.....
59537	22586	Tension (under thread) Spring Bushing (large).....
59537	22586	Tension (upper thread) Spring Bushing (large).....
59538	22586	Tension (under thread) Spring Bushing (small).....
59538	22586	Tension (upper thread) Spring Bushing (small).....
59539		Tension (under thread) Screw Stud 50326C with 51570C.....
59539		Tension (upper thread) Screw Stud 50326C with 51570C.....
59544	22585	Presser Bar.....
59603	22581	Needle Bar Lever Connecting Rod with 2089, 54969 and two each 141E and 647E, for 59604.....
59604		Needle Bar Lever Connecting Rod 59603 with 59240 and 59636.....
59606		Needle Bar Lever Connecting Rod Eccentric Lubricating Pad (wood) for 59636.....
59609		Arm Rotary Shaft Bushing (back) for 59610.....
59610	22581	Arm Rotary Shaft Bushing (back) 59609 with 52045 and 59611.....
59611		Arm Rotary Shaft Bushing (back) Oil Wick (braided cotton) for 59610.....
59612		Arm Rotary Shaft Bushing (intermediate) for 59613.....
59613	22581	Arm Rotary Shaft Bushing (intermediate) 59612 with 52045 and 128571.....
59617	22582	Feed Bar Hinge Pin Bushing (left) for 59670.....
59618	22582	Feed Bar Hinge Pin Bushing (right) for 59670.....
59629	22581	Arm Side Cover with 59631 and 132555.....
59631	22581	Arm Side Cover Oil Tube Oil Cup for 59629.....
59631	22581	Feed Lifting Eccentric Connection Bar Oil Tube Oil Cup for 59635.....
59635	22581	Feed Lifting Eccentric Connection Bar Oil Tube with Bracket complete, Nos. 59631 and 130901.....
59636	22581	Needle Bar Lever Connecting Rod Eccentric with 448AL, 1299AL and two 59606, for 59604.....
*59637		Arm, upper and lower (solid).....
59640	22583	Feed Dog, 8 teeth (6 teeth to the inch) for 59665.....
59645	22583	Presser Foot Plate for 59649 and 59690.....
59646	22583	Presser Foot Shank for 59649 and 59690.....
59647	22583	Presser Foot Yielding Heel for 59649.....
59648	22583	Presser Foot Yielding Heel Connection with 62527, for 59649.....
59649	22583	Presser Foot (triple hinged) complete, Nos. 39443, 59645, 59646, 59647, 59648 and two each 665J, 59652 and 62527.....
59650	22586	Tension (upper thread) Bracket.....
59651	22586	Tension (upper thread) Releasing Shaft Crank Link.....
59652	22583	Presser Foot Plate Hinge Stud for 59649 and 59690.....
59661	22584	Throat Plate Packing (left) with 59292.....
59662	22584	Throat Plate Packing (right).....
59663	22584	Looper Cover with two 1602E, for 59664.....
59664	22584	Looper Cover complete, Nos. 59230, 59663 and two 330J.....
59665	22583	Throat Plate for 59640.....
59666	22585	Needle Bar Bushing (lower).....


No.	Plate	Name
59667	22582	Feed Bar with two each 458AL and 882AL, for 59668.....
59668		Feed Bar 59667 with 59670 and 59671.....
59669	22582	Feed Bar Carrier with two 882AL and four 449AL, for 59670.....
59670		Feed Bar Carrier 59669 with 59617 and 59618, for 59668.....
59671	22582	Feed Bar Hinge Pin for 59668.....
59672	22585	Needle Bar Connecting Bracket with 175E and 460AL, for 59684.....
59673	22582	Needle Guard (movable).....
59674	22582	Needle Guard Clamp.....
59675	22586	Presser Bar Spring.....
59676	22586	Presser Bar Spring Block.....
59677	22585	Thread (upper) Eyelet (side of arm).....
59678	22585	Thread (upper) Take-up with 460AL.....
59679	22586	Knee Lifter Lifting Lever for 59682.....
59680	22586	Knee Lifter Lifting Lever Extension for 59682.....
59681	22586	Knee Lifter Lifting Lever Spring for 59682.....
59682		Knee Lifter complete, Nos. 21D, 219J, 32040, 32135, 59511, 59679, 59680, 59681 and two 190J.....
59683	22585	Needle Bar (hollow) with 1072F.....
59684		Needle Bar Lever 59471 with 59237, 59672 and two 40247.....
59686	22581	Machine Driving Pulley, "V" belt groove (outside diam. of belt groove 2.9 in.) with 424C, and 1354C.....
59687	22587	Feed Dog, 11 teeth (6 teeth to the inch) for 59691, for heavy overall work.....
59688	22587	Presser Foot Yielding Heel for 59690.....
59689	22587	Presser Foot Yielding Heel Connection with 62527, for 59690.....
59690	22587	Presser Foot (triple hinged) complete, for heavy overall work, Nos. 8282, 39443, 59645, 59646, 59688, 59689 and two each 665J, 59652 and 62527.....
59691	22587	Throat Plate for 59687, for heavy overall work.....
59697	22590	Machine Base for 59698.....
59698	22590	Machine Base complete, for 59699, Nos. 100J, 36006, 59296, 59697, three each 840E, 59297 and four each 6055 and 51081E.....
59699	22590	Machine Base and Oil Drain Jar (swinging type) complete, Nos. 59698 and 131268.....
62527	22583	Presser Foot Yielding Heel Connection Hinge Pin for 59649 and 59690.....
62527	22583	Presser Foot Yielding Heel Connection Spring Position Pin for 59648 and 59689.....
62527	22583	Presser Foot Yielding Heel Hinge Pin for 59649 and 59690.....
120341	22588	Tweezers (curved) Accessories.....
120344	22588	Oiler (copper plated) with 120345 (Accessories).....
120345	22588	Oiler Spout, 4-1/2 in. long, for 120344.....
121543	22584	Hemmer on Shank (adjustable) complete, Nos. 121544, 121545 and two each 217J and 7071.....
121544	22584	Hemmer on Shank for 121543.....
121545	22584	Hemmer Plate for 121543.....
128571		Arm Rotary Shaft Bushing (intermediate) Oil Wick (braided cotton) for 59613.....
130337		Feed Eccentric Lubricating Pad (wood) for 59495.....
130901	22581	Feed Lifting Eccentric Connection Bar Oil Tube Oil Pad (wick) for 59635.....
131188	22590	Machine Base Oil Drain Jar Clamp for 131217.....
131189	22590	Machine Base Oil Drain Jar Clamp Lever for 131217.....
131217		Machine Base Oil Drain Jar Clamp 131188 and 131189, for 131268.....
131265	22590	Machine Base Oil Drain Jar Nipple (long) for 131268.....

No.	Plate	Name
131266	22590	Machine Base Oil Drain Jar Nipple (short) for 131268.....
131267	22590	Machine Base Oil Drain Jar Nipple Elbow for 131268.....
131268	22590	Machine Base Oil Drain Jar (swinging type) complete, for 59699, Nos. 131217, 131266, 131961, 131962 and two each 1247C, 131265 and 131267.....
131696	22586	Tension (under thread) Thread Guide.....
131696	22586	Tension (upper thread) Thread Guide.....
131961	22590	Machine Base Oil Drain Jar (glass) for 131268.....
131962	22590	Machine Base Oil Drain Jar Cap for 131268.....
132555	22581	Arm Side Cover Oil Tube Oil Pad (braided cotton) for 59629.....
139110	22582	Feed Eccentric Connection Oil Wick for 59216.....
140050C	22586	Thread (under) Take-up Stripper Bracket Screw.....
140219C	22589	Knee Lifter Rock Shaft Spring Adjusting Dog Set Screw for 2770.....
140219C	22589	Knee Lifter Rock Shaft Stop Dog Set Screw for 2770.....
150203	23289	Thread Unwinder Spool Rest Cushion (felt) for 225258.....
200383C	23289	Thread Unwinder Spool Rest Rod Set Screw for 259658.....
201018C	23289	Thread Unwinder Spool Rest Set Screw for 225257.....
201528X	23289	Thread Unwinder Spool Pin Nut for 225257.....
201696J	23289	Thread Unwinder Thread Guide Lock Nut for 225258.....
225257	23289	Thread Unwinder Spool Rest with 201018C and two each 201528X, 228692 and 228693, for 225258.....
225258	23289	Thread Unwinder complete, for two spools or two large cones of thread, Nos. 201696J, 225257, 225324, 225326, 225388, 259658, two each 150203, 225391 and three wood screws 7/8 in. No. 12 F.H.....
225322	23289	Thread Unwinder Thread Guide Rod Washer for 225324....
225324	23289	Thread Unwinder Thread Guide Rod with 208AL and 225322, for 225258.....
225326	23289	Thread Unwinder Thread Guide Position Cup for 225258....
225388	23289	Thread Unwinder Spool Rest Rod for 225258.....
225390	23289	Thread Unwinder Thread Cone Holder, for inverted cones...
		NOTE: No. 225390 is used with, but not included in 225258.
225391	23289	Thread Unwinder Thread Guide for 225258.....
259658	23289	Thread Unwinder Spool Stand with 200383C, for 225258....
228692	23289	Thread Unwinder Spool Pin for 225257.....
228693	23289	Thread Unwinder Spool Pin Washer for 225257.....

SINGER Needles should be used
in **SINGER** Machines
These Needles and their Containers
are marked with the
Company's Trade Mark "**SIMANCO.****" 1

Needles in Containers marked
"**FOR SINGER MACHINES**"
are NOT **SINGER** made needles. 2

59635




22581-1/3

Exploded view diagram of a mechanical assembly, showing various components and their assembly points. The parts are labeled with alphanumeric codes:

- 457AL
- 449AL
- 57235
- 882AL
- 59618
- 57234
- 59669
- 59617
- 882AL
- 59671
- 449AL
- 458AL
- 59667
- 59217
- 12002
- 139110
- 59673
- 59674
- 882AL
- 59216
- 59221
- 59220
- 50395AL
- 59225
- 59381
- 59226
- 59227
- 1143AL
- 1186E
- 59224

22583-2/3

59665




1011F

596J



59640




6 = 1


59487




59649




22584-1/2







22585-1/3




From the library of: Superior Sewing Machine & Supply LLC

22587-2/3




22588-1/2





22589-1/4

32135




4885




22590-1/4

59699


59698



131268



23289 - 1/4



SINGER Needles should be used
in SINGER Machines
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO.**" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT **SINGER** made needles. 2

