

LIST OF PARTS COMPLETE

FOR

MACHINE No. 106-3

SINGLE THREAD CHAIN STITCH. BED, 17 IN. LONG, 8½ IN. FROM THE CENTRE OF THE NEEDLE BAR TO THE BASE OF THE ARM. THREE NEEDLES, THREE LOOPERS, FOOT OR KNEE LIFTER, TENSION RELEASE.

*57201	Arm, upper and lower (solid) with 57202.....
57202	" Oil Tube, for oiling 64267.....
56003	" " " with 29599, for oiling 38458.....
29599	" " " Packing (felt).....
57204	" Rock Shaft.....
12147	" " " Back Bearing Oil Pad (felt).....
64253	" " " Collar with two 624c.....
624c	" " " " Set Screw.....
57439	" " " Crank (back) with four 168c.....
168c	" " " " " Set Screw.....
38412	" " " " (front) with 443c.....
2117	" " " " " Pin.....
443c	" " " " " Set Screw.....
18154	" " " Front Bearing Oil Pad (felt).....
57207	" Rotary Shaft with 57824.....
57781	" " " Bushing (intermediate) with 49093 and 64805.....
49093	Arm Rotary Shaft Bushing (intermediate) Oil Pad (braided cotton) long.....
64805	Arm Rotary Shaft Bushing (intermediate) Oil Pad (braided cotton) short.....
832c	Arm Rotary Shaft Bushing (intermediate) Set Screw...
61005	" " " Collar with two 454c.....
454c	" " " " Set Screw.....
57782	" " " Flanged Bushing (back) with 49093 and 64805.....
49093	Arm Rotary Shaft Flanged Bushing (back) Oil Pad (braided cotton) long.....
64805	Arm Rotary Shaft Flanged Bushing (back) Oil Pad (braided cotton) short.....
159F	Arm Rotary Shaft Flanged Bushing (back) Screw.....
46200	" " " Intermediate Bearing Oil Pad (felt)
57824	" " " Oil Pad (felt).....

144D	Arm Rotary Shaft Screw
23933	" Side Cover
286D	" " " Thumb Screw
61006	Balance Wheel (double belt groove) 2 in. diam., with two 430c
430c	Balance Wheel Set Screw
57211	Cloth Plate with two 57404
57212	" " Hook
57404	" " Oil Tube
691F	" " Screw
57213	" " Slide (large)
57214	Cloth Plate Slide (large) complete, Nos. 57213, 57215 and two 725J
57215	Cloth Plate Slide (large) Spring
725J	" " " " " Screw
57216	" " " (small)
57217	Cloth Plate Slide (small) complete, Nos. 57216, 57218, 57219 and four 665J
57218	Cloth Plate Slide (small) Spring (left)
665J	" " " " " " Screw
57219	" " " " " (right)
665J	" " " " " " Screw
57435	Cloth Plate complete for 57328, 57481, 57814 and 57828, Nos. 57211, 57214 and 57217
57220	Cloth Plate 57435 with four 57212
64267	Crank Connecting Rod with 46223, 57222 and two each 896E and 1057E
50069c	Crank Connecting Rod Ball Screw Stud (upper)
1516E	" " " " " " " Nut
64268	" " " " " " " Washer
*57222	" " " Cap (lower)
896E	" " " " " Screw
*46223	" " " " (upper)
1057E	" " " " " Screw
57288	" " " Oil Case with 57290, 57291 and four each 197D and 448c
57290	Crank Connecting Rod Oil Case Cap
57291	" " " " " " Packing (felt)
197D	" " " " " " Screw
448c	" " " " " Set Screw
57223	Face Plate
46111	" " Pin
286D	" " Thumb Screw
57224	Feed Bar with two 457c
57225	" " Hinge Pin
457c	" " " " Set Screw
57327	" Dog
57480	" " for gathering

57813	Feed Dog
57827	" "
57293	" " Packing, .005 in. thick
57294	" " " .012 in. thick
57321	" " " .021 in. thick
1255F	" " Screw
*57227	" Eccentric
*23729	" " Body
443C	" " " Set Screw
61171	" " Pressure Spring
21332	" " " " Cap
934J	" " " " " Screw
203D	" " Set Screw
7071	" " " " Washer
57228	Feed Eccentric (adjustable) complete, Nos. 203D, 934J, 1103C, 7071, 21332, 23729, 57227, 61171 and two 443C
57229	Feed Eccentric Connection
57230	" Lifting Eccentric with two 624C
57231	" " " Connection
624C	" " " Set Screw
1103C	" Regulating Screw
57232	" Rocking Frame with four 624C
57233	" " " Bar
624C	" " " " Set Screw
57234	" " " Hinge Pin
57235	" " " " " Bushing
449C	" " " " " " Set Screw
624C	" " " " " " Set Screw
57441	Looper (large shank) for heavy work
57326	" Carrier with three 50370F
157D	" " Screw
57238	" Eccentric with two 889C
57239	" " Connection
57240	" " " Oil Pad (felt)
924E	" " " " " Stop Screw
889C	" " Set Screw
57241	" Rock Shaft with two 624C
57242	" " " Bar
624C	" " " " Set Screw
57243	" " " Hinge Pin with 860E
860E	" " " " " Plug Screw
446C	" " " " " Set Screw (left)
446C	" " " " " " (right)
50370F	" Set Screw
57244	Needle Bar (hollow)
57478	" " 57244 with 57479
38456	" " Bushing (lower)

1133E	Needle Bar Bushing (lower) Set Screw	
57245	" " " (upper)	
1133E	" " " " Set Screw	
38458	" " Connecting Link	
57246	" " " " Hinge Stud	
1520E	" " " " " " Nut	
57247	" " " Stud with 209F and two 391D	
391D	" " " " Clamping Screw	
57479	" Clamp with three 50014F	
57314	" Guard with two 50239c	
50239c	" " Set Screw	
57251	" " Bar	
57252	" " " Bracket (left) with 440F	
177c	" " " " " Screw	
57253	" " " " (right) with 440F	
177c	" " " " " Screw	
57254	" " " " Holder	
50154D	" " " " " Screw	
440F	" " " Set Screw	
50014F	" Set Screw	
57255	Presser Bar with 25303	
25303	" " Ball, size $\frac{1}{4}$ in.	
61046	" " Bushing (lower)	
1133E	" " " " Set Screw	
38456	" " " (upper)	
1133E	" " " " Set Screw	
57257	" " Lifter	
57258	" " " Hinge Pin	
447c	" " " " " Set Screw	
194D	" " " Stop Screw	
57259	" " Lifting Bracket with 453c and 1819	
57260	" " " " Guide	
1819	" " " " Roller and Stud	
453c	" " " " Set Screw	
57275	" " " Lever with two 460c	
57276	" " " " Connecting Rod	
57277	" " " " " Collar with two 465c	
465c	Presser Bar Lifting Lever Connecting Rod Collar Set Screw	
24122	Presser Bar Lifting Lever Connecting Rod Spring	
45057	" " " " " " Stop Washer	
*57278	" " " " " Stud	
57279	Presser Bar Lifting Lever Connecting Stud complete, Nos. 453c, 1423D, 1904 and 57278	
1904	Presser Bar Lifting Lever Connecting Stud Roller (roller only)	

1423D	Presser Bar Lifting Lever Connecting Stud Roller Cap Screw.....
453c	Presser Bar Lifting Lever Connecting Stud Set Screw..
802D	" " " " Hinge Screw.....
57280	" " " " Hook.....
460c	" " " " " Set Screw.....
38467	" " Spring (flat).....
38468	" " " Stud.....
57482	Presser Foot (hinged, adjustable) for gathering, for 57480.....
57815	Presser Foot for 57813.....
190D	" " Screw.....
574J	Pressure Regulating Thumb Screw.....
1539J	" " " " Lock Nut.....
57262	Slack Thread Controller.....
46035	" " " Clamp (inside).....
57263	" " " " (outside).....
50004F	" " " " Screw.....
2102	Tension Disc.....
57264	" Plate with 439D.....
439D	" " Position Stud.....
57265	" " Spring.....
665D	" " " Screw.....
1560c	" Regulating Thumb Nut.....
32572	" Releasing Disc.....
57266	" " Lever.....
57267	" " " Connection.....
460c	" " " " Set Screw.....
788D	" " " Hinge Screw.....
57292	" " Pin (large).....
54734	" " " (small).....
57268	" " Plate.....
691D	" " " Screw.....
50133c	" Screw Stud.....
54883	" Spring.....
17547	" Thread Guide.....
57472	Thread Controller.....
206D	" " Screw.....
57323	" Eyelet (side or arm).....
175D	" " Screw.....
57628	" Lubricating Oil Cup with Bracket.....
57629	" " " " Pad (felt).....
57630	" " " " Pin.....
57631	Thread Lubricating Oil Cup with Bracket complete, Nos. 57628 to 57630.....
57473	Thread Take-up.....
665D	" " Adjusting Screw.....
57272	" " Arm for 57247.....

209F	Thread Take-up Arm Set Screw for 57247.....
57328	Throat Plate for 57327.....
57481	" " " 57480.....
57814	" " " 57813.....
57828	" " " 57827.....
691F	" " Screw.....

IRON BASE

57515	Machine Base with 100D, 36006, 57284 and four each 6055, 50298E and 57285.....
57284	Machine Base Cover.....
100D	" " " Hinge Screw.....
36006	" " " " " Friction Washer....
50298E	" Bolt with 1524E.....
1524E	" " Nut.....
6055	" " " Washer.....
57285	" Cushion (felt).....

ACCESSORIES

120344	Oiler (copper plated) with 120345.....
120345	" Spout, 5 in. long.....
26026	Screw Driver (large).....
26485	" " (small).....
120341	Tweezers (curved).....
8908	Wrench for 1520.....
19221	" " 1516.....

SPECIAL PARTS FOR HEEL SEAMING

57331	Cloth Plate with two 57404.....
1178E	" " Adjusting Screw.....
1662C	" " " " Lock Nut.....
57404	" " Oil Tube.....
57332	" " Slide.....
57333	Cloth Plate Slide complete, Nos. 57332, two 52683 and four 725J.....
52633	Cloth Plate Slide Spring (left).....
52683	" " " " (right).....
57334	" " " " Bracket.....
193D	" " " " " Screw.....
725J	" " " " " Screw.....
57335	Cloth Plate complete for 57555, 57831 and 57832, Nos. 1178E, 1662C, 57331, 57333, two 57334 and four 193D.....

898F	Cloth Plate Screw (large).....
1011F	" " " (small).....
57554	Feed Dog.....
57829	" " Old Serial No. 32423.....
35818	Lap Seam Guide (left).....
35819	" " " (right).....
35820	Lap Seam Guide complete, Nos. 35818 and 35819.....
1423D	" " " Screw.....
61261	Presser Foot with tape guide.....
57830	" " (strip folding). Old Serial No. 32407.....
120095	Tape Holder Bracket Wire.....
120096	Tape Holder Bracket Wire complete, Nos. 26918, 35823 and 120095.....
35823	Tape Holder Disc.....
35824	" " " Hub.....
26070	" " " " Rivet.....
35825	Tape Holder Disc complete, Nos. 35823, 35824 and three 26070.....
26918	Tape Holder Tape Guide.....
35826	" " Tension Adjusting Collar with 286D.....
286D	" " " " " Thumb Screw..
13211	" " " " Spring.....
120097	Tape Holder (6 in. disc) complete, Nos. 13211, 35825, 35826 and 120096.....
452C	Tape Holder Set Screw.....
57555	Throat Plate for 57554.....
57831	" " " 57829. Old Serial No. 32424.....
57832	" " (serrated on the under side of feeding surface) for 57829. Old Serial No. 33488.....
691F	Throat Plate Screw.....

FOOT LIFTER PARTS

6439 Chain, length 36 in. to 45 in., with 56864 and 56865

NOTE: When ordering No. 6439 give length required.

4879	Chain Connecting Link.....
56864	" Hook (large).....
56865	" " (small).....
57286	Treadle.....
4882	" Shaft.....
4883	" Spring.....
4884	" Stand.....
423C	" Stop Screw.....
1650C	" " " Nut.....
57287	Treadle complete, Nos. 4879, 4882 to 4884, 57286 and two each 423C, 1650C and wood screws 1 in. No. 16.....
57282	Foot Lifter complete, Nos. 802D, 6439, 57275, 57279, 57280 and 57287.....

KNEE LIFTER PARTS

37563	Chain, length 15 in., with 56864 and 56865
56864	" Hook (large)
56865	" " (small)
2763	Rock Shaft
12242	" " Hanger with two wood screws 1 in. No. 10
6335	" " Knee Arm
6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335
2766	Rock Shaft Knee Arm Hub with 356c
356c	" " " " " Set Screw
2767	" " " Plate with 356c
356c	" " " " " Set Screw
6337	" " Lifting Bracket with two 356c
7125	" " " " Hook
356c	" " " " " Set Screw
356c	" " " " " Set Screw
2770	" " Stop Dog with 356c
356c	" " " " " Set Screw
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242
57281	Knee Lifter complete (power table) Nos. 802D, 23767, 24122, 37563, 45057, 57275 to 57277, 57279 and 57280

THREAD UNWINDER

FOR THREE SPOOLS

225389	Spool Rest with 201018c, for one spool
225395	" " " " " two spools
225388	" " Rod
200383c	" " " Set Screw
201018c	" " Set Screw
202490	" Stand with 200383c
60913	" Weight with 60914
60914	" " Centre Pin
225391	Thread Guide
201696J	" " Lock Nut
225392	" " Rod with 208E and 225393
203E	" " " Screw
225393	" " " Washer
225397	Thread Unwinder complete, Nos. 201696J, 202490, 225388, 225389, 225392, 225395, three each 60913, 225391 and wood screws $\frac{1}{8}$ in. No. 13
27739	Thread Cone (wood) for large cones
225390	" " Holder, for inverted cones

NOTE: Nos. 27739 and 225390 are used with,
but not included in, 225397.

