

106-5-105

DEPARTMENT No. 54

FEBRUARY 2, 1921

# LIST OF PARTS COMPLETE



FOR  
**MACHINES**  
Nos. 106-5 and 106-105

---

**THE SINGER MANUFACTURING COMPANY**

# LIST OF PARTS COMPLETE FOR MACHINE No. 106-5

SINGLE THREAD CHAIN STITCH. BED, 17 IN. LONG, 8½ IN. FROM  
THE CENTRE OF THE NEEDLE BAR TO THE BASE OF THE ARM.  
FIVE NEEDLES, FIVE HOOKS. FOOT OR KNEE LIFTER. TENSION  
RELEASE.

*57201	- Arm, upper and lower (solid) with 57202.....
57202	" Oil Tube, for oiling 64267.....
18130	" " " with 29599, for oiling 38458.....
29599	" " " Packing (felt) for 18130.....
57204	" Rock Shaft.....
12147	" " " Back Bearing Oil Pad (felt).....
57205	" " " Collar with two 889c.....
889c	" " " " Set Screw.....
57439	" " " Crank (back) with four 168c.....
168c	" " " " " Set Screw.....
38412	" " " " (front) with 443c.....
23724	" " " " " Pin.....
443c	" " " " " Set Screw.....
18154	" " " Front Bearing Oil Pad (felt).....
57207	" Rotary Shaft.....
61004	" " " Bushing (intermediate).....
832c	" " " " " Set Screw.....
61005	" " " Collar with two 454c.....
454c	" " " " Set Screw.....
57208	" " " Flanged Bushing (back).....
159F	" " " " " " Screw.....
46200	" " " Intermediate Bearing Oil Pad (felt).....
57209	" " " Lubricating Ring.....
144D	" " " Screw.....
23933	" Side Cover.....
286D	" " " Thumb Screw.....
61006	Balance Wheel (double, belt groove) 2 in. diam., with two 430c.....
430c	Balance Wheel Set Screw.....
57211	Cloth Plate (small) with two 57404.....
57212	" " " Hook.....
57404	" " " Oil Tube.....
691F	" " " Screw.....
57213	" " " Slide (large).....
57214	Cloth Plate (small) Slide (large) complete, Nos. 57213, 57215 and two 725H.....



57215	Cloth Plate (small) Slide (large) Spring	.....
725H	" " " " " " Screw	.....
57216	" " " " (small)	.....
57217	Cloth Plate (small) Slide (small) complete, Nos. 57216, 57218, 57219 and four 665J	.....
57218	Cloth Plate (small) Slide (small) Spring (left)	.....
665J	" " " " " " " " Screw	.....
57219	" " " " " " " (right)	.....
665J	" " " " " " " " Screw	.....
57435	Cloth Plate (small) complete for 57296, 57501 and 57507, Nos. 57211, 57214 and 57217	.....
57220	Cloth Plate (small) 57435 with four 57212	.....
57343	" " (large)	.....
1011F	" " " " Screw (left)	.....
898F	" " " " " (right)	.....
57344	" " " Slide	.....
57345	Cloth Plate (large) Slide complete, Nos. 57344, two 52683 and four 725H	.....
52683	Cloth Plate (large) Slide Spring	.....
57334	" " " " " Bracket	.....
193D	" " " " " " Screw	.....
725H	" " " " " " Screw	.....
57346	" " " Support Bracket with 29627 and two each 430c and 1520E	.....
430c	Cloth Plate (large) Support Bracket Adjusting Screw	...
1520E	" " " " " " " " Nut	.....
29627	" " " " " " Dowel Pin	.....
134D	" " " " " " Screw	.....
57347	Cloth Plate (large) complete for 57535 and 57542, Nos. 57343, 57345, two 57334 and four 193D	.....
57363	Cloth Plate (large) with two 57404	.....
57404	" " " Oil Tube	.....
57364	" " " Slide	.....
57365	Cloth Plate (large) Slide complete, Nos. 57364, two 52683 and four 725H	.....
57366	Cloth Plate (large) complete for 57730, Nos. 57363, 57365, two 57334 and four 193D	.....
64267	Crank Connecting Rod with 46223, 57222 and two each 896E and 1057E	.....
50069c	Crank Connecting Rod Ball Screw Stud (upper)	.....
1619E	" " " " " " " " Nut	.....
*57222	" " " " Cap (lower)	.....
896E	" " " " " " Screw	.....
*46223	" " " " " (upper)	.....
1057E	" " " " " " Screw	.....
57288	" " " Oil Case with 57290, 57291 and four each 197D and 448c	.....

57290	Crank Connecting Rod Oil Case Cap.....
57291	" " " " " " Packing (felt)....
197D	" " " " " " Screw.....
448C	" " " " " " Set Screw.....
57223	Face Plate.....
57367	" " for 57380.....
46111	" " Pin.....
286D	" " Thumb Screw.....
57224	Feed Bar with two 457c.....
57225	" " Hinge Pin.....
457C	" " " " Set Screw.....
57295	" Dog.....
57500	" " for gathering.....
57506	" " .....
57541	" " .....
57729	" " .....
57293	" " Packing .005 in. thick.....
57294	" " " .012 in. thick.....
57321	" " " .021 in. thick.....
1255F	" " Screw.....
*57227	" Eccentric.....
*23729	" " Body.....
443C	" " " Set Screw.....
61171	" " Pressure Spring.....
21332	" " " " Cap.....
934D	" " " " " Screw.....
196F	" " Set Screw.....
57228	Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103c, 21332, 23729, 57227, 61171 and two 443c
57229	Feed Eccentric Connection.....
57230	" Lifting Eccentric with two 624c.....
57231	" " " Connection.....
624c	" " " Set Screw.....
1103c	" Regulating Screw.....
57232	" Rocking Frame with four 624c.....
57233	" " " Bar.....
624c	" " " " Set Screw.....
57234	" " " Hinge Pin.....
57235	" " " " " Bushing.....
449C	" " " " " " Set Screw.....
624c	" " " " " " Set Screw.....
57441	Looper (large shank) for heavy work.....
57339	" (small shank) for two or more consecutive gauges of $\frac{1}{8}$ in.....
57299	Looper Carrier with five 50370r, for 57441.....
57340	" " " " " " 57339.....
57557	" " " " " " 57441.....
157D	" " Screw.....



57238	Looper Eccentric with two 889c.....
57239	“ “ Connection.....
57240	“ “ “ Oil Pad (felt).....
924E	“ “ “ “ “ Stop Screw.....
889c	“ “ Set Screw.....
57241	“ Rock Shaft with two 624c.....
57242	“ “ “ Bar.....
624c	“ “ “ “ Set Screw.....
57243	“ “ “ Hinge Pin with 860E.....
860E	“ “ “ “ “ Plug Screw.....
446c	“ “ “ “ “ Set Screw.....
50370F	“ Set Screw.....
57244	Needle Bar (hollow).....
57436	“ “ 57244 with 57305.....
57370	“ “ with 57372.....
57567	“ “ 57370 with 57566.....
38456	“ “ Bushing (lower).....
1133E	“ “ “ “ Set Screw.....
57245	“ “ “ (upper).....
61042	“ “ “ “ for 57578.....
1133E	“ “ “ “ Set Screw.....
57372	“ “ Collar with 735F.....
735F	“ “ “ Set Screw.....
38458	“ “ Connecting Link.....
57246	“ “ “ “ Hinge Stud.....
1520E	“ “ “ “ “ Nut.....
57247	“ “ “ Stud with 219r and two 391D..
57373	“ “ “ “ “ two 391D, for 57380
391D	“ “ “ “ Clamping Screw.....
57305	“ Clamp with five 50014F.....
57565	“ “ “ “ 904F.....
57375	“ “ Holder.....
1190b	“ “ “ Screw.....
57566	Needle Clamp complete, Nos. 57375, 57565 and three 1190b.....
57449	Needle Clamp Guide for 57566.....
57450	“ “ “ Bracket (left).....
158b	“ “ “ “ “ Screw.....
57450	“ “ “ “ (right).....
158b	“ “ “ “ “ Screw.....
57379	“ “ “ “ Holder.....
1193b	“ “ “ “ “ Screw.....
914b	“ “ “ Screw.....
57380	“ “ Support for 57566.....
50365b	“ “ “ Screw (lower).....
220b	“ “ “ “ (upper).....
57315	Needle Guard with two 50239c, for $\frac{7}{32}$ in. gauge and below.....

57423	Needle Guard with two 50239c, for $\frac{1}{4}$ in. gauge and above.....	
57251	Needle Guard Bar.....	
57252	" " " Bracket (left) with 440F.....	
177C	" " " " " Screw.....	
57253	" " " " (right) with 440F.....	
177C	" " " " " Screw.....	
57254	" " " " Holder for 57211.....	
57354	" " " " " " 57343.....	
57382	" " " " " " 57363.....	
50154D	" " " " " Screw.....	
440F	" " " Set Screw.....	
50239C	" " Set Screw.....	
50014F	" Set Screw for 57305.....	
904F	" " " " 57565.....	
57255	Presser Bar with 25303.....	
57669	" " " " for Universal Compensating Presser Feet.....	
25303	Presser Bar Ball, size $\frac{1}{4}$ in.....	
61046	" " Bushing (lower).....	
1133E	" " " " Set Screw.....	
38456	" " " (upper).....	
1133E	" " " " Set Screw.....	
57257	" " Lifter.....	
57258	" " " Hinge Pin.....	
447C	" " " " " Set Screw.....	
194D	" " " Stop Screw.....	
57259	" " Lifting Bracket with 453c and 1819.....	
57260	" " " " Guide.....	
1819	" " " " Roller and Stud.....	
453C	" " " " Set Screw.....	
38467	" " Spring (flat).....	
38468	" " " Stud.....	
57513	" Foot.....	
57338	" " (side hinged, adjustable) for gathering.....	
57518	" " (compensating).....	
57576	" " (universal compensating).....	
190D	" " Screw.....	
574D	Pressure Regulating Thumb Screw.....	
1539D	" " " " Lock Nut.....	
57262	Slack Thread Controller.....	
46035	" " " Clamp (inside).....	
57263	" " " " (outside).....	
50004F	" " " " Screw.....	
2102	Tension Disc.....	
57316	" Plate with 439D.....	
439D	" " Position Stud.....	
57265	" " Spring.....	

665D	Tension Plate Spring Screw	.....
1560C	" Regulating Thumb Nut	.....
32572	" Releasing Disc	.....
57266	" " Lever	.....
57267	" " " Connection	.....
460C	" " " " Set Screw	.....
788D	" " " Hinge Screw	.....
32574	" " Pin (large)	.....
54734	" " " (small)	.....
57317	" " Plate	.....
691D	" " " Screw	.....
50133C	" Screw Stud	.....
54883	" Spring	.....
17547	" Thread Guide	.....
57301	Thread Controller	.....
206D	" " Screw	.....
57324	" Eyelet (side of arm)	.....
175D	" " Screw	.....
57628	" Lubricating Oil Cup with Bracket	.....
57629	" " " " Pad (felt)	.....
57630	" " " " Pin	.....
57631	Thread Lubricating Oil Cup with Bracket complete, Nos. 57628 to 57630	.....
57302	Thread Take-up	.....
665D	" " Adjusting Screw	.....
57272	" " Arm for 57247	.....
57577	" " " " 57578	.....
57578	" " " Holder with 228D and 465C, for 57373	.....
465C	Thread Take-up Arm Holder Set Screw	.....
219F	" " " Set Screw for 57247	.....
228D	" " " " " " 57578	.....
57296	Throat Plate for 57295	.....
57501	" " for 57500	.....
57507	" " (large needle hole) for 57506	.....
57542	" " for 57541	.....
57730	" " " 57729	.....
691F	" " Screw	.....



# MACHINE No. 106-105

This Machine is the same as 106-5 with the Tuck Folding Attachment and the following exceptions:

57331	Cloth Plate (large) with two 57404	.....
1178E	" " " Adjusting Screw	.....
1662C	" " " " " Lock Nut	.....
57404	" " " Oil Tube	.....
57731	" " " Slide	.....
57732	Cloth Plate (large) Slide complete, Nos. 57215, 57731 and two 725H	.....
57215	Cloth Plate (large) Slide Spring	.....
725H	" " " " " Screw	.....
57733	Cloth Plate (large) complete for 57330 and 57342, Nos. 1178E, 1662C, 57331 and 57732, in place of 57435	.....
57329	Feed Dog	.....
57341	" "	.....
57534	" "	.....
57300	Presser Foot (side hinged)	.....
57330	Throat Plate for 57329	.....
57342	" " " 57341	.....
57535	" " " 57534	.....

## IRON BASE

57515	Machine Base with 100D, 36006, 57284 and four each 6055, 50298E and 57285	.....
57284	Machine Base Cover	.....
100D	" " " Hinge Screw	.....
36006	" " " " " Friction Washer	.....
50298E	" Bolt with 1524E	.....
1524E	" " Nut	.....
6055	" " " Washer	.....
57285	" Cushion (felt)	.....

## ACCESSORIES

36563	Oiler (copper plated) with 36564	.....
36564	" Spout, 5 in. long, with 120117	.....
120117	" " Washer (leather)	.....
26026	Screw Driver (large)	.....
26485	" " (small)	.....
35143	Tweezers	.....
8908	Wrench for 1520	.....
19221	" " 1619	.....



## FOOT LIFTER PARTS

6439 Chain, length 36 in. to 45 in. ....

NOTE: When ordering No. 6439 give length required.

4879 Chain Connecting Link. ....

57275 Lifting Lever with two 460c. ....

\*57278 " " Connecting Stud. ....

57279 Lifting Lever Connecting Stud complete, Nos. 453c,  
1423d, 1904 and 57278. ....

1904 Lifting Lever Connecting Stud Roller (roller only). ....

1423d " " " " " Cap Screw. ....

453c " " " " " Set Screw. ....

57280 " " Hook. ....

460c " " " Set Screw. ....

802d " " Hinge Screw. ....

57286 Treadle. ....

4882 " Shaft. ....

4883 " Spring. ....

4884 " Stand. ....

423c " Stop Screw. ....

1650c " " " Nut. ....

57287 Treadle complete, Nos. 4879, 4882 to 4884, 57286 and  
two each 423c, 1650c and wood screws 1 in.  
No. 16. ....

57282 Foot Lifter complete, Nos. 802d, 6439, 57275, 57279,  
57280 and 57287. ....

## KNEE LIFTER PARTS

37563 Chain, length 15 in. ....

57275 Lifting Lever with two 460c. ....

57276 " " Connecting Rod. ....

57277 " " " " Collar with two 465c. ....

465c " " " " " Set Screw. ....

24122 " " " " Spring. ....

45057 " " " " " Stop Washer. ....

\*57278 " " " Stud. ....

57279 Lifting Lever Connecting Stud complete, Nos. 453c,  
1423d, 1904 and 57278. ....

1904 Lifting Lever Connecting Stud Roller (roller only). ....

1423d " " " " " Cap Screw. ....

453c " " " " " Set Screw. ....

57280 " " Hook. ....

460c " " " Set Screw. ....

802d " " Hinge Screw. ....

2763 Rock Shaft. ....

12242 " " Hanger with two wood screws 1 in. No. 10

6335 " " Knee Arm. ....

6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335.....
2766	Rock Shaft Knee Arm Hub with 356c.....
356c	" " " " " Set Screw.....
2767	" " " " Plate with 356c.....
356c	" " " " " Set Screw.....
6337	" " Lifting Bracket with two 356c.....
7125	" " " " Hook.....
356c	" " " " " Set Screw.....
356c	" " " " " Set Screw.....
2770	" " Stop Dog with 356c.....
356c	" " " " " Set Screw.....
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242.....
57281	Knee Lifter complete (power table) Nos. 802D, 23767, 24122, 37563, 45057, 57275 to 57277, 57279 and 57280.....

## THREAD UNWINDER

### FOR FIVE LARGE SPOOLS OR FIVE LARGE CONES OF THREAD

27623	Spool Pin.....
155c	" " Set Screw.....
41534	" Rest.....
41535	" " 41534 with 1149c and four each 155c and 27623.....
60444	Spool Rest.....
60844	" " 60444 with 155c.....
60445	" " 60844 with 27623.....
1149c	" " Set Screw.....
27940	" Stand with 453c.....
41514	" Weight, 4 in. diam., with 41515.....
41515	" " Centre Pin.....
27739	Thread Cone (wood).....
41633	" Guard with 208E and four 41569.....
41569	" " Eyelet.....
41637	" " Rod (lower).....
41638	" " " (upper).....
41639	" " " Coupling with two 456c.....
456c	" " " " Set Screw.....
41640	Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639.....
453c	Thread Guard Rod Set Screw.....
208E	" " Screw.....
41635	" " Tension Bracket with 175D.....
41636	Thread Guard Tension Bracket complete, Nos. 418E, 1562J, 41635, 43808 and two 2455.....
60446	Thread Guard Tension Bracket with 175D.....

60447	Thread Guard Tension Bracket complete, Nos. 418E, 1562J, 43808, 60446 and two 2455. ....
175D	Thread Guard Tension Bracket Set Screw. ....
2455	" " " Disc. ....
1562J	" " " Regulating Thumb Nut. ....
418E	" " " Screw Stud. ....
43808	" " " Spring. ....
60685	Thread Unwinder, Nos. 27940, 41535, 41633, 41640, three wood screws 1 in. No. 12 and four 27739
41537	Thread Unwinder complete for four large spools or four large cones of thread, Nos. 60685 and four 41514
60711	Thread Unwinder complete, Nos. 41514, 41537, 60445, 60447 and four 41636. ....



