

LIST OF PARTS
MACHINE NO. 107W53

*210501	Arm with 202135
203087	" Cap
200278X	" " Screw
202248	" " " Washer
203089	" " Spool Holder Base
203090	" " " " " 203089 with 200079X and 204296
200585X	" " " " " Screw
204296	" " " " " Wire
200079X	" " " " " Hinge Screw
203088	Arm Cap and Spool Holder complete, Nos. 203087, 203090, and two 200585X
204235	" Position Pin (2)
200010E	" Screw (3)
202005	" " Washer (3)
202249	" Shaft with 224392
240802	" " Bushing (back) with 202244
202244	" " " " Oil Packing (wick)
200338C	" " " " Set Screw
207080	" " " (front) with 202244
202244	" " " " Oil Packing (wick)
200502X	" " " " " " Thumb Screw
200341C	" " " " Set Screw
224400	" " Connection Belt (reinforced neoprene)
202635	" " " " Pulley with 200327C, 200602C, and two 202253
200602C	" " " " Pulley Position Screw
200327C	" " " " " Set Screw
202253	" " " " " Spring Flange
224392	" " Oil Packing (wick)
*242001	Bed (cylinder)

MACHINE NO. 107w53

213890 Bed Base (4 inches high)
NOTE: Bed Base 213890 is furnished with this machine unless
otherwise specified on order

213353 Bed Base (6 inches high)

203184 " Clamp

200262X " " Hinge Screw

202622 " " Packing Washer

200728X " " Thumb Screw

203185 " " " " Washer

202618 " Hinge

201110X " " Screw (6)

210505 " Plate (back)

200577AL " " " Screw (2)

263099 Bobbin

210846 " Case Base

224440 " " Cap with 200592C, 201016C and 263110

224441 Bobbin Case Cap complete, Nos. 200964C, 210736, 210914 and 224440

210913 " " Latch

210914 " " " 210913 with 210734 and 210735

210735 " " " Fulcrum Pin

210734 " " " Lever

210736 " " " Spring

200964C " " " Stop Screw

242002 " " Stop

200126D " " " Screw

263110 " " Tension Spring

201016C " " " " Regulating Screw

200592C " " " " Screw

224442 Bobbin Case complete, Nos. 210846 and 224441

MACHINE NO. 107x53

242003	Cylinder End Cover with 242004 and two 200177D
200294X	" " " Hinge Screw (2)
242004	" " " Latch
200177D	" " " " Screw
210681	Face Plate
202135	" " Position Pin
200462X	" " Thumb Screw
210682	Face Plate complete, Nos. 210681, 210684 and two 200137X
— 242005	Feed Bar
242006	" " 242005 with 200641C, 201522E and 202623
200641C	" " Hinge Screw (driving)
201522E	" " " " Nut
— 202276	" " Slide Block
202624	" " " " Crank with 200038C
— 242008	" " " " " 202624 with 200205F, 201518E and 202276
200038C	" " " " " Pinch Screw
200205F	" " " " " Hinge Screw
201518E	" " " " " " Nut
242018	" Dog, for 210603
200106E	" " Screw (2)
202297	" Driving Connection with 200054E and 203101
242022	" " " Crank with 200038C
200038C	" " " " Pinch Screw
200545C	" " " Hinge Screw
201518E	" " " " " Nut
203101	" " " Oil Packing (wick)
200054E	" " " Pinch Screw
202300	" " Eccentric Regulating Bracket

203098	Feed Driving Eccentric	Regulating Bracket	202300 with 202635, two each 201014C and 201525E
201014C	"	"	Regulating Bracket Hinge Screw
201525E	"	"	" " " Nut
202301	"	"	" " Plunger
202595	"	"	" " Spring
200607C	"	"	" " Stop
			Screw
201014C	"	"	Regulating Bracket Stop Screw
201525E	"	"	" " " Nut
200429F	"	"	" " Screw
200383C	"	"	" " Check Screw
202623	"	"	Rock Shaft
202625	"	"	" " Stop Collar with two 200383C (2)
200383C	"	"	" " Set Screw
202306	"		Lifting Connection with 200054E and 203101
*210645	"	"	Crank
210589	"	"	" 210645 with 200050C and 200378C
200050C	"	"	" Pinch Screw
200378C	"	"	" Set Screw
202307	"	"	Eccentric with 200382ALX and 200437C
200437C	"	"	" Position Screw
200382ALX	"	"	" Set Screw
200545C	"	"	Hinge Screw
201518E	"	"	" " Nut
203101	"	"	Oil Packing (wick)
200054E	"	"	Pinch Screw
210531	"	"	Rock Shaft (hollow) and Hook Driving Shaft Bear- ing
202625	"	"	" " Stop Collar with two 200383C

MACHINE NO. 107W53

200333C	Food Lifting Rock Shaft Stop Collar Set Screw
200310	" Regulating Spindle with 202311, 202443 and 202619
*202311	" " " Head
202443	" " " " Pin
202619	" " " " Position Pin
224432	Hook (sewing) with 203101 and 263134 502535
224433	" 224432 with 200115C, 210536, 210541 and three 200596F
224443	Hook and Bobbin Case complete, Nos. 224433 and 224442
210614	" Driving Bevel Pinion (steel), 24 teeth, with two 200378C
200378C	" " " " Set Screw
210535	" " " " Shaft
202661	" " " " " Belt Pulley with 202324 and two 200378C
200378C	" " " " " Shaft Belt Pulley Set Screw
202324	" " " " " " " Spring Flange
210536	" Gib
200596F	" " Screw
535 263134	" Oiling Felt
203101	" Oil Wick
350984F	" Position Screw
242011	" Shaft (hollow)
210615	" " Bevel Gear (steel), 24 teeth, with two 200382ALX
200382ALX	" " " " Set Screw
242020	" " Bushing with 265683
242012	" " " 242020 with 200931F and 242011
265683	" " " Oil Packing (wick)
20363AL 201007C	" " " Set Screw
244084	" " " " " packing (fibre)
200931F	" " Position Screw

210541	Hook Washer Needle Guard
2001450	" " " " Screw
242009	Knee Lifter Lifting Lever
200242X	" " " " Hinge Screw
242010	" " " " Rod with 202302
202302	" " " " Cotter Pin
233361	" " " " Spring
200273D	" " " " Screw
233390	" " " " Washer
244090	Machine Pulley (disc) (aluminum alloy casting) "V" belt groove (outside diam. of belt groove 2.9 in.) with 3505406 and 3505410 141566C 141567C
410 3505406	" " " " Position Screw
5070 3505410	" " " " Set Screw
224317	Needle Bar with 200125ALX, 200175X and 249270
210543	" " " " Connecting Link
202333	" " " " Stud with 202299
202299	" " " " " Oil Packing (wick)
200383C	" " " " " Set Screw
200374AL	" " " " " " "
210544	" " " " Stud with 202299
210585	" " " " 210544 with 210882
202299	" " " " Oil Packing (wick)
210882	" " " " Swivel with 200387C
210725	" " " " Crank with 200335C, 200374AL, 200383C, ^{200432C} 200428C and 202333
203172	" " " " Friction Washer
04320 200428C	" " " " Position Screw
200335C	" " " " Set Screw
200388C	" " " " LOCK SCREW 50

MACHINE NO. 107W53

210683 Needle Bar Crank complete, Nos. 202399, 202400, 210543, 210585,
210725 and 244059

210546	"	"	Frame with 2000700
210542	"	"	" 210546 with 224317
210547	"	"	Guide Stud
2003340	"	"	" " Set Screw
210548	"	"	Hinge Stud
2003340	"	"	" " Set Screw
210556	"	"	Pitman with 200054E and 202277
210557	"	"	" Eccentric Stud
2000700	"	"	" " Set Screw
202277	"	"	" Oil Packing (wick)
200054E	"	"	" Pinch Screw
2003870	"	"	Set Screw
200125ALX	"	"	Set Screw
249270	"	"	Bar Thread Guide
200175X	"	"	" " Screw
202300	"	"	Vibrator Eccentric Regulating Bracket
210550	"	"	" " 202300 with 210552, two each 200256C and 210525E 201525E
210551	"	"	Regulating Bracket Cover Plate
200566D	"	"	" " " " Screw (4)
210552	"	"	Regulating Bracket Flange with two 200383C
200383C	"	"	Regulating Bracket Flange Screw
200256C	"	"	" " Hinge "
201525E	"	"	" " " " Nut
202301	"	"	" " Plunger
202595	"	"	" " Spring

200607C	Needle Vibrator Eccentric Regulating Bracket Plunger Spring Stop Screw					
2002560	"	"	"	Regulating Bracket Stop Screw		
201525E	"	"	"	"	"	" Nut
210699	"	"	Gear (spiral) with two 200382ALX			
203172	"	"	"	Friction Washer		
200382ALX	"	"	"	Set Screw		
210558	"	"	"	Shaft		
210559	"	"	"	"	Collar with two 200378C	
200378C	"	"	"	"	"	Set Screw
210700	"	"	Pinion (spiral) with two 200382ALX			
200382ALX	"	"	"	Set Screw		
200429F	"	"	Regulating Screw			
200383C	"	"	"	"	Check Screw	
233175	"	"	"	Spindle with 210554		
210554	"	"	"	"	Spring (flat)	
244033	Presser Bar (hollow)					
202335	"	"	244033 with 200074F			
207072	"	"	Bushing			
200352AL	"	"	"	Set Screw		
202554	"	"	Lifter			
200653C	"	"	"	Hinge Screw		
210789	"	"	Lifting Releasing Lever Bracket			
200260E	"	"	"	"	"	Guide Screw
206608	"	"	"	"	"	Spring
202337	"	"	Position Guide			
202338	"	"	"	"	Lever with 200086ALX	
200086ALX	"	"	"	"	Pinch Screw	
200352AL	"	"	"	"	Set Screw	

202343	Presser Bar Spring
202346	" " " Stop Rod
200492X	" " Thumb Screw (pressure regulating)
200475X	" " " " Thumb Set Screw
244084	" " " " " " " Packing (fibre)
242053	" Foot Edge Guide
200175X	" " " " Screw
230795	" " Hinge Pin
242054	" " Plate
200074F	" " Screw
202923	" " Shank
242055	Presser Foot (hinged) complete, Nos. 200175X, 202923, 230795, 242053 and 242054
210591	Take-up (auxiliary), for Swivel
200132E	" " Screw
244059	" Lever
202399	" " Driving Stud with 244071
244071	" " " " Oil Packing (wick)
202400	" " Hinge Stud with 202423
202423	" " " " Oil Packing (wick)
200383C	" " " " Set Screw
202401	" " Oiling Felt
200132E	" " " " Screw
244048	Tension Disc (back)
244049	" " (front)
202404	" Release Plunger
244061	" " Washer
223438	" Spring
263106	" " Washer

200625F	Tension Stud with 204925
200061ALX	" " Set Screw
204925	" " Washer
201572X	" Thumb Nut
244662	Tension complete, Nos. 200625F, 201572X, 202410, 223438, 244048, 244049, 244061 and 263106
202410	Thread Controller Spring
241443	" " " Stop
200132E	" " " " Screw
210593	" Guide (lower)
202412	" " (on top of Arm)
210592	" " (upper)
200582X	" " Screw (2)
240335	" Retainer
210683	" " Bracket with 200397X
200137X	" " " Screw
200368X	" " Set Screw
210993	" " Sleeve
210992	" " Spring
210957	" " Stud
210958	" " " Collar
200397X	" " " Set Screw
210684	Thread Retainer Bracket complete, Nos. 210683, 210957, 210958, 210992 and 210993
210693	Throat Plate, 53 needle hole, for needle sizes 12 and 13, for 242018
200577AL	" " " Screw (2)

ACCESSORIES

200157X	Attachment Screw
263099	Bobbin (2)
259462	Bobbin Winder
203058	Knee Lifter Lifting Lever Rock Coupling
228251	Knee Lifter Rock Shaft complete
51078	Machine Bolt (4)
6055	Machine Bolt Washer (4)
41401	Machine Rest Pin
135x5	Needles #14 (6)
120342	Oil Can
225498	Screw Driver
228476	Screw Driver (Bobbin Case)
242017	Work Plate
201011X	Work Plate Screw (back)
200577AL	Work Plate Screw (front)(2)
225554	Wrench