# LIST OF PARTS SINGER SEWING MACHINE 112 G 127

FORM 30-351 G KARLSRUHE JPD (ITD 166/951) WESTERN GERMANY From the library of: Superior Sewing Machine & Supply LLC

| ARM WITH 202135<br>ARM CAP<br>ARM CAP SCREW<br>ARM CAP SCREW WASHER<br>ARM POSITION PIN (2)<br>ARM SCREW (3)<br>ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br><b>AR</b> M SHAFT BUSHING (FRONT) WITH 202244<br><b>AR</b> M SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br><b>AR</b> M SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br><b>AR</b> M SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR<br>WITH 200113  |
|---|
| ARM CAP SCREW<br>ARM CAP SCREW WASHER<br>ARM POSITION PIN (2)<br>ARM SCREW (3)<br>ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR |
| ARM CAP SCREW WASHER<br>ARM POSITION PIN (2)<br>ARM SCREW (3)<br>ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW  |
| ARM POSITION PIN (2)<br>ARM SCREW (3)<br>ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SCREW (3)<br>ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)  |
| ARM SCREW WASHER (3)<br>ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)   |
| ARM SHAFT WITH 224392 AND 350431<br>ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)   |
| ARM SHAFT BUSHING (BACK) WITH 202244<br>ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)  |
| ARM SHAFT BUSHING (BACK) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)  |
| ARM SHAFT BUSHING (BACK) SET SCREW<br>ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR  |
| ARM SHAFT BUSHING (FRONT) WITH 202244<br>ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)   |
| ARM SHAFT BUSHING (FRONT) OIL PACKING (WICK)<br>ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)  |
| ARM SHAFT BUSHING (FRONT) OIL PACKING THUMB SCREW<br>ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SHAFT BUSHING (FRONT) SET SCREW<br>ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)   |
| ARM SHAFT CONNECTION BELT (REINFORCED NEOPRENE)<br>ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SHAFT CONNECTION BELT PULLEY WITH 200327,<br>200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR  |
| 200602 AND TWO 202253<br>ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SHAFT CONNECTION BELT PULLEY POSITION SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR  |
| ARM SHAFT CONNECTION BELT PULLEY SET SCREW<br>ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SHAFT CONNECTION BELT PULLEY SPRING FLANGE (2)<br>ARM SHAFT CONNECTION BELT TIMING COLLAR   |
| ARM SHAFT CONNECTION BELT TIMING COLLAR   |
|   |
|   |
| ARM SHAFT CONNECTION BELT TIMING COLLAR SET SCREW   |
| arm shaft connection belt timing plate  |
| ARM SHAFT CONNECTION BELT TIMING PLATE SCREW (2)  |
| ARM SHAFT OIL PACKING (WICK)  |
| ARM SHAFT OIL PACKING STOP SCREW  |
| ATTACHMENT SLIDE PLATE WITE 213479 AND 236061   |
| ATTACHMENT SLIDE PLATE FRICTION SLIDE   |
| ATTACHMENT SLIDE PLATE FRICTION SLIDE SPRING  |
| BED WITH 203376   |
| BED OIL CUP   |
| BED SLIDE (BACK)  |
| BED SLIDE (BACK) STOP   |
| BED SLIDE (BACK) STOP SPRING  |
| BED SLIDE (FRONT) FOR USE WITH THROAT PLATES IN GAUGES  |
| FROM 3/16 TO 5/8 INCH   |
| BED SLIDE (FRONT) FOR USE WITH THROAT PLATES IN GAUGES  |
| BOBBIN (2)  |
| BOBBIN CASE (CHROMIUM PLATED)   |
| BOBBIN CASE LATCH   |
|   |
| BOBBIN CASE LATCH PIN   |
|   |
|   |

| PART NO.   | DESCRIPTION   |
|------------|---|
| 241674     | BOBBIN CASE OILING FELT                                   |
| 241675     | BOBBIN CASE OILING FELT RETAINER                          |
| 350405-803 | BOBBIN CASE OILING FELT RETAINER SCREW (2)                |
| 224004     | BOBBIN CASE OPENER  |
| 224005     | BOBBIN CASE OPENER LEVER WITH 201349, 201542 AND 203101   |
| 201349-803 | BOBBIN CASE OPENER LEVER DRIVING SCREW STUD               |
| 201542-803 |   |
| 203101     | BOBBIN CASE OPENER LEVER DRIVING SCREW STUD OIL           |
|            | PACKING (WICK)  |
| 265088     |   |
| 202277     |   |
| 200364-803 |   |
| 223623     | BOBBIN CASE OPENER LEVER LINK                             |
| 200118-804 | BOBBIN CASE OPENER SCREW                                  |
| 236083     | BOBBIN CASE TENSION SPRING                                |
| 201016-806 | BOBBIN CASE TENSION SPRING REGULATING SCREW               |
| 200594-803 | BOBBIN CASE TENSION SPRING SCREW                          |
| 203216     | BOBBIN CASE WASHER (CLOTH)                                |
| 248460     | BOBBIN CASE CPL. (2) NOS. 200594, 201016, 202056, 203216, |
|            | 203473, 203474, 203648, 236083, 241674, 241675, 248459    |
|            | AND TWO 350405  |
| 237804     | FACE PLATE  |
| 202135     | FACE PLATE POSITION PIN                                   |
| 200473-819 | FACE PLATE THUMB SCREW                                    |
| 224050     | FEED BAR WITH 200336 AND 201535                           |
| 224051     | FEED BAR WITH 224050, 200040, 225837 AND 267273           |
| 350393-803 | FEED BAR HINGE SCREW (DRIVING) ·                          |
| 201518-805 | FEED BAR HINGE SCREW NUT                                  |
| 211786     | FEED DOG, FOR 248286                                      |
| 221446     | FEED DOG, FOR 248292                                      |
| 211792     | FEED DOG, FOR 2482 <b>94</b>                              |
| 200106-805 | FEED DOG SCREW (2)  |
| 200336-805 | FEED DOG SUPPORT SCREW                                    |
| 201535-805 | FEED DOG SUPPORT SCREW NUT                                |
| 224106     | FEED DRIVING CONNECTION WITH 200049 AND 202277            |
| 201407-803 | FEED DRIVING CONNECTION HINGE SCREW                       |
| 201517-805 | FEED DRIVING CONNECTION HINGE SCREW NUT                   |
| 2067 58    | FEED DRIVING CONNECTION HINGE SCREW OIL PACKING (WICK)    |
| 202277     | FEED DRIVING CONNECTION OIL PACKING (WICK)                |
| 200049-804 | FEED DRIVING CONNECTION PINCH SCREW                       |
| 202300     | FEED DRIVING ECCENTRIC REGULATING BRACKET                 |
| 224140     | FEED DRIVING ECCENTRIC REGULATING WITH 202300             |
|            | 224200, TWO EACH 201408 AND 201525                        |

From the library of: Superior Sewing Machine & Supply LLC

. ....

| PART NO.       | DESCRIPTION  |
|----------------|--|
| 201408-803     | FEED DRIVING ECCENTRIC REGULATING BRACKET HINGE              |
|                | SCREW (2)  |
| 201525-805     | FEED DRIVING ECCENTRIC REGULATING BRACKET HINGE              |
|                | SCREW NUT (2)  |
| 202301         | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER            |
| 202595         | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER            |
|                | SPRING   |
| 200607-803     | FEED DRIVING ECCENTRIC REGULATING BRACKET PLUNGER            |
|                | SPRING STOP SCREW  |
| 201408-803     | FEED DRIVING ECCENTRIC REGULATING BRACKET STOP               |
|                | SCREW  |
| 201525-805     | FEED DRIVING ECCENTRIC REGULATING BRACKET STOP               |
|                | SCREW NUT  |
| 200429-806     | FEED DRIVING ECCENTRIC REGULATING SCREW                      |
| 200383-803     | FEED DRIVING ECCENTRIC REGULATING SCREW CHECK SCREW          |
| 223650         | FEED DRIVING ROCK SHAFT                                      |
| 223651         | FEED DRIVING ROCK SHAFT WIT <b>H 2</b> 23650, 201518, 224051 |
|                | AND 350393   |
| 240590         | FEED DRIVING ROCK SHAFT CRANK WITH 200019                    |
| 200019-805     | FEED DRIVING ROCK SHAFT CRANK PINCH SCREW                    |
| 202625         | FEED DRIVING ROCK SHAFT STOP COLLAR WITH TWO 200383 (2       |
| 200383-803     | FEED DRIVING ROCK SHAFT STOP COLLAR SET SCREW (2)            |
| 224154         | FEED LIFTING CAM WITH 201220                                 |
| 267273         | FEED LIFTING CAM FORK WITH 200173 AND 223655                 |
| 200040-830     | FEED LIFTING CAM FORK SCREW                                  |
| 225837         | FEED LIFTING CAM FORK SCREW WASHER                           |
| 223655         | FEED LIFTING CAM OILING FELT                                 |
| 200173-804     |  |
| 201220-803     | FEED LIFTING CAM SET SCREW                                   |
| 224142         | FEED REGULATING SPINDLE CPL.                                 |
| +224016        | HOOK (SEWING) (2)  |
| 224115         | HOOK (2) WITH 224016, 224100, TWO EACH 200590 AND            |
|                | 201253   |
| 237204         | HOOK AND BOBBIN CASE CPL. NOS. 224115 AND 248460             |
| <b>2240</b> 19 | HOOK BUSHING (LOWER) (BRONZE)                                |
| 200364-803     | HOOK BUSHING (LOWER) SET SCREW                               |
| 224020         | HOOK BUSHING (UPPER) (BRONZE)                                |
| 200446-803     | HOOK BUSHING (UPPER) POSITION SCREW                          |
| 223867         | HOOK DRIVING GEAR (SPIRAL) WITH 200362 AND 201222            |
| 201222-803     | HOOK DRIVING GEAR POSITION SCREW                             |
| 200362-803     | HOOK DRIVING GEAR SET SCREW                                  |
| 224021         | HOOK DRIVING PINION (SPIRAL) WITH TWO 200382                 |
| 200382-803     | HOOK DRIVING PINION SET SCREW (2)                            |
| 224022         | HOOK DRIVING PINION THRUST WASHER                            |
| 237206         | HOOK DRIVING SHAFT<br>HOOK DRIVING SHAFT BUSHING WITH 202244 |
| 224111         |  |

.

| PART NO.         | DESCRIPTION   |
|------------------|---|
| 202244           | HOOK DRIVING SHAFT BUSHING OIL PACKING (WICK)   |
| 200327-803       | HOOK DRIVING SHAFT BUSHING SET SCREW  |
| 224112           | Hook driving shaft connection belt pulley with 202253 and two 201254  |
| 201254-803       | HOOK DRIVING SHAFT CONNECTION BELT PULLEY SET SCREW (2)   |
| 202253           | HOOK DRIVING SHAFT CONNECTION BELT PULLEY SPRING  |
| 224100           | HOCK GIB  |
| 201253-806       | HOOK GIB SCREW  |
| 223849           | HOOK SADDLE (LEFT) WITH 200009  |
| 224023           | HOOK SADDLE WITH 223849, 200364, 200446, 224019 AND 224020  |
| 223850           | HOOK SADDLE (RIGHT) WITH 200009   |
| 224024           | HOOK SADDLE WITH 223850, 200364, 200446, 224019 AND 224020  |
| 223680           | HOOK SADDLE BEARING (LEFT)  |
| 200327-803       | HOOK SADDLE BEARING (LEFT) SET SCREW  |
| 223681           | HOOK SADDLE BEARING (RIGHT)   |
| 200335-803       | HOOK SADDLE BEARING (RIGHT) SET SCREW   |
| 200009-805       | HOOK SADDLE PINCH SCREW   |
| 200006-805       | HOOK SADDLE SCREW (2)   |
| 225585           | HOOK SADDLE SCREW WASHER (2)  |
| 237 1 <b>9</b> 3 | HOOK SADDLE (LEFT) CPL. NOS. 200118, 200364, 223623, 224004, 224005, 224021 TO 224023, 237204 AND 265088        |
| 240033           | HOOK SADDLE (RIGHT) CPL. NOS. 200118, 200364, 223623, 224004, 224005, 224021, 224022, 224024, 237204 AND 265088 |
| 224025           | HOOK WASHER   |
| 200590           | HOOK WASHER SCREW (2)   |
| 240067           | KNEE LIFTER CONNECTION LEVER  |
| 200262-819       | knee lifter connection lever hinge screw  |
| 223684           | KNEE LIFTER CONNECTION LEVER LIFTING ROD WITH 202302  |
| 202302           | KNEE LIFTER CONNECTION LEVER LIFTING ROD COTTER PIN   |
| 206628           | knee lifter connection lever lifting rod spring   |
| 227 227          | KNEE LIFTER CONNECTION LEVER LIFTING ROD SPRING COLLAR WITH 200113  |
| 200113-806       | knee lifter connection lever lifting rod spring collar set screw  |
| 248293           | KNEE LIFTER LIFTING LEVER   |
| 200262-819       | KNEE LIFTER LIFTING LEVER HINGE SCREW   |
| 248304           | KNIFE   |
| 240434           | KNIFE BAR   |
| 248295           | KNIFE BAR ANGLE EXTENSION   |
| 200126-804       | KNIFE BAR ANGLE EXTENSION SCREW (2)   |
| 248278           | KNIFE BAR DRIVING ECCENTRIC WITH 200382 AND 200437  |
| 248305           | KNIFE BAR DRIVING ECCENTRIC FORK WITH 200029  |
| 200029-805       | KNIFE BAR DRIVING ECCENTRIC FORK PINCH SCREW  |

| PART NO.   | DESCRIPTION  |  |  |  |  |  |
|------------|--|--|--|--|--|--|
| 200437-803 | KNIFE BAR DRIVING ECCENTRIC POSITION SCREW           |  |  |  |  |  |
| 200382-803 | KNIFE BAR DRIVING ECCENTRIC SET SCREW                |  |  |  |  |  |
| 202891     | KNIFE BAR DRIVING SHAFT CRANK WITH 200694 AND 201525 |  |  |  |  |  |
| 200694-806 | KNIFE BAR DRIVING SHAFT CRANK SCREW STUD             |  |  |  |  |  |
| 201525-805 | KNIFE BAR DRIVING SHAFT CRANK SCREW STUD NUT         |  |  |  |  |  |
| 237808     | KNIFE BAR GUIDE BLOCK                                |  |  |  |  |  |
| 200011-804 | KNIFE BAR GUIDE BLOCK SCREW (2)                      |  |  |  |  |  |
| 200330-803 | KNIFE BAR GUIDE SCREW                                |  |  |  |  |  |
| 201531-805 | KNIFE BAR GUIDE SCREW NUT                            |  |  |  |  |  |
| 202343     | KNIFE BAR LIFTING SPRING                             |  |  |  |  |  |
| 234044     | KNIFE BAR LIFTING SPRING PLUNGER                     |  |  |  |  |  |
| 237809     | KNIFE BAR POSITION BRACKET                           |  |  |  |  |  |
| 201387-806 | KNIFE BAR POSITION BRACKET SCREW (2)                 |  |  |  |  |  |
| 248280     | KNIFE HOLDER   |  |  |  |  |  |
| 200190-804 | KNIFE HOLDER SCREW (2)                               |  |  |  |  |  |
| 237811     | KNIFE HOLDER SWITCH-IN HANDLE                        |  |  |  |  |  |
| 200076-804 | KNIFE SCREW (2)                                      |  |  |  |  |  |
| 248296     | KNIFE SWITCH-IN LEVER                                |  |  |  |  |  |
| 248297     | KNIFE SWITCH-IN LEVER CONNECTION STUD                |  |  |  |  |  |
| 240067     | KNIFE SWITCH-IN LEVER CONNECTION LEVER               |  |  |  |  |  |
| 248302     | KNIFE SWITCH-IN LEVER SPRING                         |  |  |  |  |  |
| 244039     | KNIFE SWITCH-OUT HANDLE                              |  |  |  |  |  |
| 248298     | KNIFE SWITCH-OUT LEVER                               |  |  |  |  |  |
| 350325-803 | KNIFE SWITCH-OUT LEVER HINGE SCREW                   |  |  |  |  |  |
| 248299     | KNIFE SWITCH-OUT LEVER SPRING                        |  |  |  |  |  |
| 241688     | MACHINE PULLEY WITH 141566 AND 141567                |  |  |  |  |  |
| 141566-803 | MACHINE PULLEY POSITION SCREW                        |  |  |  |  |  |
| 141567-803 | MACHINE PULLEY SET SCREW                             |  |  |  |  |  |
| 3305-16-2  | NEEDLE (2)   |  |  |  |  |  |
| 248281     | NEEDLE BAR AND HOLDER, IN GAUGES FROM 3/16 TO 5/8    |  |  |  |  |  |
|            | INCH, IN STEPS OF 1/32 INCH, WITH TWO 200141         |  |  |  |  |  |
| 248282     | NEEDLE BAR AND HOLDER, IN GAUGES FROM 23/32 TO       |  |  |  |  |  |
|            | 3/4 INCH, WITH TWO 200141                            |  |  |  |  |  |
| 238251     | NEEDLE BAR CONNECTING LINK                           |  |  |  |  |  |
| 264718     | NEEDLE BAR CONNECTING LINK OIL GUARD                 |  |  |  |  |  |
| 201183-804 | NEEDLE BAR CONNECTING LINK OIL GUARD SCREW           |  |  |  |  |  |
| 202333     | NEEDLE BAR CONNECTING LINK STUD WITH 202299          |  |  |  |  |  |
| 202299     | NEEDLE BAR CONNECTING LINK STUD OIL PACKING (WICK)   |  |  |  |  |  |
| 200347-819 | NEEDLE BAR CONNECTING LINK STUD SET SCREW            |  |  |  |  |  |
| 200383-803 | NEEDLE BAR CONNECTING LINK STUD SET SCREW            |  |  |  |  |  |
| 206891     | NEEDLE BAR CONNECTING STUD WITH 200086               |  |  |  |  |  |
| 202329     | NEEDLE BAR CONNECTING STUD WITH 206891 AND 202330    |  |  |  |  |  |
| 202330     | NEEDLE BAR CONNECTING STUD OIL PACKING (WICK)        |  |  |  |  |  |
| 200086-803 | NEEDLE BAR CONNECTING STUD PINCH SCREW               |  |  |  |  |  |
| 202692     | NEEDLE BAR CRANK WITH 200335, 200374, 200383, 200432 |  |  |  |  |  |
|            | AND 202333   |  |  |  |  |  |
|            | -  |  |  |  |  |  |

| PART NO.            | DESCRIPTION  |
|---------------------|--|
| 248283              | NEEDLE BAR CRANK WITH 202292, 202329, 202399, 202400,    |
|                     | 223881 AND 238251  |
| 203172              | NEEDLE BAR CRANK FRICTION WASHER                         |
| 200432-803          | NEEDLE BAR CRANK POSITION SCREW                          |
| 200335-803          | NEEDLE BAR CRANK SET SCREW                               |
| 248284              | NEEDLE BAR FRAME   |
| 237815              | NEEDLE BAR FRAME POSITION BRACKET WITH 200330 AND 201531 |
| 350129-805          | NEEDLE BAR FRAME POSITION BRACKET SCREW (2)              |
| 207069              | NEEDLE BAR FRAME POSITION PIN                            |
| 200118-804          | NEEDLE BAR FRAME SCREW                                   |
| 210910              | NEEDLE BAR FRAME STUD WITH 202277                        |
| 202277              | NEEDLE BAR FRAME STUD OIL PACKING (WICK)                 |
| 200347-819          | NEEDLE BAR FRAME STUD SET SCREW                          |
| 200141-806          | NEEDLE SET SCREW   |
| 244033              | PRESSER BAR (HOLLOW)                                     |
| 207072              | PRESSER BAR BUSHING (2)                                  |
| 200352-803          | PRESSER BAR BUSHING SET SCREW (2)                        |
| 202671              | PRESSER BAR LIFTER                                       |
| 200653-803          | PRESSER BAR LIFTER HINGE SCREW                           |
| 207963              | PRESSER BAR LIFTING RELEASING LEVER BRACKET              |
| 200975-806          | PRESSER BAR LIFTING RELEASING LEVER BRACKET GUIDE SCREW  |
| 206608              | PRESSER BAR LIFTING RELEASING LEVER BRACKET SPRING       |
| 237820              | PRESSER BAR POSITION GUIDE                               |
| 202338              | PRESSER BAR POSITION GUIDE LEVER WITH 200086             |
| 200086-806          | PRESSER BAR POSITION GUIDE LEVER PINCH SCREW             |
| 200352-803          | PRESSER BAR POSITION GUIDE SET SCREW                     |
| 240172              | PRESSER BAR SPRING (FLAT)                                |
| 210949              | PRESSER BAR SPRING BRACKET WITH 200086                   |
| 200086-833          | PRESSER BAR SPRING BRACKET PINCH SCREW                   |
| 200538-803          | PRESSER BAR SPRING REGULATING SCREW                      |
| 200 <b>94</b> 8-806 | PRESSER BAR SPRING SUPPORT SCREW                         |
| 22 <b>9</b> 288     | PRESSER FOOT, 46 NEEDLE HOLE, IN GAUGES FROM 3/16 TO     |
|                     | 3/8 INCH, IN STEPS OF 1/32 INCH                          |
| 229289              | PRESSER FOOT, 46 NEEDLE HOLE, IN GAUGES FROM 3/8 TO      |
|                     | 3/4 INCH, IN STEPS OF 1/32 INCH                          |
| 200074-806          | PRESSER FOOT SCREW                                       |
| 223881              | TAKE-UP LEVER  |
| 202399              | TAKE-UP LEVER DRIVING STUD WITH 244071                   |
| 244071              | TAKE-UP LEVER DRIVING STUD OIL PACKING (WICK)            |
| 202400              | TAKE-UP LEVER HINGE STUD WITH 202423                     |
| 202423              | TAKE-UP LEVER HINGE STUD OIL PACKING (WICK)              |
| 200363-830          | TAKE-UP LEVER HINGE STUD SET SCREW                       |
| 202401              | TAKE-UP LEVER OILING FELT                                |
| 200132-805          | TAKE-UP LEVER OILING FELT SCREW                          |

| PART NO.   | DESCRIPTION  |
|------------|--|
| 223702     | TENSION BRACKET WITH TWO EACH 201224 AND 236060          |
| 200159-806 | TENSION BRACKET SCREW                                    |
| 248217     | TENSION BRACKET CPL. NOS. 200978, 201199, 223702,        |
|            | 223703, 223706, 267368, TWO EACH 200309, 204271, 223438, |
|            | 223704, THREE 201572 AND FOUR 244048                     |
| 244048     | tension disc (4)   |
| 236060     | TENSION DISC POSITION PIN (2)                            |
| 223703     | TENSION RELEASE LEVER                                    |
| 236005     | TENSION RELEASE LEVER ROD                                |
| 200309+805 | tension release lever screw (2)                          |
| 223704     | tension release plunger (2)                              |
| 20427 1    | TENSION RELEASE WASHER (2)                               |
| 223438     | tension spring (2)                                       |
| 201224-850 | TENSION STUD (2)   |
| 201572-819 | tension thumb nut (2)                                    |
| 223706     | THREAD CONTROLLER DISC                                   |
| 200978-819 | THREAD CONTROLLER DISC SCREW                             |
| 267368     | THREAD CONTROLLER SPRING                                 |
| 241360     | THREAD CONTROLLER SPRING STOP                            |
| 200132-805 | THREAD CONTROLLER SPRING STOP SCREW                      |
| 201199-806 | THREAD CONTROLLER STUD WITH 204925                       |
| 200061-803 | THREAD CONTROLLER STUD SET SCREW                         |
| 204925     | THREAD CONTROLLER STUD WASHER                            |
| 201572-819 | THREAD CONTROLLER THUMB NUT                              |
| 224028     | THREAD GUIDE   |
| 267246     | THREAD GUIDE (UPPER)                                     |
| 210954     | THREAD GUIDE (LOWER)                                     |
| 200582-819 | THREAD GUIDE SCREW (2)                                   |
| 240034     | THREAD RETAINER (2)                                      |
| 210956     | THREAD RETAINER BRACKET WITH 200397                      |
| 200582-819 | THREAD RETAINER BRACKET SCREW (2)                        |
| 200366-819 | THREAD RETAINER SET SCREW (2)                            |
| 210993     | THREAD RETAINER SLEEVE                                   |
| 223844     | THREAD RETAINER SPRING                                   |
| 248287     | THREAD RETAINER STUD                                     |
| 210958     | THREAD RETAINER STUD COLLAR                              |
| 248288     | THREAD RETAINER STUD COLLAR (WIDE)                       |
| 200397-819 | THREAD RETAINER STUD SET SCREW                           |
| 248289     | THREAD RETAINER (LOWER) (FOR TWO THREADS) CPL. NOS.      |
|            | 210956, 210993, 223844, 248287 AND 248288                |
| 248286     | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND    |
| ,          | 18, IN GAUGES FROM 3/16 TO 3/8 INCH, IN STEPS OF 1/32    |
|            | INCH, FOR 211786   |
| 248292     | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND    |
|            | 18, IN GAUGES FROM 3/8 TO 5/8 INCH, IN STEPS OF 1/32     |
| From       | n the Norary of Superior Sewing Machine & Supply LLC     |
|            | -8-  |

| PART NO.   | DESCRIPTION   |
|------------|---|
| 248294     | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND 18, IN GAUGES 2 <b>3/3</b> 2 AND 3/4 INCH, FOR 211792 |
| 200161-804 | THROAT PLATE CLAMP SCREW  |
| 203376     | THROAT PLATE POSITION PIN   |
| 000691-806 | THROAT PLATE SCREW  |

1

,

| PART NO.   | DESCRIPTION  |
|--|--|
| 202258<br>200570-805<br>203470<br>224121<br>041400<br>3305-16-2<br>120342<br>120343<br>228476<br>225498<br>248304<br>225554  | BED HINGE CONNECTION (2)<br>BED HINGE CONNECTION SCREW (4)<br>BOBBIN (4)<br>DRIP PAN, 20 INCH LONG, WITH FOUR 3/4 INCH WIRE NAILS<br>MACHINE REST PIN (WOOD)<br>NEEDLES (10)<br>OILER (COPPER PLATED) WITH 120343<br>OILER SPOUT (3-1/2 INCH LONG)<br>SCREW DRIVER (BOBBIN CASE)<br>SCREW DRIVER (7-1/4 INCH LONG)<br>KNIVES (3)<br>WRENCH |
|  | BOBBIN WINDER  |
| 259428<br>259429<br>200113-806<br>225453<br>225454<br>244071<br>259660<br>225455<br>225456<br>259930<br>000457-830<br>225381<br>225444<br>200056-805<br>225458<br>225459<br>202478<br>200299-819<br>225461<br>200082-804<br>228026<br>002102<br>013710<br>201499-819<br>201572-819<br>201572-819<br>225462 | BRAKE (LEATHER)<br>BRAKE CLAMP<br>BRAKE CLAMP SCREW<br>FRAME WITH 244071 AND 259660<br>FRAME HINGE PIN<br>FRAME OIL PACKING (WICK)<br>FRAME OIL WELL WASHER<br>FRAME SPRING<br>FRAME SPRING PLUNGER<br>PULLEY WITH 457<br>PULLEY SET SCREW<br>SPINDLE<br>STOP LATCH  |
|  | 12 R.H.B.  |

| PART NO.             | DESCRIPTION  |  |  |  |  |  |  |
|----------------------|--|--|--|--|--|--|--|
|                      | KNEE LIFTER  |  |  |  |  |  |  |
| 228713               | ROCK LEVER WITH TWO 350231   |  |  |  |  |  |  |
| 228707               | ROCK LEVER BRACKET WITH 200347 AND THREE WOOD SCREWS                       |  |  |  |  |  |  |
|                      | 7/8 INCH, NO. 12   |  |  |  |  |  |  |
| 228709               | ROCK LEVER BRACKET WITH 228707, 228363, 228367, 228386,                    |  |  |  |  |  |  |
|                      | 228455 AND 228713  |  |  |  |  |  |  |
| <b>228</b> 370       | ROCK LEVER EXTENSION WITH 200530   |  |  |  |  |  |  |
| 350231-803           | ROCK LEVER EXTENSION SET SCREW   |  |  |  |  |  |  |
| 228363               | ROCK LEVER HINGE PIN   |  |  |  |  |  |  |
| 228364               | ROCK LEVER KNEE PLATE WITH 350231  |  |  |  |  |  |  |
| 228388               | ROCK LEVER KNEE PLATE ARM  |  |  |  |  |  |  |
| 350231-803           |  |  |  |  |  |  |  |
| 350231-803           |  |  |  |  |  |  |  |
| 228455               | ROCK LEVER POSITION SPRING   |  |  |  |  |  |  |
| 228365               | ROCK LEVER ROD   |  |  |  |  |  |  |
| 200530-803           |  |  |  |  |  |  |  |
| 228386<br>228367     | ROCK LEVER SPRING  |  |  |  |  |  |  |
| 200347-830           | ROCK LEVER STOP STUD<br>ROCK LEVER STOP STUD SET SCREW                     |  |  |  |  |  |  |
| 228710               | KNEE LIFTER ROCK LEVER CPL., NOS. 228364, 228365,                          |  |  |  |  |  |  |
| 220/10               | 228370, 228388 AND 228709  |  |  |  |  |  |  |
|                      | -  |  |  |  |  |  |  |
|                      | (OTHER KNEE LIFTER PARTS ARE LISTED WITH PARTS OF                          |  |  |  |  |  |  |
|                      | MACHINE HEAD)  |  |  |  |  |  |  |
|                      | THREAD UNWINDER  |  |  |  |  |  |  |
|                      | (FOR THREE SPOOLS)   |  |  |  |  |  |  |
| 228777               | THREAD UNWINDER (FOR THREE SPOOLS) CPL. NOS. 228765,                       |  |  |  |  |  |  |
|                      | 228766, 228767, 228768, 228771, 228774, THREE EACH                         |  |  |  |  |  |  |
|                      | 150203, 228764, 228769 AND WOCD SCREWS NO. 12,                             |  |  |  |  |  |  |
|                      | 7/8 INCH LONG  |  |  |  |  |  |  |
| 228764               | thread unwinder spool pin (3)  |  |  |  |  |  |  |
| 228765               | THREAD UNWINDER SPOOL REST (FOR ONE SPOOL) (FLAT)                          |  |  |  |  |  |  |
|                      | WITH 201254  |  |  |  |  |  |  |
| 228766               | THREAD UNWINDER SPOOL REST (FOR TWO SPOOLS) (FLAT)                         |  |  |  |  |  |  |
| 1 50000              | WITH 201254  |  |  |  |  |  |  |
| 150203               | THREAD UNWINDER SPOOL REST CUSHION (3)                                     |  |  |  |  |  |  |
| 228767<br>201254-803 | THREAD UNWINDER SPOOL REST ROD<br>THREAD UNWINDER SPOOL REST SET SCREW (2) |  |  |  |  |  |  |
| 201234-803           | THREAD UNWINDER THREAD GUIDE   |  |  |  |  |  |  |
| 2287 88              | THREAD UNWINDER THREAD GUIDE HOLDER  |  |  |  |  |  |  |
| 220//1               | MALAU UNWHINDLA MALAU GUIDE HULDEA   |  |  |  |  |  |  |

- (FOR THREE GUIDES)
- 228774 THREAD UNWINDER THREAD GUIDE ROD
- ----- THREAD UNWINDER WOOD SCREWS NO. 12, 7/8 INCH (3)

·· -

PART NO. DESCRIPTION

#### TREADLE COMPLETE

| 248300 | TREADLE  |
|--------|--|
| 232365 | TREADLE CHAIN (41-1/2 INCH LONG) (2) WITH TWO EACH   |
|        | 202784   |
| 202784 | TREADLE CHAIN HOOK (2)                               |
| 017881 | TREADLE SHAFT  |
| 014369 | TREADLE STAND  |
| 248301 | TREADLE CPL., NOS. 14369, 17881, 248300 AND TWO WOOD |
|        | SCREWS 1-1/2 INCH, NO. 12                            |
|        | TREADLE WOOD SCREWS 1-1/2 INCH, NO. 12               |
|        |  |

#### FITTINGS FEED DOGS

| 211786 | FEED | DOG, | FOR | 248285 | AND | 248286 |
|--------|------|------|-----|--------|-----|--------|
| 221446 | FEED | DOG, | FOR | 248292 |     |        |
| 211792 | FEED | DOG, | FOR | 248294 |     |        |

#### THROAT PLATES

| 248286 | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND |
|--------|---|
|        | 18, IN GAUGES FROM 3/16 TO 3/8 INCH, IN STEPS OF      |
|        | 1/32 INCH, FOR 211786                                 |
| 248292 | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND |
|        | 18, IN GAUGES FROM 3/8 TO 5/8 INCH, IN STEPS OF 1/32  |
|        | INCH, FOR 221446                                      |
| 248294 | THROAT PLATE, 46 NEEDLE HOLE, FOR NEEDLE SIZES 16 AND |
|        | 18, IN GAUGES 23/32 AND 3/4 INCH, FOR 211792          |
|        |   |

-12-

5