





SINGER

121D200AA & 121D300AA














Form 21731 (1278) Printed in U.S.A.

Copyright © 1978 The Singer Company
All Rights Reserved Throughout the World
*A Trademark of THE SINGER COMPANY

centurion





21713
UNPACKING INSTRUCTIONS



21694
OPERATORS GUIDE

21731
PICTORIAL PARTS LIST


21706
CAUTION CARD






522361



ACCESSORIES



818916-001
USED WITH ELECTRONIC
DRIVE & CONTROL SYSTEM
PACKAGE NO. 818352-001,
818352-002, 818353-001 & 818353-002



OPTIONAL PARTS

