LIST OF PARTS

FOR

No. 133K1 MACHINE



THE SINGER MANUFACTURING COMPANY

All rights reserved

PARTS COMPLETE

FOR

No. 133K1 MACHINE

Cylinder Bed, Drop Feed, Alternating Pressers, Needle Bar Link, Link Take-up, for General Cloth, Canvas and Leather Work.

No.										
NoTE *97725	Arm	with	15404,	56003,	two ea	ch 15405 an	d 94548.		1	2/32
8582	ri .	Dowel P	in (2)							
94548	11	Oiler for	front l	earing						
94548	-11	11 11	back	11						
56003	11	Oil Tube	with 2	9599 5	52045					1932
2045 20599-	- 0	11 11	Packin	ng (felt)					JUL	1932
118e	n n	Screw (4)							
97755	11	Shaft (H	orizont	al)						
97603	11	11 (11) Fla	nged Bu	shing (back)			
97605	11	11 (11)	11	п (п) Drain T	ube		
97604	11	11 (11)	11	11 (11) Oil Pad			
446c	11	11 (11)	11	11 (11) Set Scre	w		
97606	- 11	11 (- 11)	11	" (front)			
97607	11	11 (11)	11	11 (11) Oil Pad			
50084c	11	11 (11)	11	11 (11) Set Scre	ew		
97608	11	п (- 0) Gea	r with t	wo 50083c				
97609	- 11	11 (11) 11	Case (2 pieces) wi	th 121e a	nd 502	234d	
50234d	11	11 (- 11) "	11 F	Plug Screw			***	
121e	11	11 (- 11) 11	11 S	crew				
50083c	11	11 (11) "	Set Sc	rew				
1440 0	11	11 (11) Scre	ew					9/34
97610	- 11	11 (U	pright)							
97611	11	11 (11)	Bushin	g (lower	r)				
575c	11	11 (. ()	11	(11) Set Screw				
97612	11	11 (11)	11	(uppe					
575c	11	11 (11)	11	(") Set Screw				
98437	11	11 (11)	Gear (l		ith SS520c		0c		
50200c	.11	11 (11)	" (The same	osition Scre	W			
SS520c	11	11 (11)	11 (et Screw				
97613	11	11 (11)	11 (1		vith SS520c		0c		
50200c	- 11	" (11)	" (Position Scre	:W			
SS520c	11	" (11)	" (") 5	et Screw				
97615 1,224 ^D 286d	11	Side Cove							•••	rı,
		II II		nb Scre		•••			•••	184
202247	11	Top Cove				Mr. Carlon			***	
SS505h	"	11 11	Screv			***		***	***	
NOTE.—Due	to the	accuracy	requir	ed for	Gear ali	gnment, Arn	n cannot	be suf	plied	200
- Provide	ery cen	ia cun oni	y oe ser	u out a	s a unit,	Arm and B	ed assemt	iled.	001 10	133
i ioiii t	iie II	bialy C	л. О О	Perio	i Jew	ing Mac	inie a	Oup	PIY LLC	

No.

	202248	Arm	Top (over S	crew Wa	sher					
	82403	11		Pin (2		01101					
	97616	11	II II		ushing						
	0.010			" 1							
	97617	Balan	nce W	heel,	5¼" pulley				***	***	
	97791	- 11		11	51" "	(9"	diam.)	with t	wo 434c, fo	or Foot	Power
	434c	- 11		11 5	Set Screw						
	Nome	37	0201	~ .		,	7	1	.11	basified.	
	NOTE								otherwise st		
						IVO.	. 97793	must t	e used wit	n Baian	ce
		Wh	eel No	. 9779.	I.						
,											
1	*98401	Bed									
(NOTE.—L								and Bed ass		
	97726		Plate		y de sem (our u	···		ina Dea ass		
	158f	11	"		(front)						
	120f		11		(back)						
	SS45f		"	11	(upper)						
	97622	"	11		d Guard						
1	907 207d		"			Scre					
ľ	98484				e Thread						
	20101		Tax	c I Iai	.c imead	Out	ild IIII	cad Itel	amer		
	98402	Feed	Dog								•••
	98403		11	Carrie					****		• • • •
	98404	11	- 11	11	Hinge S				•••	•••	
	1396c	11	11	- 11				ng Screv	N	***	
	46224	11	11	11	- 11		Oiler			•••	
	98406	- 11	11	11	Lifting					***	•••
	1177c	11	- 11	11		11		ping Sc	rew		•••
	98405	11	11	11	Link		•••	•••	•••	• • •	•••
	50042c	11	11	11			Screw (
	1620c	11	- 11	- 11				Nut (2)	•••		
	971c	0	11	"	Position	Scr					
	SS50c	11	11	Screw	(2)				***		***
	97711	Feed	Ecce	ntric							
	98407	11		11 .	Adjusting	Dis	C				
	97628	n		11	11		nge				
	97629	11		11	11	,	Con	upling v	with five 50	083c	
	50083c	11		11	- 11	,	ij.	11 S	Screw		
	213655	11		11	Friction S	Sprin	g Wash	ner			
	SS513e	11		11	11	"	"	Scre	w		
	1521e	11		11	11	11	11	11	Nut		
	SS514e	11		95	Fulcrum :	Scre	W				
	1521e	"		,,	- 11	11	Nut				

No.									
97713	Feed	Lifting Ec	centric	with tw	o 446c				
446c	11	"	11	Set Scre	ew				
98408	11	" Ro	ck Shaft	t					
98409	11		- 11	Bushir	ng (front				
423c	11	" "	"	11) Set S			
98410	"	11 11	11	"	(back	The second second			
435c	11	11 11	"		-) Set S			
98412	"	" "	"		The second second		97716 and		
97716	"		"	- II	"	Commercial			
1186e	"	11 11	"	11	"		Screw		
SS534c	"	" "	"		,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		ge Screw		•••
1608c	"	0 0	"	"	"	-		ut	
98411	"		11	Crank		"			•••
SS370c	11	" "			Set Scre				
213161			T error :					•••	***
SS506c		Regulating							
	"	"		Hinge S		•••	•••	• • • • •	***
97771	"	"		Spring					
213657	11	. "	11		Pin	•••			•••
98413		Rock Shaft				•••		•••	•••
98414		11 11		ig (fron			•••	•••	***
423c	11	11. (1	- 11) Set Sc		•••		
98415	"	11 11		(back	1				• • • • • • • • • • • • • • • • • • • •
435c	11	0 0) Set Sc				• • • •
98417	11	и и	Connec				and two 1	186e	• • • •
97716	11	11 11	11	1			1		
1186e	11	11 11	- 11						***
SS534c	11	11 11	11		Hinge	Screw			
1608c	11	11 11	11	11		11	Nut		
98416	11	11 11	Crank	with SS					
SS523c	11	11 11	"	Clampi	ng Screv	V			
85527	Guide	e							
793d	11	Thumb So	rew (2)						
97654	T iftin	g Presser	Don						
97729		-		ell Cran					•••
1480c		"				(0		•••	•••
97730	11	"	11 1			crew (2		•••	
1480c	- 11	"	11 1			cting L			
97731	- 11	"	11 11		Deissie		" Cap So		***
97735	11	11	11 11		Drivin		Tanan taila	···	
	11	"	11 11		"	11	Eccentric		tion
SS534	- 11	"	11 1	" "	11	"	"	TT:	C
1000							T	-	Screw
1608c	11	"	11 1	" "	11	11	Eccentric		
0117								ige Scre	
2117	-11	11	11 1		11	- 11	Pin	•••	•••
453c	- 11	11	11 11	11	11	11	Set Screw		***

```
No.
          Lifting Presser Bar Bell Crank Driving Arm Shaft
97732
97733
                                                              Bracket
50307d
                                                                      complete.
97734
                                                  Nos. 2117 and 97731 to 97733
97736
                                Guide Bracket with two 1186c
                                               Clamping Screw
 1186c
97762
                                                          ...
  440c
                                                   Adjusting Screw
 1698c
                                                                    Nut
                                               Support
97737
                                                       Screw (2)
  171e
97738
SS329f
 1547c
97644
          Needle Bar (hollow) ...
97645
                       Bushing (lower)
                                    ) Set Screw
  889c
                                                                    . . .
97646
                                (upper)
SS509e
                                      ) Cap Screw ...
46224
                                      ) Oiler
  889c
                                      ) Set Screw
97648
                       Connecting Link
97649
                                        Stud with two SS512c
SS512c
                                             Clamping Screw
                                             Slide Block
97650
97727
                       Crank
97778
                              97727 with SS320c, SS370c, 2022 and 97777
97777
                              Eccentric .
 2022
                                        Position Pin
SS370c
                              Position Screw
SS320c
                              Set Screw
97794
                  Clamp
97652
                         97794 with 156f, 217f and 97653
   156f
                         Thread Guide
97653
                                        Screw
   217f
 82429
           Presser Bar Lifter
SS186f
                               Screw
  1518c
                                 11
                                      Nut ...
                         Lifting and Releasing Lever Bracket
 97763
 97706
                         Spring ...
           Pressure Regulating Thumb Screw ...
   252e
```

		IC CONTRACTOR		-	A banding and				1	
98474 Rot	tating I	look (Sho	ort Poir	it) wi	th 97663,	two 40	ld and thre	e SS	522c	
98465	11	11 9847	4 with	98466				. AP	R 193	2
98461	11	" Bob	bin Cas	e	MACHIN			1 30	7	
98462	11	11 11		Nos	. SS549f,	662f, 50	0056f, 97666	, 984	61	
								nd 98	3475	VI
98466	#ROTAT	" Bob	bin Cas	e 984	62 with 9'	7664		7700		1/32
98475	11	11 11	37.000	Ten	sion Sprin	ıg				-7
SS549f	11	11 11	Bornin				sting Screw			46
97665	- 11		11	Case		ouce				73
97668	11	obsol	elen	- 11	Nos. 33	7f, 662f	f, 50056f a	nd 9		
					0=000			L	97667	4/2
97760	11	11	11	- 11			64 for 97759			115
97666	- 11	-11	11	11	Bobbin 1			***	***	
50056f	.11	- 11		11	11	11	Screw			
98418	- 11			11	Position			***	***	,
185₹€	11	11		. 17	n	11	Screw (2)		***	12/31
98419	- 11	11	11	11	Retainer				•••	
98420	11	11	- 11	11	11	Bracke		(0)	***	
446c	- 11	11	11	11	- 11	"	Set Screw		•••	
98493	- 11	11.	- 11	- 11	11	Guard			•••	
193d	- 11	11	11	11	11	11	Screw (2)			
98422	- 11	11	"	11	11	Hinge		•••	***	
889c	- 11	- 11	11	11	"	n	Set Sc	rew		
98421	11	- 11	11	-11	- 11		n Spring			
792e	- 11	11	"	11	11	. "	11 Sc		• • • • • • • • • • • • • • • • • • • •	
98423	- 11	- 11	ii.	11	11		with 98468		•••	
*98468	- 11	11	11	11	"	11	Pad			
201F 2171		- 11	11	11	11.	C .	Screw		***	4/32
97667	11	- 11	11	11			obsolete		1.00	
337f	11	- 11	11	- 11	11		Adjusting S			
662f	11	11	11	T21 4	11		Screw		***	
98424	11	11	Cover		Desalest	•••	•••	•••		
98425	11	11	11	11	Bracket		-""		CED	
SS45¢	"	.11	11	11		Screw			SER.	
98426	- 11	11	11	11	Hinge Pi	n Set So	***			
1019c	- 11	- 11	"	11		361 30			***	
98427	- 11	11	11	11	Spring	crew (2)			CED	1000
176	- 11	- 11	11	11		1	1019c, 984	21 +0	SEP	1932
98494	11	11	11	11	complete		two each 1			1932
CCTOO			Screw			50455,		101 a.		1002
SS522c	11	11	Shaft							
97676	- 11	11		Ruchi	ng (back)					
98428	"	11		DUSIH		Oil Pac				
97678	11	11	"	"	11.5	Set Scr				
448c	"	11	- "	11	(front)					
98429		- 11	11	11		Oil Pa				
98473	11	11	11		,	Set Sci			•••	
423c	11	- 11	11	Coon	with SS5			•••		
98437	"	11						1 5099		
97680	"	11					ith 121e and			
50234d	"	11	11	11		Screw				
121e	- 11	11	- 11	- 11	" Scre	w				

		Page 8	3
	0=001		
	97804		
8	97805	and the second second and brook in	
	97690		
	SS515	" " Clamping Screw	
	50200c 55530c		
		s set Screw	
		W Thread Guard	
	401d	ıı ıı ıı Screw	***
	98463	Slack Thread Regulator Obsolete use 978.04	
	190d	C	•••
	1000	" " Screw	
	97795	Tonsion Dies (inner)	
	97796	Tension Disc (inner)	•••
	1560d	" (outer)	
	97683	Regulating Thumb Nut Releasing Disc	
	97684		
	646d	11	
	12329		
	97799	Di-	
	SS536d	Camara Charl	***
	11422	" Spring	•••
	82446	Washer (felt)	
	97797	" (fibre)	
	97800	Tension (Rotating) and Thread Take-up Spring, complete, N	
		SS536d, 1560d, 11422, 82446, 82525, 97683, 97696, 97698	
		97795 to 97798	
	97756	Thread Guard (side of arm)	
	1143c	" Set Screw	
	97769	Thread Lubricating Cup	
	97770	" 97769 with 160c, 97772 and 250519	
9	250519	" Oil Pad (felt)	
	160c	" Set Screw	
	97772	" " Thread Guide	
	89363	Retaining Disc	
	1110e	" Screw Stud	
	1560d	" " Regulating Thumb Nut	
	2103	" " Spring	
	97757	Retainer, complete, Nos. 1110e, 1560d, 2103 and two 8936	3
	82450	" Thread Eyelet	
	SS50f	п п п Screw	
	97687	Take-up Crank	
	SS484e	" Cap Screw	
	97688	" Cotter Pin	
	690c	" " " Screw	
	97689	" " Lever	•••
	97690 SSELEA	" " Bushing	•••
	SS515d 97691	" " Clamping Screw	•••
	91091	" " Hinge Pin	***

	No.			1-1-1						
	97692	Thread Ta	ike-up Le							
	97693		11	" " F	Hinge Pir			•••		
	457e	11	11	11 11		End Screw				
	430c	11	п	11 11		Set Screw				
	97694		11	" comple	ete, Nos.	. SS515d,	457e an	d 97689	to	
								976	393	
	82525	11	" SI	oring						
	97696	11	11	" Adjus	ting Slee	ve				
	97798	II .	11	" Lever						
	97698	11	11	" Regul	ator					
	443c	u u	11	11 11	Set	Screw				
	98430	Throat Pla	ate							
	98431	. 11 1	Body							
	SS45f		1 11			4				
	98476		1 11			130, 98431				
	50123f	11 1		N						
							•••		•••	
	97739	Vibrating	Presser	Bar						
7802	97710	"I	11 11 11	и Сар			•••	•••	•••	10/0
1207	1480c	"	11		Screw for			•••		10/31
	207f	"	"			97740		•••	•••	
17803	97741	"	11	" Cushi					•••	
1005	97742	"	"		g	•••		•••	•••	10/31
	225d				Screw				•••	
	97743	-10	-11	Foot "		•••	•••	•••	•••	
	898d		11						•••	
	1547e	"	11	" Screv				***	•••	
	15476	11	11	11 11	Nut				•••	
	00100									
	98486	Work Plat					•••	•••		
	98487	n n	Bracke							
	50512d	11 11		Screw		•••				
	98488	11 11	comple	ete, Nos. 98	486, 984	87 and two	50512d			
	NIC	TE N. OO	100:-	1			,			
	NC	OTE.—No. 98	488 15 on			ecified on or	der and a	it an		
				extra che	arge.					

Trade Mark ...

Rivet

*15404

15405

Accessories

No.								
	Instruction Boo	k	•••		•••	•••		
938e	Machine Bolt w		< ½" (4)					
6055	11 11 V	Vasher (4)			•••	•••		
2/6 X / 216 × 3	Needles (6)						FEB. 193	
120342	Oiler						•••	
97664	Rotating Hook	Bobbin (5)						
11831	Screw Driver (la	arge)						
120378	11 11 (S	mall)		•••.		•••	***	

Bobbin Winder

(Swinging Automatic, Left Hand)

No.								
41894	Base with 449c							
894d	" Screw							
97745	Bobbin Holder							
97746	" " Pin							
41896	Frame							
41441	Hinge Pin		***					
449c	ıı ıı ıı Set	Screw						9/
125044 4781	ii Oil Pad	***						139
41897	- Spring							
43270	Friction Pulley with	43271, tv	vo 448c ai	nd ten 1	5405			
43271		(Leather	Eurony a					
15405		Rivet (B	rass)			***		
448c	ıı ıı Set S	crew						
97747	Spindle		***			***		
97748	Stop Latch							
41446	" " Hinge Pi	n						
2269	" " Pin							
97749	Support Bracket			***				
346e	ıı scre	ew						
97774	Tension Bracket							
50073d		ew (2)						
2102	Disc	***						
SS521c	" Screw Stud						• • • •	
889c		Set Screw						
1560d		Thumb N	ut				• • • •	
2103	" Spring							
97775	" Thread Guar		•••		•••	•••		
889c	0 0 0							
97776	Tension, complete, N				97774, 8		each	
41000	889c and 2102					•••	***	
41899	Tripping Arm with 1			***			***	
176d	" " Clampir	-			•••			
97750	" " Spring	***	•••			•••	***	
0===1	Dobbin Windon and	noloto X	00 2160	2000 125	044	11446 4	1904	9/3
97751	Bobbin Winder, con 41896, 41897, 4							-15
	and three 894d		•••					

Bobbin Winder

(Swinging Automatic, Left Hand)

For machine when fitted with Balance Wheel No. 97791 for Foot Power.

This is the same as Bobbin Winder No. 97751 with the following exceptions:-

No.
97792 Support Bracket /25044:
97793 Bobbin Winder, complete, Nos. 346e, 2269, 4784, 41441, 41446, 41894, 41896, 41897, 41899, 43270, 97745 to 97748, 97750, 97776, 97792, two 50073d and three 894d

9/3

Thread Unwinder

FOR TWO SPOOLS OF THREAD

No.						
27623	Spool Pin	255	***	111	WAR .	***
98489	Rest	•••		***		1932.
98490	98489 with 1149c	and two	27623		111	***
225388	" Rod Screw	***	***		***	•••
200383c	" Set Screw	•••	***			
1149c	Set Screw	***	***	***	111	***
202490	" Stand with 200383c		***		***	
98491	Thread Guide with 208e					
208e	" Set Screw	***			***	111
_	Screw (Wood) 7" No. 13 (for				***	***
98492	Thread Unwinder, complet	te, Nos.	98490, 98491,	202490	225388	3 and
	three Wood Screws 7" No	0. 13		***	***	***

Foot Lifter

8/ 844		Deat T									
011		Foot L			 Dl.						
84 84	184	tt			Bracket			-1\ 11// 3	T- 14 (9)	•••	•••
200 -	_	11	11						No. 14 (2)		
7828±		11	11	0	Pin			•••		•••	•••
83 944		11		11		ing			***		11//
847	772	≥ öbso	lete	ins	e 488	5			d two Wo		No. 14
977	785	11	11	Chain	(34" lon	g) wit	h 395	75, 3957	3 and 5686	4	
395	576	11	11	11	Hook (t	ipper)					
395	575	11	11.	1 11	11 (C	centre))	***			
568	364	11	11	11	" (1	owera	~	***		***	
977	786	11	u .	comple	ete, Nos	8177	2 and	97785		•••	
977	787	Lifting	g Lev	er with	448c				***		
984	170	11	11	Con	necting :	Rod					
124	116	11	11		11	ıı J	oint				
	76d	it	11		11	- 11	11 I	Hinge Sci	ew		
15	521e	11	11		11	11 I	ock N	Vut	***		
(394d	п	11	Hin	ge Screw	v					
977	768	11	11	Link	2						
]	100d	п	11	11	Hinge	Screw					
977	723	11	11	Pin							***
4	148c	11	11	11	Set Scre	W.					
977	767	11	11	Spri	ng						***
984	171	Foot 1	Lifte	r, com	plete, 1	Nos. 7	6d, 1	.00d, 694	d, 1521e,	12416,	97723,
					97786,						



