
ILLUSTRATED LIST OF PARTS

FOR


SINGER** MACHINE No. 138K1




**A Trademark of THE SINGER MANUFACTURING COMPANY




From the library of: Superior Sewing Machine & Supply LLC






From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

ILLUSTRATED LIST OF PARTS FOR MACHINE No. 138K1

CONTENTS

								Page
Parts, Complete,	for Ma	chine No	o. 138KJ	•••	•••	• • •		21
Accessories	•••	•••		•••	•••	•••	•••	26
Foot Lifter	•••	••	•••		•••	•••	•••	26
Thread Unwinde	r						•••	27
Numerical List o	f Parts							29

INSTRUCTIONS FOR ORDERING

In ordering from this List, the code number with the part number MUST BE quoted exactly as they are shown in the first column.

A number always indicates the same part in whatever List it may appear, or for whatever machine.

The code numbers (where shown) indicate the style of finish as follows:

New Code	Old Code	Description
801	A.	Hardened, Polished, Nickel Plated and Buffed.
802	В.	Polished, Nickel Plated and Buffed.
803	C.	Hardened only.
804	D.	Polished only.
805	E.	Soft, Not Polished.
806	F.	Hardened and Polished.
807	G.	Bright Rumbled and Nickel Plated.
808	н.	Blued.
809	J.	Nicke! Plated only.
810	K.	Hardened and Nickel Plated.
811	L.	Brass Plated.
812	м.	Oxidized.
813	R.	Phosphate Coating Formed on Surface of Iron or Steel.
814	8.	Cadmium Plated.
815	т.	Copper Plated.
816	U.	Zinc Plated.
817	٧.	Silver Plated.
818	w.	Polished and Nickel Plated.
819	x.	Black Oxide for Iron and Steel.
820	Υ.	Black Nickel Plated only.
821	Z.	Chromium Plated.
822	A.A.	Buffed and Chromium Plated.
823	A.B.	Hardened, Polished, Buffed and Chromium Plated.
824	A.E.	Hardened, Bright Rumbled and Nickel Plated.
825	A.F.	Hardened, Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.
826	A.G.	Alumilite. (Plain).
827	A.H.	Alumilite. (Dyed). Colour must be stated.
828	A.J.	Polished, Nickel Plated and Chromium Plated.
829	A.K.	Hardened, Polished, Nickel Plated and Chromium Plated.
830	A.L.	Heat Treated for Toughness.
831	A.L.D.	Heat Treated for Toughness and Polished.
832	A.L.J.	Heat Treated for Toughness and Nickel Plated.
833	A.L.X.	Heat Treated for Toughness and Black Oxide.
834	A.L.Z.B.	Heat Treated for Toughness, Polished, Nickel Plated,
		Buffed and Chromium Plated.
835	A.S.	Cancelled, use Paint Code 701.
836	A.T.	Cancelled, use Paint Code 709.
837	A.U.	Cancelled, use Paint Code 720.
838		
839	B.A.	Chrome Nickel, Satin Finish.
840	B.B.	Hardened and Chrome Nickel, Satin Finish.
841	C.R.	Hardened and Phosphate Coating Formed on Surface of Steel.
842	C.U.	Hardened and Zinc Plated.
843	F.J.	Hardened, Polished and Nickel Plated.
844	T.A.	Hardened, Polished, Copper and Nickel Plated and Buffed.
845	T.B.	Copper and Nickel Plated and Polished.
846	T.J.	Copper and Nickel Plated only.
847	T.K.	Hardened, Copper and Nickel Plated.
848	T.L.	Copper and Brass Plated.

INSTRUCTIONS FOR ORDERING-Continued.

New Code	Old Code	Description
849	T.M.	Copper Plated and Oxidized.
850	x.c.	Hardened and Black Oxide for Iron and Steel.
851	Z.A.	Hardened, Polished, Nickel Plated, Buffed and Chromium
•••		Plated.
852	Z.B.	Polished, Nickel Plated, Buffed and Chromium Plated.
853	z.c.	Hardened and Chromium Plated.
854	z.D.	Polished and Chromium Plated.
855	z.g.	Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated.
856	Z.J.	Nickel and Chromium Plated.
857	Z.T.	Copper and Chromium Plated.
858	A.L.Z.J.	Heat Treated for Toughness, Nickel and Chromium Plated.
859		Heat Treated for Toughness, Copper Plated and Oxidized.
860		Nickel Plated and Buffed only.
861		Alumilite (dyed)—Black.
862		" (")—Light Almond Green.
863		" (")—Dark Brown.
864		" (")—Russet Brown.
865		" (")—Dark Green.
866		" (")—Medium Gold.
867		Nickel-Satin Finish.
868		Hardened and Nickel-Satin Finish.
Code No.	Paint Colours	Code No. Paint Colours
701	Gloss Black	734 Pale Red
702	Dull Black	735 Emerald Green
703	Brown	736 Green Metallic
704	Grey Wrinkle	737 Light Beige Satin Matte
705	Beige Wrinkle	738 Copper Tan
706	Black Wrinkle	739 Buff
707	Light Green	740 White
708	Dark Green	741 Dark Fawn
709	Dark Beige	742 Plum
710	Light Beige	743 Birch Brown
711	Oyster White	744 Satin Black
712		745 Gold-Buff
713	Bright Cherry Red	
714	Light Ivory	747 Medium Gold 748 Sand
715	Peacock Blue	749 Khaki
716 717	Bright Yellow Slate Grey	750 Flame Red
717 718	Deep Brown	751 Brite Green
719	Beep Brown	752 Sage Green
720	Dark Brown	753 Mist Green
721	Aluminium	754 Ice Green Metallic
722	Dark Grey	755 Dark Beige Metallic
723	Light Grey Beige	756 Shell Pink 757 Surf Green
724	Rosewood Brown	757 Surf Green 758 Colonial Rose
725	Light Bisque	758 Colonial Rose 759 Cream
726 727	Light Fawn	760 Oak Brown
727 728	Grey Metallic	761 Deep Fawn
728 729	Russet Brown	762 Medium Green
730	Pale Green	763 Light Green Metallic
731	Light Almond Gre	een 764 Light Gold
732	Dusty Bisque	765 Persimmon
733	Chocolate Brown	

Parts marked with an asterisk (*) are furnished only when the repairs are made at Factory.

List of Parts Complete for MACHINE No. 138K1

For Blanket Whipping; provided with Needle, Hook Needle and Looper; also with Guides and Feeding Presser Feet to give widths of whipped edge of 1", 3" and 3".

The Mechanism is cam operated and other special features include Alternating Pressers, Top Feed and Stitch Regulator.

No.	Plate		
† *99 001	-	Arm	•••
16532	1703	Dowel Pin (2)	
12454	1703	" Oil Tube with 132590	•••
132590		" " Packing (felt)	•••
116e	1711	" Screw (long) (3)	•••
880e	1711	" " (short)	
99002	1704	" Shaft	•••
99003	1703	" " Bushing (back)	• • •
56006		" " (") Oil Pad (braided cotton)	•••
448c	1711	" " (") Set Screw	•••
52195	1703	" " (front)	•••
56006	_	" " (") Oil Pad (braided cotton)	•••
423 c	1711	n n (n) Set Screw	•••
144c	1711	" " Screw	•••
†16036	1702	" Side Cover	•••
50053d	1712	" " " Thumb Screw	• • • • • • • • • • • • • • • • • • • •
*99004		Bed	•••
99005	1702	" Cover	•••
69 0d	1711	" " Screw (2)	
†99006	1702		•••
176f	1711	" " Screw (2)	•••

[†] For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

No.	Plate										
+99007	1702	Feed	Bar								
99008	1708	**		Bell	Crank				•••		• • •
1467h	1712	**	**	11		Cap So	crew		•••	• •	
99009	1708	11		н		Conne	cting	Link	•••		
1131c	1711	**	11	11	11			**	Hinge Screw		
1520r	1712	11	**	11	11					Nut	
+99011	1708	11	.,	Guid	le						
143d	1711	"	11	11	Scre	w (2)				•••	•••
45c	1711	"	11	Hing	ge Scre	w		• • • •		•••	
†99012	1708	u	н	Roc	king F	rame w	rith 4	5 3 c	•••		
99013	1708	11	11	,	1	" F	Iinge	Pin	•••	•••	
453c	1711	11	11	,	,	n S	et Sc	rew	•••		
99014	1703	11	Cam	with	1036c	and 1	375c				
1375c	1711	11	**	Posi	ition S	crew			•••	•••	• • • •
1036c	1711	11			Screw	•••		• • • •	• • •	• • •	• • •
99015	1703	11	Cont	rectir	ng Rod	with 9	99016	and	two 896e	• • •	
*99016		11		**	11	Cap		• • •	•••		
896e	1711	11		11	11	n S			•••	•••	• • •
1373c	1711	**		11	••	Hinge	Scre	w	•••	• • •	
1520r	1712	11		11	"	н	ч		ıt	• • •	••
1374c	1712	11	Regi	ulatii	ng Scre	w Stu			•••	• • •	
NN93c	1712			n	n	**	Nut			• • •	•••
41544	1707	"		11	11	"	Was	sher	•••	•••	
†99019	1702	н	Reg	ulato	r with			• • • •	•••	••	•••
99020	1703	**		11	Conn	ecting	Link		•••	• • •	
50562c	1712	**		11		"	**	Hing	e Screw	•••	
1520r	1712	"		11		**	"	"	" Nut	••	
2022	1703	"		11	Pin	•••		• • •	• • •	•••	•••
1125d	1711	11		н	Set S			•••		• • •	• · •
99021	1707	н		11	Shaft			•••		• • •	•••
99022	1702	**		"	"	Crank	•	,	***	•••	•••
99023		11		"	"	11			felt)	• • •	• • •
1293c	1711	"		"	11	11			Screw	• • •	•••
446c	1711	"		"	11	п		Screv		•••	• • •
1342e	1711	11		н	Stop	Screw		• • •	•••	• • •	
00001		D1	1	D4							
99024	1705	Feed	ıng I		 Pt		441	· · · ·	3//	•••	• • •
99017	1705	"		11					∄″ gauge	•••	• • • •
99018	1705	"		"	11	(3) "	5" " 1" "	•••	
99060	1705	"		"	"	(3) "	•	•••	•••
99061	1705	11		"	"	(2) "	5" " 1"	•••	•••
99062	1705	**		11	"	(2	rew) "	½" "	•••	•••
190d	1711	,,		"	Llingo			•••	•••	•••	
50459c	1712	"		"		Screw		•••	•••	•••	•••
2656	1703	"		"	Spring			•••	•••	•••	• • •

[†] For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

```
No.
          Plate
 99025
          1707
                  Guide (for Hem) 1 gauge
 99026
                                n ) 5"
                                                               . . .
                                                                        ...
 99063
          1707
                          (plain)
 99027
          1702
                         Holder
   690d
          1711
                                 Screw (2) ...
 82538
          1706
                                        Washer (2)
   176f
          1711
                         Screw (2)
  7071
          1706
                                Washer (2) ...
99028
          1705
                  Hook Needle
99029
          1708
                                 Clamp
                                           ...
  1253c
          1711
                                        Set Screw
99030
          1708
                                 Closing Block
   640f
          1711
                                               Screw (2)
99031
          1707
                                 Guide
   690d
          1711
                                       Screw
82538
          1706
                                              Washer
50302f
          1712
                                 Set Screw ...
99032
          1705
                  Looper (lower) ...
                                           • • •
99033
         1706
                                 ) Carrier with 460c and two 1147e
64520
         1706
                                          Hinge Stud
  448c
         1711
                                            ••
                                                  II Set Screw (2)
99034
         1704
                                          Pitman
                                                    ...
50458c
         1712
                                                  Hinge Screw (left)
  460c
         1711
                                                                ( " ) Set Screw
 1131c
         1711
                          (
                                )
                                                                (right) ...
 1520r
         1712
                                                                ( " ) Nut
99035
         1704
                                1
                                  Driving Lever with 50083c ...
99036
         1704
                                                 Hinge Pin
43840
         1706
                                                         " Collar with two 624c
                                )
                                             u
  624c
         1711
                                                                   Set Screw
 1940
         1712
                                                 Roller and Screw Stud with
                                                                  1519e and 22142
 1519e
         1712
                                                                   Stud Nut
                    11
                                     "
                                                   ••
22142
         1706
                                                                           Washer
50083c
         1712
                                                 Set Screw
                                     "
 1147e
         1711
                                ) Set Screw
99037
         1706
                          (upper)
99064
         1706
                                  Carrier
                                                    ...
99039
         1706
                          (
                                )
                                          Connecting Link
                             "
                                     •
                                                             ...
   46d
         1711
                                )
                                                       ,,
                                                           Hinge Screw (2)
                            **
                                     11
 1718h
         1712
                               )
                                                                    " Nut (2)
                                     ..
                                                              11
99065
         1706
                                )
                                     ..
                                          Bell Crank
99041
                                )
                                                     Connecting Link ...
                                     ••
```

No. 1131c	Plate 1711	Looper	(u	ppe	r)	Carrier	Bell (Crank	Conne	ecting L	ink Hinge	(3)
											Screw	(2)
1520r	1712	11	(**)	11	11	11	"		" Hinge	
											Screw Nut	(2)
1232c	1711	11	(**)	11	11	"		Screw	•••	• · •
SS500c	1712	11	(11)	ч	Hingo	e Scre	w Stuc	i	•••	
99066	1706	11	(**)	11	11	· 11	11	Collar	with 220c	
220c	1711	11	(11)	11		11	11	11	Screw	
1655c	1712	11	(11)		11	**	**	Nut	•••	
†99045	1707	11	(11)	Driving	Cran	k wit	h 1036	c and 1	259c	
1036c	1711	11	(11)	11	11	Set	Screw	(long)		•••
1259c	1711	11	(**)	11	"	11	**	(short)	
99046	1704	11	(.,)	11	"	Sha	ıft			
†99047	1707	11	(11)		11	!!	Cra	nk with	two 5044 <mark>3</mark>	с
50443c	1712	11	(**)	11	н	11	**	Clar	nping Screv	r
1940	1712	11	ì	11)	11	"	н	,,	Roll	er and Scre	w
			•		ĺ				Stuc	l with 1	519e and 2	2142
1519e	1712	"	(11)	11	11	.,	Cra	nk Roll	er and Scre	w
					,						Stud	Nut
22142	1706	,,	(p)	.,	11	,,			and Scre	w
	1.00		`		,						tud Nut Wa	
99042	1704	**	(11	١	Rock S	Shaft				•••	
99043	1706	"	ì	11)				(lower		•••	
2022	1703		ì		í		н .	"	("	·		
99044	1706	.,	(,,	í				•	,	two 504430	
50443c	1712	"	(")			11	("	,	ping Screw	
1940	1712	"	(")		11	"	•	•	er and Scre	
1540	1/12	"	'	"	,	' ''	"	"	,	,	1519e and 2	
1519e	1712	11	(1) "	,,	11			er and Scre	
10106	1112	11	,	"	,	, "	"	11	(upp)	.1) 10011		Nut
22142	1706		((") "	" Scre	
22142	1700	н	•	11) "	"	11	, "	,	tud Nut W	
1006	1-11		,			Caram				_		
190f	1711	"	() Screw	 Wash		•••	. • • •	•••	•••
7071	1706	11	(,				•••	•••	•••
99048	1704	"	•			ith 1036		1370		•••	•••	•••
1375c	1711	**		11		osition S				•••	•••	•••
1036c	1711	"		**	5	et Screw	<i>'</i>		•••	•••	• • •	•••
10050		No1-1		ъ	.11.	443.77	, lanik			. 411	1:	. 114
13950						•		-			liameter of	
E0000	1504					with tw		Stri	•••	•••	•••	• • • •
52063	1704		ne	11		ey Oil C			•••	•••	•••	•••
210d	1711	11			"	II		Screw		•••	***	•••
443al		11			11	Set S	crew		•••	•••	•••	•••
Catalogue	:				_							
2043		Needle	e,	size	2	$2 (85 \times 1)$)		• • •	•••		

[†] For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

No.	Plate							
99049	1704	Needle Ba	r with 88	57c			•••	•••
37152	1707	11 11	Bushin	g (lower)				
453c	1711		II.	(")	Set Scre	w	•••	
37152	1707		11	(upper)	•••		•••	
435c	1711	tt H	11	(")	Set Scre	w	•••	
99050	1706		Cam wi	ith 400c a	and two	l057e	•••	
400c	1711	11 11	п Ас	djusting S	Screw	•••		
1057e	1711	11 11	" Cl	amping S	crew	•••		
RR70	1712	n n	п Re	oller and	Stud	•••	•••	
1143c	1711	11 #	11	11 11	" Pos	ition Scre	w	
452al	1711	" "	11	11 11	" Set	Screw		
99051	1702	11 11	Crank a	nd Feed	Lifting E	Eccentric v	vith <i>SS</i> 498	3c
1293c	1711		п	0 11	11	ıı I	Position Sc	rew
SS498c	1712	n n	п	H II	11	ıı 9	Set Screw	
857c	1711	" Set	Screw		•••	•••	•••	
99052	1705	" Thr	ead Guar	'd			•••	
460c	1711	11 11	tt	Set Scr			•••	
05000	7504	D D.						
37023	1704	Presser Ba		 D14 -			•••	•••
99053	1708	" "		Bracket y			•••	•••
1057e	1711	11	H . C.		Clamping		•••	•••
99054	1708	11 11	Lifter		,	•••	•••	•••
66593	1708	11 11		Hinge Stu		•••	•••	•••
440c	1711	11 11		11 11		rew	•••	•••
37408	1708	11 II	Spring			•••	•••	•••
37025	1703	11 11		Extensio	n Pin	•••	•••	•••
99055	1705	" Foo		•••	•••	•••	•••	•••
176f	1711	11 11	Screw	•••	•••	•••	•••	•••
1210e	1711	Pressure R	egulatin	g Thum	b Screw	·		
			.,	•				
99056	1707	Tension Br	acket	•••		•••		
176f	1711	"		rew (2)	•••	•••	•••	•••
2102	1703		c (2)	•••	•••		•••	
1560c	1712			Thumb N		•••		
*916c	1711		ew Stud			•••		
44209	_	" "		916c with		•••	•••	•••
1698c	1712		••	Nut	•••	•••	•••	
10148	1703		ing "		•••	•••	•••	•••
10110	1.00	" Opi	····8	• • • • • • • • • • • • • • • • • • • •	•••	***	•••	***
99057	1705	Throat Plat		•••	•••	•••	•••	•••
691f	1711	0 9	Screw		•••	•••	•••	•••
99058	1705	11 11		Retainer		•••	•••	•••
217f	1711	11 11	ш	**	Screw	•••	•••	•••
94013		Drip Pan	•••	•••	•••	•••		•••
		-						

Accessories

No.	Plate	Instruction Bo	ok					•••
99028	1705	Hook Needle (6)	•••	•••	•••	•••	•••
12361	_	Machine Hinge	Connec	ction (2)	•••	•••	•••	· • •
Catalogue								
2043		Needles, three	each siz	es 22 and	26 (85×	(1)	•••	•••
86720	1710	Oiler		•••	•••	•••	•••	•••
120440	1710	Screw Driver	• • •	•••	•••	•••	•••	•••
8908	1710	Wrench		•••		•••	•••	•••
68547	1710	Wrench	•••	••	• • •	•••	•••	•••

Foot Lifter

No.	Plate						
6439	1709	Chain, 36" to 4	5", with 56864	and 56865	•••	• • •	•••
	•	NOTE.—When or	dering 6439 giv	e length req	uired.		
4879	1709	Chain Connect	ing Link	•••			
56864	1709	и Hook (la	ırge)			•••	• • •
56865	1709	,, ,, (st	nall)	•••	•••	•••	•••
99059	1704	Lifting Lever					
694d	1711	,, ,, 1	Hinge Screw		•••	•••	•••
53081	1709	5	Spring	•••	•••	•••	•••
50393 c	1712	н п	Stop Screw	•••	•••	•••	
4881	1709	Treadle					
4882	1709	" Shaft		•••	•••	•••	
4883	1709	" Spring	; ····	•••	•••	•••	
4884	1709	" Stand		•••	•••	•••	•••
4885		Treadle, compl	lete, Nos. 4879,	4881 to 488	34 and tw	ro Wood S	crews
		1" No. 16	•••	•••	•••	•••	•••
99067		Foot Lifter, co	mplete, Nos. 6	94d, 4885,	6439, 503	393c, 5308	l and
		99059		•••	•••		•••

Thread Unwinder

For One Spool of Thread

No.	Plate	
228692	_	Spool Pin
201528h		п п Nut
82538		" " Washer
225259	2212	Spool Rest with 82538, 201018c, 201528h and 228692
150203	_	" " Cushion (felt)
225388	2212	" " Rod
200383c	1712	" " Set Screw
201018c	1712	" Set Screw
202490	2212	" Stand with 200383c
225391	2212	Thread Guide
		T 1 NT /
201696j	1712	" Lock Nut
225326	-	" Position Cup
225324	2212	Rod with 208e and 225322
208e	1711	и и в Screw
225322		" " " Washer
225260	2212	Thread Hawinder complete No. 150902 901606; 902400
225200	2212	Thread Unwinder, complete, Nos. 150203, 201696j, 202490,
		225259, 225324, 225326, 225388, 225391, and three Wood
		Screws \(\xi' \) No. 12
27739		Thread Cone (wood) (only supplied when specified on order and
21139		
		at an extra charge).

Numerical List of Parts

No.	Plate		
45c	1711	Feed Bar Hinge Screw	
46d	1711	Looper (upper) Carrier Connecting Link H	Iinge
		Screw	•••
RR70	1712	Needle Bar Cam Roller and Stud	
NN93c	1712	Feed Regulating Screw Stud Nut	
116e	1711	Arm Screw (long)	
143d	1711	Feed Bar Guide Screw	
144c	1711	Arm Shaft Screw	• • •
176f	1711	Face Plate Screw	
176f	1711	Guide Screw	
176f	1711	Presser Foot Screw	
176f	1711	Tension Bracket Screw	
190d	1711	Feeding Foot Extension Screw	
190f	1711	Looper (upper) Screw	
208e	1711	Thread Unwinder Thread Guide Rod S	crew
		for 225324	
210d	1711	Machine Pulley Oil Cover Screw	
217f	1711	Throat Plate Thread Retainer Screw	
220c	1711	Looper (upper) Carrier Hinge Screw	Stud
		Collar Screw for 99066	
400c	1711	Needle Bar Cam Adjusting Screw for 9908	50
423c	1711	Arm Shaft Bushing (front) Set Screw	
435c	1711	Needle Bar Bushing (upper) Set Screw	
440c	1711	Presser Bar Lifter Hinge Stud Set Screw	• • • •
443al		Machine Pulley Set Screw for 13950	
446c	1711	Feed Regulator Shaft Crank Set Screw	
448c	1711	Arm Shaft Bushing (back) Set Screw	
448c	1711	Looper (lower) Carrier Hinge Stud Set Se	crew
452al	1711	Needle Bar Cam Roller and Stud Set Scre	w
453c	1711	Feed Bar Rocking Frame Set Screw for 9	
453c	1711	Needle Bar Bushing (lower) Set Screw	•••
460c	1711	Looper (lower) Carrier Pitman Hinge Se	
		(left) Set Screw for 99033	• • • •
460c	1711	Needle Thread Guard Set Screw	
SS498c	1712	Needle Bar Crank and Feed Lifting Eccer	
		Set Screw for 99051	
SS500c	1712	Looper (upper) Carrier Hinge Screw Stud	
624c	1711	Looper (lower) Driving Lever Hinge	
~ ~		Collar Set Screw for 43840	
640f	1711	Hook Needle Closing Block Screw	•••
690d	1711	Dad Carray Comme	•••
690d	1711	Cuida Haldan Canass	•••
690d	1711	Heals Mardle Colds C	• • • •
691f	1711	Throat Plate Screw	•••
177711	1111	I III OAE PIATE SETEW	

694d 1711 Foot Lifter Lifting Lever Hinge Screw for 99067 857c 1711 Needle Set Screw for 99049 880e 1711 Feed Connecting Rod Cap Screw for 99015 *916c 1711 Tension Screw Stud for 44209 *1036c 1711 Looper (upper) Driving Crank Set Screw (long) for 99045 1036c 1711 Looper Cam Set Screw for 99048 1036c 1711 Looper Cam Set Screw for 99048 1036c 1711 Looper Cam Set Screw for 99048 1057c 1711 Presser Bar Guide Bracket Clamping Screw for 99050 1057c 1711 Presser Bar Guide Bracket Clamping Screw for 99050 1125d 1711 Feed Regulator Set Screw for 99019 1131c 1711 Looper (lower) Carrier Bell Crank Connecting Link Hinge Screw 1131c 1711	No.	Plate	
857c 1711 Needle Set Screw for 99049 880e 1711 Arm Screw (short) *916c 1711 Feed Connecting Rod Cap Screw for 99015 *1036c 1711 Feed Cam Set Screw for 99014 1036c 1711 Looper (upper) Driving Crank Set Screw (long) for 99045 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1125d 1711 Feed Regulator Set Screw for 99019 1131c 1711 Feed Regulator Set Screw for 99019 1131c 1711 Looper (lower) Carrier Bell Crank Hinge Screw 1131c 1711 Looper (lower) Carrier Bell Crank Connecting Link Hinge Screw 1143c 1711 Looper (upper) Driving Crank Set Screw Grew (short) for 9903 </td <td>694d</td> <td>1711</td> <td>Foot Lifter Lifting Lever Hinge Screw for</td>	694d	1711	Foot Lifter Lifting Lever Hinge Screw for
880e 1711 Arm Screw (short)			99067
896e 1711 Feed Connecting Rod Cap Screw for 99015 *916c 1711 Tension Screw Stud for 44209 1036c 1711 Looper (upper) Driving Crank Set Screw (long) for 99045 1036c 1711 Looper Cam Set Screw for 99048 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1125d 1711 Feed Regulator Set Screw for 99019 1131c 1711 Feed Regulator Set Screw for 99019 1131c 1711 Looper (lower) Set Screw for 99019 1131c 1711 Looper (lower) Carrier Pitman Hinge Screw (right) 1131c 1711 Looper (lower) Carrier Bell Crank Connecting Link Hinge Screw 1131c 1711 Looper (lower) Set Screw for 99033 1147c 1711 Looper (lower) Set Screw for 99033 1147e 17	857c	1711	Needle Set Screw for 99049
*916c 1711 Tension Screw Stud for 44209 1036c 1711 Feed Cam Set Screw for 99014 1036c 1711 Looper (upper) Driving Crank Set Screw (long) for 99045 1057e 1711 Needle Bar Cam Clamping Screw for 99050 1057e 1711 Presser Bar Guide Bracket Clamping Screw for 99053 1125d 1711 Feed Regulator Set Screw for 99019 1131c 1711 Feed Regulator Set Screw for 99019 1131c 1711 Feed Regulator Set Screw for 99019 1131c 1711 Looper (lower) Carrier Pitman Hinge Screw 1131c 1711 Looper (upper) Carrier Bell Crank Connecting Link Hinge Screw 1131c 1711 Looper (upper) Carrier Bell Crank Connecting Screw 1131c 1711 Looper (lower) Set Screw for 99033 1147e 1711 <td< td=""><td>880e</td><td>1711</td><td></td></td<>	880e	1711	
1036c 1711	896e	1711	
1036c 1711 Looper (upper) Driving Crank Set Screw (long) for 99045	*916c	1711	Tension Screw Stud for 44209
(long) for 99045	1036c	1711	Feed Cam Set Screw for 99014
1036c	1036c	1711	Looper (upper) Driving Crank Set Screw
1057e			(long) for 99045
1057e	1036c	1711	Looper Cam Set Screw for 99048
1125d 1711 Feed Regulator Set Screw for 99019 1131c 1711 Feed Bar Bell Crank Connecting Link Hinge Screw 1131c 1711 Looper (lower) Carrier Pitman Hinge Screw (right) 1131c 1711 Looper (upper) Carrier Bell Crank Connecting Link Hinge Screw 1143c 1711 Looper (upper) Carrier Bell Crank Connecting Link Hinge Screw 1147e 1711 Looper (lower) Set Screw for 99033 1210e 1711 Looper (lower) Set Screw for 99033 1232c 1711 Looper (upper) Carrier Bell Crank Hinge Screw 1253c 1711 Hook Needle Clamp Set Screw 1259c 1711 Looper (upper) Driving Crank Set Screw (short) for 99045 1293c 1711 Feed Regulator Shaft Crank Position Screw (short) for 99045 1293c 1711 Feed Regulator Staft Crank Position Screw 1342e 1711 Feed Regulator Stop Screw 1373c 1711 Feed Regulator Stop Screw 1375c 1711 Feed Connecting Rod Hinge Screw 1375c 1711 Feed Carn Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1057e	1711	
1131c	1057e	1711	
1131c	1125d	1711	Feed Regulator Set Screw for 99019
1131c 1711 Looper (lower) Carrier Pitman Hinge Screw (right)	1131c	1711	
1131c 1711 Looper (lower) Carrier Pitman Hinge Screw (right)			Screw
1131c	1131c	1711	
Link Hinge Screw			(right)
1143c	1131c	1711	
Screw			
1147e	1143c	1711	
1210e			
1232c			• •
Screw			
1253c 1711 Hook Needle Clamp Set Screw 1259c 1711 Looper (upper) Driving Crank Set Screw (short) for 99045 1293c 1711 Feed Regulator Shaft Crank Position Screw 1293c 1711 Needle Bar Crank and Feed Lifting Eccentric Position Screw 1342e 1711 Feed Regulator Stop Screw 1373c 1711 Feed Connecting Rod Hinge Screw 1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Can. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1232c	1711	
1259c 1711 Looper (upper) Driving Crank Set Screw (short) for 99045	10590	1711	Hoch Needle Clamp Cat Comm
(short) for 99045 1293c 1711 Feed Regulator Shaft Crank Position Screw Needle Bar Crank and Feed Lifting Eccentric Position Screw 1342e 1711 Feed Regulator Stop Screw 1373c 1711 Feed Connecting Rod Hinge Screw 1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Car. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut			Looper (upper) Driving County Set County
1293c 1711 Feed Regulator Shaft Crank Position Screw 1293c 1711 Needle Bar Crank and Feed Lifting Eccentric Position Screw 1342e 1711 Feed Regulator Stop Screw 1373c 1711 Feed Connecting Rod Hinge Screw 1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Can. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	12090	1711	
1293c 1711 Needle Bar Crank and Feed Lifting Eccentric	19020	1711	,
Position Screw			**
1342e 1711 Feed Regulator Stop Screw 1373c 1711 Feed Connecting Rod Hinge Screw 1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Can. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	12000	1711	· · · · · · · · · · · · · · · · · · ·
1373c 1711 Feed Connecting Rod Hinge Screw 1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Can. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1342e	1711	
1374c 1712 Feed Regulating Screw Stud 1375c 1711 Feed Cam. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1373c	1711	
1375c 1711 Feed Cam. Position Screw for 99014 1375c 1711 Looper Cam Position Screw for 99048 1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1374c	1712	
1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1375c	1711	
1467h 1712 Feed Bar Bell Crank Cap Screw 1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1375c	1711	Looper Cam Position Screw for 99048
1519e 1712 Looper (lower) Driving Lever Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1467h	1712	
Screw Stud Nut for 1940 1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1519e	1712	
1519e 1712 Looper (upper) Rock Shaft Crank (upper) Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut			
Roller and Screw Stud Nut for 1940 1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1519e	1712	
1519e 1712 Looper (upper) Driving Crank Shaft Crank Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut			
Roller and Screw Stud Nut for 1940 1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	1519e	1712	
1520r 1712 Feed Bar Bell Crank Connecting Link Hinge Screw Nut	-	_	
Screw Nut	1520r	1712	
			* •
	1520r	1712	

No.	Plate	
1520r	1712	Feed Regulator Connecting Link Hinge Screw
		Nut
1520r	1712	Looper (lower) Carrier Pitman Hinge Screw
		(right) Nut
1520r	1712	Looper (upper) Carrier Bell Crank Connect-
		ing Link Hinge Screw Nut
1560c	1712	Tension Regulating Thumb Nut for 44209
1655c	1712	Looper (upper) Carrier Hinge Screw Stud Nut
1698c	1712	Tension Screw Stud Nut
1718h	1712	Looper (upper) Carrier Connecting Link
		Hinge Screw Nut
1940	1712	Looper (lower) Driving Lever Roller and
		Screw Stud with 1519e and 22142
1940	1712	Looper (upper) Rock Shaft Crank (upper)
		Roller and Screw Stud with 1519e and
		22142
1940	1712	Looper (upper) Driving Crank Shaft Crank
		Roller and Screw Stud with 1519e and
		22142
2022	1703	Feed Regulator Pin
2022	1703	Looper (upper) Rock Shaft Crank (lower) Pin
2102	1703	Tension Disc
2656	1703	Feeding Foot Spring
4879	1709	Foot Lifter Chain Connecting Link for 4885
4881	1709	Foot Lifter Treadle for 4885
4882	1709	Foot Lifter Treadle Shaft for 4885
4883	1709	Foot Lifter Treadle Spring for 4885
4884	1709	Foot Lifter Treadle Stand for 4885
4885	_	Foot Lifter Treadle, complete, Nos. 4879,
		4881 to 4884 and two Wood Screws 1"
		No. 16, for 99067
6439	1709	Foot Lifter Chain, 36" to 45", with 56864 and
		56865 for 99067
No	OTE.—	When ordering 6439 give length required.
7071	1706	Guide Screw Washer
7071	1706	Looper (upper) Screw Washer
8908	1710	Wrench (Accessories)
10148	1703	Tension Spring
12361		Machine Hinge Connection (Accessories)
12454	1703	Arm Oil Tube with 132590
13950		Machine Pulley, "V" belt groove, outside
		diameter of belt groove 2.9", with two-
		443ai
16036	1702	Arm Side Cover
16532	1703	Arm Dowel Pin
+ 1	For Tana	Tone Machines the finish of these parts

† For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

t

No.	Plate		
No. 22142	1706	Looper (lower) Driving Lever Roller an	d
22172	1100	Screw Stud Nut Washer for 1940	
22142	1706	Looper (upper) Rock Shaft Crank (upper	
22172	1100	Roller and Screw Stud Nut Washer for	'n
22142	1706	Looper (upper) Driving Crank Shaft Cran	k
20		Roller and Screw Stud Nut Washer for	or
27739		Thread Unwinder Thread Cone (wood	1)
		(only supplied when specified on order an	ıd
		at an extra charge	
37023	1704	Presser Bar	
37025	1703		
37152	1707	2100010 33111 2711311-10 ()	
37152	1707	Needle Bar Bushing (upper)	
37408	1708	Tremer of the contract of the	• •
41544	1707		••
43840	1706	Looper (lower) Driving Lever Hinge P	in
		South west one says	• •
44209		Tell woll below to the state of the	•••
50053d	1712		•••
50083c	1712	Looper (lower) Driving Lever Set Screw for	
			••
50302f	1712	110011 1100010 000	
5039 3 c	1712	Foot Lifter Lifting Lever Stop Screw for 9900	
5044 3 c	1712	Looper (upper) Rock Shaft Crank (upper	
		Clamping Screw for 99044	
5044 3 c	1712	Looper (upper) Driving Crank Shaft Cran	ıĸ
=0.4=0		Clamping Screw for 99047	•••
50458c	1712	Looper (lower) Carrier Pitman Hinge Scree	
50450-	1510	(1010)	• • • •
50459c	1712	Feed Regulator Connecting Link Hinge Screen	
50562c 52063	$\begin{array}{c} 1712 \\ 1704 \end{array}$	Machine Pulley Oil Cover	
52195	1704		· · ·
53081	1709	Foot Lifter Lifting Lever Spring for 99067	
56006		Arm Shaft Bushing (back) Oil Pad (braid	
00000			
56006		Arm Shaft Bushing (front) Oil Pad (braid	
90000			
56864	1709	,	
56865	1709	· · · · · · · · · · · · · · · · · · ·	
64520	1706		
66593	1708		
68547	1710	Wrench (Accessorie	
82538	1706		
82538	1706	Hook Needle Guide Screw Washer	
0.000			

No.	Plate		
82538	_	Thread Unwinder Spool Pin Washer	for
		225259	•••
86720	1710	Oiler (Accessor	
94013	_	Drip Pan	
† * 99001		Arm	
99002	1704	Arm Shaft	
99003	1703	Arm Shaft Bushing (back)	
*99004	_	D-J	
99005	1702	Bed Cover	•••
†99006	1702	72 TM-4-	
†99007	1702	Post Day	•••
99008	1708	Feed Bar Bell Crank	•••
99009	1708	Feed Bar Bell Crank Connecting Link	•••
†99011	1708	E 10 0 11	•••
†99012	1708	Feed Bar Rocking Frame with 453c	•••
99013	1708		•••
99014	1703	Feed Bar Rocking Frame Hinge Pin	•••
99015	1703	Feed Cam with 1036c and 1375c	
*99016	1703 —	Feed Connecting Rod with 99016 and two 8	
		Feed Connecting Rod Cap for 99015	•••
99017	1705	Feeding Foot Extension (3 teeth) for 3" ga	
99018	1705	Feeding Foot Extension (3 teeth) for §" ga	-
†99019	1702	Feed Regulator with 1125d	•••
99020	1703	Feed Regulator Connecting Link	•••
99021	1707	Feed Regulator Shaft	•••
99022	1702	Feed Regulator Shaft Crank (forked)	•••
99023		Feed Regulator Shaft Crank Oil Pad (felt)	٠
99024	1705	Feeding Foot	•••
99025	1707	Guide (for Hem) ½" gauge	• • •
99026		Guide (for Hem) § gauge	• • •
99027	1702	Guide Holder	•••
99028	1705	Hook Needle	•••
99029	1708	Hook Needle Clamp	•••
99030	1708	Hook Needle Closing Block	•••
99031	1707	Hook Needle Guide	• • •
99032	1705	Looper (lower)	•••
99033	1706	Looper (lower) Carrier with 460c and t	wo
		1147e	•••
99034	1704	Looper (lower) Carrier Pitman	•••
99035	1704	Looper (lower) Driving Lever with 50083c	
99036	1704	Looper (lower) Driving Lever Hinge Pin	
99037	1706	Looper (upper)	•••
99039	1706	Looper (upper) Carrier Connecting Link	
99041	_	Looper (upper) Carrier Bell Crank Conne	
99042	1704	ing Link	•••
00042	1704	Looper (upper) Rock Shaft	•••

[†] For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

99044 1706 Looper (upper) Rock Shaft Crank (upper) with two 50443c	No.	Plate	
with two 50443c	99043	1706	
199045 1707	99044	1706	Looper (upper) Rock Shaft Crank (upper)
99046 1704 Looper (upper) Driving Crank Shaft 1707 Looper (upper) Driving Crank Shaft Crank with two 50443c 99048 1704 Looper Cam with 1036c and 1375c 99049 1704 Needle Bar with 857c 99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99054 1708 Presser Bar Guide Bracket with two 1057e 99055 1705 Presser Bar Lifter 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99061 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,			
99046 1704 Looper (upper) Driving Crank Shaft †99047 1707 Looper (upper) Driving Crank Shaft Crank with two 50443c 99048 1704 Looper Cam with 1036c and 1375c 99049 1704 Needle Bar with 857c 99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99051 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate Thread Retainer 99059 1704	†99045	1707	Looper (upper) Driving Crank with 1036c
199047 1707 Looper (upper) Driving Crank Shaft Crank with two 50443c			
with two 50443c 99048 1704 Looper Cam with 1036c and 1375c 99049 1704 Needle Bar with 857c 99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge <t< td=""><td>99046</td><td>1704</td><td></td></t<>	99046	1704	
99048 1704 Looper Cam with 1036c and 1375c 99049 1704 Needle Bar with 857c 99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge <td>†99047</td> <td>1707</td> <td>Looper (upper) Driving Crank Shaft Crank</td>	†99047	1707	Looper (upper) Driving Crank Shaft Crank
99049 1704 Needle Bar with 857c 99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain)			•
99050 1706 Needle Bar Cam with 400c and two 1057e 99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain) 99	99048	1704	Looper Cam with 1036c and 1375c
99051 1702 Needle Bar Crank and Feed Lifting Eccentric with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain) 99064 1706 Looper (99049	1704	
with SS498c 99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier	99050	1706	Needle Bar Cam with 400c and two 1057e
99052 1705 Needle Thread Guard 99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier Bell Crank	99051	1702	Needle Bar Crank and Feed Lifting Eccentric
99053 1708 Presser Bar Guide Bracket with two 1057e 99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½ gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½ gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier Bell Crank 99065 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,			with SS498c
99054 1708 Presser Bar Lifter 99055 1705 Presser Foot 99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½" gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99052	1705	Needle Thread Guard
99055 1705 Presser Foot	99053	1708	Presser Bar Guide Bracket with two 1057c
99056 1707 Tension Bracket 99057 1705 Throat Plate 99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½" gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99054	1708	Presser Bar Lifter
99057 1705 Throat Plate	99055	1705	Presser Foot
99058 1705 Throat Plate Thread Retainer 99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½" gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99056	1707	Tension Bracket
99059 1704 Foot Lifter Lifting Lever for 99067 99060 1705 Feeding Foot Extension (3 teeth) for ½" gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99057	1705	Throat Plate
99060 1705 Feeding Foot Extension (3 teeth) for ½" gauge 99061 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99058	1705	=
99061 1705 Feeding Foot Extension (2 teeth) for § gauge 99062 1705 Feeding Foot Extension (2 teeth) for § gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c	99059	1704	Foot Lifter Lifting Lever for 99067
99062 1705 Feeding Foot Extension (2 teeth) for ½" gauge 99063 1707 Guide (plain) 99064 1706 Looper (upper) Carrier Bell Crank 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99060	1705	Feeding Foot Extension (3 teeth) for ½" gauge
99063 1707 Guide (plain) <td>. 99061</td> <td>. 1705</td> <td>Feeding Foot Extension (2 teeth) for §" gauge</td>	. 99061	. 1705	Feeding Foot Extension (2 teeth) for §" gauge
99064 1706 Looper (upper) Carrier 99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c	99062	1705	Feeding Foot Extension (2 teeth) for ½" gauge
99065 1706 Looper (upper) Carrier Bell Crank 99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c	99063	1707	Guide (plain)
99066 1706 Looper (upper) Carrier Hinge Screw Stud Collar with 220c 99067 — Foot Lifter, complete, Nos. 694d, 4885,	99064	1706	Looper (upper) Carrier
Collar with 220c 199067 — Foot Lifter, complete, Nos. 694d, 4885,	99065	1706	Looper (upper) Carrier Bell Crank
99067 - Foot Lifter, complete, Nos. 694d, 4885,	99066	.1706	Looper (upper) Carrier Hinge Screw Stud
_			Collar with 220c
6439, 50393c, 53081 and 99059	. 99067		Foot Lifter, complete, Nos. 694d, 4885,
the state of the s			6439, 50393c, 53081 and 99059

† For Two-Tone Machines the finish of these parts is Grey Metallic (Colour Code No. 728).

No.	Plate		•		
			•		
•			:.·.		1 v. 2
		Might see the			21.2
		30			
• •					
			nane.		
	πi.				<u>:</u> 5 :
	Maté,				1.51
,					66.4
		en er	, i		=
				::	2 2
1	54		v.:		
• • • •			197.3		*:
· 24.					
	-				
	. :	• G	.:f1 .		
•		•	59		
			31		
					1.28
		122	•		
		15%	- January 1	**	C. 637
			1		*
	•	3 1 1.		2	

No.	Plate	
120440	1710	Screw Driver (Accessories)
132590		Arm Oil Tube Packing (felt) for 12454
150203		Thread Unwinder Spool Rest Cushion (felt) for 225260
200383c	1712	Thread Unwinder Spool Rest Rod Set Screw for 202490
201018c	1712	Thread Unwinder Spool Rest Set Screw for 225259
201528h		Thread Unwinder Spool Pin Nut for 225259
201696j	1712	Thread Unwinder Thread Guide Lock Nut for 225260
202490	2212	Thread Unwinder Spool Stand with 200383c for 225260
225259	2212	Thread Unwinder Spool Rest with 82538, 201018c, 201528h and 228692 for 225260
225260	2212	Thread Unwinder (for one spool of thread), complete, Nos. 150203, 201696j, 202490, 225259, 225324, 225326, 225388, 225391 and three Wood Screws ‡" No. 12
225322		Thread Unwinder Thread Guide Rod Washer for 225324
225324	2212	Thread Unwinder Thread Guide Rod with 208e and 225322 for 225260
225326	_	Thread Unwinder Thread Guide Position Cup for 225260
225388	2212	Thread Unwinder Spool Rest Rod for 225260
225391	2212	Thread Unwinder Thread Guide for 225260
228692		Thread Unwinder Spool Pin for 225259

