

SINGER

145W302

Form 2633w
(240)

PRINTED IN U. S. A.

REPAIR KIT
FOR SINGER


13067 - 1/2

SINGER


145 w 302




THE SINGER MANUFACTURING COMPANY




16124 - 3/8




16127 - $\frac{3}{4}$




16148 - 1/7




16149 - 1/7




16169 - 5/8




16170 - 1/2










16171 - 1/2










16172 - 5/8



16174 - 1/2

265237	265230	265236	265238
			
1/4 - 3/32 - 5/16 - 1/32 - 3/8 - 13/32 7/16 - 5/32 - 1/2 - 17/32 - 9/16 - 19/32 5/8 - 21/32 - 11/16 - 23/32	2/32 - 1/16 - 23/32 - 3/4	3/4 - 25/32 - 3/16 - 27/32 7/8 - 29/32 - 5/16 - 3/32	1 - 1/32 - 1/16 - 13/32 - 1/8 5/32 - 3/16 - 7/32 - 1/4 - 9/32 5/16 - 11/32 - 3/8 - 13/32 7/16 - 15/32 - 1/2
265267-35	265325-16	265266-35	265268-35
			
200006F			

16175 - 1/2

2001612	265259	265257-35	265258
			
265250 265223-35 2014912 7-27 1/4 - 9/32	5/16 - 11/32 - 3/8 - 13/32 - 7/16 - 5/32 - 1/2 - 7/32		9/16 - 19/32 - 5/8 - 27/32 - 1/16 - 23/32 - 3/4 - 25/32 13/16 - 27/32 - 7/8 - 29/32 - 15/16 - 31/32
265261	265221-23	265226-35	265227-35
			
	1 - 1/32 - 1/16 - 3/32 - 1/8 - 15/32 - 13/16 - 7/32 - 1/4 19/32 - 15/16 - 11/32 - 3/8 - 13/32 - 7/16 - 15/32 - 1/2 - 17/32 - 9/16 - 19/32 - 5/8 12/32 - 11/16 - 23/32 - 13/16 - 25/32 - 13/16 - 27/32 - 7/8 - 29/32 - 15/16		2 - 2 1/16 - 2 1/8 - 2 3/16 - 2 1/4 - 2 5/16 - 2 3/8 - 2 7/16 - 2 1/2

