

LIST OF PARTS



MACHINE No. 150w3

THE SINGER MANUFACTURING COMPANY

From the library of: Superior Sewing Machine & Supply LLC

Copyright, U. S. A., 1919, 1922, 1925, 1935 and 1936
by The Singer Manufacturing Co.
All Rights Reserved for all Countries

INDEX

	Page
Accessories	14
Bobbin Winder	14
Feed Dogs	16
Hemmer Feet	16
Knee Lifter	15
Machine No.150w3	7
Miscellaneous Parts	18
Numerical List Of Parts	19
Obsolete Parts	18
Presser Feet	16
Thread Unwinder	18
Throat Plates	17

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the PART number in the FIRST column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above case), must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished only.
- E. Soft, not polished.
- F. Hardened and Polished.
- H. Blued.
- J. Nickle Plated only.
- R. Merlized.
- Y. Black Nickle Plated only.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series


200001 to 201500 and 350001 to 351500 are Screw Numbers.
201501 to 201800 and 351501 to 351800 are Nut Numbers.
201801 to 202000 and 351801 to 352000 are Roller Numbers.
202001 to 350000 are Numbers of Machine Parts.

The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE
FOR



MACHINE No. 150w3

HIGH SPEED LOCK STITCH
BALL BEARING

FOR LIGHT AND MEDIUM WEIGHT FABRICS

No.	Plate	Name
*263001	-----	Arm with 202135 and 263003
202247	15926	" Cap
200278H	15901	" " Screw
202248	15901	" " " Washer
263003	15901	" Oil Cup
204235	15901	" Position Pin (2)
200010E	15901	" Screw (3)
202005	15901	" " Washer (3)
263004	15927	" Shaft with 200357E and 224392
263005	-----	" " Ball Bearing
*263006	-----	" " " " Collar with 200352C and 201007C
263007	15926	Arm Shaft Ball Bearing Collar 263006 with 263005
200352C	15925	Arm Shaft Ball Bearing Collar Position Screw
201007C	15901	Arm Shaft Ball Bearing Collar Set Screw
263008	15926	" " " " Retainer

PARTS FOR MACHINE 150w3

No.	Plate	Name
200098E	15901	Arm Shaft Ball Bearing Retainer Screw (3)
263098	15926	Arm Shaft Bushing (front) with 223847
223847	-----	" " " Oil Packing (wick)
200502B	15901	Arm Shaft Bushing (front) Oil Packing Thumb Screw
204329	-----	Arm Shaft Bushing (front) Oil Pad
200338C	15925	" " " Set Screw
263105	15927	" " " Connection Belt
263009	15926	" " " Pulley with 200327C, 200602E and two 202253
263010	-----	Arm Shaft Connection Belt Pulley 263009 with 263020, 263021, 263094, 263095, 351845, two each 201531E and 350351C
200602E	15901	Arm Shaft Connection Belt Pulley Position Screw
200327C	15901	Arm Shaft Connection Belt Pulley Set Screw
202253	15901	Arm Shaft Connection Belt Pulley Spring Flange
224392	-----	Arm Shaft Oil Packing (wick)
200357E	15901	" " " " Stop Screw
263011	15927	Balance Wheel (disc)(belt groove 2-1/8 in. diam.) with 200328C and 200335C
144D	15901	Balance Wheel Adjusting Screw
200328C	15901	" " " Position Screw
200335C	15925	" " " Set Screw
*263012	-----	Bed
263013	15926	" Plate (back)
200577H	15901	" " " Screw (2)
207966Y	15926	" Slide (front)
263099	15901	Bobbin
263014	15901	" Case Base
263108	15901	" " Cap with 200592C, 201016F and 263110
263109	-----	Bobbin Case Cap complete, Nos. 200964E, 210736, 210914 and 263108
210913	15901	Bobbin Case Latch
210914	-----	" " " 210913 with 210734 and 210735
210735	15901	Bobbin Case Latch Fulcrum Pin
210734	15901	" " " Lever
210736	15901	" " " Spring
200964E	15901	" " " Stop Screw
263017	15901	" " " Stop
200138D	15901	" " " Screw
263110	15925	" " " Tension Spring
201016F	15901	" " " " Regulating Screw

Screw

Regulating

PARTS FOR MACHINE 150w3

9

No.	Plate	Name
200592C	15901	Bobbin Case Tension Spring Screw
263019	-----	Bobbin Case complete, Nos. 263014 and 263109
263091	15927	Face Plate
202135	15901	" " Position Pin
200482B	15901	" " Thumb Screw
202275	15926	Feed Bar
200641C	15904	" " Hinge Screw (driving)
201522E	15904	" " " " Nut
202276	15904	" " Slide Block
202298	15904	" " " " Crank with 200038C
203124	-----	" " " " " " 202298 with 200205F, 201518E and 202276
200038C	15904	Feed Bar Slide Block Crank Pinch Screw
200205F	15904	" " " " Hinge Screw
201518E	15904	" " " " " " Nut
202282	15908	" Dog
200106E	15904	" " Screw
202297	15927	" Driving Connection with 200054E and 202277
202298	15904	Feed Driving Connection Crank with 200038C
200038C	15904	Feed Driving Connection Crank Pinch Screw
200545C	15904	Feed Driving Connection Hinge Screw
201518E	15904	" " " " " Nut
202277	-----	" " " Oil Packing (wick)
200054E	15904	" " " Pinch Screw
263020	15926	" " Eccentric (indexed) with 263023
263021	15926	Feed Driving Eccentric Adjusting Disc
263094	15904	" " " " " "
		Locking Stud
263095	15904	Feed Driving Eccentric Adjusting Disc Locking Stud Spring
351845	15904	Feed Driving Eccentric Roller
263023	15904	" " " " Stud
350351C	15904	" " " Screw
201531E	15904	" " " " Nut
202303	15927	" " Rock Shaft
206860	-----	" " " " 202303 with 200641C, 201522E and 202275
203121	-----	Feed Driving Rock Shaft 206860 with 202282 and two 200106E
202305	15904	Feed Driving Rock Shaft Center (2)
200043C	15904	" " " " " Set Screw (2)
202308	15927	Feed Lifting Connection with 200054E and 202277

PARTS FOR MACHINE 150w3

No.	Plate	Name
202307	15904	Feed Lifting Connection Eccentric with 200382C and 200437C
200437C	15904	Feed Lifting Connection Eccentric Position Screw
200382C	15904	Feed Lifting Connection Eccentric Set Screw
200545C	15904	Feed Lifting Connection Hinge Screw
201518E	15904	" " " " " Nut
202277	-----	" " " Oil Packing (wick)
200054E	15904	" " " Pinch Screw
202308	15927	" " Rock Shaft
202305	15904	" " " " Center (2)
200043C	15904	" " " " Set Screw (2)
213161	15904	" Regulating Lever with 213657
200665C	15904	" " " Hinge Screw
206452	15904	" " " Spring
213657	15904	" " " Pin
* 263131	-----	Hook with 263134 and two 462C
263132	15926	" 263131 with 200145C, 210536, 263034 and three 200596F
263133	-----	Hook and Bobbin Case complete, Nos. 263019 and 263132
210636	15928	Hook Gib
200596F	15928	" " Screw
263134	-----	" Oiling Felt
462C	15928	" Set Screw
263135	15927	" Shaft with 263139
263029	-----	" " Ball Bearing
* 263030	-----	" " " " Collar with two 200383C
263031	15926	Hook Shaft Ball Bearing Collar 263030 with 263029
200383C	-----	Hook Shaft Ball Bearing Collar Set Screw
263032	15926	" " " " Retainer
200098E	15901	" " " " Screw (3)
263136	15926	" " Bushing (front) with 263137 and four 263138
263136	-----	Hook Shaft Bushing (front) Oil Plug (wood)
263137	-----	Hook Shaft Bushing (front) Oil Wick
204329	-----	" " " " Pad
200346C	15928	" " " Set Screw
263033	15926	" " Connection Belt Pulley with 202324 and two 201018C
201018C	15907	Hook Shaft Connection Belt Pulley Set Screw
202324	15928	Hook Shaft Connection Belt Pulley Spring Flange

PARTS FOR MACHINE 150w3

11

No.	Plate	Name
222583	-----	Hook Shaft Oil Packing (wick)(back)
202260	-----	" " " " " (front)
263139	-----	" " " Wick
263034	15928	" Washer Needle Guard
200145C	15928	" " " " Screw
237837	13398	Knee Lifter Connection Lever
244035	-----	" " " " 237837 with 202447, 244034 and two 200262H
200262H	15925	Knee Lifter Connection Lever Hinge Screw
202447	13398	" " " " Lifting Rod with 202302
202302	15925	Knee Lifter Connection Lever Lifting Rod Cotter Pin
244034	13398	Knee Lifter Lifting Lever
200262H	15925	" " " " Hinge Screw
263155	15925	Needle Bar with 200141F
263117	15925	" " Bushing
263144	-----	" " " 263117 with 263155
200352C	15925	" " " Set Screw
263035	15928	" " Connecting Link
263036	15928	" " " " Oil Guard
200161D	10247	" " " " " " Screw
263037	-----	" " " " Oiling Felt
200161D	10247	" " " " " " Screw
202333	15925	" " " " Stud with 202254
202254	-----	Needle Bar Connecting Link Stud Oil Pack- ing (wick)
200374C	15928	Needle Bar Connecting Link Stud Set Screw
*206891	-----	" " " Stud
202329	15925	" " " " 206891 with 200086C and 202330
202330	-----	Needle Bar Connecting Stud Oil Packing (wick)
200086C	15925	Needle Bar Connecting Stud Pinch Screw
202328	13398	" " Crank with 200335C, 200428C, 202333 and two 200374C
263036	-----	Needle Bar Crank 202328 with 202329, 202398 to 202400 and 263035
203172	15925	Needle Bar Crank Friction Washer
200428C	15925	" " " Position Screw
200335C	15925	" " " Set Screw
200141F	15925	" Set Screw
244033	-----	Presser Bar (hollow)
202335	13398	" " 244033 with 200074F
263039	15928	" " Bushing
200352C	15925	" " " Set Screw
202339	15928	" " Lifter
200653C	15928	" " " Hinge Screw

No.	Plate	Name
244004	15906	Presser Bar Lifting Releasing Lever Bracket
200260D	15906	Presser Bar Lifting Releasing Lever Bracket Guide Screw
206608	15906	Presser Bar Lifting Releasing Lever Bracket Spring
202337	15906	Presser Bar Position Guide
202338	15906	" " " " Lever with 200086F
200086F	15925	Presser Bar Position Guide Lever Pinch Screw
200352C	15925	Presser Bar Position Guide Set Screw
263098	15906	" " Spring
202346	15906	" " " Stop Rod
200492B	15906	" " Thumb Screw (pressure regulating)
200475B	15906	Presser Bar Thumb Screw Thumb Set Screw
202355	15906	" " " " " " " "
		Packing (brass)
202090	15906	Presser Foot Hinge Pin
203009	-----	" " Plate
202924	-----	" " Shank
229864	15906	Presser Foot (hinged) complete, Nos. 202090, 202924 and 203009
200074F	15906	Presser Foot Screw
202397	15906	Take-up (auxiliary)
200842E	15906	" " Screw
202398	10247	" Lever
202399	10247	" " Driving Stud with 202277
202277	-----	" " " " Oil Packing (wick)
202400	10247	Take-up Lever Hinge Stud with 202423
202423	-----	" " " " Oil Packing (wick)
200383C	-----	Take-up Lever Hinge Stud Set Screw
263040	-----	" " Oiling Felt
200132E	10247	" " " " Screw (2)
263041	15906	" " " Wick with 263097
263097	-----	" " " Wire
244048	10247	Tension Disc (back)
244049	10247	" " (front)
202404	10247	" Release Plunger
202405	15907	" " Washer
202407	10881	" Spring
263106	15925	" " Washer
200625F	15907	" Stud with 204925
200061C	15907	" " Set Screw
204925	15907	" " Washer
201572B	10881	" Thumb Nut

PARTS FOR MACHINE 150w3

13

No.	Plate	Name
263107	-----	Tension complete, Nos. 200625F, 201572B, 202405, 202407, 202410, 244048, 244049 and 263106
202410	15907	Thread Controller Spring
202411	15907	" " " Stop
200132E	10247	" " " " Screw
202412	15907	" Guide
202414	15907	" "
202415	15907	" "
202417	15925	" "
263118	-----	" " (on needle bar bushing)
200582H	15907	" " Screw
200355H	15907	" " Set Screw
200397C	15907	" " " "
240034	-----	" Retainer
200368H	15907	" " Set Screw
263042	15909	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D
200577H	15901	Throat Plate Screw (2)

ACCESSORIES

No.	Plate	Name
200157B	15907	Attachment Screw
263099	15901	Bobbin
*225482	-----	" Case Screw Driver Blade
*225483	-----	" " " " Handle
225497	14334	Bobbin Case Screw Driver complete, Nos. 225482 and 225483
231337	15907	Cloth Guide
200459D	15907	" " Thumb Screw
12361	14334	Machine Hinge Connection
135 x 1	-----	Needles, three each, sizes 12 and 14
228212	-----	Drip Pan (short) with four 1 in. wire nails
41400	14334	Machine Rest Pin (wood)
120342	14334	Oilier (copper plated) with 120343
120343	14334	" Spout, 3-1/2 in. long
*225484	-----	Screw Driver Blade
*225485	-----	" " Handle
225498	14334	Screw Driver complete (7-1/4 in. long), Nos. 225484 and 225485
225554	14334	Wrench (steel)

BOBBIN WINDER

Swing Automatic, Right Hand

225453	10884	Frame with 202277 and 225438
225454	10884	" Hinge Pin
202277	-----	" Oil Packing (wick)
225438	10884	" " Well Cap
225455	10884	" Spring
225456	10884	" " Plunger
202473	10885	Pulley with 200380C
200380C	15907	" Set Screw
225381	10884	Spindle
225444	10884	Stop Latch
200056E	10884	" " Screw
225458	10884	" " Thumb Lever
225459	10884	" " " " Hinge Stud
225459	10884	" " " " Joint Stud
202478	10884	" " Trip Lever
200299H	10884	" " " " Hinge Screw
225461	10881	Tension Bracket with 201499B
200082D	10881	" " Screw

ACCESSORIES

15

No.	Plate	Name
228026	10884	Tension Bracket Screw Washer
2102	10881	" Disc
202407	10881	" Spring
201499B	10881	" Stud
201572B	10881	" " Thumb Nut
225462	10881	Bobbin Winder Tension Bracket complete, Nos.201572B,202407,225461 and two 2102
225433	10885	Bobbin Winder and Tension Bracket Base
225382	10885	Universal Bobbin Winder complete,Nos. 200056E,200082D,200299H,202473, 202478,225381,225433,225444,225453 to 225456,225458,225462,228026,two each 225459 and wood screws 3/4 in., No.12,R.H.B.

KNEE LIFTER

228294	15911	Rock Lever with two 356C
228295	15911	" " Bracket with 356C
228299	-----	" " " 228295 with 228294 and 228297
228296	15911	Rock Lever Extension with 200529C
356C	15911	" " " Set Screw
228297	15911	" " Hinge Pin
356C	15911	" " " " Set Screw
202455	15911	" " Knee Arm
356C	15911	" " " " Set Screw
228284	15911	" " " Plate with 356C
356C	15911	" " " " Set Screw
227728	15911	" " Rod with 227729
* 227729	-----	" " " Cap
200529C	15911	" " " Set Screw
228298	15911	Knee Lifter complete,Nos.202455,227728, 228284,228296 and 228299

(Other Knee Lifter parts are listed with parts of machine head.)

FEED DOGS

No.	Plate	Name
202279	15908	Feed Dog, for 263043
202280	15908	" " " 263049
202281	15930	" " " 263054
202282	15908	" " " 203121, 263042, 263044, 263052 and 263053
202283	15908	Feed Dog, for 263048
202287	15930	" " " 263051
202288	15908	" " " 263047
202294	15908	" " " 263046
202970	15908	" " " 263045
207051	15908	" " " 263048
207052	15908	" " " 263048
207075	15908	" " " 263050
263125	15930	" " " 263055

HEMMER FEET

263111	15930	Hemmer Foot, for 3/32 in. hem
263112	15930	" " " 1/8 in. hem
263113	-----	" " " 5/32 in. hem
263114	15930	" " " 3/16 in. hem
263115	15930	" " " 1/4 in. hem

PRESSER FEET

202090	15906	Presser Foot Hinge Pin
203009	-----	" " " Plate
263126	-----	" " " "
263129	-----	" " " "
202924	-----	" " " Shank
202996	-----	" " " "
263128	-----	" " " "
226080	15925	" " " Spring
229864	15906	Presser Foot (hinged) complete, Nos. 202090, 202924 and 203009
263127	15930	Presser Foot (hinged) complete, Nos. 202090, 263126 and 263128
263130	15930	Presser Foot (hinged) complete, Nos. 202090, 202996, 226080 and 263129

THROAT PLATES

No.	Plate	Name
263017	15901	Bobbin Case Stop
200136D	15901	" " " Screw
263042	15909	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202282
263043	15909	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202279
263044	15909	Throat Plate, 60 needle hole, for needle sizes 8 and 9, with 263017 and two 200136D, for 202282
263045	15909	Throat Plate, 53 needle hole, for needle sizes 12 and 13, with 263017 and two 200136D, for 202970
263046	15909	Throat Plate, 53 needle hole, for needle sizes 12 and 13, with 263017 and two 200136D, for 202294
263047	15910	Throat Plate, 46 elongated needle hole, for needle sizes 20 and 22, with 263017 and two 200136D, for 202288
263048	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202283, 207051 and 207052
263049	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, grooved for thread back of needle, with 263017 and two 200136D, for 202280
263050	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 207075
263051	15929	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202287
263052	15929	Throat Plate, 56 needle hole, for needle sizes 10 and 11, with 263017 and two 200136D, for 202282
263053	15929	Throat Plate, 46 needle hole, for needle sizes 16 and 18, with 263017 and two 200136D, for 202282
263054	15929	Throat Plate, 53 needle hole, for needle sizes 12 and 13, with 263017 and two 200136D, for 202281
263055	15929	Throat Plate, 60 needle hole, for needle sizes 8 and 9, with 263017 and two 200136D, for 263125, for Rayon

THREAD UNWINDER

No.	Plate	Name
225257	14363	Spool Rest (for two spools)(flat) with 201018C
150203	-----	Spool Rest Cushion (felt)
225388	14363	" " Rod
200383C	-----	" " " Set Screw
201018C	15907	" " Set Screw
202490	14363	" Stand with 200383C
225391	14363	Thread Guide
201696J	15907	" " Lock Nut
225326	15907	" " Position Cup
225324	14363	" " Rod with 208E and 225322
208E	15907	" " " Screw
225322	15907	" " " Washer
225258	14363	Thread Unwinder (for two spools) complete, Nos. 201696J, 202490, 225257, 225324, 225326, 225388, two each 150203, 225391 and three wood screws 7/8 in., No. 12

MISCELLANEOUS PARTS

USED IN CONJUNCTION WITH THREAD UNWINDER

60913	14363	Spool Weight with 60914
60914	-----	" " Center Pin
225377	14363	" Wire, for small spools
27739	13398	Thread Cone (wood)

OBSOLETE PARTS

263022	15907	Feed Driving Eccentric Friction Washer
350344C	15907	" " " Screw
263024	15907	" " " Washer

NUMERICAL LIST OF PARTS
FOR
MACHINE No. 150w3

NUMERICAL LIST OF PARTS

FOR

MACHINE NO. 1234

NUMERICAL LIST OF PARTS

No.	Plate	Name
144D	15901	Balance Wheel Adjusting Screw
208E	15907	Thread Unwinder Thread Guide Rod Screw, for 225324
356C	15911	Knee Lifter Rock Lever Extension Set Screw, for 228294
356C	15911	Knee Lifter Rock Lever Hinge Pin Set Screw, for 228295
356C	15911	Knee Lifter Rock Lever Knee Arm Set Screw, for 228294
356C	15911	Knee Lifter Rock Lever Knee Plate Set Screw, for 228284
462C	15928	Hook Set Screw, for 263131
2102	10881	Bobbin Winder Tension Disc, for 225462
12361	14334	Machine Hinge Connection
27739	13398	Thread Cone (wood)
41400	14334	Machine Rest Pin (wood)
60913	14363	Spool Weight with 60914
60914	-----	" " Center Pin, for 60913
120342	14334	Oiler (copper plated) with 120343
120343	14334	" Spout, 3-1/2 in. long, for 120342
200010E	15901	Arm Screw
200038C	15904	Feed Bar Slide Block Crank Pinch Screw, for 202298
200038C	15904	Feed Driving Connection Crank Pinch Screw, for 202298
200043C	15904	Feed Driving Rock Shaft Center Set Screw
200043C	15904	Feed Lifting Rock Shaft Center Set Screw
200054E	15904	Feed Driving Connection Pinch Screw, for 202297
200054E	15904	Feed Lifting Connection Pinch Screw, for 202306
200056E	10884	Bobbin Winder Stop Latch Screw, for 225382
200061C	15907	Tension Stud Set Screw
200074F	15906	Presser Foot Screw, for 202335
200082D	10881	Bobbin Winder Tension Bracket Screw, for 225382
200086C	15925	Needle Bar Connecting Stud Pinch Screw, for 202329
200086F	15925	Presser Bar Position Guide Lever Pinch Screw, for 202338

NUMERICAL LIST OF PARTS

No.	Plate	Name
200098E	15901	Arm Shaft Ball Bearing Retainer Screw
200098E	15901	Hook Shaft Ball Bearing Retainer Screw
200106E	15904	Feed Dog Screw, for 203121
200132E	10247	Take-up Lever Oiling Felt Screw
200132E	10247	Thread Controller Spring Stop Screw
200136D	15901	Bobbin Case Stop Screw, for 263042 to 263055
200141F	15925	Needle Set Screw, for 263155
200145C	15926	Hook Washer Needle Guard Screw, for 263132
200157B	15907	Attachment Screw
200161D	10247	Needle Bar Connecting Link Oiling Felt Screw
200161D	10247	Needle Bar Connecting Link Oil Guard Screw
200205F	15904	Feed Bar Slide Block Hinge Screw, for 203124
200260D	15906	Presser Bar Lifting Releasing Lever Bracket Guide Screw
200262H	15925	Knee Lifter Connection Lever Hinge Screw, for 244035
200262H	15925	Knee Lifter Lifting Lever Hinge Screw, for 244035
200278H	15901	Arm Cap Screw
200299H	10884	Bobbin Winder Stop Latch Trip Lever Hinge Screw, for 225382
200327C	15901	Arm Shaft Connection Belt Pulley Set Screw, for 263009
200328C	15901	Balance Wheel Position Screw, for 263011
200335C	15925	" " Set Screw, for 263011
200335C	15925	Needle Bar Crank Set Screw, for 202328
200338C	15925	Arm Shaft Bushing Set Screw
200346C	15928	Hook Shaft Bushing (front) Set Screw
200352C	15925	Arm Shaft Ball Bearing Collar Position Screw, for 263006
200352C	15925	Needle Bar Bushing Set Screw
200352C	15925	Presser Bar Bushing Set Screw
200352C	15925	" " Position Guide Set Screw
200355H	15907	Thread Guide Set Screw
200357E	15901	Arm Shaft Oil Packing Stop Screw, for 263004
200366H	15907	Thread Retainer Set Screw
200374C	15928	Needle Bar Connecting Link Stud Set Screw, for 202328
200380C	15907	Bobbin Winder Pulley Set Screw, for 202473
200382C	15904	Feed Lifting Connection Eccentric Set Screw, for 202307
200383C	-----	Hook Shaft Ball Bearing Collar Set Screw, for 263030

NUMERICAL LIST OF PARTS

21

No.	Plate	Name
200383C	-----	Take-up Lever Hinge Stud Set Screw
200383C	-----	Thread Unwinder Spool Rest Rod Set Screw,for 202490
200397C	15907	Thread Guide Set Screw
200428C	15925	Needle Bar Crank Position Screw,for 202328
200437C	15904	Feed Lifting Connection Eccentric Position Screw,for 202307
200459D	15907	Cloth Guide Thumb Screw
200462B	15901	Face Plate Thumb Screw
200475B	15906	Presser Bar Thumb Screw Thumb Set Screw
200492B	15906	" " " " (pressure regulating)
200502B	15901	Arm Shaft Bushing (front) Oil Packing Thumb Screw
200529C	15911	Knee Lifter Rock Lever Rod Set Screw, for 228296
200545C	15904	Feed Driving Connection Hinge Screw
200545C	15904	" Lifting Connection Hinge Screw
200577H	15901	Bed Plate (back) Screw
200577H	15901	Throat Plate Screw
200582H	15907	Thread Guide Screw
200592C	15901	Bobbin Case Tension Spring Screw,for 263108
200596F	15928	Hook Gib Screw,for 263132
200602E	15901	Arm Shaft Connection Belt Pulley Position Screw,for 263009
200625F	15907	Tension Stud with 204925,for 263107
200641C	15904	Feed Bar Hinge Screw (driving), for 206860
200653C	15928	Presser Bar Lifter Hinge Screw
200665C	15904	Feed Regulating Lever Hinge Screw
200842E	15906	Take-up (auxiliary) Screw
200964E	15901	Bobbin Case Latch Stop Screw,for 263109
201007C	15901	Arm Shaft Ball Bearing Collar Set Screw, for 263006
201016F	15901	Bobbin Case Tension Spring Regulating Screw,for 263108
201018C	15907	Hook Shaft Connection Belt Pulley Set Screw,for 263033
201018C	15907	Thread Unwinder Spool Rest Set Screw, for 225257
201499B	10881	Bobbin Winder Tension Stud,for 225461
201518E	15904	Feed Bar Slide Block Hinge Screw Nut, for 203124
201518E	15904	Feed Driving Connection Hinge Screw Nut
201518E	15904	" Lifting Connection Hinge Screw Nut
201522E	15904	" Bar Hinge Screw Nut,for 206860
201531E	15904	" Driving Eccentric Screw Nut,for 263010

NUMERICAL LIST OF PARTS

No.	Plate	Name
201572B	10881	Bobbin Winder Tension Stud Thumb Nut, for 225462
201572B	10881	Tension Thumb Nut,for 263107
201696J	15907	Thread Unwinder Thread Guide Lock Nut, for 225258
202005	15901	Arm Screw Washer
202090	15906	Presser Foot Hinge Pin,for 229864, 263127 and 263130
202135	15901	Face Plate Position Pin,for 263001
202247	15926	Arm Cap
202248	15901	" " Screw Washer
202253	15901	" Shaft Connection Belt Pulley Spring Flange,for 263009
202254	-----	Needle Bar Connecting Link Stud Oil Packing (wick),for 202333
202260	-----	Hook Shaft Oil Packing (wick)(front)
202275	15926	Feed Bar,for 206860
202276	15904	" " Slide Block,for 203124
202277	-----	Bobbin Winder Frame Oil Packing (wick), for 225453
202277	-----	Feed Driving Connection Oil Packing (wick),for 202297
202277	-----	Feed Lifting Connection Oil Packing (wick),for 202306
202277	-----	Take-up Lever Driving Stud Oil Packing (wick),for 202399
202279	15908	Feed Dog,for 263043
202280	15908	" " " 263049
202281	15930	" " " 263054
202282	15908	" " " 203121, 263042, 263044, 263052 and 263053
202283	15908	Feed Dog,for 263048
202287	15930	" " " 263051
202288	15908	" " " 263047
202294	15908	" " " 263046
202297	15927	" Driving Connection with 200054E and 202277
202298	15904	Feed Bar Slide Block Crank with 200038C, for 203124
202298	15904	Feed Driving Connection Crank with 200038C
202302	15925	Knee Lifter Connection Lever Lifting Rod Cotter Pin,for 202447
202303	15927	Feed Driving Rock Shaft,for 206860
202305	15904	" " " " Center
202305	15904	" Lifting Rock Shaft Center
202306	15927	" " Connection with 200054E and 202277
202307	15904	Feed Lifting Connection Eccentric with 200382C and 200437C

NUMERICAL LIST OF PARTS

23

No.	Plate	Name
202308	15927	Feed Lifting Rock Shaft
202324	15928	Hook Shaft Connection Belt Pulley Spring Flange, for 263033
202328	13398	Needle Bar Crank with 200335C, 200428C, 202333 and two 200374C, for 263038
202329	15925	Needle Bar Connecting Stud 206891 with 200086C and 202330, for 263038
202330	-----	Needle Bar Connecting Stud Oil Packing (wick), for 202329
202333	15925	Needle Bar Connecting Link Stud with 202254, for 202328
202335	13398	Presser Bar 244033 with 200074F
202337	15906	" " Position Guide
202338	15906	" " " " Lever with 200086F
202339	15928	Presser Bar Lifter
202346	15906	" " Spring Stop Rod
202355	15906	" " Thumb Screw Thumb Set Screw Packing (brass)
202397	15906	Take-up (auxiliary) Nos. 202398 to 202400, for 263038
202398	10247	Take-up Lever
202399	10247	" " Driving Stud with 202277
202400	10247	" " Hinge Stud with 202423
202404	10247	Tension Release Plunger
202405	15907	" " Washer, for 263107
202407	10881	Bobbin Winder Tension Spring, for 225462
202407	10881	Tension Spring, for 263107
202410	15907	Thread Controller Spring, for 263107
202411	15907	" " " Stop
202412	15907	" Guide
202414	15907	" "
202415	15907	" "
202417	15925	" "
202423	-----	Take-up Lever Hinge Stud Oil Packing (wick), for 202400
202447	13398	Knee Lifter Connection Lever Lifting Rod with 202302, for 244035
202455	15911	Knee Lifter Rock Lever Knee Arm, for 228298
202473	10885	Bobbin Winder Pulley with 200380C, for 225382
202478	10884	Bobbin Winder Stop Latch Trip Lever, for 225382
202490	14363	Thread Unwinder Spool Stand with 200383C for 225258
202924	-----	Presser Foot Shank, for 229864
202970	15908	Feed Dog, for 263045
202996	-----	Presser Foot Shank, for 263130
203009	-----	" " Plate, for 229864

NUMERICAL LIST OF PARTS

No.	Plate	Name
203121	-----	Feed Driving Rock Shaft 20686C with 202282 and two 200106E
203124	-----	Feed Bar Slide Block Crank 202298 with 200205F, 201518E and 202276
203172	15925	Needle Bar Crank Friction Washer
204235	15901	Arm Position Pin
204329	-----	" Shaft Bushing (front) Oil Pad
204329	-----	Hook Shaft Bushing (front) Oil Pad
204925	15907	Tension Stud Washer, for 200625F
206452	15904	Feed Regulating Lever Spring
206608	15906	Presser Bar Lifting Releasing Lever Bracket Spring
206860	-----	Feed Driving Rock Shaft 202303 with 200641C, 201522E and 202275, for 203121
*206891	-----	Needle Bar Connecting Stud, for 202329
207051	15908	Feed Dog, for 263048
207052	15908	" " " 263048
207075	15908	" " " 263050
207966Y	15926	Bed Slide (front)
210536	15928	Hook Gib, for 263132
210734	15901	Bobbin Case Latch Lever, for 210914
210735	15901	" " " Fulcrum Pin, for 210914
210736	15901	Bobbin Case Latch Spring, for 263109
210913	15901	" " " for 210914
210914	-----	" " " 210913 with 210734 and 210735, for 263109
213161	15904	Feed Regulating Lever with 213657
213657	15904	" " " Spring Pin, for 213161
222583	-----	Hook Shaft Oil Packing (wick)(back)
223847	-----	Arm Shaft Bushing (front) Oil Packing (wick), for 263096
224392	-----	Arm Shaft Oil Packing (wick), for 263004
225257	14363	Thread Unwinder Spool Rest (for two spools) (flat) with 201018C, for 225258
225258	14363	Thread Unwinder (for two spools) com- plete, Nos. 201696J, 202490, 225257, 225324, 225326, 225388, two each 150203, 225391 and three wood screws 7/8 in., No. 12
225322	15907	Thread Unwinder Thread Guide Rod Washer, for 225324
225324	14363	Thread Unwinder Thread Guide Rod with 208E and 225322, for 225258
225326	15907	Thread Unwinder Thread Guide Position Cup, for 225258

NUMERICAL LIST OF PARTS

25

No.	Plate	Name
225377	14363	Spool Wire (for small spools)
225381	10884	Bobbin Winder Spindle, for 225382
225382	10885	Universal Bobbin Winder complete, Nos. 200056E, 200082D, 200299H, 202473, 202478, 225381, 225433, 225444, 225453 to 225456, 225458, 225462, 228026, two each 225459 and wood screws 3/4 in., No. 12, R.H.B.
225388	14363	Thread Unwinder Spool Rest Rod, for 225258
225391	14363	Thread Unwinder Thread Guide, for 225258
225433	10885	Bobbin Winder and Tension Bracket Base, for 225382
225438	10884	Bobbin Winder Frame Oil Well Cap, for 225453
225444	10884	Bobbin Winder Stop Latch, for 225382 Nos. 225453 to 225456, for 225382
225453	10884	Bobbin Winder Frame with 202277 and 225438
225454	10884	Bobbin Winder Frame Hinge Pin
225455	10884	" " " Spring
225456	10884	" " " Plunger
225458	10884	" " Stop Latch Thumb Lever, for 225382
225459	10884	Bobbin Winder Stop Latch Thumb Lever Hinge Stud, for 225382
225459	10884	Bobbin Winder Stop Latch Thumb Lever Joint Stud, for 225382
225461	10881	Bobbin Winder Tension Bracket with 201499B, for 225462
225462	10881	Bobbin Winder Tension Bracket complete, Nos. 201572B, 202407, 225461 and two 2102, for 225382
*225482	-----	Bobbin Case Screw Driver Blade, for 225497
*225483	-----	Bobbin Case Screw Driver Handle, for 225497
*225484	-----	Screw Driver Blade, for 225498
*225485	-----	" " Handle, for 225498
225497	14334	Bobbin Case Screw Driver complete, Nos. 225482 and 225483
225498	14334	Screw Driver complete (7-1/4 in. long), Nos. 225484 and 225485
225554	14334	Wrench (steel)
226080	15925	Presser Foot Spring, for 263130
227728	15911	Knee Lifter Rock Lever Rod with 227729, for 228298
*227729	-----	Knee Lifter Rack Lever Rod Cap, for 227728

NUMERICAL LIST OF PARTS

No.	Plate	Name
228026	10884	Bobbin Winder Tension Bracket Screw Washer,for 225382
228212	-----	Drip Pan (short) with four 1 in. wire nails
228284	15911	Knee Lifter Rock Lever Knee Plate with 356C,for 228298
228294	15911	Knee Lifter Rock Lever with two 356C, for 228299
228295	15911	Knee Lifter Rock Lever Bracket with 356C,for 228299
228296	15911	Knee Lifter Rock Lever Extension with 200529C,for 228298
228297	15911	Knee Lifter Rock Lever Hinge Pin,for 228299
228298	15911	Knee Lifter complete,Nos.202455,227728, 228284,228296 and 228299
228299	-----	Knee Lifter Rock Lever Bracket 228295 with 228294 and 228297,for 228298
229664	15906	Presser Foot (hinged) complete,Nos. 202090,202924 and 203009
231337	15907	Cloth Guide
237837	13398	Knee Lifter Connection Lever,for 244035
240034	-----	Thread Retainer
244004	15906	Presser Bar Lifting Releasing Lever Bracket
244033	-----	Presser Bar (hollow),for 202335
244034	13398	Knee Lifter Lifting Lever,for 244035
244035	-----	" " Connection Lever 237837 with 202447,244034 and two 200262H
244048	10247	Tension Disc (back),for 263107
244049	10247	" " (front),for 263107
* 263001	-----	Arm with 202135 and 263003
263003	15901	" Oil Cup,for 263001
263004	15927	" Shaft with 200357E and 224392
263005	-----	" " Ball Bearing,for 263007
* 263006	-----	" " " Collar with 200352C and 201007C,for 263007
263007	15926	Arm Shaft Ball Bearing Collar 263006 with 263005
263008	15926	Arm Shaft Ball Bearing Retainer
263009	15926	" " Connection Belt Pulley with 200327C,200602E and two 202253,for 263010
263010	-----	Arm Shaft Connection Belt Pulley 263009 with 263020,263021,263094,263095, 351845,two each 201531E and 350351C
263011	15927	Balance Wheel (disc)(belt groove 2-1/8 in.diam.) with 200328C and 200335C
* 263012	-----	Bed

NUMERICAL LIST OF PARTS

27

No.	Plate	Name
263013	15926	Bed Plate (back)
263014	15901	Bobbin Case Base,for 263019
263017	15901	" " Stop,for 263042 to 263055
263019	-----	Bobbin Case complete,Nos.263014 and 263109,for 263133 and 263142
263020	15926	Feed Driving Eccentric (indexed) with 263023,for 263010
263021	15926	Feed Driving Eccentric Adjusting Disc, for 263010
263022	15907	Feed Driving Eccentric Friction Washer (obsolete)
263023	15904	Feed Driving Eccentric Roller Stud,for 263020
263024	15907	Feed Driving Eccentric Washer (obsolete)
263029	-----	Hook Shaft Ball Bearing,for 263031
263030	-----	" " " " Collar with two 200383C,for 263031
263031	15926	Hook Shaft Ball Bearing Collar 263030 with 263029
263032	15926	Hook Shaft Ball Bearing Retainer
263033	15926	" " Connection Belt Pulley with 202324 and two 201018C
263034	15926	Hook Washer Needle Guard,for 263132
263035	15926	Needle Bar Connecting Link,for 263038
263036	15926	" " " " Oil Guard
263037	-----	" " " " Oiling Felt
263038	-----	" " Crank 202328 with 202329, 202398 to 202400 and 263035
263039	15926	Presser Bar Bushing
263040	-----	Take-up Lever Oiling Felt
263041	15906	" " " Wick with 263097
263042	15909	Throat Plate,50 needle hole,for needle sizes 14 and 15,with 263017 and two 200136D,for 202282
263043	15909	Throat Plate,50 needle hole,for needle sizes 14 and 15,with 263017 and two 200136D,for 202279
263044	15909	Throat Plate,60 needle hole,for needle sizes 8 and 9,with 263017 and two 200136D,for 202282
263045	15909	Throat Plate,53 needle hole,for needle sizes 12 and 13,with 263017 and two 200136D,for 202970
263046	15909	Throat Plate,53 needle hole,for needle sizes 12 and 13,with 263017 and two 200136D,for 202294
263047	15910	Throat Plate,46 elongated needle hole, for needle sizes 20 and 22,with 263017 and two 200136D,for 202288

NUMERICAL LIST OF PARTS

No.	Plate	Name
263046	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202263, 207051 and 207052
263049	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, grooved for thread back of needle with 263017 and two 200136D, for 202260
263050	15910	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 207075
263051	15929	Throat Plate, 50 needle hole, for needle sizes 14 and 15, with 263017 and two 200136D, for 202287
263052	15929	Throat Plate, 56 needle hole, for needle sizes 10 and 11, with 263017 and two 200136D, for 202262
263053	15929	Throat Plate, 46 needle hole, for needle sizes 16 and 18, with 263017 and two 200136D, for 202282
263054	15929	Throat Plate, 53 needle hole, for needle sizes 12 and 13, with 263017 and two 200136D, for 202281
263055	15929	Throat Plate, 60 needle hole, for needle sizes 8 and 9, with 263017 and two 200136D, for 263125, for Rayon
263091	15927	Face Plate
263094	15904	Feed Driving Eccentric Adjusting Disc Locking Stud, for 263010
263095	15904	Feed Driving Eccentric Adjusting Disc Locking Stud Spring, for 263010
263096	15926	Arm Shaft Bushing (front) with 223847
263097	-----	Take-up Lever Oiling Wick Wire, for 263041
263098	15906	Presser Bar Spring
263099	15901	Bobbin
263105	15927	Arm Shaft Connection Belt
263106	15925	Tension Spring Washer
263107	-----	Tension complete, Nos. 200625F, 201572B, 202405, 202407, 202410, 244048, 244049 and 263106
263108	15901	Bobbin Case Cap with 200592C, 201016F and 263110, for 263109
263109	-----	Bobbin Case Cap complete, Nos. 200964E, 210736, 210914 and 263108, for 263019
263110	15925	Bobbin Case Tension Spring, for 263108
263111	15930	Hemmer Foot, for 3/32 in. hem
263112	15930	" " " 1/8 in. hem
263113	-----	" " " 5/32 in. hem
263114	15930	" " " 3/16 in. hem
263115	15930	" " " 1/4 in. hem

NUMERICAL LIST OF PARTS

29

No.	Plate	Name
263117	15925	Needle Bar Bushing,for 263144
263118	-----	Thread Guide (on needle bar bushing)
263125	15930	Feed Dog,for 263055
263126	-----	Presser Foot Plate,for 263127
263127	15930	Presser Foot (hinged) complete,Nos. 202090,263126 and 263128
263128	-----	Presser Foot Shank,for 263127
263129	-----	" " Plate,for 263130
263130	15930	Presser Foot (hinged) complete,Nos. 202090,202989,202996 and 263129
* 263131	-----	Hook with 263134 and two 462C,for 263132
263132	15928	Hook 263131 with 200145C,210536,263034 and three 200596F,for 263133
263133	-----	Hook and Bobbin Case complete,Nos. 263019 and 263132
263134	-----	Hook Oiling Felt,for 263131
263135	15927	" Shaft with 263139
263136	15926	" " Bushing (front) with 263137 and four 263138
263137	-----	Hook Shaft Bushing (front) Oil Wick,for 263136
263138	-----	Hook Shaft Bushing (front) Oil Plug (wood),for 263136
263139	-----	Hook Shaft Oil Wick,for 263135
263144	-----	Needle Bar Bushing 263117 with 263155
263155	15925	" " with 200141F,for 263144
350344C	15907	Feed Driving Eccentric Screw (obsolete)
350351C	15904	" " " Screw,for 263010
351845	15904	" " " Roller,for 263010

Genuine Singer Needles should be used
in Singer Machines.
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO." 1


Needles in Containers marked
"For Singer Machines"
are not Singer made needles. 2

ILLUSTRATIONS OF PARTS
FOR
MACHINE No. 150w3

ILLUSTRATIONS OF PARTS
FOR
MACHINE NO. 15003

PLATE 10247—FULL SIZE

202398



202399



202401



202405



244048



244049



202407



200081



200161



200132




201572



PLATE 10881—FULL SIZE

225461



200082




202104



2102



225462



202407



201499



201572



PLATE 10884 — FULL SIZE





PLATE 10885--ONE-FOURTH SIZE

225433



202473



225382




PLATE 13398-ONE-HALF SIZE

244034



237837




202447




202335



202275



27739



202328





PLATE 14334—ONE-HALF SIZE

120342



120343

225498



225497



225554




41400



12361



PLATE 14363—ONE-SIXTH SIZE



200010 144 204235 202005

200502

202253

200327 200602 200328

200136 200352 200357

202248

263003

200278

263014

263015

200577

200998

210913 263099

210734 263017

263018 210735 201016 200462

210736 202135 201007

200592 200964

PLATE 15904—FULL SIZE

200641



202276




200545



206452



202298



201518



201522



201531




200437



200054



213161



202307

200038



263095



200205



200382



202305



200106



213657



200043



351845



263023



350351



263094



200665




PLATE 15906—FULL SIZE

263098 263041




200492



244004



202338



202337



202346



229864



200475



202090



202355



200842



200074



202397



206608



200260



PLATE 15907—FULL SIZE






PLATE 15908—FULL SIZE


207051




207052




202283




202279




202280




202294




202282



202970



202288



207075






PLATE 15909--FULL SIZE


263042
263044



263043



263045




263046




PLATE 15910—FULL SIZE


263047



263048



263049



263050




PLATE 15911-ONE-FOURTH SIZE




PLATE 15925 — FULL SIZE

263155



263117




202333




202329



203172



263106



202302



202417



263110



226080



200141



200428



200338



200335



200352



200262




200086




PLATE 15926 — ONE-HALF SIZE


202247



263007



263013



210616




263096



263136




263008




202275



263020




263032



263033



263009



263031



263021




PLATE 15927—ONE-FOURTH SIZE

263004



263135



202303



202308



202297



202306



263091



263011



263105



PLATE 15928 — FULL SIZE


263039



202339



263036



200346




200382



263132



263034



200145



462



263035



202324

200596



200374



200653



210536






PLATE 15929—FULL SIZE


263051



263054



263055



263052
263054





PLATE 15930 — FULL SIZE

263111



263112



263114



263115



263127



263130



202281



202287



263125



Genuine Singer Needles should be used
in Singer Machines.
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"For Singer Machines"
are not Singer made needles. 2

