Form 19021 (936) Printed in U.S.A.

LIST of PARTS



MACHINE No. 17-31

THE SINGER MANUFACTURING COMPANY

From the library of: Superior Sewing Machine & Supply LLC

INSTRUCTIONS FOR OILING

To ensure easy running and prevent unnecessary wear of the parts which are in movable contact, the machine requires oiling and when in continuous use, it should be oiled at least twice each day with Singer Manufacturing Sewing Machine 011 (Cloth and Leather).

> Copyright, U. S. A., 1935 and 1936 by The Singer Manufacturing Co. All Rights Reserved for all Countries

INDEX

Accessories	Page 9
Bobbin Winders	9
Foot Lifter Parts	10
Knee Lifter Parts	11
Machine Base	9
Machine No. 17-31	5
Numerical List of Parts	13
Thread Unwinder	12
Work Guiding Sleeve	12

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

B-Polished, Nickel Plated and Buffed

C-Hardened Only

D-Polished Only

E-Soft, Not Polished

F-Hardened and Polished

F.J-Hardened, Polished and Nickel Plated

G-Bright Rumbled and Nickel Plated

H-Blued

J-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M-Oxidized

N-Japanned, Dull

P-Japanned, Bright

R-Merlized

T-Copper Plated

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed

T.B-Copper and Nickel Plated and Polished

T.J-Copper and Nickel Plated Only

T.K-Hardened, Copper and Nickel Plated

T.M-Copper Plated and Oxidized

T. L-Copper and Brass Plated

U-Zinc Plated

V-Silver Plated

W-Polished and Nickel Plated

Y-Black Nickel Plated Only

Z-Chromium Plated

Z.B-Polished, Nickel Plated, Buffed and Chromium Plated

Z.J-Nickel and Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000 are Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers 1801 to 2000 and 51801 to 52000 are Roller Numbers 2001 to 50000 and 52001 to 140000 and 142001 to 190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at factory.

From the library of: Superior Sewing Machine & Supply LLC

LIST OF PARTS COMPLETE



MACHINE No. 17-31

For Darning Table Linen, Towels, Knit Underwear, etc. Cylinder 17/8 inches diameter. No feeding mechanism. Knee Lifter. Speed 1800 R. P. M.

No.	Plate	Name
*65105		Arm with 4448, 15404, 16717 and two 15405.
4389	20907	" Dowel Pin
4448	20907	" Oil Tube for oiling intermediate
		bearing
123E	20908	Arm Screw
65106	20922	" Shaft
65127		" 65106 with 65107 and 65112
65107	20910	" Counterbalance with 1362C
13620	20908	" " Position Screw
3005	20910	" Bushing (back)
448C	20908	" " " Set Screw
•16717	20910	" " (front)
144D	20908	" Screw
4288	20919	" Side Cover
51224W	20908	" " Thumb Screw
12403	20907	" Spool Pin and Thread Eyelet
8879	20910	" " Washer (cloth)

No.	Plate	Name
16267	20921	Balance Wheel (disc) 2 3/4 in. pulley
		with two 4480
16278	20921	Balance Wheel (disc) 3 in. pulley, for
200.0	20002	clamp stop motion
448C	20908	Balance Wheel Set Screw
256J	20910	Clamp Stop Motion Clamp Screw
248A	20908	" " Stop Screw
2020	20908	" " Washer
*3023		" " Flanged Bushing
4933	20910	" " " 3023 with
4300	20310	two 462C
2022	20907	Clamp Stop Motion Flanged Bushing Pin
462C	20908	" " " Set Screw
3022	20900	
3022		Clamp Stop Motion complete, Nos. 248A, 256J
16718	20921	2020 and 4933
		Cloth Plate
16719	20921	" Bracket with 345C
345C	20907	" " Set Screw
389F	20908	Screw
16695	20919	S11de
3286	20919	Spring
725J	20908	Screw
16720		Cloth Plate complete, Nos. 3286, 16695,
		16718 and two 725J
16721		Cloth Plate with Bracket complete, Nos.
		16719,16720 and two 389F
4292	20909	Crank Connecting Rod with two 145E
145E	20908	cap poraw
375C	20908	Hinge Screw
1518J	20908	Nut
•65108		Cylinder, 1 7/8 in. diam
16723	20921	Face Plate
16881		" " 16723 with 2105
16883		Face Plate complete, Nos. 448C, 460C, 2107,
		2127,12296,16881,16882 and two 233J
164J	20908	Face Plate Screw
2107	20908	" Thread Guard (lower)
233J	20908	" " " " Screw
12296	20908	" " (upper)
460C	20908	" " " Set Screw
65109	20909	Needle Bar (hollow)
*3045	20907	" " Connecting Link
65110		" " " 3045 with
		65111
377C	20907	Needle Bar Connecting Link Hinge Screw
1518J	20908	" " " " Nut
65111	20907	" " Stud with 187E
187E	20907	" " Clamping Screw
290E	20907	" " Screw Bushing
16725	20907	" Thread Eyelet
662J	20907	" " " Screw

No.	Plate	Name
167	8C 20907	Needle Clamping Nut
1672	6 20911	" Plate, large needle hole
1672	7	" small needle hole
123	1D 20911	" " Screw
*602	2 20909	Oscillating Rock Shaft with 4784
1680	6	Oscillating Rock Shaft complete, Nos. 6022
		and 65131
6513	0 20919	Oscillating Rock Shaft Hinge Pin
6513	1	" " " 65130
		with 1513J
151	3J 20907	Oscillating Rock Shaft Hinge Pin Nut
478		" " " Oil Pad (felt)
646	2 20909	" Shaft
•722		" Crank with 219C and
. 22		1813
705	4 20911	Oscillating Shaft Crank with 1813 and
.00		two 462C
204	9 20911	Oscillating Shaft Crank Pin
181		" " Roller and Stud.
21		" " Set Screw, for
21	20000	7225
46	2C 20908	Oscillating Shaft Crank Set Screw, for
40	20000	7054
822	4 20909	Presser Bar
5201		" Lifter
		" " Hinge Screw
68		" " " Nut
152		" Lifting Bracket with 453C
561		" " Set Screw
	3C 20911	
	OE 20907	ocrew bushing
310		opring
207		" " Washer " Stop Collar with 4600
653		" " Set Screw
	00 20908	
•6503		F000
6503		ringer duard
6503	9 20912	Presser Foot with Finger Guard complete, Nos.65037 and 65038
10	01 00011	Presser Foot Screw
	OJ 20911	Pressure Regulating Thumb Screw
	2J 20912 6 20913	Shuttle Bobbin
299	and the second second	" " Case Latch
1514		
297		" " Lever
297	4 20913	
cor	E 00012	Pin
297		Shuttle Bobbin Case Latch Spring
	92E 20913	" " Stop Screw " " Hinge, Nos. 2973, 2974
1514		Hinge, Nos. 2975, 2974
B000	00018	and 15140 Shuttle Bobbin Case Position Finger
3962		" " Rivet
From the	ibrary of	Superior Sewing Machine & Supply LLC
		capanor coming macrimo a cappiy LEO

No.	Plate	Name
40112	20913	Shuttle Bobbin Case complete, Nos. 591F,
		592E, 2523, 2975, 15141, 15278 and
		39623
16614	20913	Shuttle Body
591F	20913	" Tension Regulating Screw
15278	20913	Spring
16735	20913	1 1/2 in.diam., Nos. 2996, 16614
		and 40112
16736	20914	Shuttle Driver
2049	20911	Pin
16838	20914	Race
16738	20914	Cover
979D	20914	Hinge Screw
50258J	20914	Screw
2102	20912	Tension Disc
1560C	20912	" Regulating Thumb Nut
600C	20912	" Screw Stud
16202		" " 600C with 1560C
448C	20908	" " Set Screw
10148	20912	" Spring
2105	20912	" Thread Guard
16882		Tension complete, Nos. 10148, 16202, 16766
		and two 2102
•65112		Thread Take-up Cam
65113	20919	" " 65112 with 446C
3012	20907	" " Pin
446C	20907	" " Set Screw
•16740	20912	" Lever with 1819
65034		" " 16740 with 1088C
1088C	20915	" " Hinge Screw
1819	20915	" " Roller and Stud
16766	20915	" " Spring
2127	20915	" " Regulator Plate
233J	20908	" " " " "
		Adjusting Screw
6053	20921	Drip Pan
•15404		Trade Mark
15405		" " Rivet

Genuine Singer Needles should be used in Singer Machines. These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO." 1

> Needles in Containers marked "For Singer Machines" are not Singer made needles.

MACHINE BASE

No.	Plate	Name
7169	20922	Machine Base with four each 6055,51070E
		and wood screws 1 in. No. 12
51070E	20915	Machine Bolt with 51581E, to secure ma-
		chine to base
51581E	20915	Machine Bolt Nut
6055	20915	" Washer

ACCESSORIES

No.	Plate	Name
51072E	20915	Machine Bolt with 51581E, to secure ma-
		chine to table
51581E	20915	Machine Bolt Nut
6055	20915	" " Washer
120342	20920	Oiler (copper plated) with 120343
120343	20920	" Spout, 3 1/2 in. long
26026	20920	Screw Driver (machine)
26485	20920	" (shuttle tension)
8908	20920	Wrench for 1520
4347	20920	" " 1513 and 1518
19079	20920	" " 1678

BOBBIN WINDERS

BOBBIN WINDER

(SWINGING AUTOMATIC, RIGHT HAND)

No.	Plate	Name
27540	20917	Base
15072	20915	Bobbin Position Pin
27302	20917	Frame
50356D	20915	" Hinge Screw
1620J	20915	" " Nut
27303	20915	" Spring
27541	20917	Pulley
•27849		Spindle
27538	20917	" 27849 with 15072,27850 and 41828.
*27850		" Collar
41828	20915	" " Pin
27306	20917	Spool Pin
150534	20917	" Stand

No.	Plate	Nome
NO.	Flace	Name
150535	20917	Spool Stand complete, Nos. 418E, 1562J, 2106
		10141,11241,27306,150534 and two
		each 2455 and wood screws 1 in. No.
		10
11241	20917	Spool Washer (cloth)
27312	20917	Stop Latch
35D	20915	" " Hinge Screw
2455	20915	Tension Disc
1562J	20915	" Regulating Thumb Nut
418E	20915	" Screw Stud
10141	20915	" Spring
2106	20915	" Thread Guide
27647	20917	Bobbin Winder, Nos. 35D, 1620J, 27302, 27303,
		27312,27538,27540,27541,50356D and
		two wood screws 1 in. No. 7
150536		Bobbin Winder (swinging automatic, right
		hand) complete, Nos. 27647 and 150535
		,

BOBBIN WINDER

(LOOSE WHEEL)

No.	Plate	Name
2466	20916	Eccentric
51224W	20908	" Thumb Screw
5526	20919	Frame
2460	20916	Friction Ring (rubber)
2461	20916	Pulley
2852		Spindle for Bobbin
2846		" " Spool
2853	20919	" 2852 with 2846
5533	20919	Bobbin Winder complete, Nos. 2460, 2461,
		2466,2853,5526 and 51224W
1489J	20916	Bobbin Winder Screw

FOOT LIFTER PARTS

Plate	Name
	Chain, 36 in. to 45 in. with 56864 and
	56865
te: Whe	en ordering 6439, state length required.
20918	Chain Connecting Link, for 4885
20918	" Hook (large)
20918	" " (small)
20922	Lifting Lever
20916	" Hinge Screw
	te: Whe 20918 20918 20918 20922

No.	Plate	Name
16659	20909	Lifting Lever Spring
5612	20911	Presser Bar Lifting Bracket with 453C
453C	20911	" " " Set Screw
4881	20921	Treadle
4882	20918	" Shaft
4883	20918	" Spring
4884	20921	" Stand
4885	20921	Treadle complete, Nos. 4879, 4881 to 4884
		and two wood screws 1 in. No. 16
6346		Foot Lifter complete, Nos. 802D, 4885, 5612,
		6439,7170 and 16659

KNEE LIFTER PARTS

No.	Plate	Name
7170	20922	Lifting Lever
802D	20916	" " Hinge Screw
16659	20909	" " Spring
6333	20922	Pitman
5612	20911	Presser Bar Lifting Bracket with 453C
453C	20911	" " " Set Screw
2763	20922	Rock Shaft
6334	20922	" " Hanger with two wood screws 1
		in. No. 10
16646	20922	Rock Shaft Knee Arm
16647		Rock Shaft Knee Arm complete, Nos. 2766,
		2767 and 16646
2766	20922	Rock Shaft Knee Arm Hub with 356C
356C	20916	" " " Set Screw
2767	20922	" " Plate with 356C
356C	20916	" " " Set Screw
6337	20922	" " Lifting Bracket with two 3560
6338	20922	" " Hook
356C	20916	" " " Set Screw
356C	20916	" " Set Screw
2770	20922	" Stop Dog with 356C
356C	20916	" " Set Screw
6339	20922	Rock Shaft complete, Nos. 2763, 2770, 6337,
		6338,16647 and two 6334
6332		Knee Lifter complete (power table or stand) Nos.802D,5612,6333,6339,7170 and 16659

THREAD UNWINDER

FOR ONE LARGE SPOOL OR ONE LARGE CONE OF THREAD

No.	Plate	Name
225259	8405	Spool Rest with 201018C
150203	8405	" Cushion (felt)
225388	8405	" " Rod
2003830	20916	" " Set Screw
2010180	20916	" Set Screw
202490	8405	" Stand with 200383C
225391	8405	Thread Guide
201696J	20916	" Lock Nut
225326	20916	" Position Cup
225324	8405	" Rod with 208E and 225322
208E	20916	" - " " Screw
225322	20916	" " Washer
225260	8405	Thread Unwinder complete, Nos. 150203,
		201696J, 202490, 225259, 225324, 225326
		225388,225391 and three wood screws
		7/8 in. No. 12
27739	8405	Thread Cone (wood) for large cones
225390	8405	" Holder for inverted cones
No	te: Nos	. 27739 and 225390 are used with, but not
		ed in 225260.

WORK GUIDING SLEEVE

No.	Plate			Name		
121166	20921	Work	Guiding	Sleeve	with	50379C
50379C	20907	. 11	"	11	Stop	Screw

Genuine Singer Needles should be used in Singer Machines. These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO." 1

> Needles in Containers marked "For Singer Machines" are not Singer made needles.

FOR MACHINE No. 17-31

NUMERICAL LIST OF PARTS

No.	Plate	Name
35D	20915	Bobbin Winder Stop Latch Hinge Screw, for
		27647
123E	20908	Arm Screw
144D	20908	" Shaft Screw
145E	20908	Crank Connecting Rod Cap Screw, for 4292.
164J	20908	Face Plate Screw
187E	20907	Needle Bar Connecting Stud Clamping
		Screw, for 65111
190J	20911	Presser Foot Screw
208E	20916	Thread Unwinder Thread Guide Rod Screw,
2002	20010	for 225324
2190	20908	Oscillating Shaft Crank Set Screw, for
2100	2,0000	7225
233J	20908	Face Plate Thread Guard (lower) Screw,
2000	20300	for 16883
0771	20908	Thread Take-up Spring Regulator Plate
233J	20900	
248A	00000	Adjusting Screw
240A	20908	
0507	00010	3022
256J	20910	Clamp Stop Motion Clamp Screw, for 3022.
262J	20912	Pressure Regulating Thumb Screw
290E	20907	Needle Bar Screw Bushing
290E	20907	Presser Bar Screw Bushing
345C	20907	Cloth Plate Bracket Set Screw, for 16719
356C	20916	Rock Shaft Knee Arm Hub Set Screw, for
		2766
356C	20916	Rock Shaft Knee Plate Set Screw, for 2767
356C	20916	" Lifting Bracket Hook Set
		Screw, for 6337
356C	20916	Rock Shaft Lifting Bracket Set Screw, for
		6337
356C	20916	Rock Shaft Stop Dog Set Screw, for 2770.
375C	20908	Crank Connecting Rod Hinge Screw
377C	20907	Needle Bar Connecting Link Hinge Screw
389F	20908	Cloth Plate Bracket Screw, for 16721
418E	20915	Bobbin Winder Tension Screw Stud, for
		150535
446C	20907	Thread Take-up Cam Set Screw, for 65113.
448C	20908	Arm Shaft Bushing (back) Set Screw
448C	20908	Balance Wheel Set Screw, for 16267
448C	20908	Tension Screw Stud Set Screw, for 16883.
453C	20911	Presser Bar Lifting Bracket Set Screw,
		for 5612
460C	20908	Presser Bar Stop Collar Set Screw, for
		6533
460C	20908	Face Plate Thread Guard (upper) Set
		Screw, for 16883
462C	20908	Clamp Stop Motion Flanged Bushing Set
 177		Screw for 4933

No.	Plate	Name
462C	20908	Oscillating Shaft Crank Set Screw, for
		7054
591F	20913	Shuttle Tension Regulating Screw, for
		40112
592E	20913	Shuttle Bobbin Case Latch Stop Screw, for
		40112
600C	20912	Tension Screw Stud, for 16202
662J	20907	Needle Bar Thread Eyelet Screw
689C	20911	Presser Bar Lifter Hinge Screw
725J	20908	Cloth Plate Slide Spring Screw, for 16720
802D	20916	Lifting Lever Hinge Screw, for 6332 and
		6346
979D	20914	Shuttle Race Cover Hinge Screw
1088C	20915	Thread Take-up Lever Hinge Screw, for
		65034
1231D	20911	Needle Plate Screw
1362C	20908	Arm Shaft Counterbalance Position Screw,
		for 65107
1489J	20916	Bobbin Winder Screw, for 5533
1513J	20907	Oscillating Rock Shaft Hinge Pin Nut, for
20200	2000.	65131
1518J	20908	Crank Connecting Rod Hinge Screw Nut
1518J	20908	
10100	20300	Needle Bar Connecting Link Hinge Screw
1520J	20911	Nut
1560C	20911	Presser Bar Lifter Hinge Screw Nut
1562J		Tension Regulating Thumb Nut, for 16202.
19920	20915	Bobbin Winder Tension Regulating Thumb
10007	00015	Nut, for 150535
1620J	20915	Bobbin Winder Frame Hinge Screw Nut, for
		27647
1678C	20907	Needle Clamping Nut
1813	20911	Oscillating Shaft Crank Roller and Stud,
		for 7054 and 7225
1819	20915	Thread Take-up Lever Roller and Stud, for
No. of the last of		16740
2020	20908	Clamp Stop Motion Clamp Washer, for 3022.
2022	20907	" " Flanged Bushing Pin
2049	20911	Oscillating Shaft Crank Pin
2049	20911	Shuttle Driver Pin
2070	20911	Presser Bar Spring Washer
3103	20912	Tension Disc, for 16882
2105	20912	" Thread Guard, for 16881
2106	20915	Bobbin Winder Tension Thread Guide, for
		150535
2107	20908	Face Plate Thread Guard (lower) for
		16883
2127	20915	Thread Take-up Spring Regulator Plate.
		for 16883
2455	20915	Bobbin Winder Tension Disc, for 150535
2460	20916	" Friction Ring (rubber) for
		5533

No.	Plate	Name
2466	20916	Bobbin Winder Eccentric, for 5533
2523	20913	Shuttle Bobbin Case Position Finger Riv-
		et, for 40112
2763	20922	Rock Shaft, for 6339
2766	20922	" Knee Arm Hub with 356C, for
		16647
2767	20922	Rock Shaft Knee Plate with 356C, for
		16647
2770	20922	Rock Shaft Stop Dog with 3560, for 6339.
2846		Bobbin Winder Spindle, for spool, for 2853
2852		
2002		0000111,101
2853	20919	2853
2000	20313	Bobbin Winder Spindle 2852 with 2846, for
2973	00017	5533
2910	20913	Shuttle Bobbin Case Latch Lever, for
0004		15141
2974	20913	Shuttle Bobbin Case Latch Lever Fulcrum
		Pin, for 15141
2975	20913	Shuttle Bobbin Case Latch Spring, for
		40112
2996	20913	Shuttle Bobbin, for 16735
3005	20910	Arm Shaft Bushing (back)
3012	20907	Thread Take-up Cam Pin
3022		Clamp Stop Motion complete, Nos. 248A, 256J
		2020 and 4933
*3023		Clamp Stop Motion Flanged Bushing, for
		4933
*3045	20907	Needle Bar Connecting Link, for 65110
3100	20912	Presser Bar Spring
3286	20919	Cloth Plate Slide Spring, for 16720
4288	20919	Arm Side Cover
4292	20909	Crank Connecting Rod with two 145E
4347	20920	Wrench for 1513 and 1518 (Accessories)
4389	20907	Arm Dowel Pin
4448	20907	" Oil Tube for oiling intermediate
	2000	bearing, for 65105
4784	20907	Oscillating Rock Shaft Oil Pad (felt)
	20001	for 6000
4879	20918	for 6022
4881	20921	Chain Connecting Link, for 4885
4882	20918	Treadle, for 4885
4883	20918	" Shaft, for 4885
4884		" Spring, for 4885
	20921	" Stand, for 4885
4885	20921	Treadle complete for 6346, Nos. 4879, 4881
		to 4884 and two wood screws 1 in.
1000		No. 16
4933	20910	Clamp Stop Motion Flanged Bushing 3023
		with two 4620, for 3022
5526	20919	Bobbin Winder Frame, for 5533
5533	20919	Bobbin Winder complete, Nos. 2460, 2461,
		2466 2853 5506 and 5100411

No.	Plate	Name
5612	20911	Presser Bar Lifting Bracket with 453C,
		for 6332 and 6346
*6022	20909	Oscillating Rock Shaft with 4784, for
		16806
6053	20921	Drip Pan
6055	20915	Machine Bolt Nut Washer, for 7169
6332	20310	Knife Lifter complete (power table or
0000		stand) Nos.802D,5612,6333,6339,7170
		and 16659
6333	20922	Pitman, for 6332
6334	20922	Rock Shaft Hanger with two wood screws 1
		in. No. 10, for 6339
6337	20922	Rock Shaft Lifting Bracket with two 356C
		for 6339
6338	20922	Rock Shaft Lifting Bracket Hook, for 6339
6339	20922	Rock Shaft complete for 6332, Nos. 2763,
		2770,6337,6338,16647 and two 6334
6346		Foot Lifter complete, Nos. 802D, 4885, 5612,
		6439,7170 and 16659
6439		Chain, 36 in. to 45 in., with 56864 and
0400		56865, for 6346
6462	20909	Oscillating Shaft
6533	20909	Presser Bar Stop Collar with 460C
7054	20911	Oscillating Shaft Crank with 1813 and
72.00	00000	two 462C
7169	20922	Machine Base with four each 6055,51070E
		and wood screws 1 in. No. 12
7170	20922	Lifting Lever, for 6332 and 6346
•7225		Oscillating Shaft Crank with 219C and
		1813
8224	20909	Presser Bar
8879	20910	Arm Spool Pin Washer (cloth)
8908	20920	Wrench for 1520 (Accessories)
10141	20915	Bobbin Winder Tension Spring, for 150535.
10148	20912	Tension Spring, for 16882
11241	20917	Bobbin Winder Spool Washer (cloth) for
		150535
12296	20908	Face Plate Thread Guard (upper) for
		16883
12403	20907	Arm Spool Pin and Thread Eyelet
15072	20915	Bobbin Winder Bobbin Position Pin, for
		27538
15140	20913	Shuttle Bobbin Case Latch, for 15141
15141	20310	" " Hinge, Nos. 2973, 2974
10141		and 15140, for 40112
15278	20913	Shuttle Tension Spring, for 40112
• 15404	20913	Trade Mark, for 65105
15404		" Rivet, for 65105
16202		Tension Screw Stud 6000 with 15600, for
		16882

27.0	Diete	240
No.	Plate	Name
16278	20921	Balance Wheel (disc) 3 in. pulley, for clamp stop motion
16614	20913	Shuttle Body, for 16735
16646	20922	Rock Shaft Knee Arm, for 16647
16647		Rock Shaft Knee Arm complete for 6339,
10047	and the second	Nos.2766,2767 and 16646
16659	20909	Lifting Lever Spring, for 6332 and 6346.
16695	20919	
•16717	20919	Cloth Plate Slide, for 16720
	20910	Cloth Plate, for 16720
16718 16719	20921	" Bracket with 3450, for 16721.
16720		Cloth Plate complete, Nos. 3286, 16695,
10720		16718 and two 725J, for 16721
16721		Cloth Plate with Bracket complete, Nos.
10/21		16719,16720 and two 389F
16723	20921	Face Plate, for 16881
16725	20907	Needle Bar Thread Eyelet
16726	20907	
16727	20911	" Plate, large needle hole " small needle hole
16735	20913	Shuttle, 1 1/2 in.diam., Nos. 2996, 16614
10700	20313	and 40112
16736	20914	Shuttle Driver
16738	20914	" Race Cover
•16740	20912	Thread Take-up Lever with 1819, for 65034
16766	20915	" " Spring, for 16882
16806		Oscillating Rock Shaft complete, Nos. 6022
10000		and 65131
16838	20914	Shuttle Race
16881		Face Plate 16723, with 2105, for 16883
16882		Tension complete, Nos. 10148, 16202, 16766
		and two 2102, for 16883
16883		Face Plate complete, Nos. 448C, 460C, 2107,
		2127,12296,16881,16882 and two 233J
19079	20920	Wrench for 1678 (Accessories)
26026	20920	Screw Driver (machine) Accessories
26485	20920	" (shuttle tension) Accesso-
		ries
27302	20917	Bobbin Winder Frame, for 27647
27303	20915	" " Spring, for 27647
27306	20917	" Spool Pin, for 150535
27312	20917	" " Stop Latch, for 27647
27538	20917	Bobbin Winder Spindle 27849 with 15072,
		27850 and 41828, for 27647
27540	20917	Bobbin Winder Base, for 27647
27541	20917	" Pulley, for 27647
27647	20917	Nos.35D, 1620J, 27302, 27303,
		27312,27538,27540,27541,50356D and
		two wood screws 1 in. No. 7, for
ORGEO	0405	150536
27739	8405	Thread Unwinder Thread Cone (wood) for
		large cones

No.	Plate	Name
•27850		Bobbin Winder Spindle Collar, for 27538.
39623	20913	Shuttle Bobbin Case Position Finger, for 40112.
40112	20913	Shuttle Bobbin Case complete, Nos. 591F,
		592E,2523,2975,15141,15278 and
		39623, for 16735
41828	20915	Bobbin Winder Spindle Collar Pin, for 27538
50258J	20914	Shuttle Race Screw
50356D	20915	Bobbin Winder Frame Hinge Screw, for 27647
503790	20907	Work Guiding Sleeve Stop Screw, for 121166
51070E	20915	Machine Bolt with 51581E, to secure ma-
		chine to base, for 7169
51072E	20915	Machine Bolt with 51581E, to secure ma- chine to table (Accessories)
51224W	20908	Arm Side Cover Thumb Screw
51224W	20908	Bobbin Winder Eccentric Thumb Screw, for 5533
51581E	20915	Machine Bolt Nut, for 51070E and 51072E.
52016	20911	Presser Bar Lifter
56864	20918	Chain Hook (large) for 6439
56865	20918	" (small) for 6439
65034		Thread Take-up Lever 16740 with 1088C
•65037		Presser Foot, for 65039
65038	20912	" Finger Guard, for 65039
65039	20912	Presser Foot with Finger Guard complete,
		Nos. 65037 and 65038
•65105		Arm with 4448,15404,16717 and two 15405.
65106	20922	" Shaft, for 65127
65107	20910	6512765127
*65108		Cylinder, 1 7/8 in. diam
65109	20909	Needle Bar (hollow)
65110		" Connecting Link 3045, with 65111
65111	20907	Needle Bar Connecting Stud with 187E, for 65110
•65112		Thread Take-up Cam, for 65113 and 65127
65113	20919	" " 65112 with 4460
65127		Arm Shaft 65106 with 65107 and 65112
65130	20919	Oscillating Rock Shaft Hinge Pin, for 65131
65131		Oscillating Rock Shaft Hinge Pin 65130 with 1513J, for 16806
120342	20920	Oiler (copper plated) with 120343 (Ac-
120343	20920	cessories) Oiler Spout, 3 1/2 in. long, for 120342
		(Accessories)
121166	20921	Work Guiding Sleeve with 50379C
From the libra	ary of:	Work Guiding Sleeve with 50379C


No.	Plate	Name
150203	8405	Thread Unwinder Spool Rest Cushion (felt)
		for 225260
150534	20917	Bobbin Winder Spool Stand, for 150535
150535	20917	Bobbin Winder Spool Stand complete, Nos.
1		418E,1562J,2106,10141,11241,27306, 150534 and two each 2455 and wood
		screws 1 in. No. 10, for 150536
150536		Bobbin Winder (swinging automatic, right hand) complete, Nos.27647 and 150535
2003830	20916	Thread Unwinder Spool Rest Rod Set Screw, for 202490
201018C	20916	Thread Unwinder Spool Rest Set Screw, for 225259
201696J	20916	Thread Unwinder Thread Guide Lock Nut, for
202490	8405	225260
202490	0405	for 225260
225259	8405	Thread Unwinder Spool Rest with 201018C,
		for 225260
225260	8405	Thread Unwinder complete, Nos. 150203,
		201696J,202490,225259,225324,225326,
		225388,225391 and three wood screws 7/8 in. No. 12
225322	20916	Thread Unwinder Thread Guide Rod Washer,
225002	~~~~	for 225324
225324	8405	Thread Unwinder Thread Guide Rod with
		208E and 225322, for 225260
225326	20916	Thread Unwinder Thread Guide Position Cup for 225260
225388	8405	Thread Unwinder Spool Rest Rod, for 225260
225390	8405	" Thread Cone Holder, for
225391	8405	inverted cones
220031	0400	THE OLD ONWINGS THE OLD GUILD, TOT ENDEDO.

Genuine Singer Needles should be used in Singer Machines. These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"For Singer Machines"
are not Singer made needles.


FOR MACHINE No. 17-31

PLATE 8405-ONE-FOURTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE 20907 - FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC






PLATE 20909 - ONE-HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC


PLATE 20911 - FULL SIZE




From the library of: Superior Sewing Machine & Supply LLC

From the library of: Superior Sewing Machine & Supply LLC

PLATE 20913 - FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC






PLATE 20916 - FULL SIZE









PLATE 20917 - ONE-HALF SIZE








PLATE 20919 - ONE-HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC

PLATE 20920 - ONE-HALF SIZE




From the library of: Superior Sewing Machine & Supply LLC

PLATE 20921 - ONE-FOURTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE 20922 - ONE-FOURTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

Genuine Singer Needles should be used in Singer Machines. These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO."

Needles in Containers marked
"For Singer Machines"
are not Singer made needles.

From the library of: Superior Sewing Machine & Supply LLC

Genuine Singer Needles should be used in Singer Machines. These Needles and their Containers are marked with the Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"For Singer Machines"
are not Singer made needles.

2



