

Form 20948

(1157)

Printed in U.S.A.

LIST OF PARTS



SINGER^{**}

MACHINE No. 253-212

THE SINGER MANUFACTURING COMPANY

From the library of: Superior Sewing Machine & Supply LLC

** A Trademark of THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

Before starting the machine, fill the oil reservoir in the base to the HIGH MARK with TYPE A or TYPE C OIL, sold by Singer Sewing Machine Company, as instructed in Form 20748

TYPE C OIL is to be used, when an oil is desired which will produce a minimum of stain on fabrics, even after a long period of storage.

The reservoir holds approximately 1-1/2 pints.

When in operation, the oil level in the reservoir should be frequently inspected to keep it from going below the LOW MARK in the reservoir. Refill to HIGH MARK with TYPE A or TYPE C OIL.

INDEX

	Page
Accessories.....	21
Belt Guard (Hinged).....	21
Face Plate Thread Lubricator.....	22
Foot Lifter Parts.....	22
Knee Lifter Parts	23
Machine No. 253-212.....	7
Numerical List of Parts.....	25
Thread Unwinder (For Four Spools).....	23

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A—Hardened, Polished, Nickel Plated and Buffed
- B—Polished, Nickel Plated and Buffed
- C—Hardened Only
- D—Polished Only
- E—Soft, Not Polished
- F—Hardened and Polished
- G—Bright Rumbled and Nickel Plated
- H—Blued
- J—Nickel Plated Only
- K—Hardened and Nickel Plated
- L—Brass Plated
- M—Oxidized
- R—Phosphate Coating Formed on Surface of Iron or Steel
- S—Cadmium Plated
- T—Copper Plated
- U—Zinc Plated
- V—Silver Plated
- W—Polished and Nickel Plated
- X—Black Oxide for Iron and Steel
- Y—Black Nickel Plated Only
- Z—Chromium Plated
- A.A—Buffed and Chromium Plated
- A.B—Hardened, Polished, Buffed and Chromium Plated
- A.E—Hardened, Bright Rumbled and Nickel Plated
- A.F—Hardened, Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated
- A.G—Alumilite (Plain)
- A.H—Alumilite (Dyed) Color Must be Stated
- A.J—Polished, Nickel Plated and Chromium Plated
- A.K—Hardened, Polished, Nickel Plated and Chromium Plated
- A.L—Heat Treated for Toughness
- A.L.D—Heat Treated for Toughness and Polished
- A.L.X—Heat Treated for Toughness and Black Oxide

INSTRUCTIONS FOR ORDERING

- A.S—Black Moulded Phenolic
- A.T—Beige Moulded Phenolic
- A.U—Brown Moulded Phenolic
- A.W—Hardened then Flame Coated with Tungsten Carbide
- B.A—Chrome Nickel Satin Finish
- B.B—Hardened and Chrome Nickel, Satin Finished
- C.R—Hardened and Phosphate Coating Formed on Surface of Steel
- F.J—Hardened, Polished and Nickel Plated
- T.A—Hardened, Polished, Copper and Nickel Plated and Buffed
- T.B—Copper and Nickel Plated and Polished
- T.J—Copper and Nickel Plated Only
- T.K—Hardened, Copper and Nickel Plated
- T.L—Copper and Brass Plated
- T.M—Copper Plated and Oxidized
- X.C—Hardened and Black Oxide for Iron and Steel
- Z.A—Hardened, Polished Nickel Plated, Buffed and Chromium Plated
- Z.B—Polished, Nickel Plated, Buffed and Chromium Plated
- Z.C—Hardened and Chromium Plated
- Z.D—Polished and Chromium Plated
- Z.G—Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Plated
- Z.J—Nickel and Chromium Plated
- Z.T—Copper and Chromium Plated

These letters **MUST BE USED** when they appear in the list; and **AFTER** the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142,000 are screw numbers

1501 to 1800 and 51500 to 51800 are nut numbers

1801 to 2000 and 51801 to 52000 are roller numbers

2001 to 50000 and 52001 to 140000 and 142001 to 190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are **NOT TO BE USED** in ordering.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.


When ordering parts which differ as to gauge (the distance between seams), the gauge as well as the number must be given on the order.

SINGER Needles should be used
in SINGER Machines
These Needles and their Containers
are marked with the
Company's Trademark "SIMANCO" 1

Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles 2

LIST OF PARTS COMPLETE FOR

7



MACHINE No. 253-212

For Seat Seaming Medium and Medium Heavy Trousers.
Two Needles, Two Loopers. Needles Set Tandem 3/16 in.
Apart. Length of Stitches 6 to 20 to the inch. Needle
Bar Stroke 1 5/16 in.

No.	Plate	Name
*146863	-----	Arm.....
NOTE: When ordering No. 146863, state color required.		
16532	25037	Arm Dowel Pin (2).....
146552	25037	Arm Screw (front) (2).....
146551	25037	Arm Screw Stud (back) (2).....
146865	25107	Arm Shaft (horizontal) with 1036AL, 140542AL and 140552AL.....
146866	-----	Arm Shaft (horizontal) 146865 with 146581
146864	25107	Arm Shaft (horizontal) Bevel Gear, right hand spiral with 140333AL and two 1259AL.....
140333AL	25107	Arm Shaft (horizontal) Bevel Gear Position Screw
1259AL	25107	Arm Shaft (horizontal) Bevel Gear Set Screw (2)
143008	25107	Arm Shaft (horizontal) Bushing (center)..
140296AL	25107	Arm Shaft (horizontal) Bushing (center) Set Screw
147112	25107	Arm Shaft (horizontal) Flanged Bushing (back).....

No.	Plate	Name
146790	25107	Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube with Holder.....
207E	25107	Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube Holder Screw....
140296AL	25107	Arm Shaft (horizontal) Flanged Bushing (back) Set Screw.....
146672	25107	Arm Shaft (horizontal) Flanged Bushing (front).....
140331AL	25107	Arm Shaft (horizontal) Flanged Bushing (front) Set Screw.....
144D	25107	Arm Shaft (horizontal) Screw (back)
140359E	25107	Arm Shaft (horizontal) Screw Plug(front).
143236	25107	Arm Shaft (horizontal) Screw Plug(front). Washer (fiber).....
146661	25107	Arm Shaft (upright)
143015	25107	Arm Shaft (upright) Bevel Gear (lower) left hand spiral with two 1259AL.....
1259AL	25107	Arm Shaft (upright) Bevel Gear (lower) Set Screw (2)
143015	25107	Arm Shaft (upright) Bevel Gear (upper) left hand spiral with two 1259AL.....
1259AL	25107	Arm Shaft (upright) Bevel Gear (upper) Set Screw (2)
146505	25107	Arm Shaft (upright) Bushing (lower)
140298AL	25107	Arm Shaft (upright) Bushing (lower) Set Screw
147111	25107	Arm Shaft (upright) Bushing (upper)
140298AL	25107	Arm Shaft (upright) Bushing (upper) Set Screw.....
146867	25074	Arm Top Cover.....
	NOTE:	When ordering No. 146867, state color required.
146868	25074	Arm Top Cover and Stitch Regulator Cap .
	NOTE:	When ordering No. 146868, state color required.
146869	25074	Arm Top Cover with Stitch Regulator Cap complete, Nos. 335X, 146868, 146870 and 146871
146870	25074	Arm Top Cover and Stitch Regulator Cap Gasket.....
146871	25074	Arm Top Cover and Stitch Regulator Cap Latch.....
335X	25074	Arm Top Cover and Stitch Regulator Cap Latch Screw
146508	25074	Arm Top Cover Gasket
51369R	25074	Arm Top Cover Screw (4).....
146872	25108	Attachment Slide.....
146873	25108	Attachment Slide complete, Nos. 51282X, 146872 and 146874.....
146874	25108	Attachment Slide Spring.....
51282X	25108	Attachment Slide Spring Screw.....

No.	Plate	Name
*146876	-----	Bed with 146570 and two each 126150 and 140734E.....
NOTE: Due to the accuracy required for gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.		
143024	25107	Bed Hole Plug
146514	25037	Bed Leg (back)
965E	25037	Bed Leg (back) Screw (2)
146877	25037	Bed Leg (front, long).....
146516	25073	Bed Rotary Shaft
146650	-----	Bed Rotary Shaft 146516 with 146558
146517	25073	Bed Rotary Shaft Bevel Gear, right hand spiral with two 1259AL
1259AL	25073	Bed Rotary Shaft Bevel Gear Set Screw (2)
146518	25073	Bed Rotary Shaft Bushing (back)
50554AL	25073	Bed Rotary Shaft Bushing (back) Set Screw
146519	25073	Bed Rotary Shaft Bushing (front).....
50554AL	25073	Bed Rotary Shaft Bushing (front) Set Screw
146520	25073	Bed Rotary Shaft Bushing (intermediate)..
448AL	25073	Bed Rotary Shaft Bushing (intermediate) Set Screw
64342	25073	Bed Rotary Shaft Collar with 454AL.....
454AL	25073	Bed Rotary Shaft Collar Set Screw
146521	25041	Bed Slide (left)
4307	25041	Bed Slide (left) Spring
725X	25041	Bed Slide (left) Spring Screw (2).....
146522	25041	Bed Slide (left) complete, Nos. 4307, 146521 and two 725X
146006	25108	Bed Slide (right, button type) for 146007..
146523	-----	Bed Slide (right, button type) for 146526..
146834	-----	Bed Slide (right, button type) for 146835..
146848	-----	Bed Slide (right, button type) for 146846..
146849	-----	Bed Slide (right, button type) for 146847..
146061	25108	Bed Slide (right, latch type) for 146062...
146687	-----	Bed Slide (right, latch type) for 146692...
146722	-----	Bed Slide (right, latch type) for 146723...
146820	-----	Bed Slide (right, latch type) for 146821...
146827	-----	Bed Slide (right, latch type) for 146828...
146007	25108	Bed Slide (right, button type) complete for Throat Plates with no off-set, Nos. 1423X, 146006, 146524, 146525 and two 240C
146526	-----	Bed Slide (right, button type) complete for Throat Plates with 3/64 in. off-set, Nos. 1423X, 146523, 146524, 146525 and two 240C
146835	-----	Bed Slide (right, button type) complete for Throat Plates with 3/32 in. off-set, Nos. 1423X, 146524, 146525, 146834 and two 240C

No.	Plate	Name
146846	-----	Bed Slide (right, button type) complete for Throat Plates with 9/64 in. off-set, Nos. 1423X, 146524, 146525, 146848 and two 240C.....
146847	-----	Bed Slide (right, button type) complete for Throat Plates with 3/16 in. off-set, Nos. 1423X, 146524, 146525, 146849 and two 240C.....
146062	25108	Bed Slide (right, latch type) complete for Throat Plates with no off-set, Nos. 146061, 146688, 146689, 146690, 146691 and four 1470X.....
146692	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/64 in. off-set, Nos. 146687, 146688, 146689, 146690, 146691 and four 1470X.....
146828	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/32 in. off-set, Nos. 146688, 146689, 146690, 146691, 146827 and four 1470X.....
146723	-----	Bed Slide (right, latch type) complete for Throat Plates with 9/64 in. off-set, Nos. 146688, 146689, 146690, 146691, 146722 and four 1470X.....
146821	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/16 in. off-set, Nos. 146688, 146689, 146690, 146691, 146820 and four 1470X.....
146525	-----	Bed Slide (right) Knob
146688	25108	Bed Slide (right) Latch.....
146689	25108	Bed Slide (right) Latch Guide.....
1470X	25108	Bed Slide (right) Latch Guide Screw (2) ..
146690	25108	Bed Slide (right) Latch Spring
146691	25108	Bed Slide (right) Spring
146524	25108	Bed Slide (right) Spring
1423X	25108	Bed Slide (right) Spring Screw
1470X	25108	Bed Slide (right) Spring Screw (2)
240C	25108	Bed Slide (right) Spring Stop Screw (2)...
146878	-----	Combination of Feed and Stitch Regulator Parts, Nos. 143015, 146537, 146545, 146864, 146883 and 146884
146528	25041	Face Plate.....
NOTE: When ordering No. 146528, state color required.		
146529	25041	Face Plate Gasket.....
140061J	25041	Face Plate Screw (lower) (3)
140050J	25041	Face Plate Screw (upper)
146879	25072	Feed Bar.....
146880	-----	Feed Bar 146879 with 1607X and 140695X .
146949	-----	Feed Bar 146880 with 146935
147022	25072	Feed Bar Carrier with two each 158E and 176E
158E	25072	Feed Bar Carrier Clamping Screw (2) ...

No.	Plate	Name
147023	25072	Feed Bar Carrier Hinge Pin.....
176E	25072	Feed Bar Carrier Hinge Pin Clamping Screw (2).....
143031	25072	Feed Bar Carrier Oil Wick.....
143032	25072	Feed Bar Carrier Oil Wick Holder.....
147024	-----	Feed Bar Carrier Oil Wick Holder 143032 with 143031.....
228E	25072	Feed Bar Carrier Oil Wick Holder Screw (2).....
146934	25072	Feed Bar Slide Block.....
146881	25072	Feed Bar Slide Block Oil Wick.....
146539	25072	Feed Bar Slide Block Oil Wick Holder.....
146882	-----	Feed Bar Slide Block Oil Wick Holder 146539 with 146881.....
50579J	25072	Feed Bar Slide Block Oil Wick Holder Screw.....
146950	25109	Feed Dog, 14 teeth (10 teeth to the inch) for 146957.....
131559	25109	Feed Dog, 12 teeth (8 teeth to the inch) for 146958.....
157J	25109	Feed Dog Screw.....
140695X	25072	Feed Dog Stop Screw.....
1607X	25072	Feed Dog Stop Screw Nut.....
51061AL	25107	Feed Eccentric Body Set Screw (3).....
7071	25107	Feed Eccentric Clamping Washer (2)....
217J	25107	Feed Eccentric Clamping Washer Screw (2).....
146883	25107	Feed Eccentric (adjustable) complete, Nos. 50328C, two each 217J. 7071 and three 51061AL.....
146884	25107	Feed Lifting Eccentric with three 440AL..
440AL	25107	Feed Lifting Eccentric Set Screw (3).....
146885	25072	Feed Lifting Rock Shaft.....
143052	25072	Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder.....
228E	25072	Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder Screw.....
147042	25072	Feed Lifting Rock Shaft Bushing (back)...
146933	25072	Feed Lifting Rock Shaft Bushing (front)...
447AL	25072	Feed Lifting Rock Shaft Bushing Set Screw (2).....
143039	25072	Feed Lifting Rock Shaft Cap.....
223E	25072	Feed Lifting Rock Shaft Cap Screw (2)....
147029	25072	Feed Lifting Rock Shaft Collar with two 460AL (2).....
460AL	25072	Feed Lifting Rock Shaft Collar Set Screw (2).....
146537	25107	Feed Lifting Rock Shaft Connecting Rod...
146887	25107	Feed Lifting Rock Shaft Connecting Rod Hinge Pin.....
462AL	25072	Feed Lifting Rock Shaft Connecting Rod Hinge Pin Set Screw.....
146888	25072	Feed Lifting Rock Shaft Crank (back) with 462AL and two 50083AL.....

No.	Plate	Name
50083AL	25072	Feed Lifting Rock Shaft Crank (back) Clamping Screw (2).....
146889	25072	Feed Lifting Rock Shaft Crank (front) with 157X
146935	-----	Feed Lifting Rock Shaft Crank (front) 146889 with 146934.....
157X	25072	Feed Lifting Rock Shaft Crank (front) Clamping Screw.....
146945	25072	Feed Lifting Rock Shaft Hole Plug.....
140359E	25072	Feed Lifting Rock Shaft Oil Plug Screw...
143236	25072	Feed Lifting Rock Shaft Oil Plug Screw Washer (fiber).....
146891	25072	Feed Lifting Rock Shaft Oil Wick.....
146892	25072	Feed Lifting Rock Shaft Oil Wick (long)...
147037	25072	Feed Lifting Rock Shaft Oil Wick (short) (2).....
147047	25072	Feed Lifting Rock Shaft Oil Wick Clamping Plate
197E	25072	Feed Lifting Rock Shaft Oil Wick Clamping Plate Screw
50328C	25107	Feed Regulating Screw.....
146893	25072	Feed Rock Shaft.....
146894	-----	Feed Rock Shaft Nos. 197E, 140359E, 143236, 146891, 146893, 146896, 147647 and two 147045.....
147042	25072	Feed Rock Shaft Bushing (back).....
147043	25072	Feed Rock Shaft Bushing (front)
447AL	25072	Feed Rock Shaft Bushing Set Screw (2)...
143048	25072	Feed Rock Shaft Cap.....
223E	25072	Feed Rock Shaft Cap Screw (2).....
147029	25072	Feed Rock Shaft Collar with two 460AL...
460AL	25072	Feed Rock Shaft Collar Set Screw (2)....
146545	25107	Feed Rock Shaft Connecting Rod
146887	25107	Feed Rock Shaft Connecting Rod Hinge Pin
462AL	25072	Feed Rock Shaft Connecting Rod Hinge Pin Set Screw
146895	25072	Feed Rock Shaft Crank with 462AL and two 157X.....
157X	25072	Feed Rock Shaft Crank Clamping Screw (2)
140359E	25072	Feed Rock Shaft Oil Plug Screw.....
143236	25072	Feed Rock Shaft Oil Plug Screw Washer (fiber).....
146891	25072	Feed Rock Shaft Oil Wick
146896	25072	Feed Rock Shaft Oil Wick (long)
147045	25072	Feed Rock Shaft Oil Wick (short) (2)
147047	25072	Feed Rock Shaft Oil Wick Clamping Plate .
197E	25072	Feed Rock Shaft Oil Wick Clamping Plate Screw.....
146951	25110	Looper (back) closed eye
1253AL	25110	Looper (back) Set Screw.....
146952	25110	Looper (front) closed eye
1253AL	25110	Looper (front) Set Screw.....
146550	25073	Looper Avoiding Eccentric with two 1259AL

No	Plate	Name
146553	25073	Looper Avoiding Eccentric Connection (forked) with two 896AL.....
896AL	25073	Looper Avoiding Eccentric Connection Clamping Screw (2).....
1259AL	25073	Looper Avoiding Eccentric Set Screw (2)..
146554	25073	Looper Avoiding Eccentric Slide Block....
146556	25073	Looper Ball Crank.....
146897	25110	Looper Ball Crank Arm with 51320AL....
146923	25110	Looper Ball Crank Arm 146897 with 1520J, 128551 and 146919.....
51320AL	25110	Looper Ball Crank Arm Clamping Screw..
132790	25073	Looper Ball Crank Connection Ball Sleeve (two pieces)
164232	25073	Looper Ball Crank Connection Ball Sleeve Guide
146557	25073	Looper Ball Crank Connection Nos. two each 896AL, 51715AL, 131927 and 131928
146558	-----	Looper Ball Crank Connection 146557 with 132790, 146556 and 164232
896AL	25073	Looper Ball Crank Connection Cap (lower) Screw (2).....
131927	25073	Looper Ball Crank Connection Cap (upper) Screw Stud (2).....
51715AL	25073	Looper Ball Crank Connection Cap (upper) Screw Stud Nut (2).....
131928	25073	Looper Ball Crank Connection Cap (upper) Screw Stud Nut Lock Washer (2)
146559	25073	Looper Ball Crank Hinge Pin
448AL	25073	Looper Ball Crank Hinge Pin Set Screw(2)
146948	25110	Looper Ball Crank Pitman Ball Screw Stud (right).....
1520J	25110	Looper Ball Crank Pitman Ball Screw Stud (right) Nut.....
128551	25110	Looper Ball Crank Pitman Ball Screw Stud (right) Nut Locking Plate.....
146730	25110	Looper Ball Crank Pitman End Bearing (left) Body with two 175AL
175AL	25110	Looper Ball Crank Pitman End Bearing (left) Cap Screw (2).....
1664J	25110	Looper Ball Crank Pitman End Bearing (left) Nut
146918	25110	Looper Ball Crank Pitman End Bearing (right) Body with two 175AL.....
175AL	25110	Looper Ball Crank Pitman End Bearing (right) Cap Screw (2)
146919	-----	Looper Ball Crank Pitman End Bearing (right) 146918 with 146948.....
146936	25110	Looper Ball Crank Pitman Rod.....
146937	25110	Looper Ball Crank Pitman Rod 146936 with 51769C
146938	25110	Looper Ball Crank Pitman Rod with Throw- out Device complete, Nos. 29043, 50169J, 146732, 146733, 146754, 146904, 146937 and two 51159J

No.	Plate	Name
51769C	25110	Looper Ball Crank Pitman Rod Nut.....
146947	25110	Looper Ball Crank Pitman Rod Nut Oil Shield
51460E	25110	Looper Ball Crank Pitman Rod Oil Shield Screw.....
7071	25110	Looper Ball Crank Pitman Rod Oil Shield Screw Washer
146565	25110	Looper Holder with 896AL and two 1253AL
146739	25110	Looper Holder 146565 with 1664J, 146567 and 146730
146567	25110	Looper Holder Bushing (eccentric) with 146647.....
146647	25110	Looper Holder Bushing Pin.....
896AL	25110	Looper Holder Clamping Screw.....
146568	25073	Looper Holder Hinge Pin.....
146569	25073	Looper Holder Rock Shaft with 140439E...
*146570	-----	Looper Holder Rock Shaft Bracket
NOTE: Due to the accuracy required for Looper Rock Shaft alignment, Looper Holder Rock Shaft Bracket cannot be supplied separately and can only be sent out as a unit, Arm, Bed and Looper Holder Rock Shaft Bracket assembled.		
143126	-----	Looper Holder Rock Shaft Bracket Oil Pipe Clamping Sleeve Adaptor.....
231E	-----	Looper Holder Rock Shaft Bracket Oil Plug Screw (2)
140734E	25037	Looper Holder Rock Shaft Bracket Screw (2)
126150	-----	Looper Holder Rock Shaft Bracket Screw Washer (2)
146571	25073	Looper Holder Rock Shaft Bushing (back).
448AL	25073	Looper Holder Rock Shaft Bushing (back) Set Screw
146572	25073	Looper Holder Rock Shaft Bushing (front).
448AL	25073	Looper Holder Rock Shaft Bushing (front) Set Screw
140439E	25073	Looper Holder Rock Shaft Oil Plug Screw.
146732	25110	Looper Throw-out Releaser.....
146733	25110	Looper Throw-out Releaser Cap.....
51159J	25110	Looper Throw-out Releaser Cap Screw (2)
146754	25110	Looper Throw-out Sleeve
146904	25110	Looper Throw-out Spring
50169J	25110	Looper Throw-out Spring Screw
29043	25110	Looper Throw-out Spring Screw Washer..
146924	-----	Looper Throw-out Device and Pitman Rod complete, Nos. 1520J, 128551, 146919 and 146938 (for Agents only)
146512	25074	Machine Pulley (disc power) "V" belt groove (outside diameter of belt groove 2.9 in.) with two 51283AL
51283AL	25074	Machine Pulley Set Screw (2).....
146573	25111	Needle Bar (hollow)

No.	Plate	Name
146953	-----	Needle Bar complete, Nos. 146573 and 146954.....
146907	25111	Needle Bar Bushing (lower).....
1133E	25111	Needle Bar Bushing (lower) Set Screw ...
146804	25111	Needle Bar Bushing (lower and upper) Oil Wick
146805	25111	Needle Bar Bushing (lower and upper) Oil Wick complete, Nos. 146703, 146804 and two 146580
146703	25111	Needle Bar Bushing (lower and upper) Oil Wick Clamp and Retainer.....
146580	25111	Needle Bar Bushing (lower and upper) Oil Wick Clip (2).....
146576	25111	Needle Bar Bushing (upper).....
140440J	25111	Needle Bar Bushing (upper) Oil Plug Screw
1133E	25111	Needle Bar Bushing (upper) Set Screw ...
146959	25111	Needle Bar Connecting Link.....
146581	-----	Needle Bar Connecting Link 146959 with 146582.....
146582	25107	Needle Bar Connecting Link Hinge Stud...
140552AL	25107	Needle Bar Connecting Link Hinge Stud Clamping Screw
1036AL	25107	Needle Bar Connecting Link Hinge Stud Position Set Screw
175E	25111	Needle Bar Connecting Stud Clamping Screw.....
139110	25111	Needle Bar Connecting Stud Oil Pad (wick)
139111	25111	Needle Bar Connecting Stud Slide Block ..
146908	25111	Needle Bar Connecting Stud Slide Block Guide
SS329E	25111	Needle Bar Connecting Stud Slide Block Guide Screw (2).....
140542AL	25107	Needle Bar Crank Position Screw.....
146665	25047	Needle Bar Thread Retainer (lower).....
146666	25047	Needle Bar Thread Retainer (upper).....
146585	25047	Needle Bar Thread Retainer Bracket.....
146586	25047	Needle Bar Thread Retainer Bracket complete, Nos. 10107, 140546C, 146585, 146665, 146666 and two each 42483, 50163XC and 54865
402J	25047	Needle Bar Thread Retainer Bracket Screw
43483	25047	Needle Bar Thread Retainer Disc (2) ...
140546C	25047	Needle Bar Thread Retainer Disc Screw..
50163XC	25047	Needle Bar Thread Retainer Screw (2)...
54865	25047	Needle Bar Thread Retainer Screw Washer (2).....
10107	25047	Needle Bar Thread Retainer Spring.....
146954	25111	Needle Clamp with two 50014F
146682	25108	Needle Guard
146742	25108	Needle Guard Holder
146743	25108	Needle Guard Holder Bracket
190J	25108	Needle Guard Holder Bracket Screw

No.	Plate	Name
190J	25108	Needle Guard Holder Screw.....
176J	25108	Needle Guard Screw
50014F	25111	Needle Set Screw (2)
146591	25046	Oil Flow Body
143061	25046	Oil Flow Body Gasket (2).....
143062	25046	Oil Flow Window
143063	25046	Oil Flow Window Cap
50257X	25046	Oil Flow Window Cap Screw (4).....
143370	25046	Oil Lead
51369E	25046	Oil Lead Screw.....
146593	25046	Oil Pipe, for 146597.....
146594	25010	Oil Pipe with two each 143124 and 143125, for oiling Bed Rotary Shaft Intermediate Bearing
146595	25010	Oil Pipe with two each 143124 and 143125, for oiling Looper Rock Shaft Hinge Pin..
146596	25010	Oil Pipe with two each 143124 and 143125, for oiling Thread (under) Take-up Shaft Front Bearing.....
143065	25046	Oil Pipe Clamping Sleeve, for 146597.....
143066	25046	Oil Pipe Clamping Sleeve Nut.....
146597	25046	Oil Pipe complete from Oil Pump to Arm Shaft (horizontal) Center Bearing Nos. 146593 with 143065 and 143066 (for Agents only).....
143124	25010	Oil Pipe Clamping Sleeve (6).....
143126	25046	Oil Pipe Clamping Sleeve Adaptor for 146660 (3)
143126	-----	Oil Pipe Clamping Sleeve Adaptor (fastened to Bed) (2).....
143125	25010	Oil Pipe Clamping Sleeve Nut (6).....
146659	25046	Oil Pump (centrifugal) Body.....
146660	-----	Oil Pump (centrifugal) Body 146659 with three 143126
143071	25046	Oil Pump (centrifugal) Body Position Pin (2).....
157E	25046	Oil Pump (centrifugal) Body Screw (3)...
146600	25046	Oil Pump (centrifugal) Cover.....
143073	25046	Oil Pump (centrifugal) Impeller
50123E	25107	Oil Pump (centrifugal) Impeller Locking Screw.....
146657	25046	Oil Pump (centrifugal) Screen
146658	25046	Oil Pump (centrifugal) Screen Frame....
189E	25046	Oil Pump (centrifugal) Screen Frame.... Screw (3).....
146744	25037	Oil Removing Wick (head end)
146745	25037	Oil Removing Wick (head end) Holder Body
146746	-----	Oil Removing Wick (head end) Holder Body 146745 with 146698 and 146744 (for Agents only).....
140553E	25037	Oil Removing Wick (head end) Holder Body Hinge Screw
146698	25037	Oil Removing Wick (head end) Holder Body Spring.....
146700	25037	Oil Removing Wick (head end) Holder Body Stop and Spring Clip

No.	Plate	Name
228E	25037	Oil Removing Wick (head end) Holder
		Body Stop and Spring Clip Screw.....
146747	25037	Oil Removing Wick (head end) Holder
		Body complete, Nos. 228E, 140553E,
		146696, 146697, 146698, 146700, 146744
		and 146745.....
146696	25037	Oil Removing Wick (head end) Hinge Plate
		and Cover.....
146697	25037	Oil Removing Wick (head end) Hinge Plate
		and Cover Gasket.....
1364X	25037	Oil Removing (head end) Hinge Plate and
		Cover Screw (3)
146604	25037	Oil Wick, for oiling Looper Ball Crank
		Pitman End Bearing (left)
146605	25073	Oil Wick Holder
193E	25073	Oil Wick Holder Tube Bracket Screw....
146606	25073	Oil Wick Position Bracket with 140239AL.
140239AL	25073	Oil Wick Position Bracket Screw
139462	25111	Presser Bar
146751	25111	Presser Bar Bushing (lower)
1133E	25111	Presser Bar Bushing (lower) Set Screw..
146694	25111	Presser Bar Lifting Bracket with 1057AL
1057AL	25111	Presser Bar Lifting Barcket Clamping
		Screw
146676	25097	Presser Bar Lifting Bracket Lifter.....
807X	25097	Presser Bar Lifting Bracket Lifter Hinge
		Screw
146791	25097	Presser Bar Lifting Lever.....
		NOTE: When ordering No. 146791, state color
		required.
146609	25097	Presser Bar Lifting Lever Extension
161X	25097	Presser Bar Lifting Lever Extension
		Screw (2)
802X	25097	Presser Bar Lifting Lever Hinge Screw..
146610	25097	Presser Bar Lifting Lever Spring
146611	25111	Presser Bar Spring.....
146612	25111	Presser Bar Spring Guide Pin.....
146752	25111	Presser Bar Stop with 190J.....
190J	25111	Presser Bar Stop Clamping Screw
131556	25109	Presser Foot Plate
442AL	25109	Presser Foot Plate Adjusting Screw
1695J	25109	Presser Foot Plate Adjusting Screw Nut..
26276	25109	Presser Foot Plate Hinge Pin.....
146955	25109	Presser Foot Shank with 442AL and 1695J
146956	25109	Presser Foot (hinged) complete, Nos.
		26276, 131556 and 146955.....
131560	25109	Presser Foot Plate
26276	25109	Presser Foot Plate Hinge Pin.....
146780	25109	Presser Foot Shank.....
131561	25109	Presser Foot (hinged) complete, Nos.
		26276, 131560 and 146780.....
190J	25111	Presser Foot Screw.....
140441W	25111	Pressure Regulating Thumb Screw.....
51614W	25111	Pressure Regulating Thumb Screw Nut...

No.	Plate	Name
146617	25050	Slack Thread Controller.....
54242	25050	Slack Thread Controller Clamp
176J	25050	Slack Thread Controller Clamp Screw
140239AL	25050	Slack Thread Controller Position Screw...
2102	25098	Tension (looper thread) Disc (4)
51570C	25098	Tension (looper thread) Regulating Thumb Nut (2).....
146792	25099	Tension (looper thread) Releaser (2)
146794	25099	Tension (looper thread) Releaser Slide ...
146620	25099	Tension (looper thread) Releaser Slide Connecting Link.....
110C	25099	Tension (looper thread) Releaser Slide Connecting Link Hinge Screw
72C	25099	Tension (looper thread) Releaser Slide Hinge Screw (2)
217J	25099	Tension (looper thread) Releaser Screw (2).....
146801	25099	Tension (looper thread) Releaser Nos. 110C, 146620, 146794, 146796, 146797 and two each 72C, 217J, 146792 and 146795
140442C	25098	Tension (looper thread) Screw Stud (2) ...
146618	-----	Tension (looper thread) Screw Stud 140442C with 51570C.....
131740	25098	Tension (looper thread) Spring (2).....
59537	25098	Tension (looper thread) Spring Bushing (large) (2).....
59538	25098	Tension (looper thread) Spring Bushing (small) (2)
146619	25098	Tension (looper thread) Thread Guard
131696	25098	Tension (looper thread) Thread Guide (2) .
68002	25097	Tension (needle thread) Bracket
140443J	25097	Tension (needle thread) Bracket Screw ...
2102	25097	Tension (needle thread) Disc (4)
51570C	25097	Tension (needle thread) Regulating Thumb Nut (2)
32572	25097	Tension (needle thread) Releasing Disc (2)
54988	25097	Tension (needle thread) Releasing Pin (2).
68003	25097	Tension (needle thread) Releasing Shaft...
54872	25097	Tension (needle thread) Releasing Shaft Crank with 624AL
146620	25097	Tension (needle thread) Releasing Shaft Crank Connecting Link.....
110C	25097	Tension (needle thread) Releasing Shaft Crank Connecting Link Hinge Screw
624AL	25097	Tension (needle thread) Releasing Shaft Crank Set Screw.....
68261	25097	Tension (needle thread) Releasing Shaft Spring
316C	25097	Tension (needle thread) Releasing Shaft Stop Screw.....
1547J	25097	Tension (needle thread) Releasing Shaft Stop Screw Nut.....

No.	Plate	Name
50326C	25097	Tension (needle thread) Screw Stud (2)...
59539	-----	Tension (needle thread) Screw Stud 50326C with 51570C (2).....
225X	25077	Tension (needle thread) Screw Stud Hole Plug.....
131741	25097	Tension (needle thread) Spring (2).....
59537	25097	Tension (needle thread) Spring Bushing (large) (2)
59538	25097	Tension (needle thread) Spring Bushing (small) (2)
131696	25097	Tension (needle thread) Thread Guide (2).
146621	25073	Thread (looper) Take-up with 465AL....
1029J	25073	Thread (looper) Take-up Screw
146622	25073	Thread (looper) Take-up Screw Washer (fiber).....
465AL	25073	Thread (looper) Take-up Set Screw.....
146623	25047	Thread (looper) Take-up Stripper
146624	25047	Thread (looper) Take-up Stripper Holder with 906AL.....
146625	25047	Thread (looper) Take-up Stripper Plate..
146603	-----	Thread (looper) Take-up Stripper Plate 146625 with 237J, 139148, 146623, 146624, 146626, 146628 and two 190J ..
237J	25047	Thread (looper) Take-up Stripper Plate Screw
146626	25047	Thread (looper) Take-up Stripper Plate Support Plate (2).....
		NOTE: One No. 146626 is screwed onto Machine Bed.
190X	25047	Thread (looper) Take-up Stripper Plate Support Plate Screw (4).....
906AL	25047	Thread (looper) Take-up Stripper Set Screw.....
139148	25047	Thread (looper) Take-up Stripper Staple..
190J	25047	Thread (looper) Take-up Stripper Staple Screw (2)
146627	25047	Thread (looper) Take-up Thread Guide (left).....
237J	25047	Thread (looper) Take-up Thread Guide (left) Screw.....
146628	25047	Thread (looper) Take-up Thread Guide (right)
237J	25047	Thread (looper) Take-up Thread Guide (right) Screw
146631	25098	Thread (looper) Thread Tube.....
1628X	25098	Thread (looper) Thread Tube Screw Stud Nut
146671	25098	Thread (looper) Thread Tube Screw Stud Nut Washer.....
146632	25098	Thread (looper) Thread Tube Thread Guide
50027J	25098	Thread (looper) Thread Tube Thread Guide Screw
146795	25099	Thread (looper) Uncurler (2)
146796	25099	Thread (looper) Uncurler Plate (back)...
146797	25099	Thread (looper) Uncurler Plate (front) ..

No.	Plate	Name
146633	25050	Thread (needle) Eyelet (side of arm).....
176J	25050	Thread (needle) Eyelet (side of arm) Position Screw.....
7071	25050	Thread (needle) Eyelet (side of arm) Position Screw Washer
724J	25050	Thread (needle) Eyelet (side of arm) Screw.....
146634	25111	Thread (needle) Take-up with 51460E
51460E	25111	Thread (needle) Take-up Clamping Screw.
54095	25111	Thread (needle) Take-up Plate
68164	25111	Thread (needle) Take-up Plate Spring....
1449J	25111	Thread (needle) Take-up Plate Spring Screw.....
146635	25111	Thread (needle) Take-up complete, Nos. 1449J, 54095, 68164 and 146634
139158	25050	Thread (needle) Thread Guide (2).....
146629	25050	Thread (needle) Thread Guide Bracket ...
140443J	25050	Thread (needle) Thread Guide Bracket Screw.....
146630	25050	Thread (needle) Thread Guide Bracket Support
NOTE: When ordering No. 146630, state color required.		
217J	25050	Thread (needle) Thread Guide Bracket Support Screw (lower).....
237J	25050	Thread (needle) Thread Guide Bracket Support Screw (upper)
229J	25050	Thread (needle) Thread Guide Screw (4)..
146957	25109	Throat Plate for 146950.....
146958	25109	Throat Plate for 131559.....
691F	25109	Throat Plate Screw (2).....

**SINGER Needles should be used
in SINGER Machines
These Needles and their Containers
are marked with the
Company's Trademark "SIMANCO "**

1

**Needles in Containers marked
"FOR SINGER MACHINES"
are NOT SINGER made needles**

2

ACCESSORIES

No.	Plate	Name
146637	25015	Machine Base and Oil Reservoir.....
146638	25015	Machine Base and Oil Reservoir 146637 with 146639, 146693, 146695 and two 146640 (for Agents only).....
146639	25015	Machine Base and Oil Reservoir Gasket (left).....
146693	25015	Machine Base and Oil Reservoir Oil Return Wick.....
146695	25015	Machine Base and Oil Reservoir Oil Return Wick Position Pad (felt)
143308	25090	Machine Cushion (felt) (4)
12361	25090	Machine Hinge Connection (2)
146640	25015	Machine Pad (felt) (2).....
41400	25090	Machine Rest Pin (wood).....
123044	25090	Oiler with 120345.....
120345	25090	Oiler Spout.....
121741	25090	One Quart Can of Light Grade Stainless Oil
120440	25090	Screw Driver
121108	25090	Screw Driver.....
120341	25090	Tweezers (curved).....
8908	25090	Wrench.....
23535	25090	Wrench.....
42850	25090	Wrench.....
146057	25090	Wrench (socket) for 140552AL
151281	25090	Wrench (socket).....

BELT GUARD (Hinged)

No.	Plate	Name
151362	25091	Belt Guard Bottom Section with 2273 and 140321C
151363	25091	Belt Guard Top Section with 151366 and two 219R
151366	25091	Belt Guard Top Section Fill-in Plate
219R	25091	Belt Guard Top Section Fill-in Plate Screw (2).....
151364	25091	Belt Guard Top Section Hinge Pin.....
140321C	25091	Belt Guard Top Section Hinge Pin Set Screw
151365	25091	Belt Guard Top Section Lock Spring.....
2273	25091	Belt Guard Top Section Lock Spring Position Pin.....
217E	25091	Belt Guard Top Section Lock Spring Screw.
151367	25091	Belt Guard (hinged) complete, Nos. 217E, 151362, 151363, 151364, 151365 and two wood Screws 1 1/4 in. No. 12 F.H. B. ..
NOTE:		No. 151367 is furnished only when ordered.

FACE PLATE THREAD LUBRICATOR

No.	Plate	Name
146810	25051	Thread Lubricator Adaptor.....
140224J	25051	Thread Lubricator Adaptor Screw.....
7071	25051	Thread Lubricator Adaptor Screw Washer
241755	25051	Thread Lubricator Oil Pad (felt).....
146806	25051	Thread Lubricator Oil Pad Holder
146807	-----	Thread Lubricator Oil Pad Holder 146806 with 62827, 240439 and 241755.....
240439	25051	Thread Lubricator Oil Pad Retainer.....
17822	25051	Thread Lubricator Oil Reservoir Rivet...
8068	25051	Thread Lubricator Oil Reservoir Rivet Washer (inside).....
124371	25051	Thread Lubricator Oil Reservoir Rivet Washer (outside).....
62827	25051	Thread Lubricator Oil Wick.....
146808	-----	Thread Lubricator complete, Nos. 8068, 17822, 124371 and 146807.....
146809	25051	Thread Lubricator 146808 with 7071, 21202, 50222J, 140224J and 146810.....
50222J	25051	Thread Lubricator Screw
21202	25051	Thread Lubricator Screw Washer.....

FOOT LIFTER PARTS

No.	Plate	Name
6439	-----	Chain 36 in. to 45 in., with 56864 and 56865.....
	NOTE:	When ordering No. 6439, state length required.
4879	25030	Chain Connecting Link.....
56864	-----	Chain Hook (large).....
56865	-----	Chain Hook (small).....
126249	25030	Treadle.....
4882	25030	Treadle Shaft.....
126250	25030	Treadle Spring.....
150451	25030	Treadle Stand.....
150452	25030	Treadle complete, Nos. 4879, 4882, 126249, 126250, 150451 and two wood screws 1 in. No. 16 F.H.....

KNEE LIFTER PARTS

23

No.	Plate	Name
146764	25030	Chain, length 10 1/4 in., with 46865 and 56865.....
56865	25030	Chain Hook.....
46865	25030	Chain Hook Link.....
146765	25030	Rock Shaft
146766	25030	Rock Shaft Hanger with two wood screws 1 in. No. 10 F.H. (2)
143283	25030	Rock Shaft Knee Arm.....
143285	-----	Rock Shaft Knee Arm complete, Nos. 2767, 143283 and 143284
143284	25030	Rock Shaft Knee Arm Hub with 356C and 140351AL.....
140351AL	25030	Rock Shaft Knee Arm Hub Clamping Screw.
356C	25030	Rock Shaft Knee Arm Hub Set Screw
2767	25030	Rock Shaft Knee Arm Plate with 356C.....
356C	25030	Rock Shaft Knee Arm Plate Set Screw.....
6337	25030	Rock Shaft Lifting Bracket with two 356C..
7125	25030	Rock Shaft Lifting Bracket Hook.....
356C	25030	Rock Shaft Lifting Bracket Hook Set Screw.
356C	25030	Rock Shaft Lifting Bracket Set Screw.....
146768	25030	Rock Shaft Spring.....
1115AL	25030	Rock Shaft Spring Screw.....
146769	25030	Rock Shaft Stop Dog (back) with 140351AL.
146770	25030	Rock Shaft Stop Dog (front) with 140351AL.
140351AL	25030	Rock Shaft Stop Dog Clamping Screw (2)...
146771	25030	Rock Shaft complete, Nos. 1115AL, 6337, 7125, 143285, 146765, 146768, 146769, 146770 and two 146766.....
146779	25030	Knee Lifter complete, Nos. 146764 and 146771.....

THREAD UNWINDER (For Four Spools)

No.	Plate	Name
151032	25106	Base with 138R and three wood screws 1 in. No. 12 F.H.
228764	25106	Spool Pin (4)
228766	25106	Spool Rest with 201254C (2).....
151033	25106	Spool Rest Bracket.....
151034	25106	Spool Rest Bracket Rod.....
138R	25106	Spool Rest Bracket Rod Set Screw
51276R	-----	Spool Rest Bracket Screw.....
150203	25106	Spool Rest Cushion (felt) (4)
201254C	25106	Spool Rest Set Screw (2).....
151035	25106	Thread Guide (4).....
1521R	25106	Thread Guide Nut (8)
9525	25106	Thread Guide Nut Washer (8)
151037	25106	Thread Unwinder complete, for four spools, Nos. 51276R, 151032, 151033, 151034, two 228766, four each 150203, 151035, 228764 and eight each 1521R and 9525...

No.	Plate	Name
72C	25099	Tension (looper thread) Releaser Slide Hinge Screw for 146801.....
110C	25099	Tension (looper thread) Releaser Slide Connecting Link Hinge Screw for 146801.
110C	25097	Tension (needle thread) Releasing Shaft Crank Connecting Link Hinge Screw.....
138R	25106	Thread Unwinder Spool Rest Bracket Rod Set Screw for 151032.....
144D	25107	Arm Shaft (horizontal) Screw (back).....
157J	25109	Feed Dog Screw.....
157X	25072	Feed Lifting Rock Shaft Crank (front) Clamping Screw for 146889
157X	25072	Feed Rock Shaft Crank Clamping Screw for 146895
157E	25046	Oil Pump (centrifugal) Body Screw
158E	25072	Feed Bar Carrier Clamping Screw for 147022
161X	25097	Presser Bar Lifting Lever Extension Screw
175AL	25110	Looper Ball Crank Pitman End Bearing (left) Cap Screw for 146730.....
175AL	25110	Looper Ball Crank Pitman End Bearing (right) Cap Screw for 146918.....
175E	25111	Needle Bar Connecting Stud Clamping Screw
176E	25072	Feed Bar Carrier Hinge Pin Clamping Screw for 147022
176J	25108	Needle Guard Screw.....
176J	25050	Slack Thread Controller Clamp Screw.....
176J	25050	Thread (needle) Eyelet (side of arm) Position Screw
189E	25046	Oil Pump (centrifugal) Screen Frame Screw
190J	25108	Needle Guard Holder Bracket Screw
190J	25108	Needle Guard Holder Screw.....
190J	25111	Presser Bar Stop Clamping Screw for 146752.....
190J	25111	Presser Foot Screw.....
190X	25047	Thread (looper) Take-up Stripper Plate Support Plate Screw.....
190J	25047	Thread (looper) Take-up Stripper Staple Screw for 146603
193E	25073	Oil Wick Holder Tube Bracket Screw.....
197E	25072	Feed Lifting Rock Shaft Oil Wick Clamping Plate Screw.....
197E	25072	Feed Rock Shaft Oil Wick Clamping Plate Screw for 146894
207E	25107	Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube Holder Screw.....
217E	25091	Belt Guard Top Section Lock Spring Screw for 151367.....
217J	25107	Feed Eccentric Clamping Washer Screw for 146883

No.	Plate	Name
217J	25099	Tension (looper thread) Releaser Screw for 146801.....
217J	25050	Thread (needle) Thread Guide Bracket Support Screw (lower).....
219R	25091	Belt Guard Top Section Fill-in Plate Screw for 151363.....
223E	25072	Feed Lifting Rock Shaft Cap Screw.....
223E	25072	Feed Rock Shaft Cap Screw.....
225X	25077	Tension (needle thread) Screw Stud Hole Plug.....
228E	25072	Feed Bar Carrier Oil Wick Holder Screw.
228E	25072	Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder Screw.....
228E	25037	Oil Removing Wick (head end) Holder Body Stop and Spring Clip Screw for 146747.....
229J	25050	Thread (needle) Thread Guide Screw.....
231E	-----	Looper Holder Rock Shaft Bracket Oil Plug Screw.....
237J	25047	Thread (looper) Take-up Stripper Plate Screw for 146603.....
237J	25047	Thread (looper) Take-up Thread Guide (left) Screw.....
237J	25047	Thread (looper) Take-up Thread Guide (right) Screw.....
237J	25050	Thread (needle) Thread Guide Bracket Support Screw (upper).....
240C	25108	Bed Slide (right) Spring Stop Screw for 146007, 146526, 146835, 146846 and 146847.....
316C	25097	Tension (needle thread) Releasing Shaft Stop Screw.....
SS329E	25111	Needle Bar Connecting Stud Slide Block Guide Screw.....
335X	25074	Arm Top Cover and Stitch Regulator Cap Latch Screw for 146869.....
356C	25030	Knee Lifter Rock Shaft Knee Arm Hub Set Screw for 143284.....
356C	25030	Knee Lifter Rock Shaft Knee Arm Plate Set Screw for 2767.....
356C	25030	Knee Lifter Rock Shaft Lifting Bracket Hook Set Screw for 6337.....
356C	25030	Knee Lifter Rock Shaft Lifting Bracket Set Screw for 6337.....
402J	25047	Needle Bar Thread Retainer Bracket Screw.....
440AL	25107	Feed Lifting Eccentric Set Screw for 146884.....
442AL	25109	Presser Foot Plate Adjusting Screw for 146955.....
447AL	25072	Feed Lifting Rock Shaft Bushing Set Screw
447AL	25072	Feed Rock Shaft Bushing Set Screw.....
448AL	25073	Bed Rotary Shaft Bushing (intermediate) Set Screw.....
448AL	25073	Looper Ball Crank Hinge Pin Set Screw...

No.	Plate	Name
448AL	25073	Looper Holder Rock Shaft Bushing (back) Set Screw.....
448AL	25073	Looper Holder Rock Shaft Bushing (front) Set Screw.....
454AL	25073	Bed Rotary Shaft Collar Set Screw for 64342
460AL	25072	Feed Lifting Rock Shaft Collar Set Screw for 147029
460AL	25072	Feed Rock Shaft Collar Set Screw for 147029
462AL	25072	Feed Lifting Rock Shaft Connecting Rod Hinge Pin Set Screw for 146888
462AL	25072	Feed Rock Shaft Connecting Rod Hinge Pin Set Screw for 146895.....
465AL	25073	Thread (looper) Take-up Set Screw for 14662L
624AL	25097	Tension (needle thread) Releasing Shaft Crank Set Screw for 54872.....
691F	25109	Throat Plate Screw.....
724J	25050	Thread (needle) Eyelet (side of arm) Screw
725X	25041	Bed Slide (left) Spring Screw for 146522..
802X	25097	Presser Bar Lifting Lever Hinge Screw...
807X	25097	Presser Bar Lifting Bracket Lifter Hinge Screw
896AL	25073	Looper Avoiding Eccentric Connection Clamping Screw for 146553.....
896AL	25073	Looper Ball Crank Connection Cap (lower) Screw for 146557.....
896AL	25110	Looper Holder Clamping Screw for 146565
906AL	25047	Thread (looper) Take-up Stripper Set Screw for 146624.....
914J	25098	Tension (looper thread) Thread Guard Screw
965E	25037	Bed Leg (Back) Screw.....
1029J	25073	Thread (looper) Take-up Screw.....
1036AL	25107	Needle Bar Connecting Link Hinge Stud Position Set Screw for 146865.....
1057AL	25111	Presser Bar Lifting Bracket Clamping Screw for 146694.....
1115AL	25030	Knee Lifter Rock Shaft Spring Screw for 146771
1133E	25111	Needle Bar Bushing (lower) Set Screw....
1133E	25111	Needle Bar Bushing (upper) Set Screw....
1133E	25111	Presser Bar Bushing (lower) Set Screw...
1253AL	25110	Looper (back) Set Screw for 146565
1253AL	25110	Looper (front) Set Screw for 146565.....
1259AL	25107	Arm Shaft (horizontal) Bevel Gear Set Screw for 146864.....
1259AL	25107	Arm Shaft (upright) Bevel Gear (lower) Set Screw for 143015.....
1259AL	25107	Arm Shaft (upright) Bevel Gear (upper) Set Screw for 143015.....

No.	Plate	Name
1259AL	25073	Bed Rotary Shaft Bevel Gear Set Screw for 146517.....
1259AL	25073	Looper Avoiding Eccentric Set Screw for 146550.....
1364X	25037	Oil Removing Wick (head end) Hinge Plate and Cover Screw.....
1423X	25108	Bed Slide (right) Spring Screw for 146007, 146526, 146835, 146846 and 146847
1449J	25111	Thread (needle) Take-up Plate Spring Screw for 146635.....
1470X	25108	Bed Slide (right) Latch Guide Screw for 146062, 146692, 146723, 146821 and 146828.....
1470X	25108	Bed Slide (right) Spring Screw for 146062, 146692, 146723, 146821 and 146828
1520J	25110	Looper Ball Crank Pitman Ball Screw Stud (right) Nut for 146923 and 146924..
1521R	25106	Thread Unwinder Thread Guide Nut for 151037.....
1547J	25097	Tension (needle thread) Releasing Shaft Stop Screw Nut.....
1607X	25072	Feed Dog Stop Screw Nut for 146880.....
1628X	25098	Thread (looper) Thread Tube Screw Stud Nut.....
1664J	25110	Looper Ball Crank Pitman End Bearing (left) Nut for 146739.....
1695J	25109	Presser Foot Plate Adjusting Screw Nut for 146955.....
2102	25098	Tension (looper thread) Disc.....
2102	25097	Tension (needle thread) Disc.....
2273	25091	Belt Guard Top Section Lock Spring Position Pin for 151362.....
2767	25030	Knee Lifter Rock Shaft Knee Arm Plate with 356C, for 143285.....
4307	25041	Bed Slide (left) Spring for 146522.....
4879	25030	Foot Lifter Chain Connecting Link for 150452.....
4882	25030	Foot Lifter Treadle Shaft for 150452
6337	25030	Knee Lifter Rock Shaft Lifting Bracket with two 356C, for 146771.....
6439	-----	Foot Lifter Chain, 36 in. to 45 in., with 56864 and 56865.....
NOTE: When ordering No. 6439, state length required.		
7071	25051	Face Plate Thread Lubricator Adaptor Screw Washer for 146809.....
7071	25107	Feed Eccentric Clamping Washer for 146883.....
7071	25110	Looper Ball Crank Pitman Rod Oil Shield Screw Washer.....
7071	25050	Thread (needle) Eyelet (side of arm) Position Screw Washer.....
7125	25030	Knee Lifter Rock Shaft Lifting Bracket Hook for 146771.....

No.	Plate	Name
8068	25051	Face Plate Thread Lubricator Oil Reservoir Rivet Washer (inside) for 146808.....
8908	25090	Wrench (accessories).....
9525	25106	Thread Unwinder Thread Guide Nut Washer for 151037
10107	25047	Needle Bar Thread Retainer Spring for 146586
12361	25090	Machine Hinge Connection (accessories) ..
16532	25037	Arm Dowel Pin.....
17822	25051	Face Plate Thread Lubricator Oil Reservoir Rivet for 146808.....
21202	25051	Face Plate Thread Lubricator Screw Washer for 146809.....
23535	25090	Wrench (accessories).....
26276	25109	Presser Foot Plate Hinge Pin for 131561 and 146956.....
29043	25110	Looper Throw-out Spring Screw Washer for 146938
32572	25097	Tension (needle thread) Releasing Disc ...
41400	25090	Machine Rest Pin (wood) accessories.....
42483	25047	Needle Bar Thread Retainer Disc for 146586
42850	25090	Wrench (accessories).....
46865	25030	Knee Lifter Chain Hook Link for 146764...
50014F	25111	Needle Set Screw for 146954
50027J	25098	Thread (looper) Thread Tube Thread Guide Screw
50083AL	25072	Feed Lifting Rock Shaft Crank (back) Clamping Screw for 146888
50123E	25107	Oil Pump (centrifugal) Impeller Locking Screw.....
50163XC	25047	Needle Bar Thread Retainer Screw for 146586.....
50169J	25110	Looper Throw-out Spring Screw for 146938
50222J	25051	Face Plate Thread Lubricator Screw for 146809.....
50257X	25046	Oil Flow Window Cap Screw.....
50326C	25097	Tension (needle thread) Screw Stud for 59539.....
50328C	25107	Feed Regulating Screw for 146883
50554AL	25073	Bed Rotary Shaft Bushing (back) Set Screw
50554AL	25073	Bed Rotary Shaft Bushing (front) Set Screw
50579J	25072	Feed Bar Slide Block Oil Wick Holder Screw.....
51061AL	25107	Feed Eccentric Body Set Screw for 146883.
51159J	25110	Looper Throw-out Releaser Cap Screw for 146938.....
51276R	-----	Thread Unwinder Spool Rest Bracket Screw for 151037
51282X	25108	Attachment Slide Spring Screw for 146873 .
51283AL	25074	Machine Pulley Set Screw for 146512.....
51320AL	25110	Looper Ball Crank Arm Clamping Screw for 146897

No.	Plate	Name
51369R	25074	Arm Top Cover Screw.....
51369E	25046	Oil Lead Screw.....
51460E	25110	Looper Ball Crank Pitman Rod Oil Shield Screw
51460E	25111	Thread (needle) Take-up Clamping Screw for 146634
51570C	25098	Tension (looper thread) Regulating Thumb Nut for 146618.....
51570C	25097	Tension (needle thread) Regulating Thumb Nut for 59539.....
51614W	25111	Pressure Regulating Thumb Screw Nut....
51715AL	25073	Looper Ball Crank Connection Cap (upper) Screw Stud Nut, for 146557
51769C	25110	Looper Ball Crank Pitman Rod Nut for 146937.....
54095	25111	Thread (needle) Take-up Plate for 146635.
54242	25050	Slack Thread Controller Clamp.....
54865	25047	Needle Bar Thread Retainer Screw Washer for 146586
54872	25097	Tension (needle thread) Releasing Shaft Crank with 624AL.....
54988	25097	Tension (needle thread) Releasing Pin
56864	-----	Foot Lifter Chain Hook (large) for 6439...
56865	-----	Foot Lifter Chain Hook (small) for 6439...
56865	25030	Knee Lifter Chain Hook for 146764.....
59537	25098	Tension (looper thread) Spring Bushing (large)
59537	25097	Tension (needle thread) Spring Bushing (large)
59538	25098	Tension (looper thread) Spring Bushing (small)
59538	25097	Tension (needle thread) Spring Bushing (small)
59539	-----	Tension (needle thread) Screw Stud 50326C with 51570C.....
62827	25051	Face Plate Thread Lubricator Oil Wick for 146807
64342	25073	Bed Rotary Shaft Collar with 454AL.....
68002	25097	Tension (needle thread) Bracket.....
68003	25097	Tension (needle thread) Releasing Shaft...
68164	25111	Thread (needle) Take-up Plate Spring for 146635
68261	25097	Tension (needle thread) Releasing Shaft Spring.....
120341	25090	Tweezers (curved) accessories
120344	25090	Oiler with 120345 (accessories).....
120345	25090	Oiler Spout for 120344 (accessories).....
120440	25090	Screw Driver (accessories).....
121108	25090	Screw Driver (accessories).....
121741	25090	One Quart Can of Light Grade Stainless Oil (accessories)
124371	25051	Face Plate Thread Lubricator Oil Reservoir Rivet Washer (outside) for 146808

No.	Plate	Name
126150	-----	Looper Holder Rock Shaft Bracket Screw Washer for 146876.....
126249	25030	Foot Lifter Treadle for 150452.....
126250	25030	Foot Lifter Treadle Spring for 150452
128551	25110	Looper Ball Crank Pitman Ball Screw Stud (right) Nut Locking Plate for 146923 and 146924
131556	25109	Presser Foot Plate for 146956
131559	25109	Feed Dog 12 teeth (8 teeth to the inch) for 146958
131560	25109	Presser Foot Plate for 131561
131561	25109	Presser Foot (hinged) complete, Nos. 26276, 131560 and 146780
131696	25098	Tension (looper thread) Thread Guide
131696	25097	Tension (needle thread) Thread Guide
131740	25098	Tension (looper thread) Spring.....
131741	25097	Tension (needle thread) Spring.....
131927	25073	Looper Ball Crank Connection Cap (upper) Screw Stud for 146557.....
131928	25073	Looper Ball Crank Connection Cap (upper) Screw Stud Nut Lock Washer for 146557.
132790	25073	Looper Ball Crank Connection Ball Sleeve (two pieces) for 146558
139110	25111	Needle Bar Connecting Stud Oil Pad (wick)
139111	25111	Needle Bar Connecting Stud Slide Block...
139148	25047	Thread (looper) Take-up Stripper Staple for 146603
139158	25050	Thread (needle) Thread Guide
139462	25111	Presser Bar.....
140050J	25041	Face Plate Screw (upper)
140061J	25041	Face Plate Screw (lower)
140224J	25051	Face Plate Thread Lubricator Adaptor Screw for 146809.....
140239AL	25073	Oil Wick Position Bracket Screw for 146606
140239AL	25050	Slack Thread Controller Position Screw...
140296AL	25107	Arm Shaft (horizontal) Bushing (center) Set Screw
140296AL	25107	Arm Shaft (horizontal) Flanged Bushing (back) Set Screw
140298AL	25107	Arm Shaft (upright) Bushing (lower) Set Screw.....
140298AL	25107	Arm Shaft (upright) Bushing (upper) Set Screw.....
140321C	25091	Belt Guard Top Section Hinge Pin Set Screw for 151362
140331AL	25107	Arm Shaft (horizontal) Flanged Bushing (front) Set Screw.....
140333AL	25107	Arm Shaft (horizontal) Bevel Gear Position Screw for 146864.....
140351AL	25030	Knee Lifter Rock Shaft Knee Arm Hub Clamping Screw for 143284.....
140351AL	25030	Knee Lifter Rock Shaft Stop Dog Clamping Screw 146769 and 146770

No.	Plate	Name
140359E	25107	Arm Shaft (horizontal) Screw Plug (front)
140359E	25072	Feed Lifting Rock Shaft Oil Plug Screw...
140359E	25072	Feed Rock Shaft Oil Plug Screw for 146894
140439E	25073	Looper Holder Rock Shaft Oil Plug Screw for 146569
140440J	25111	Needle Bar Bushing (upper) Oil Plug Screw
140441W	25111	Pressure Regulating Thumb Screw.....
140442C	25098	Tension (looper thread) Screw Stud for 146618
140443J	25097	Tension (needle thread) Bracket Screw...
140443J	25050	Thread (needle) Thread Guide Bracket Screw
140542AL	25107	Needle Bar Crank Position Screw for 146865
140546C	25047	Needle Bar Thread Retainer Disc Screw for 146586
140552AL	25107	Needle Bar Connecting Link Hinge Stud Clamping Screw for 146865
140553E	25037	Oil Removing Wick (head end) Holder Body Hinge Screw for 146747.....
140695X	25072	Feed Dog Stop Screw for 146880.....
140734E	25037	Looper Holder Rock Shaft Bracket Screw for 146876
143008	25107	Arm Shaft (horizontal) Bushing (center)..
143015	25107	Arm Shaft (upright) Bevel Gear (lower) left hand spiral with two 1259AL.....
143015	25107	Arm Shaft (upright) Bevel Gear (upper) left hand spiral with two 1259AL, for 146878
143024	25107	Bed Hole Plug.....
143031	25072	Feed Bar Carrier Oil Wick for 147024 ...
143032	25072	Feed Bar Carrier Oil Wick Holder for 147024.....
143039	25072	Feed Lifting Rock Shaft Cap.....
143048	25072	Feed Rock Shaft Cap
143052	25072	Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder
143061	25046	Oil Flow Body Gasket
143062	25046	Oil Flow Window.....
143063	25046	Oil Flow Window Cap.....
143065	25046	Oil Pipe Clamping Sleeve, for 146597....
143066	25046	Oil Pipe Clamping Sleeve Nut for 146597 .
143071	25046	Oil Pump (centrifugal) Body Position Pin.
143073	25046	Oil Pump (centrifugal) Impeller.....
143124	25010	Oil Pipe Clamping Sleeve for 146594, 146595 and 146596
143125	25010	Oil Pipe Clamping Sleeve Nut for 146594, 146595 and 146596
143126	-----	Looper Holder Rock Shaft Bracket Oil Pipe Clamping Sleeve Adaptor
143126	25046	Oil Pipe Clamping Sleeve Adaptor for 146660

No.	Plate	Name
143126	-----	Oil Pipe Clamping Sleeve Adaptor (fastened to Bed).....
143236	25107	Arm Shaft (horizontal) Screw Plug (front) Washer (fiber).....
143236	25072	Feed Lifting Rock Shaft Oil Plug Screw Washer (fiber).....
143236	25072	Feed Rock Shaft Oil Plug Screw Washer (fiber) for 146894.....
143283	25030	Knee Lifter Rock Shaft Knee Arm for 143285.....
143284	25030	Knee Lifter Rock Shaft Knee Arm Hub with 356C and 140351AL, for 143285.....
143285	-----	Knee Lifter Rock Shaft Knee Arm complete, Nos. 2767, 143283 and 143284, for 146771.....
143308	25090	Machine Cushion (felt) accessories
143370	25046	Oil Lead
146006	25108	Bed Slide (right, button type) for 146007..
146007	25108	Bed Slide (right, button type) complete for Throat Plates with no off-set, Nos. 1423X, 146006, 146524, 146525 and two 240C
146057	25090	Wrench (socket) for 140552AL (accessories).....
146061	25108	Bed Slide (right, latch type) for 146062...
146062	25108	Bed Slide (right, latch type) complete for Throat Plates with no off-set Nos. 146061, 146688, 146689, 146690, 146691 and four 1470X.....
146505	25107	Arm Shaft (upright) Bushing (lower)
146508	25074	Arm Top Cover Gasket
146512	25074	Machine Pulley (disc power) "V" belt groove (outside diameter of belt groove 2.9 in.) with two 51283AL
146514	25037	Bed Leg (back)
146516	25073	Bed Rotary Shaft for 146650.....
146517	25073	Bed Rotary Shaft Bevel Gear, right hand spiral with two 1259AL
146518	25073	Bed Rotary Shaft Bushing (back).....
146519	25073	Bed Rotary Shaft Bushing (front).....
146520	25073	Bed Rotary Shaft Bushing (intermediate)..
146521	25041	Bed Slide (left) for 146522
146522	25041	Bed Slide (left) complete, Nos. 4307 146521 and two 725X.....
146523	-----	Bed Slide (right, button type) for 146526..
146524	25108	Bed Slide (right) Spring for 146007, 146526, 146835, 146846 and 146847.....
146525	-----	Bed Slide (right) Knob for 146007, 146526, 146835, 146846 and 146847.....
146526	-----	Bed Slide (right, button type) complete for Throat Plates with 3/64 in. off-set, Nos. 1423X, 146523, 146524, 146525 and two 240C

No.	Plate	Name
146528	25041	Face Plate.....
	NOTE:	When ordering No. 146528, state color required.
146529	25041	Face Plate Gasket.....
146537	25107	Feed Lifting Rock Shaft Connecting Rod for 146878.....
146539	25072	Feed Bar Slide Block Oil Wick Holder for 146882.....
146545	25107	Feed Rock Shaft Connecting Rod for 146878.....
146550	25073	Looper Avoiding Eccentric with two 1259AL
146551	25037	Arm Screw Stud (back).....
146552	25037	Arm Screw (front).....
146553	25073	Looper Avoiding Eccentric Connection (forked) with two 896AL.....
146554	25073	Looper Avoiding Eccentric Slide Block...
146556	25073	Looper Ball Crank for 146558.....
146557	25073	Looper Ball Crank Connection Nos. two each 896AL, 51715AL, 131927 and 131928, for 146558.....
146558	-----	Looper Ball Crank Connection 146557 with 132790, 146556 and 164232 for 146650 ..
146559	25073	Looper Ball Crank Hinge Pin
146565	25110	Looper Holder with 896AL and two 1253AL, for 146739.....
146567	25110	Looper Holder Bushing (eccentric) with 146647, for 146739.....
146568	25073	Looper Holder Hinge Pin.....
146569	25073	Looper Holder Rock Shaft with 140439E...
*146570	-----	Looper Holder Rock Shaft Bracket for 146876.....
	NOTE:	Due to the accuracy required for Looper Rock Shaft alignment, Looper Holder Rock Shaft Bracket cannot be supplied separately and can only be sent out as a Unit Arm, Bed and Looper Holder Rock Shaft Bracket assembled.
146571	25073	Looper Holder Rock Shaft Bushing (back) ..
146572	25073	Looper Holder Rock Shaft Bushing (front) ..
146573	25111	Needle Bar (hollow) for 146953
146576	25111	Needle Bar Bushing (upper)
146580	25111	Needle Bar Bushing (lower and upper) Oil Wick Clip for 146805
146581	-----	Needle Bar Connecting Link 146959 with 146582, for 146866
146582	25107	Needle Bar Connecting Link Hinge Stud for 146581
146585	25047	Needle Bar Thread Retainer Bracket for 146586
146586	25047	Needle Bar Thread Retainer Bracket complete, Nos. 10107, 140546C, 146585, 146665, 146666 and two each 42483, 50163XC and 54865

NUMERICAL LIST OF PARTS

35

No.	Plate	Name
146591	25046	Oil Flow Body.....
146593	25046	Oil Pipe, for 146597
146594	25010	Oil Pipe with two each 143124 and 143125, for oiling Bed Rotary Shaft intermediate Bearing
146595	25010	Oil Pipe with two each 143124 and 143125, for oiling Looper Rock Shaft Hinge Pin..
146596	25010	Oil Pipe with two each 143124 and 143125, for oiling Thread (under) Take-up Shaft Front Bearing
146597	25046	Oil Pipe complete from Oil Pump to Arm Shaft (horizontal) Center Bearing, Nos. 146593 with 143065 and 143066 (for Agents only)
146600	25046	Oil Pump (centrifugal) Cover
146603	-----	Thread (looper) Take-up Stripper Plate 146625 with 237J, 139148, 146623, 146624, 146626, 146628 and two 190J...
146604	25073	Oil Wick, for oiling Looper Ball Crank Pitman End Bearing (left)
146605	25073	Oil Wick Holder
146606	25073	Oil Wick Position Bracket with 140239AL ..
146609	25097	Presser Bar Lifting Lever Extension
146610	25097	Presser Bar Lifting Lever Spring
146611	25111	Presser Bar Spring
146612	25111	Presser Bar Spring Guide Pin
146617	25050	Slack Thread Controller
146618	-----	Tension (looper thread) Screw Stud 140442C with 51570C
146619	25098	Tension (looper thread) Thread Guard....
146620	25099	Tension (looper thread) Releaser Slide Connecting Link for 146801
146620	25097	Tension (needle thread) Releasing Shaft Crank Connecting Link
146621	25073	Thread (looper) Take-up with 465AL
146622	25073	Thread (looper) Take-up Screw Washer (fiber)
146623	25047	Thread (looper) Take-up Stripper for 146603
146624	25047	Thread (looper) Take-up Stripper Holder with 906AL, for 146603
146625	25047	Thread (looper) Take-up Stripper Plate for 146603
146626	25047	Thread (looper) Take-up Stripper Plate Support Plate for 146603
NOTE: One No. 146626 is screwed onto Machine Bed.		
146627	25047	Thread (looper) Take-up Thread Guide (left)
146628	25047	Thread (looper) Take-up Thread Guide (right) for 146603
146629	25050	Thread (needle) Thread Guide Bracket....
146630	25050	Thread (needle) Thread Guide Bracket Support
NOTE: When ordering No. 146630, state color required.		

No.	Plate	Name
146631	25098	Thread (looper) Thread Tube.....
146632	25098	Thread (looper) Thread Tube Thread Guide
146633	25050	Thread (needle) Eyelet (side of arm).....
146634	25111	Thread (needle) Take-up with 51460E, for 146635.....
146635	25111	Thread (needle) Take-up complete, Nos. 1449J, 54095, 68164 and 146634
146637	25015	Machine Base and Oil Reservoir for 146638 (accessories)
146638	25015	Machine Base and Oil Reservoir 146637 with 146639, 146693, 146695 and two 146640 (for Agents only) accessories...
146639	25015	Machine Base and Oil Reservoir Gasket (left) for 146638 (accessories)
146640	25015	Machine Pad (felt) for 146638 (accessories)
146647	25110	Looper Holder Bushing Pin for 146567....
146650	-----	Bed Rotary Shaft 146516 with 146558
146657	25046	Oil Pump (centrifugal) Screen.....
146658	25046	Oil Pump (centrifugal) Screen Frame
146659	25046	Oil Pump (centrifugal) Body for 146660...
146660	-----	Oil Pump (centrifugal) Body 146659 with three 143126
146661	25107	Arm Shaft (upright)
146665	25047	Needle Bar Thread Retainer (lower) for 146586
146666	25047	Needle Bar Thread Retainer (upper) for 146586
146671	25098	Thread (looper) Thread Tube Screw Stud Nut Washer
146672	25107	Arm Shaft (horizontal) Flanged Bushing (front)
146676	25097	Presser Bar Lifting Bracket Lifter.....
146682	25108	Needle Guard.....
146687	-----	Bed Slide (right, latch type) for 146692 ..
146688	25108	Bed Slide (right) Latch for 146062, 146692, 146723, 146821 and 146828....
146689	25108	Bed Slide (right) Latch Guide for 146062, 146692, 146723, 146821 and 146828....
146690	25108	Bed Slide (right) Latch Spring for 146062, 146692, 146723, 146821 and 146828....
146691	25108	Bed Slide (right) Spring for 146062, 146692, 146723, 146821 and 146828....
146692	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/64-in. off-set, Nos. 146687, 146688, 146689, 146690, 146691 and four 1470X.....
146693	25015	Machine Base and Oil Reservoir Oil Return Wick for 146638 (accessories)..
146694	25111	Presser Bar Lifting Bracket with 1057AL
146695	25015	Machine Base and Oil Reservoir Oil Return Wick Position Pad (felt) for 146638 (accessories).....

NUMERICAL LIST OF PARTS

37

No.	Plate	Name
146696	25037	Oil Removing Wick (head end) Hinge Plate and Cover for 146747.....
146697	25037	Oil Removing Wick (head end) Hinge Plate and Cover Gasket for 146747.....
146698	25037	Oil Removing Wick (head end) Holder Body Spring for 146746 and 146747.....
146700	25037	Oil Removing Wick (head end) Holder Body Stop and Spring Clip for 146747.....
146703	25111	Needle Bar Bushing (lower and upper) Oil Wick Clamp and Retainer for 146805....
146722	-----	Bed Slide (right, latch type) for 146723 ...
146723	-----	Bed Slide (right, latch type) complete for Throat Plate with 9/64 in. off-set, Nos. 146688, 146689, 146690, 146691, 146722 and four 1470X
146730	25110	Looper Ball Crank Pitman End Bearing (left) Body with two 175AL, for 146739...
146732	25110	Looper Throw-out Releaser for 146938....
146733	25110	Looper Throw-out Releaser Cap for 146938.....
146739	25110	Looper Holder 146565 with 1664J, 146567 and 146730.....
146742	25108	Needle Guard Holder.....
146743	25108	Needle Guard Holder Bracket
146744	25037	Oil Removing Wick (head end) for 146746 and 146747.....
146745	25037	Oil Removing Wick (head end) Holder Body for 146746 and 146747.....
146746	-----	Oil Removing Wick (head end) Holder Body 146745 with 146698 and 146744 (for Agents only).....
146747	25037	Oil Removing Wick (head end) Holder Body complete, Nos. 228E, 140553E, 146696, 146697, 146698, 146700, 146744 and 146745
146751	25111	Presser Bar Bushing (lower).....
146752	25111	Presser Bar Stop with 190J
146754	25110	Looper Throw-out Sleeve for 146938.....
146764	25030	Knee Lifter Chain,length 10-1/4 in., with 46865 and 56865 for 146779.....
146765	25030	Knee Lifter Rock Shaft for 146771.....
146766	25030	Knee Lifter Rock Shaft Hanger with two wood screws 1 in. No. 10 F.H., for 146771
146768	25030	Knee Lifter Rock Shaft Spring for 146771..
146769	25030	Knee Lifter Rock Shaft Stop Dog (back) with 140351AL, for 146771
146770	25030	Knee Lifter Rock Shaft Stop Dog (front) with 140351AL, for 146771
146771	25030	Knee Lifter Rock Shaft complete for 146779 Nos. 1115AL, 6337, 7125, 143285, 146765, 146768, 146769, 146770 and two 146766

No.	Plate	Name
146779	25030	Knee Lifter complete, Nos. 146764 and 146771.....
146780	25109	Presser Foot Shank for 131561.....
146790	25107	Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube with Holder
146791	25097	Presser Bar Lifting Lever.....
	NOTE:	When ordering No. 146791, state color required.
146792	25099	Tension (looper thread) Releaser for 146801.....
146794	25099	Tension (looper thread) Releaser Slide for 146801.....
146795	25099	Thread (looper) Uncurler for 146801.....
146796	25099	Thread (looper) Uncurler Plate (back) for 146801.....
146797	25099	Thread (looper) Uncurler Plate (front) for 146801.....
146801	25099	Tension (looper thread) Releaser Nos. 110C, 146620, 146794, 146796, 146797 and two each 72C, 217J, 146792 and 146795.....
146804	25111	Needle Bar Bushing (lower and upper) Oil Wick for 146805
146805	25111	Needle Bar Bushing (lower and upper) Oil Wick complete, Nos. 146703, 146804 and two 146580.....
146806	25051	Face Plate Thread Lubricator Oil Pad Holder for 146807.....
146807	-----	Face Plate Thread Lubricator Oil Pad Holder 146806 with 62827, 240439 and 241755, for 146808.....
146808	-----	Face Plate Thread Lubricator complete, for 146809, Nos. 8068, 17822, 124371 and 146807.....
146809	25051	Face Plate Thread Lubricator 146808 with 7071, 21202, 50222J, 140224J and 146810
146810	25051	Face Plate Thread Lubricator Adaptor for 146809.....
146820	-----	Bed Slide (right, latch type) for 146821 ...
146821	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/16 in. off-set, Nos. 146688, 146689, 146690, 146691, 146820 and four 1470X
146827	-----	Bed Slide (right, latch type) for 146828 ...
146828	-----	Bed Slide (right, latch type) complete for Throat Plates with 3/32 in. off-set, Nos. 146688, 146689, 146690, 146691, 146827 and four 1470X
146834	-----	Bed Slide (right, button type) for 146835 ..
146835	-----	Bed Slide (right, button type) complete for Throat Plates with 3/32 in. off-set, Nos. 1423X, 146524, 146525, 146834 and two 240C


No.	Plate	Name
146846	-----	Bed Slide (right, button type) complete for Throat Plates with 9/64 in. off-set, Nos. 1423X, 146524, 146525, 146848 and two 240C.....
146847	-----	Bed Slide (right, button type) complete for Throat Plates with 3/16 in. off-set, Nos. 1423X, 146524, 146525, 146849 and two 240C
146848	-----	Bed Slide (right, button type) for 146846..
146849	-----	Bed Slide (right, button type) for 146847...
*146863	-----	Arm
		NOTE: When ordering No. 146863, state color required.
146864	25107	Arm Shaft (horizontal) Bevel Gear, right hand spiral with 140333AL and two 1259AL, for 146878.....
146865	25107	Arm Shaft (horizontal) with 1036AL, 140542AL and 140552AL, for 146866....
146866	-----	Arm Shaft (horizontal) 146865 with 146581.
146867	25074	Arm Top Cover
		NOTE: When ordering No. 146867, state color required.
146868	25074	ArmTop Cover and Stitch Regulator Cap for 146869
		NOTE: When ordering No. 146868, state color required.
146869	25074	Arm Top Cover with Stitch Regulator Cap complete, Nos. 335X, 146868, 146870 and 146871.....
146870	25074	Arm Top Cover and Stitch Regulator Cap Gasket for 146869
146871	25074	Arm Top Cover and Stitch Regulator Cap Latch for 146869
146872	25108	Attachment Slide for 146873
146873	25108	Attachment Slide complete, Nos. 51282X, 146872 and 146874.....
146874	25108	Attachment Slide Spring for 146873.....
*146876	-----	Bed with 146570 and two each 126150 and 140734E.....
		NOTE: Due to the accuracy required for gear alignment, Bed cannot be supplied separately and can only be sent out as a unit, Arm and Bed assembled.
146877	25037	Bed Leg (front, long).....
146878	-----	Combination of Feed and Stitch Regulator Parts, Nos. 143015, 146537, 146545, 146864, 146883 and 146884
146879	25072	Feed Bar for 146880.....
146880	-----	Feed Bar 146879 with 1607X and 140695X for 146949
146881	25072	Feed Bar Slide Block Oil Wick for 146882.
146882	-----	Feed Bar Slide Block Oil Wick Holder 146539 with 146881

No.	Plate	Name
146883	25107	Feed Eccentric (adjustable) complete, for 146878, Nos. 50328C, two each 217J, 7071 and three 51061AL.....
146884	25107	Feed Lifting Eccentric with three 440AL for 146878
146885	25072	Feed Lifting Rock Shaft.....
146887	25107	Feed Lifting Rock Shaft Connecting Rod Hinge Pin
146887	25107	Feed Rock Shaft Connecting Rod Hinge Pin
146888	25072	Feed Lifting Rock Shaft Crank (back) with 462AL and two 50083AL.....
146889	25072	Feed Lifting Rock Shaft Crank (front) with 157X, for 146935.....
146891	25072	Feed Lifting Rock Shaft Oil Wick
146891	25072	Feed Rock Shaft Oil Wick for 146894.....
146892	25072	Feed Lifting Rock Shaft Oil Wick (long) ..
146893	25072	Feed Rock Shaft for 146894
146894	-----	Feed Rock Shaft Nos. 197E, 140359E, 143236, 146891, 146893, 146896, 147047 and two 147045
146895	25072	Feed Rock Shaft Crank with 462AL and two 157X.....
146896	25072	Feed Rock Shaft Oil Wick (long) for 146894.....
146897	25110	Looper Ball Crank Arm with 51320AL, for 146923
146904	25110	Looper Throw-out Spring for 146938.....
146907	25111	Needle Bar Bushing (lower).....
146908	25111	Needle Bar Connecting Stud Slide Block Guide.....
146918	25110	Looper Ball Crank Pitman End Bearing (right) Body with two 175AL, for 146919.....
146919	-----	Looper Ball Crank Pitman End Bearing (right) 146918 with 146948, for 146923 and 146924.....
146923	25110	Looper Ball Crank Arm 146897 with 1520J, 128551 and 146919.....
146924	-----	Looper Throw-out Device and Pitman Rod complete, Nos. 1520J, 128551, 146919 and 146938 (for Agents only).....
146933	25072	Feed Lifting Rock Shaft Bushing (front) ..
146934	25072	Feed Bar Slide Block for 146935.....
146935	-----	Feed Lifting Rock Shaft Crank (front) 146889 with 146934, for 146949.....
146936	25110	Looper Ball Crank Pitman Rod for 146937
146937	25110	Looper Ball Crank Pitman Rod 146936 with 51769C, for 146938.....
146938	25110	Looper Ball Crank Pitman Rod with Throw- out Device complete, for 146924 Nos. 29043, 50169J, 146732, 146733, 146754, 146904, 146937 and two 51159J.....
146945	25072	Feed Lifting Rock Shaft Hole Plug


No.	Plate	Name
146947	25110	Looper Ball Crank Pitman Rod Oil Shield. .
146948	25110	Looper Ball Crank Pitman Ball Screw Stud (right) for 146919
146949	-----	Feed Bar 146880 with 146935.....
146950	25109	Feed Dog, 14 teeth (10 teeth to the inch) for 146957
146951	25110	Looper (back) closed eye.....
146952	25110	Looper (front) closed eye.....
146953	-----	Needle Bar complete, Nos. 146573 and 146954
146954	25111	Needle Clamp with two 50014F, for 146953
146955	25109	Presser Foot Shank with 442AL and 1695J, for 146956
146956	25109	Presser Foot (hinged) complete, Nos. 26276, 131556 and 146955.....
146957	25109	Throat Plate for 146950
146958	25109	Throat Plate for 131559
146959	25111	Needle Bar Connecting Link for 146581....
147022	25072	Feed Bar Carrier with two each 158E and 176E
147023	25072	Feed Bar Carrier Hinge Pin
147024	-----	Feed Bar Carrier Oil Wick Holder 143032 with 143031
147029	25072	Feed Lifting Rock Shaft Collar with two 460AL
147029	25072	Feed Rock Shaft Collar with two 460AL....
147037	25072	Feed Lifting Rock Shaft Oil Wick (short) ..
147042	25072	Feed Lifting Rock Shaft Bushing (back)....
147042	25072	Feed Rock Shaft Bushing (back)
147043	25072	Feed Rock Shaft Bushing (front).....
147045	25072	Feed Rock Shaft Oil Wick (short) for 146894
147047	25072	Feed Lifting Rock Shaft Oil Wick Clamping Plate
147047	25072	Feed Rock Shaft Oil Wick Clamping Plate for 146894
147111	25107	Arm Shaft (upright) Bushing (upper).....
147112	25107	Arm Shaft (horizontal) Flanged Bushing (back).....
150203	25106	Thread Unwinder Spool Rest Cushion (felt) for 151037
150451	25030	Foot Lifter Treadle Stand for 150452.....
150452	25030	Foot Lifter Treadle complete, Nos. 4879, 4882, 126249, 126250, 150451 and two wood screws 1 in. No. 16 F.H.
151032	25106	Thread Unwinder Base with 138R and three wood wcrews 1 in. No. 12 F.H. for 151037
151033	25106	Thread Unwinder Spool Rest Bracket for 151037
151034	25106	Thread Unwinder Spool Rest Bracket Rod for 151037
151035	25106	Thread Unwinder Thread Guide for 151037.

NUMERICAL LIST OF PARTS



No.	Plate	Name
151037	25106	Thread Unwinder complete, for four spools, Nos. 51276R, 151032, 151033, 151034, two 228766, four each 150203, 151035, 228764 and eight each 1521R and 9525.....
151281	25090	Wrench (socket) accessories
151362	25091	Belt Guard Bottom Section with 2273 and 140321C, for 151367.....
151363	25091	Belt Guard Top Section with 151366 and two 219R, for 151367
151364	25091	Belt Guard Top Section Hinge Pin for 151367
151365	25091	Belt Guard Top Section Lock Spring for 151367
151366	25091	Belt Guard Top Section Fill-in Plate for 151363
151367	25091	Belt Guard (hinged) complete, Nos. 217E, 151362, 151363, 151364, 151365 and two wood screws 1-1/4 in. No. 12 F.H.B... NOTE: No. 151367 is furnished only when ordered.
164232	25073	Looper Ball Crank Connection Ball Sleeve Guide for 146558
201254C	25106	Thread Unwinder Spool Rest Set Screw for 228766
228764	25106	Thread Unwinder Spool Pin for 151037....
228766	25106	Thread Unwinder Spool Rest with 201254C, for 151037.....
240439	25051	Face Plate Thread Lubricator Oil Pad Retainer for 146807.....
241755	25051	Face Plate Thread Lubricator Oil Pad (felt) for 146807.....




From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC



25037-1/2



2504I-1/2

140061J




140061J



140050J




146528




140061J



146529




146522




25046-1/2



146597




25047-2/3



25050-1/2




146809




25051-1/2

From the library of: Superior Sewing Machine & Supply LLC

25072-1/3




From the library of: Superior Sewing Machine & Supply LLC




25073-1/3

From the library of: Superior Sewing Machine & Supply LLC


25074-1/2






25090-1/2

151367



25091-1/3


From the library of: Superior Sewing Machine & Supply LLC




25097-1/2

From the library of: Superior Sewing Machine & Supply LLC

25098.1/2




146801




From the library of: Superior Sewing Machine & Supply LLC

25099.1/2

25106-1/6






25107-1/3

From the library of: Superior Sewing Machine & Supply LLC

25108.1/2

146007



146524

146873



146872




146874



51282X



146743



190J

146682



176J




146742






190J




146062



25109-1/2





25110-1/2

25III-1/2

