

SINGER
262-21,-23,-24

Form 21227
(262)
Printed in U. S. A.

Singer Sewing Machine

LIST OF PARTS COMPLETE

FOR

Machine Nos. 262-21 to 262-24

WITH

HIGH MORTALITY LIST

THE SINGER MANUFACTURING COMPANY

From the library of: Superior Sewing Machine & Supply LLC

List of Parts Complete

for

Machine No. 262-21

No.		Name
16532	2	Arm Dowel Pin
50608(813)		Arm Hole Plug Screw (for access to Needle Bar Bushing Oil Wick)
139017		Arm Hole Plug Screw Washer
146551	2	Arm Screw (back)
146552		Arm Screw (front)
146121		Arm Shaft (horizontal) with 1036(830) and 140542(830)
146122		Arm Shaft (horizontal) 146121 with 143494
146864		Arm Shaft (horizontal) Bevel Gear, right hand spiral with 140333(830) and two 1259(830)
140333(830)		Arm Shaft (horizontal) Bevel Gear Position Screw
1259(830)	2	Arm Shaft (horizontal) Bevel Gear Set Screw
152503		Arm Shaft (horizontal) Bushing (center)
140296(830)		Arm Shaft (horizontal) Bushing (center) Set Screw
147112		Arm Shaft (horizontal) Flanged Bushing (back)
146790		Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube
207(805)		Arm Shaft (horizontal) Flanged Bushing (back) Oil Sump Tube Holder Screw
140296(830)		Arm Shaft (horizontal) Flanged Bushing (back) Set Screw
147005		Arm Shaft (horizontal) Flanged Bushing (front)
140331(830)		Arm Shaft (horizontal) Flanged Bushing (front) Set Screw
50555(805)		Arm Shaft (horizontal) Plug Screw

Machine No. 262-21

No.		Name
144(804)		Arm Shaft (horizontal) Screw (back)
140359(805)		Arm Shaft (horizontal) Screw Plug (front)
143236		Arm Shaft (horizontal) Screw Plug (front) Washer (fiber)
147468		Arm Shaft (horizontal) Thrust Collar with two 457(830)
457(830)	2	Arm Shaft (horizontal) Thrust Collar Set Screw
146077		Arm Shaft (upright)
143015		Arm Shaft (upright) Bevel Gear (lower) left hand spiral with two 1259(830)
1259(830)	2	Arm Shaft (upright) Bevel Gear (lower) Set Screw
143015		Arm Shaft (upright) Bevel Gear (upper) left hand spiral with two 1259(830)
1259(830)	2	Arm Shaft (upright) Bevel Gear (upper) Set Screw
146505		Arm Shaft (upright) Bushing (lower)
140298(830)		Arm Shaft (upright) Bushing (lower) Set Screw
147111		Arm Shaft (upright) Bushing (upper)
50504(830)		Arm Shaft (upright) Bushing (upper) Set Screw
146867		Arm Top Cover
146868		Arm Top Cover and Stitch Regulator Cap
146869		Arm Top Cover and Stitch Regulator Cap complete, Nos. 335(819), 146868, 146870 and 146871
146870		Arm Top Cover and Stitch Regulator Cap Gasket
146871		Arm Top Cover and Stitch Regulator Cap Latch
335(819)		Arm Top Cover and Stitch Regulator Cap Latch Screw
146508		Arm Top Cover Gasket

Machine No. 262-21

No.		Name
51369(813)	4	Arm Top Cover Screw
142385		Attachment Slide
142386		Attachment Slide complete, Nos. 51282(819), 142385 and 146874
146874		Attachment Slide Spring
51282(819)		Attachment Slide Spring Screw
143024		Bed Hole Plug
146078		Bed Leg (back)
965(805)	2	Bed Leg (back) Screw
146079		Bed Leg (front, long)
146005		Bed Rotary Shaft
146044		Bed Rotary Shaft 146005 with 132790, 146556, 164232 and two 131928 (for Agents only)
146517		Bed Rotary Shaft Bevel Gear, right hand spiral with two 1259(830)
1259(830)	2	Bed Rotary Shaft Bevel Gear Set Screw
146518		Bed Rotary Shaft Bushing (back)
448(830)		Bed Rotary Shaft Bushing (back) Set Screw
146519		Bed Rotary Shaft Bushing (front)
50554(830)		Bed Rotary Shaft Bushing (front) Set Screw
64342		Bed Rotary Shaft Collar with 454(830)
454(830)		Bed Rotary Shaft Collar Set Screw
146521		Bed Slide (left)
4307		Bed Slide (left) Spring

Machine No. 262-21

No.		Name
725(819)		Bed Slide (left) Spring Screw
146522		Bed Slide (left) complete, Nos. 4307, 146521 and two 725(819)
146127		Bed Slide (right) Body for 146131
146128		Bed Slide (right) Body for 146132
146129		Bed Slide (right) Body for 146133
146130		Bed Slide (right) Body for 146134
146688		Bed Slide (right) Latch
146689		Bed Slide (right) Latch Guide
1470(819)	2	Bed Slide (right) Latch Guide Screw
146690		Bed Slide (right) Latch Spring
146691		Bed Slide (right) Spring
1470(819)	2	Bed Slide (right) Spring Screw
146131		Bed Slide (right) Latch-type complete, for Throat Plates with .054 Off-set, Nos. 146127, 146688, 146689, 146690, 146691 and four 1470(819)
146132		Bed Slide (right) Latch-type complete for Throat Plates with .100 off-set, Nos. 146128, 146688, 146689, 146690, 146691 and four 1470(819)
146133		Bed Slide (right) Latch-type complete for Throat Plates with .116 off-set, Nos. 146129, 146688, 146689, 146690, 146691 and four 1470(819)
146134		Bed Slide (right) Latch-type complete for Throat Plates with .145 off-set, Nos. 146130, 146688, 146689, 146690, 146691 and four 1470(819)
152579		Combination of Feed and Stitch Regulator Parts, Nos. 143015, 143040, 143049, 146864, 146883 and 152578 (for Agents only)

Machine No. 262-21

No.		Name
143447		Face Plate
143543		Face Plate Gasket
140061(809)	3	Face Plate Screw (lower)
140050(809)		Face Plate Screw (upper)
146240		Feed Bar
146241		Feed Bar 146240 with 1607(819) and 140695(819)
146243		Feed Bar Assembly 146241 with 146244 (for Agents only)
147022		Feed Bar Carrier with two each 158(805) and 176(805)
158(805)	2	Feed Bar Carrier Clamping Screw
147023		Feed Bar Carrier Hinge Pin
176(805)	2	FeedBar Carrier Hinge Pin Clamping Screw
143031		Feed Bar Carrier Oil Wick (felt) for oiling Feed Bar Connecting Link
143032		Feed Bar Carrier Oil Wick Holder
147024		Feed Bar Carrier Oil Wick Holder 143032 with 143031
228(805)	2	Feed Bar Carrier Oil Wick Holder Screw
52266		Feed Bar Slide Block
52267		Feed Bar Slide Block 52266 with 125060
125060		Feed Bar Slide Block Hinge Stud
146881		Feed Bar Slide Block Oil Wick
146539		Feed Bar Slide Block Oil Wick Holder
50579(809)		Feed Bar Slide Block Oil Wick Holder Screw

Machine No. 262-21

No.	Name
146175	Feed Dog, 21 teeth (16 teeth to the inch) for 3/32 in. and 1/8 in. gauges, for 146176 Note: No. 146175 is furnished as regular to the machine when called for in standard gauge of 1/8 in. Note: When ordering No. 146175, state gauge required.
142375	Feed Dog with row of teeth between needles, 22 teeth (18 teeth to the inch) for 5/32 in. to 3/8 in. gauges for 10 to 18 stitches per inch, for chaining-off for use with 146290 Note: No. 142375 is furnished as regular to the machine when called for in standard gauges of 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 142375, state gauge required.
131321	Feed Dog, 16 teeth (16 teeth to the inch) for 5/32 in. to 11/32 in. gauges, with row of teeth between needles, for 131527 and 131528 Note: When ordering No. 131321, state gauge required.
131093	Feed Dog, 16 teeth (16 teeth to the inch) for 3/8 in. and 13/32 in. gauges, for 131094 and 131149 Note: When ordering No. 131093, state gauge required.
131160	Feed Dog, 16 teeth (16 teeth to the inch) for 3/8 in. to 1/2 in. gauges, for 131163 and 131166 Note: When ordering No. 131160, state gauge required.
131938	Feed Dog, 14 teeth (14 teeth to the inch) with row of teeth between the needles, for 5/32 in. to 11/32 in. gauges, for 131527 and 131528 Note: When ordering No. 131938, state gauge required.
157(809)	Feed Dog Screw
140695(819)	Feed Dog Stop Screw
1607(819)	Feed Dog Stop Screw Nut

Machine No. 262-21

No.		Name
51061(830)	3	Feed Eccentric Body Set Screw
7071	2	Feed Eccentric Clamping Washer
217(809)	2	Feed Eccentric Clamping Washer Screw
146883		Feed Eccentric (adjustable) complete, Nos. 50328(803), two each 217(809), 7071 and three 51061(830)
152578		Feed Lifting Eccentric with three 440(830)
440(830)	3	Feed Lifting Eccentric Set Screw
146095		Feed Lifting Rock Shaft
146096		Feed Lifting Rock Shaft Nos. 197(805), 140359(805), 143236, 146095, 146891, 146892, 147047 and two 147037
143052		Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder
228(805)		Feed Lifting Rock Shaft and Feed Rock Shaft Oil Wick Holder Screw
147028		Feed Lifting Rock Shaft Bushing (back)
147042		Feed Lifting Rock Shaft Bushing (front)
447(830)	2	Feed Lifting Rock Shaft Bushing Set Screw
143039		Feed Lifting Rock Shaft Cap
223(805)	2	Feed Lifting Rock Shaft Cap Screw
147029	2	Feed Lifting Rock Shaft Collar with two 460(830)
460(830)	4	Feed Lifting Rock Shaft Collar Set Screw
143040		Feed Lifting Rock Shaft Connecting Rod
140230(803)		Feed Lifting Rock Shaft Connecting Rod Hinge Screw
1518(809)		Feed Lifting Rock Shaft Connecting Rod Hinge Screw Nut
146094		Feed Lifting Rock Shaft Crank (back) with 140228(830)

Machine No. 262-21

No.	Name
140228(830)	Feed Lifting Rock Shaft Crank (back) Clamping Screw
146889	Feed Lifting Rock Shaft Crank (front) with 157(819)
146244	Feed Lifting Rock Shaft Crank (front) 146889, with 50579(809) 52267, 146539 and 146881
157(819)	Feed Lifting Rock Shaft Crank (front) Clamping Screw
140359(805)	Feed Lifting Rock Shaft Oil Plug Screw
143236	Feed Lifting Rock Shaft Oil Plug Screw Washer (fiber)
146891	Feed Lifting Rock Shaft Oil Wick
146892	Feed Lifting Rock Shaft Oil Wick (long)
147037	2 Feed Lifting Rock Shaft Oil Wick (short)
147047	Feed Lifting Rock Shaft Oil Wick Clamping Plate
197(805)	Feed Lifting Rock Shaft Oil Wick Clamping Plate Screw
50328(803)	Feed Regulating Screw
146091	Feed Rock Shaft
146092	Feed Rock Shaft Nos. 197(805), 140359(805), 143236, 146091, 146891, 146896, 147047 and two 147045
147028	Feed Rock Shaft Bushing (back)
447(830)	Feed Rock Shaft Bushing (back) Set Screw
146097	Feed Rock Shaft Bushing (front)
624(830)	Feed Rock Shaft Bushing (front) Set Screw
146098	Feed Rock Shaft Cap
50258(805)	Feed Rock Shaft Cap Screw (long)
223(805)	Feed Rock Shaft Cap Screw (short)

Machine No. 262-21

No.	Name
147029	Feed Rock Shaft Collar with two 460(830)
460(830)	2 Feed Rock Shaft Collar Set Screw
143049	Feed Rock Shaft Connecting Rod
140230(803)	Feed Rock Shaft Connecting Rod Hinge Screw
1518(809)	Feed Rock Shaft Connecting Rod Hinge Screw Nut
146099	Feed Rock Shaft Crank with 140228(830)
140228(830)	Feed Rock Shaft Crank Clamping Screw
140359(805)	Feed Rock Shaft Oil Plug Screw
143236	Feed Rock Shaft Oil Plug Screw Washer (fiber)
146891	Feed Rock Shaft Oil Wick
146896	Feed Rock Shaft Oil Wick (long)
147045	2 Feed Rock Shaft Oil Wick (short)
147047	Feed Rock Shaft Oil Wick Clamping Plate
197(805)	Feed Rock Shaft Oil Wick Clamping Plate Screw
207(809)	Lap Seam Feller Adjusting Screw
161661	Lap Seam Feller on Shank (adjustable) with 207(809), for Light to Heavyweight material for 3/32 in. to 1/2 in. gauges, in steps of 1/32 in.
	Note: No. 161661 is regularly furnished unless otherwise specified on order.
	Note: When ordering No. 161661, state gauge and weight of material for which required.
160588	Lap seam Feller Clamping Plate

Machine No. 262-21

No.	Name
131458	Looper (back) closed eye for 3/32 in. to 1/2 in. gauges, in steps of 1/32 in. for lap seam felling
	Note: No. 131458 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.
	Note: When ordering No. 131458, state gauge required.
624(830)	Looper (back) Set Screw
131459	Looper (front) closed eye, for 3/32 in. to 1/2 in. gauges, steps of 1/32 in. for lap seam felling
	Note: No. 131459 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.
	Note: When ordering No. 131459, state gauge required.
624(830)	Looper (front) Set Screw
146550	Looper Avoiding Eccentric with two 1259(830)
146234	Looper Avoiding Eccentric Connection (forked) with two 896(830)
896(830)	2 Looper Avoiding Eccentric Connection Clamping Screw
1259(830)	2 Looper Avoiding Eccentric Set Screw
146554	Looper Avoiding Eccentric Slide Block
146556	Looper Ball Crank
146897	Looper Ball Crank Arm with 51320(830)
146923	Looper Ball Crank Arm 146897 with 1520(809), 128551 and 146919
51320(830)	Looper Ball Crank Arm Clamping Screw
132790	Looper Ball Crank Connection Ball Sleeve (two pieces)
164232	Looper Ball Crank Connection Ball Sleeve Guide

Machine No. 262-21

No.		Name
146557		Looper Ball Crank Connection with two 131928 (for Agents only)
146558		Looper Ball Crank Connection with two 132790, 146556, 164232 and two 131928 (for Agents only)
896(830)	2	Looper Ball Crank Connection Cap (lower) Screw
131927	2	Looper Ball Crank Connection Cap (upper) Screw Stud
51715(830)	2	Looper Ball Crank Connection Cap (upper) Screw Stud Nut
131928	2	Looper Ball Crank Connection Cap (upper) Screw Stud Nut Lock Washer
146559		Looper Ball Crank Hinge Pin
448(830)	2	Looper Ball Crank Hinge Pin Set Screw
146948		Looper Ball Crank Pitman Ball Screw Stud (right)
1520(809)		Looper Ball Crank Pitman Ball Screw Stud (right) Nut
128551		Looper Ball Crank Pitman Ball Screw Stud (right) Nut Locking Plate
146730		Looper Ball Crank Pitman End Bearing (left) with two 175(830) (for Agents only)
175(830)	2	Looper Ball Crank Pitman End Bearing (left) Cap Screw
1664(809)		Looper Ball Crank Pitman End Bearing (left) Nut
175(830)	2	LooperBall Crank Pitman EndBearing (right) Body Cap Screw
146918		Looper Ball Crank Pitman Head (right) with two 175(830)
146919		Looper Ball Crank Pitman Head (right) 146918 with 146948
146965		Looper Ball Crank Pitman Rod
146966		Looper Ball Crank Pitman Rod 146965 with 51769(803)

Machine No. 262-21

No.	Name
146967	Looper Ball Crank Pitman Rod with Throw-out Device complete, Nos. 240(809), 447(830), 1700(819), 146904, 146966, 146968, 146969, 146970, 146971 and two 51159(809)
51769(803)	Looper Ball Crank Pitman Rod Nut
146947	Looper Ball Crank Pitman Rod Oil Shield
51460(805)	Looper Ball Crank Pitman Rod Oil Shield Screw
7071	Looper Ball Crank Pitman Rod Oil Shield Screw Washer
146565	Looper Holder with 896(830) and two 624(830)
146739	Looper Holder 146565 with 1664(809), 146567 and two 175(830)
146567	Looper Holder Bushing (eccentric) with 146647
146647	Looper Holder Bushing Pin
896(830)	Looper Holder Clamping Screw
146105	Looper Holder Hinge Pin
146106	Looper Holder Hinge Pin Spacer
146225	Looper Holder Rock Shaft with 140439(805)
143126	Looper Holder Rock Shaft Bracket Oil Pipe Clamping Sleeve Adaptor
231(805)	Looper Holder Rock Shaft Bracket Oil Plug Screw (back)
140640(805)	Looper Holder Rock Shaft Bracket Oil Plug Screw (front)
147109	Looper Holder Rock Shaft Bracket Oil Plug Screw (front) Washer (fiber)
140734(805)	2 Looper Holder Rock Shaft Bracket Screw
126150	2 Looper Holder Rock Shaft Bracket Screw Washer
146226	Looper Holder Rock Shaft Bushing (back)

Machine No. 262-21

No.		Name
448(830)		Looper Holder Rock Shaft Bushing (back) Set Screw
146227		Looper Holder Rock Shaft Bushing (front)
448(830)		Looper Holder Rock Shaft Bushing (front) Set Screw
140439(805)		Looper Holder Rock Shaft Oil Plug Screw
146968		Looper Throw-out Releaser
146969		Looper Throw-out Releaser Cap
51159(809)	2	Looper Throw-out Releaser Cap Screw
146970		Looper Throw-out Releaser Guide
447(830)		Looper Throw-out Releaser Guide Screw and Pitman Rod Stop
1700(819)		Looper Throw-out Releaser Guide Screw and Pitman Rod Stop Nut
146971		Looper Throw-out Sleeve
146904		Looper Throw-out Spring
240(809)		Looper Throw-out Spring Screw
146512		Machine Pulley (disc power) "V" belt groove (outside diameter of belt groove 2.9 in.) with two 51283(830)
51283(830)	2	Machine Pulley Set Screw
143488		Needle Bar (hollow)
143489		Needle Bar complete for 3/32 in. to 3/8 in. gauges, Nos. 139116, 143488 and 143497

Note: No. 143489 is furnished as regular to machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.

Note: When ordering No. 143489, state gauge required.

Machine No. 262-21

No.	Name
146136	Needle Bar complete for 7/16 in. to 1/2 in. gauges, Nos. 131044 and 143488
	Note: When ordering No. 146136, state gauge required.
146907	Needle Bar Bushing (lower)
1133(830)	Needle Bar Bushing (lower) Set Screw
143490	Needle Bar Bushing (lower and upper) Oil Wick
143491	Needle Bar Bushing (lower and upper) Oil Wick complete, Nos. 143490, 146703 and two 146580
146703	Needle Bar Bushing (lower and upper) Oil Wick Clamp and Retainer
146580	2 Needle Bar Bushing (lower and upper) Oil Wick Clip
143492	Needle Bar Bushing (lower and upper) Oil Wick Guide Tube (in Arm)
143493	Needle Bar Bushing (upper)
140440(819)	Needle Bar Bushing (upper) Oil Plug Screw
1133(830)	Needle Bar Bushing (upper) Set Screw
143494	Needle Bar Connecting Link with 139533 and 143495
140552(830)	Needle Bar Connecting Link Hinge Stud Clamping Screw
1036(830)	Needle Bar Connecting Link Hinge Stud Position Set Screw
139533	Needle Bar Connecting Link Screw Cap
143495	Needle Bar Connecting Stud with 140061(805) and 143619
143619	Needle Bar Connecting Stud Oil Wick (felt)
140061(805)	Needle Bar Connecting Stud and Thread Take-up Lever Clamping Screw
139111	Needle Bar Connecting Stud Slide Block

Machine No. 262-21

No.	Name
143496	Needle Bar Connecting Stud Slide Block Guide
1485(805)	2 Needle Bar Connecting Stud Slide Block Guide Screw
59456	2 Needle Bar Connecting Stud Slide Block Guide Screw Washer
140542(830)	Needle Bar Crank Position Screw
139116	Needle Clamp with two 1498(806), for 3/32 in. to 3/8 in. gauges Note: No. 139116 is furnished as regular to machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 139116, state gauge required.
131044	Needle Clamp with two 1498(806) for 3/32 in. to 1/2 in. gauges Note: When ordering No. 131044, state gauge required.
143497	Needle Clamp Thread Guide
146137	Needle Guard for 3/32 in. to 5/32 in. gauges Note: No. 146137 is furnished as regular to machine when called for in standard gauges of 1/8 in. and 5/32 in. Note: When ordering No. 146137, state gauge required.
146138	Needle Guard for 3/16 in. to 9/32 in. gauges Note: No. 146138 is furnished as regular to machine when called for in standard gauges of 3/16 in. and 1/4 in. Note: When ordering No. 146138, state gauge required.
146139	Needle Guard for 5/16 in. to 3/8 in. gauges Note: When ordering No. 146139, state gauge required.
146140	Needle Guard for 7/16 in. to 1/2 in. gauges Note: When ordering No. 146140, state gauge required.

Machine No. 262-21

No.		Name
146109		Needle Guard Holder
146743		Needle Guard Holder Bracket
190(809)		Needle Guard Holder Bracket Screw
190(809)		Needle Guard Holder Screw
190(809)		Needle Guard Screw
1498(806)	2	Needle Set Screw
143176	2	Number Plate Rivet
146591		Oil Flow Body
143061	2	Oil Flow Body Gasket
143062		Oil Flow Window
143063		Oil Flow Window Cap
50257(809)	4	Oil Flow Window Cap Screw
143370		Oil Lead
51369(805)		Oil Lead Screw
146593		Oil Pipe
146022		Oil Pipe with two each 143124 and 143125, for oiling Looper Rock Shaft Hinge Pin
146110		Oil Pipe with two each 143124 and 143125, for oiling Thread (under) Take-up Shaft Front Bearing
143065		Oil Pipe Clamping Sleeve
143066		Oil Pipe Clamping Sleeve Nut
146597		Oil Pipe complete from Oil Pump to Arm Shaft (horizontal) Center Bearing 146593 with 143065 and 143066 (for Agents only)
143124	4	Oil Pipe Clamping Sleeve

Machine No. 262-21

No.		Name
143126	2	Oil Pipe Clamping Sleeve Adaptor for 146024
143126		Oil Pipe Clamping Sleeve Adaptor (fastened to Looper Ball Crank Hinge Pin)
143125	4	Oil Pipe Clamping Sleeve Nut
146659		Oil Pump (centrifugal) Body
146024		Oil Pump (centrifugal) Body 146659 with 146025 and two 143126
146025		Oil Pump (centrifugal) Body Plug
143071	2	Oil Pump (centrifugal) Body Position Pin
157(805)	3	Oil Pump (centrifugal) Body Screw
146600		Oil Pump (centrifugal) Cover
143073		Oil Pump (centrifugal) Impeller
50123(805)		Oil Pump (centrifugal) Impeller Locking Screw
146657		Oil Pump (centrifugal) Screen
146658		Oil Pump (centrifugal) Screen Frame
189(805)	3	Oil Pump (centrifugal) Screen Frame Screw
147107		Oil Removing Wick (head end)
149205		Oil Removing Wick (head end) Hinge Plate and Cover
147055		Oil Removing Wick (head end) Hinge Plate and Cover Gasket
197(819)	4	Oil Removing Wick (head end) Hinge Plate and Cover Screw
146745		Oil Removing Wick (head end) Holder Body
147108		Oil Removing Wick (head end) Holder Body 146745 with 146698 and 147107 (for Agents only)
140553(805)		Oil Removing Wick (head end) Holder Body Hinge Screw

Machine No. 262-21

No.	Name
146698	Oil Removing Wick (head end) Holder Body Spring
149206	Oil Removing Wick (head end) Holder Body complete, Nos. 140553(805), 146698, 146745, 147055, 147107 and 149205
146604	Oil Wick for oiling Looper Ball Crank Pitman End Bearing (left)
146605	Oil Wick Holder
193(805)	Oil Wick Holder Tube Bracket Screw
146606	Oil Wick Position Bracket with 140239(830)
140239(830)	Oil Wick Position Bracket Screw
139462	Presser Bar
146751	Presser Bar Bushing (lower)
1133(830)	Presser Bar Bushing (lower) Set Screw
146694	Presser Bar Guide Bracket with 1057(830)
1057(830)	Presser Bar Guide Bracket Clamping Screw
146676	Presser Bar Guide Bracket Lifter
807(819)	Presser Bar Guide Bracket Lifter Hinge Screw
143510	Presser Bar Lifting Lever
146111	Presser Bar Lifting Lever Extension
161(819)	2 Presser Bar Lifting Lever Extension Screw
802(819)	Presser Bar Lifting Lever Hinge Screw
143511	Presser Bar Lifting Lever Spring
146611	Presser Bar Spring
146612	Presser Bar Spring Guide Pin

Machine No. 262-21

No.	Name
146141	Presser Foot Plate (back) for standard gauges 1/8 in., 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 146141, state gauge required.
26276	Presser Foot Plate (back) Hinge Pin
146142	Presser Foot Plate (front) for standard gauges 1/8 in., 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 146142, state gauge required.
26276	Presser Foot Plate (front) Hinge Pin
146167	Presser Foot Plate Connection
26276	Presser Foot Plate Connection Hinge Pin
37160	Presser Foot Plate Connection Spring
139137	Presser Foot Shank
146143	Presser Foot (triple hinged) complete, for 1/8 in. to 1/2 in. gauges, for standard gauges 1/8 in., 5/32 in., 3/16 in. and 1/4 in. Nos. 37160, 139137, 146141, 146142, 146167 and three 26276 Note: No. 146143 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 146143, state gauge required.
26276	Presser Foot Hinge Pin
131591	Presser Foot Plate Note: When ordering No. 131591, state gauge required.
46087	Presser Foot Shank
131592	Presser Foot (hinged) complete, for 3/32 in. to 13/32 in. gauges, for plain stitching, for 131094, 131172 and 131528, Nos. 26276, 46087 and 131591 Note: When ordering No. 131592, state gauge required.

Machine No. 262-21

No.	Name
26276	Presser Foot Hinge Pin
131916	Presser Foot Plate
	Note: When ordering No. 131916, state gauge required.
46087	Presser Foot Shank
131917	Presser Foot (hinged) complete, for 3/32 in. to 13/32 in. gauges, for lap seam felling, Nos. 26276, 46087 and 131916
	Note: When ordering No. 131917, state gauge required.
26276	Presser Foot Hinge Pin
131161	Presser Foot Plate
	Note: When ordering No. 131161, state gauge required.
54120	Presser Foot Shank
131162	Presser Foot (hinged) complete, for 3/8 in. to 1/2 in. gauges, for lap seam felling, Nos. 26276, 54120 and 131161
	Note: When ordering No. 131162, state gauge required.
26276	Presser Foot Hinge Pin
131164	Presser Foot Plate
	Note: When ordering No. 131164, state gauge required.
46087	Presser Foot Shank
131165	Presser Foot (hinged) complete, for 3/32 in. to 1/2 in. gauges, for plain stitching, Nos. 26276, 46087 and 131164
	Note: When ordering No. 131165, state gauge required.
175(809)	Presser Foot Screw
141001(818)	Pressure Regulating Thumb Screw

Machine No. 262-21

No.		Name
51614(818)		Pressure Regulating Thumb Screw Nut
146616		Set of Mated Gears for Lower Shaft, Nos. 143015 and 146517
146911		Set of Mated Gears for Upper Shaft, Nos. 143015 and 146864
146617		Slack Thread Controller Clamp
54242		Slack Thread Controller
176(809)		Slack Thread Controller Clamp Screw
140239(809)		Slack Thread Controller Position Screw
2102	4	Tension (looper thread) Disc
51570(803)	2	Tension (looper thread) Regulating Thumb Nut
140442(803)	2	Tension (looper thread) Screw Stud
146618	2	Tension (looper thread) Screw Stud 140442(803) with 51570(803)
131740	2	Tension (looper thread) Spring
59537	2	Tension (looper thread) Spring Bushing (large)
59538	2	Tension (looper thread) Spring Bushing (small)
146117		Tension (looper thread) Thread Guard
131696	2	Tension (looper thread) Thread Guide
146795	2	Tension (looper thread) Uncurler
68002		Tension (needle thread) Bracket
140443(809)		Tension (needle thread) Bracket Screw
2102	4	Tension (needle thread) Disc
51570(803)	2	Tension (needle thread) Regulating Thumb Nut

Machine No. 262-21

No.		Name
146144 -		TENSION RELEASE COMPLETE 262-21 x 2 2077 r 2y
32572	2	Tension (needle thread) Releasing Disc
54988	2	Tension (needle thread) Releasing Pin
68003		Tension (needle thread) Releasing Shaft
54872		Tension (needle thread) Releasing Shaft Crank with 624(830)
146620		Tension (needle thread) Releasing Shaft Crank Connecting Link
110(803)	2	Tension (needle thread) Releasing Shaft Crank Connecting Link Hinge Screw
624(830)		Tension (needle thread) Releasing Shaft Crank Set Screw
68261		Tension (needle thread) Releasing Shaft Spring
316(803)		Tension (needle thread) Releasing Shaft Stop Screw
15444		Tension (needle thread) Releasing Shaft Stop Screw 316(803) with 1547(809)
1547(809)		Tension (needle thread) Releasing Shaft Stop Screw Nut
50326(803)	2	Tension (needle thread) Screw Stud
59539	2	Tension (needle thread) Screw Stud 50326(803) with 51570(803)
225(819)		Tension (needle thread) Screw Stud Hole Plug
131741	2	Tension (needle thread) Spring
59537	2	Tension (needle thread) Spring Bushing (large)
59538	2	Tension (needle thread) Spring Bushing (small)
131696	2	Tension (needle thread) Thread Guard
143570		Thread Guide (front of arm)
140180(809)		Thread Guide (front of arm) Screw
146621		Thread (looper) Take-up with 465(830)

Machine No. 262-21

No.		Name
1029(809)		Thread (looper) Take-up Screw
146622		Thread (looper) Take-up Screw Washer (fiber)
465(830)		Thread (looper) Take-up Screw Set Screw
146623		Thread (looper) Take-up Stripper
146624		Thread (looper) Take-up Stripper Plate Holder with 906(830)
146625		Thread (looper) Take-up Stripper Plate
146603		Thread (looper) Take-up Stripper Plate 146625 with 237(809), 139148, 146623, 146624, 146626, 146628 and two 190(809)
237(809)		Thread (looper) Take-up Stripper Plate Screw
146626	2	Thread (looper) Take-up Stripper Plate Support Plate Note: One No. 146626 is screwed onto Machine Bed.
190(805)	4	Thread (looper) Take-up Stripper Plate Support Plate Screw
906(830)		Thread (looper) Take-up Stripper Set Screw
139148		Thread (looper) Take-up Stripper Staple
190(809)	2	Thread (looper) Take-up Stripper Staple Screw
146627		Thread (looper) Take-up Thread Guide (left)
237(809)		Thread (looper) Take-up Thread Guide (left) Screw
146628		Thread (looper) Take-up Thread Guide (right)
237(809)		Thread (looper) Take-up Thread Guide (right) Screw
146238		Thread (looper) Thread Tube
1628(819)		Thread (looper) Thread Tube Screw Stud Nut
146671		Thread (looper) Thread Tube Screw Stud Nut Washer

Machine No. 262-21

No.		Name
146632		Thread (looper) Thread Tube Thread Guide
50027(809)		Thread (looper) Thread Tube Thread Guide Screw
146633		Thread (needle) Eyelet (side of arm)
176(809)		Thread (needle) Eyelet (side of arm) Position Screw
7071		Thread (needle) Eyelet (side of arm) Position Screw Washer
724(809)		Thread (needle) Eyelet (side of arm) Screw
143523		Thread (needle) Take-up with two 147079
147079	2	Thread (needle) Take-up Thread Eyelet Bushing
139158	2	Thread (needle) Thread Guide
146629		Thread (needle) Thread Guide Bracket
229(809)	4	Thread (needle) Thread Guide Screw
146176		Throat Plate for 3/32 in. and 1/8 in gauges, for 146175 Note: No. 146176 is furnished as regular to the machine when called for in standard gauge of 1/8 in. Note: When ordering No. 146176, state gauge required.
146290		Throat Plate for 5/32 in. to 3/8 in. gauges for 10 to 18 stitches per inch for chaining-off, for use with 142375 Note: No. 146290 is furnished as regular to the machine when called for in standard gauges of 5/32 in., 3/16 in. and 1/4 in. Note: When ordering No. 146290, state gauge required.
131527		Throat Plate, for 5/32 in. to 11/32 in. gauges, for 131321 and 131938, for lap seam felling Note: When ordering No. 131527, state gauge required.

Machine No. 262-21

No.		Name
131149		Throat Plate, for 3/8 in. and 13/32 in. gauges, for 131093, for lap seam felling
		Note: When ordering No. 131149, state gauge required.
131163		Throat Plate, for 3/8 in. to 1/2 in. gauges, for 131160, for lap seam felling
		Note: When ordering No. 131163, state gauge required.
131528		Throat Plate, for 5/32 in. to 11/32 in. gauges, for 131321 and 131938, for plain stitching.
		Note: When ordering No. 131528, state gauge required.
131094		Throat Plate, for 3/8 in. and 13/32 in. gauges, for 131093, for plain stitching
		Note: When ordering No. 131094, state gauge required.
131166		Throat Plate, for 3/8 in. to 1/2 in. gauges, for 131160, for plain stitching
		Note: When ordering No. 131166, state gauge required.
691(806)	2	Throat Plate Screw
143176	2	Trade Mark Rivet
Cat. No. 2793 (149xs25)		Needle

Machine Nos. 262-21 to 262-24

ACCESSORIES

(Domestic)

No.		Name
21145		Caution Tag Knee Lifter (see page headed "Knee Lifter Parts") Machine Base (see page headed "Machine Base and Oil Reservoir")
12361	2	Machine Hinge Connection
151559	4	Machine Rest Pad (rubber)
232333(805)	4	Machine Rest Pad Nail (5/8 in. (flat head) #17 barbed)
41564		Machine Rest Pin
Cat. No. 2793 (149xs25)	12	Needles for 262-21 and 262-22 Machines
Cat. No. 4107 (62x45)	12	Needles for 262-23 and 262-24 Machines
120344		Oiler (not filled) with 120345
120345		Oiler Spout
121741		One Quart Can (light grade) Oil
120341		Tweezers (curved)
150452		Foot Lifter Treadle complete, Nos. 4879, 4882, 126249, 126250, 150451 and two wood screws 1 in. No. 16 F.H.

Note: No. 150452 will be furnished on request in place of Knee Lifter parts in the Accessories.

Note: Presser Bar Stop No. 146752 must be fitted to the machine when using Foot Lifter No. 150452

Machine Nos. 262-21 to 262-24

ACCESSORIES

(Export)

No.		Name
21145		Caution Tag
		Knee Lifter (see page headed "Knee Lifter Parts")
		Machine Base (see page headed "Machine Base and Oil Reservoir")
12361	2	Machine Hinge Connection
151559	4	Machine Rest Pad (rubber)
232333(805)	4	Machine Rest Pad Nail (5/8 in. (flat head) #17 barbed)
41564		Machine Rest Pin
Cat. No. 2793 (149xs25)		Needles for 262-21 and 262-22 Machines
Cat. No. 4107 (62x45)		Needles for 262-23 and 262-24 Machines
120344		Oiler (not filled) with 120345
120345		Oiler Spout
121741		One Quart Can (light grade) Oil
121108		Screw Driver (machine) with 121107
121107		Screw Driver Blade
120093		Screw Driver Ferrule
120440		Screw Driver with 120441
120441		Screw Driver Blade
120089		Screw Driver Ferrule
151037		Thread Unwinder (see page headed "Thread Unwinder")
120341		Tweezers (curved)
8908		Wrench
23535		Wrench

Machine Nos. 262-21 to 262-24

ACCESSORIES

(Export)

No.	Name
42850	Wrench
151281	Wrench (socket)
150452	Foot Lifter Treadle complete, Nos. 4879, 4882, 126249, 126250, 150451 and two wood screws 1 in. No. 16 F. H.

Note: No. 150452 will be furnished on request in place of
Knee Lifter parts in the Accessories

Note: Presser Bar Stop No. 146752 must be fitted to the
machine when using Foot Lifter No. 150452.

Machine Nos. 262-21 to 262-24

Knee Lifter Parts

No.	Name
146188	Chain, 13-1/2 in. with 39576 and 56864
56864	Chain Hook (large)
39576	Chain Hook (small)
12501	Chain Pulley
141054(850)	Chain Pulley Hinge Screw Stud
1608(850)	Chain Pulley Hinge Screw Stud Nut
146169	Rock Shaft
146170	Rock Shaft Crank with 140351(830) and 143282
140350(803)	Rock Shaft Crank Adjusting Screw
143282	Rock Shaft Crank Adjusting Screw 140350(803) with 51649(809)
51649(809)	Rock Shaft Crank Adjusting Screw Lock Nut
140351(830)	Rock Shaft Crank Clamping Screw
146171	Rock Shaft Crank Collar with two 462(830)
462(830)	2 Rock Shaft Crank Collar Set Screw
143283	Rock Shaft Knee Arm
147489	Rock Shaft Knee Arm Hub with 140351(830) and 140737(869)
140351(830)	Rock Shaft Knee Arm Hub Clamping Screw
2767	Rock Shaft KneeArm Plate with 356(830)
150668	Rock Shaft Knee Arm Plate Pad (rubber)

Note: No. 150668 is used with but not regularly furnished
with the Knee Lifter and is supplied on order only.

Machine Nos. 262-21 to 262-24

(Knee Lifter Parts)

No.	Name
356(830)	Rock Shaft Knee Arm Plate Set Screw
140737(869)	Rock Shaft Knee Arm Set Screw
146236	Rock Shaft Lifting Lever with 51183(805)
51183(805)	Rock Shaft Lifting Lever Set Screw
146768	Rock Shaft Spring
1115(819)	Rock Shaft Spring Screw

Machine Base and Oil Reservoir

146148	Machine Base and Oil Reservoir with 141139(869)
146151	Machine Base and Oil reservoir 146148 with 146150, 146245, 146640, 146693, 151560 and 151561 (For Agents only)
141139(869)	Machine Base and Oil Reservoir Drain Plug
146150	Machine Base and Oil Reservoir Gasket (left)
146693	Machine Base and Oil Reservoir Oil Return Wick
146245	Machine Base and Oil Reservoir Oil Return Wick Position Pad (left)
146640	Machine Pad (felt)
151560	Machine Pad (felt, left back)
151561	Machine Pad (felt, left front)

Machine Nos. 262-21 to 262-24

Tension (looper thread) Releaser Assembly

No. 146144

No.		Name
146792	2	Tension (looper thread) Releaser
217(809)	2	Tension (looper thread) Releaser Screw
146794		Tension (looper thread) Releaser Slide
146114		Tension (looper thread) Releaser Slide Connecting Link
110(803)	2	Tension (looper thread) Releaser Slide Connecting Link Hinge Screw
72(803)	2	Tension (looper thread) Releaser Slide Hinge Screw
146144		Tension (looper thread) Releaser, Nos. 146114, 146794, 146796, 146797 and two each 72(803), 110(803), 217(809). and 146792
		Note: No. 146144 is not regularly furnished with machine but will be supplied if machine order so states and at an additional charge.
146796		Thread (looper) Uncurler Plate (back)
146797		Thread (looper) Uncurler Plate (front)

Machine Nos. 262-21 to 262-24

Thread Unwinder
(for Four Spools)

No.		Name
151032		Base with 138(813) and three wood screws 1 in. No. 12 F. H.
228764	4	Spool Pin
228766	2	Spool Rest with 201254(803)
151033		Spool Rest Bracket
151034		Spool Rest Bracket Rod
138(813)		Spool Rest Bracket Rod Set Screw
51276(813)		Spool Rest Bracket Screw
150203	4	Spool Rest Cushion (felt)
201254(803)	2	Spool Rest Set Screw
151035	4	Thread Guide
1521(813)	8	Thread Guide Nut
9525(813)	8	Thread Guide Nut Washer
151037		Thread Unwinder complete, for four spools, Nos. 51276(813), 151032, 151033, 151034 two 228766, four each 150203, 151035, 228764 and eight each 1521(813) and 9525(813)

Machine No. 262-22

Note: This machine is the same as No. 262-21 Machine
but with the following exceptions:

No.	Name
146075	Arm Shaft (horizontal) with 1036(830) and 140542(830) - In place of 146121
146076	Arm Shaft (horizontal) 146075 with 143494 - In place of 146122
146081	Bed Rotary Shaft - In place of 146005
146082	Bed Rotary Shaft 146081 with 132790, 146556, 164232 and two 131928 (for Agents only) - In place of 146044
146242	Combination of Feed and Stitch Regulator Parts, Nos. 143015, 143040, 143049, 146864, 146883 and 146914 (for Agents only) - In place of 152579
146914	Feed Lifting Eccentric with three 440(830) - In place of 152578

Machine No. 262-23

Note: This machine is the same as No. 262-21 Machine
but with the following exceptions:

No.	Name
146152	Arm Shaft (horizontal) with 1036(830) - In place of 146121
146153	Arm Shaft (horizontal) 146152 with 143494 - In place of 146122
146154	Bed Rotary Shaft - In place of 146005
146155	Bed Rotary Shaft 146154 with 132790, 146556, 164232 and two 131928 (for Agents only) - In place of 146044
146242	Combination of Feed and Stitch Regulator Parts, Nos 143015, 143040, 143049, 146864, 146883 and 146914 (for Agents only) - In place of 152579
146950	Feed Dog, 14 teeth (10 teeth to the inch) - In place of 142375
146914	Feed Lifting Eccentric with three 440(830) - In place of 152578
131552	Looper (back) closed eye, 3/16 in. gauge - In place of 131458
	Note: When ordering No. 131552, state gauge required.
131553	Looper (front) closed eye, 3/16 in. gauge - In place of 131459
	Note: When ordering No. 131553, state gauge required.
146173	Needle Bar complete for 3/16 in. gauge, Nos. 131555, 143488 and 143497 - In place of 143489
	Note: When ordering No. 146173, state gauge required.
131555	Needle Clamp with two 50014(806), for 3/16 in. gauge - In place of 139116
	Note: When ordering No. 131555, state gauge required.
146174	Needle Guard for 3/16 in. gauge - In place of 146137

Machine No. 262-23

No.		Name
50014(806)	2	Needle Set Screw - In place of (2) 1498(806)
143512		Presser Bar Spring - In place of 146611
131561		Presser Foot (hinged) complete, for 3/16 in. gauge, Nos. 26276, 131560 and 146780 - In place of 146143
		Note: When ordering No. 131561, state gauge required.
146160		Thread (looper) Take-up (small) with two 465(830)
465(830)	2	Thread (looper) Take-up (small) Set Screw
146161		Thread (looper) Take-up Stripper Plate - In place of 146625
146237		Thread (looper) Take-up Stripper Plate 146161 with 237(809), 139148, 146623, 146624, 146626, 146628 and two 190(809) - In place of 146603
146235		Thread (looper) Take-up Stripper Staple (left)
131558		Throat Plate for 3/16 in. gauge - In place of 146176
Cat. No. 4107 (62x45)		Needle - In place of Cat. No. 2793 (149xs25)

Machine No. 262-24

Note: This machine is the same as No. 262-21 Machine
but with the following exceptions:

No.	Name
146152	Arm Shaft (horizontal) with 1036(830) and 140542(830) - In place of 146121
146153	Arm Shaft (horizontal) 146152 with 143494 - In place of 146122
146154	Bed Rotary Shaft - In place of 146005
146155	Bed Rotary Shaft 146154 with 132790, 146556, 164232 and two 131928 (for Agents only) - In place of 146044
146242	Combination of Feed and Stitch Regulator Parts, Nos. 143015, 143040, 143049, 146864, 146883 and 146914 (for Agents only) - In place of 152579
146950	Feed Dog, 14 teeth (10 teeth to the inch) - In place of 142375
146914	Feed Lifting Eccentric with three 440(830) - In place of 152578
131563	Looper (back) closed eye, 1/32 in. gauge - In place of 131458
131564	Looper (front) closed eye, 1/32 in. gauge - In place of 131459
146179	Needle Bar complete for 1/32 in. gauge, Nos. 131064, 143488 and 143497 - In place of 143489
131064	Needle Clamp with two 50014(806) for 1/32 in gauge - In place of 139116
146174	Needle Guard - In place of 146137
50014(806)	2 Needle Set Screw - In place of (2) 1498(806)
143512	Presser Bar Spring - In place of 146611
131570	Presser Foot (hinged) with Knife complete, for 1/32 in. gauge, Nos. 239(809), 68140, 131349, 131568 and 131569 - In place of 146143

Machine No. 262-24

No.	Name
146160	Thread (looper) Take-up (small) with two 465(830)
465(830)	Thread (looper) Take-up (small) Set Screw
146161	Thread (looper) Take-up Stripper Plate - In place of 146625
146237	Thread (looper) Take-up Stripper Plate 146161 with 237(809), 139148, 146623, 146624, 146626, 146628 and two 190(809) - In place of 146603
146235	Thread (looper) Take-up Stripper Staple (left)
131567	Throat Plate for 1/32 in. gauge - In place of 146176
Cat. No. 4107 (62x45)	Needle - In place of Cat. No. 2793 (149xs25)

Recommended Spare Parts and Needles for one years maintenance

262-21 Machine				
** Gauge required must be stated				
1 M/c	Quantity 5 M/c	10 M/c	Part Number	Name
1	5	10	4307	Bed Slide (left) Spring
2	10	20	725(819)	Bed Slide (left) Spring Screw
1	5	10	146688	Bed Slide (right) Latch
1	5	10	146690	Bed Slide (right) Latch Spring
1	5	10	146691	Bed Slide (right) Spring
2	10	20	1470(819)	Bed Slide (right) Spring Screw
1	5	10	**146175	Feed Dog for use with 146175 (3/32 in. and 1/8 in. gauges)
Note: No. 146175 is furnished as regular to the machine when called for in standard gauge of 1/8 in.				
1	5	10	**142375	Feed Dog for use with 147290 (5/32 in. to 3/8 in. gauges)
Note: No. 142375 is furnished as regular to the machine when called for in standard gauges of 5/32 in., 3/16 in. and 1/4 in.				
2	10	20	157(809)	Feed Dog Screw
2	10	20	**131458	Looper (back) closed eye for 3/32 in. to 1/2 in. gauges in steps of 1/32 for lap seam felling
Note: No. 131458 is furnished as regular when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.				
2	10	20	**131459	Looper (front) closed eye for 3/32 in. to 1/2 in. gauges in steps of 1/32 in. for lap seam felling
Note: No. 131459 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.				
4	20	40	624(830)	Looper Set Screw

262-21 Machine

1 M/c	Quantity 5 M/c	10 M/c	Part Number	Name
1	5	10	**143489	Needle Bar complete for 3/32 in. to 3/8 in. gauges Note: No. 143489 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.
2	10	20	**146137	Needle Guard for 3/32 in. to 5/32 in. gauges Note: No. 146137 is furnished as regular to the machine when called for in standard gauges of 1/8 in and 5/32 in.
2	10	20	**146138	Needle Guard for 3/16 in. to 9/32 in. gauges Note: No. 146138 is furnished as regular to machine when called for in standard gauges of 3/16 in and 1/4 in.
6	30	60	1498(806)	Needle Set Screw
1	5	10	139462	Presser Bar
1	5	10	143510	Presser Bar Lifting Lever
1	5	10	146611	Presser Bar Spring
1	5	10	**146143	Presser Foot (triple hinged) complete (1/8 in. to 1/2 in. gauges) Note: No. 146143 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 5/32 in., 3/16 in. and 1/4 in.
1	5	10	176(809)	Presser Foot Screw
1	5	10	146617	Slack Thread Controller
16	80	160	2102	Tension Disc
2	10	20	146618	Tension (looper thread) Screw Stud
1	5	10	146617	Tension (looper thread) Thread Guard
4	20	40	131696	Tension Thread Guide
2	10	20	59539	Tension (needle thread) Screw Stud
1	5	10	143570	Thread Guide (front of arm)
1	5	10	140180(809)	Thread Guide (front of arm) Screw
1	5	10	146621	Thread (looper) Take-up
1	5	10	146623	Thread (looper) Take-up Stripper
1	5	10	146603	Thread (looper) Take-up Stripper Plate
1	5	10	146627	Thread (looper) Take-up Thread Guide (left)
1	5	10	146628	Thread (looper) Take-up Thread Guide (right)
2	10	20	237(809)	Thread (looper) Take-up Thread Guide Screw

262-21 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
1	5	10	146632	Thread (looper) Thread Tube Thread Guide
1	5	10	50027(809)	Thread (looper) Thread Tube Thread Guide Screw
1	5	10	146633	Thread (needle) Eyelet (side of arm)
1	5	10	724(809)	Thread (needle) Eyelet (side of arm) Screw
1	5	10	143523	Thread (needle) Take-up
2	10	20	139158	Thread (needle) Thread Guide
1	5	10	**146176	Throat Plate (3/32 in. and 1/8 in. gauges) for use with 146175
				Note: No. 146176 is furnished as regular to the machine when called for in standard gauge of 1/8 in.
1	5	10	**146290	Throat Plate (5/32 in. to 3/8 in. (gauges) for use with 142375
				Note: No. 146290 is furnished as regular to the machine when called for in standard gauges of 5/32 in., 3/16 in. and 1/4 in.
4	20	40	891(806)	Throat Plate Screw

Needles

Cat. No. 2793 (149xs25)

Recommended Spare Parts and Needles for one years maintenance

262-22 Machine

** Gauge required must be stated

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
1	5	10	4307	Bed Slide (left Spring
2	10	20	725(819)	Bed Slide (left) Spring Screw
1	5	10	146688	Bed Slide (right) Latch
1	5	10	146690	Bed Slide (right) Latch Spring
1	5	10	146691	Bed Slide (right) Spring
2	10	20	1470(819)	Bed Slide (right) Spring Screw
1	5	10	**146175	Feed Dog for use with 146176 (3/32 in. to 1/8 in. gauges)
				Note: No. 146175 is furnished as regular to the machine when called for in standard gauge of 1/8 in.
1	5	10	**142375	Feed Dog for use with 146290 (5/32 in. to 3/8 in. gauges)
				Note: No. 142375 is furnished as regular to the machine when called for in standard gauges of 3/16 in. and 1/4 in.
1	5	10	**146177	Feed Dog for use with 146178 (7/16 in. and 1/2 in. gauges)
				Note: No. 146177 is furnished as regular to the machine when called for in standard gauge of 1/2 in.
2	10	20	157(809)	Feed Dog Screw
2	10	20	**131458	Looper (back) closed eye for 3/32 in. to 1/2 in. gauges, in steps of 1/32 in. for lap seam felling
				Note: No. 131458 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 3/16 in., 1/4 in. and 1/2 in.
2	10	20	**131459	Looper (front) closed eye, for 3/32 in. to 1/2 in. gauges, in steps of 1/32 in. for lap seam felling
				Note: No. 131459 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 3/16 in., 1/4 in. and 1/2 in.

262-22 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
4	20	40	624(830)	Looper Set Screw
1	5	10	**143489	Needle Bar complete for 3/32 in. to 3/8 in. gauges Note: No. 143489 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 3/16 in. and 1/4 in.
1	5	10	**146136	Needle Bar complete for 7/16 in. and 1/2 in. gauges Note: No. 146136 is furnished as regular to the machine when called for in standard gauges of 1/2 in.
2	10	20	**146137	Needle Guard for 3/32 in. to 5/32 in. gauges Note: No. 146137 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 3/16 in. and 1/4 in.
2	10	20	**146138	Needle Guard for 3/16 in. to 9/32 in. gauges Note: No. 146138 is furnished as regular to the machine when called for in standard gauges of 3/16 in. and 1/4 in.
6	30	60	1498(806)	Needle Set Screw
1	5	10	139462	Presser Bar
1	5	10	143510	Presser Bar Lifting Lever
1	5	10	146611	Presser Bar Spring
1	5	10	**146143	Presser Foot (triple hinged) complete (1/8 in. to 1/2 in. gauges) Note: No. 146143 is furnished as regular to the machine when called for in standard gauges of 1/8 in., 3/16 in., 1/4 in. and 1/2 in.
1	5	10	176(809)	Presser Foot Screw
1	5	10	146617	Slack Thread Controller
16	80	160	2102	Tension Disc
2	10	20	146618	Tension (looper thread) Screw Stud
1	5	10	146117	Tension (looper thread) Thread Guard
4	20	40	136696	Tension Thread Guide
2	10	20	59539	Tension (needle thread) Screw Stud
1	5	10	143570	Thread Guide (front of arm)
1	5	10	140180(809)	Thread Guide (front of arm) Screw
1	5	10	146621	Thread (looper) Take-up

262-22 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
1	5	10	146623	Thread (looper) Take-up Stripper
1	5	10	146603	Thread (looper) Take-up Stripper Plate
1	5	10	146627	Thread (looper) Take-up Thread Guide (left)
1	5	10	146628	Thread (looper) Take-up Thread Guide (right)
2	10	20	237(809)	Thread (looper) Take-up Thread Guide Screw
1	5	10	146632	Thread (looper) Thread Tube Thread Guide
1	5	10	50027(809)	Thread (looper) Thread Tube Thread Guide Screw
1	5	10	146633	Thread (needle) Eyelet (side of arm)
1	5	10	724(809)	Thread (needle) Eyelet (side of arm) Screw
1	5	10	143523	Thread (needle) Take-up
2	10	20	139138	Thread (needle) Thread Guide
1	5	10	**146176	Throat Plate (3/32 in. and 1/8 in. gauges)
				Note: No. 146176 is furnished as regular to the machine when called for in standard gauge of 1/8 in.
1	5	10	**146290	Throat Plate (5/32 in. to 3/8 in. gauges)
				Note: No. 146290 is furnished as regular to the machine when called for in standard gauges of 3/16 in. and 1/4 in.
1	5	10	**146178	Throat Plate (7/16 in. and 1/2 in. gauges)
				Note: No. 146178 is furnished as regular to the machine when called for in standard gauge of 1/2 in.
4	20	40	691(806)	Throat Plate Screw

Needles

Cat. No. 2793 (149xs25)

Recommended Spare Parts and Needles for one years maintenance

262-23 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
1	5	10	4307	Bed Slide (left) Spring
2	10	20	725(819)	Bed Slide (left) Spring Screw
1	5	10	146688	Bed Slide (right) Latch
1	5	10	146690	Bed Slide (right) Latch Spring
1	5	10	146691	Bed Slide (right) Spring
2	10	20	1470(819)	Bed Slide (right) Spring Screw
1	5	10	146950	Feed Dog for use with 131558
1	5	10	157(809)	Feed Dog Screw
2	10	20	131552	Looper (back) closed eye
2	10	20	131553	Looper (front) closed eye
4	20	40	624(830)	Looper Set Screw
1	5	10	146173	Needle Bar complete
2	10	20	146174	Needle Guard
6	30	60	1498(806)	Needle Set Screw
1	5	10	139462	Presser Bar
1	5	10	143510	Presser Bar Lifting Lever
1	5	10	143512	Presser Bar Spring
1	5	10	131561	Presser Foot (hinged) complete
1	5	10	176(809)	Presser Foot Screw
1	5	10	146617	Slack Thread Controller
16	80	160	2102	Tension Disc
2	10	20	146618	Tension (looper thread) Screw Stud
1	5	10	146117	Tension (looper thread) Thread Guard
4	20	40	131696	Tension Thread Guide
2	10	20	59539	Tension (needle thread) Screw Stud
1	5	10	143570	Thread Guide (front of arm)
1	5	10	140180(809)	Thread Guide (front of arm) Screw
1	5	10	146621	Thread (looper) Take-up (large)
1	5	10	146160	Thread (looper) Take-Up (small)
2	10	20	1029(809)	Thread (looper) Take-up Screw
1	5	10	146623	Thread (looper) Take-up Stripper
1	5	10	146237	Thread (looper) Take-up Stripper Plate
1	5	10	146627	Thread (looper) Take-up Thread Guide (left)
1	5	10	146628	Thread (looper) Take-up Thread Guide (right)

262-23 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
2	10	20	190(809)	Thread (looper) Take-up Thread Guide Screw
1	5	10	146632	Thread (looper) Thread Tube Thread Guide
1	5	10	50027(809)	Thread (looper) Thread Tube Thread Guide Screw
1	5	10	146623	Thread (needle) Eyelet (side of arm)
1	5	10	724(809)	Thread (needle) Eyelet (side of arm) Screw
1	5	10	143523	Thread (needle) Take-up
2	10	20	139158	Thread (needle) Thread Guide
1	5	10	131558	Throat Plate for use with 146950
2	10	20	691(806)	Throat Plate Screw

Needles

Cat. No. 4107 (62x45)

Recommended Spare Parts and Needles for one years maintenance

262-24 Machine

1 M/c	Quantity		Part Number	Name
	5 M/c	10 M/c		
1	5	10	4307	Bed Slide (left) Spring
2	10	20	725(819)	Bed Slide (left) Spring Screw
1	5	10	146688	Bed Slide (right) Latch
1	5	10	146690	Bed Slide (right) Latch Spring
1	5	10	146691	Bed Slide (right) Spring
2	10	20	1470(819)	Bed Slide (right) Spring Screw
1	5	10	146950	Feed Dog for use with 131567
1	5	10	157(809)	Feed Dog Screw
2	10	20	131563	Looper (back) closed eye
2	10	20	131564	Looper (front) closed eye
4	20	40	624(830)	Looper Set Screw
1	5	10	146179	Needle Bar complete
2	10	20	146174	Needle Guard
6	30	60	50014(806)	Needle Set Screw
1	5	10	139462	Presser Bar
1	5	10	143510	Presser Bar Lifting Lever
1	5	10	143512	Presser Bar Spring
1	5	10	131570	Presser Foot (hinged) with Knife complete
1	5	10	176(809)	Presser Foot Screw
1	5	10	146617	Slack Thread Controller
16	80	160	2102	Tension Disc
2	10	20	146618	Tension (looper thread) Screw Stud
1	5	10	146117	Tension (looper thread) Thread Guard
4	20	40	131696	Tension Thread Guide
2	10	20	59539	Tension (needle thread) Screw Stud
1	5	10	143570	Thread Guide (front of arm)
1	5	10	140180(809)	Thread Guide (front of arm) Screw
1	5	10	146621	Thread (looper) Take-up (large)
1	5	10	146160	Thread (looper) Take-up (small)
2	10	20	1029(809)	Thread (looper) Take-up Screw
1	5	10	146623	Thread (looper) Take-up Stripper
1	5	10	146624	Thread (looper) Take-up Stripper Plate
1	5	10	146627	Thread (looper) Take-up Thread Guide (left)
1	5	10	146628	Thread (looper) Take-up Thread Guide (right)
2	10	20	190(809)	Thread (looper) Take-up Thread Guide Screw

262-24 Machine

<u>1 M/c</u>	<u>Quantity</u> 5 M/c	10 M/c	<u>Part</u> <u>Number</u>	<u>Name</u>
1	5	10	146633	Thread (needle) Eyelet (side of arm)
1	5	10	724(809)	Thread (needle) Eyelet (side of arm)
				Screw
1	5	10	143523	Thread (needle) Take-up
2	10	20	139158	Thread (needle) Thread Guide
1	5	10	131567	Throat Plate for 146950
2	10	20	691(806)	Throat Plate Screw

Needles

Cat. No. 4107 (62x45)