

62-29

NUMBERING DEPARTMENT  
MARCH 17, 1915

# LIST OF PARTS COMPLETE



FOR

## Machine No. 62=29

---

THE SINGER MANUFACTURING COMPANY

# LIST OF PARTS COMPLETE FOR MACHINE NO. 62-29

For Casket Linings. Has positive ruffling mechanism for full or scant ruffling, fitted with a combination edge folder and edge guide for folding the edge of the backing, guiding and ruffling silk facing and Tube Foot for laying the braid over the folded and ruffled edges in one operation.

## FORMERLY 62 S. V. 58 MACHINE

*52799	Arm, upper and lower (solid) with 52814, 52815 and two each 129E and 190D.....
52630	Arm Oil Tube with 49092, for oiling 46221.....
49092	" " " Packing (felt).....
46216	" Rock Shaft.....
46217	" " " Crank (back) with two 1497c.....
1497c	" " " " " Set Screw.....
38412	" " " " (front) with 443c.....
23724	" " " " " Pin.....
443c	" " " " " Set Screw.....
46218	" Rotary Shaft.....
38329	" " " Collar with two 457c.....
457c	" " " " " Set Screw.....
38174	" " " Flanged Bushing.....
159F	" " " " " Screw.....
4784	" " " Oil Pad (felt).....
144D	" " " Screw.....
17509	" Side Cover (lower).....
286D	" " " " Thumb Screw.....
52554	" " " (upper).....
9533	" " " " Pin.....
190D	" " " " Screw.....
52800	Balance Wheel and Ruffling Eccentric with two 430c..
430c	" " " " " Set Screw.....
46078	Cloth Plate.....
691F	" " " Screw (left).....
1094F	" " " (right).....
46461	" " " Slide (left).....



38419	Cloth Plate Slide (left) Spring.....
725J	" " " " " Screw.....
46462	Cloth Plate Slide (left) complete, Nos. 38419, 46461 and two 725J.....
38105H	Cloth Plate Slide (right) with 1602E.....
1602E	" " " " Bushing.....
286D	" " " " Thumb Screw.....
46079	Cloth Plate complete, Nos. 286D, 1460H, 38105H, 46078, 46082 and 46462.....
46221	Crank Connecting Rod with 46222, 46223 and two each 896E and 1057E.....
50069C	Crank Connecting Rod Ball Screw Stud.....
1619E	" " " " " " Nut.....
*46222	" " " Cap (lower).....
896E	" " " " " Screw.....
*46223	" " " " (upper).....
1057E	" " " " " Screw.....
46225	" " " Washer (fibre).....
46179	Face Plate.....
46111	" " Pin.....
286D	" " Thumb Screw.....
38425	Feed Bar with 231c and 460c.....
23716	" " Bushing.....
23726	" " Hinge Pin.....
231c	" " Set Screw.....
38426	" " Slide Block.....
38427	Connecting Rod with 1057E, 23865 and two 896E.....
*23865	" " Cap.....
896E	" " " " Screw.....
23866	" " " Hinge Pin (eccentric).....
1057E	" " " " Clamping Screw.....
52801	" Dog.....
898D	" " Screw.....
460c	" " Stop Screw.....
*38127	" Eccentric.....
*23729	" " Body.....
443c	" " " Set Screw.....
21331	" " Pressure Spring.....
21332	" " " " Cap.....
934D	" " " " " Screw.....
196F	" " Set Screw.....
38128	Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103c, 21331, 21332, 23729, 38127 and two 443c.....
38429	Feed Lifting Eccentric with two 465c.....
46113	" " " Cover.....
335D	" " " " Screw.....
465c	" " " Set Screw.....

1103c	Feed Regulating Screw.....	
38431	" Rocking Frame.....	
38432	" " " Bracket with two 465c.....	
123E	" " " " Screw.....	
38433	" " " Hinge Pin.....	
465c	" " " " " Set Screw.....	
46082	Folder Holder Seat Cover.....	
1460H	" " " " Screw.....	
46335	Looper with 590b and 38393.....	
46226	" Bell Crank with 1037c.....	
38436	" " " Hinge Stud.....	
443c	" " " " " Set Screw.....	
46227	Looper Bell Crank Pitman complete, Nos. 1706E, 1713E and 46233 to 46235.....	
50070c	Looper Bell Crank Pitman Ball Screw Stud (upper)...	
1636E	" " " " " " " Nut	
46228	" " " " " " Stud (lower).....	
1037c	" " " " " " Set Screw	
*46229	" " " " " Cap (lower).....	
171E	" " " " " " Screw.....	
*46230	" " " " " (upper).....	
171E	" " " " " " Screw.....	
*46231	" " " " " End Bearing (lower).....	
*46232	" " " " " " (upper).....	
46233	" " " " " Head (lower) Nos. 46228, 46229, 46231 and two 171E.....	
46234	Looper Bell Crank Pitman Head (upper) Nos. 46230, 46232, 50070c and two 171E.....	
46235	Looper Bell Crank Pitman Rod.....	
1706E	" " " " " Nut (lower).....	
1713E	" " " " " " (upper).....	
38439	" Carrier with 1143c and two 1147c.....	
38440	" " Hinge Pin.....	
1147c	" " " " Set Screw.....	
46236	Looper Carrier Pitman complete, Nos. 1708E, 1709E and 46241 to 46243.....	
50070c	Looper Carrier Pitman Ball Screw Stud (right).....	
1636E	" " " " " " " Nut...	
46237	" " " " " Stud (left).....	
1147c	" " " " " " Set Screw.....	
*46238	" " " " Cap (left).....	
171E	" " " " " " Screw.....	
*46238	" " " " " (right).....	
171E	" " " " " " Screw.....	
*46239	" " " " End Bearing (left).....	
*46240	" " " " " (right).....	
46241	" " " " Head (left) Nos. 46237 to 46239 and two 171E.....	



46242	Looper Carrier Pitman Head (right) Nos. 46238, 46240, 50070c and two 171E.	
46243	Looper Carrier Pitman Rod	
1708E	" " " " Nut (left)	
1709E	" " " " " (right)	
46244	" " " Washer (fibre)	
46042	" " Rock Shaft with two 175D	
175D	" " " " Adjusting Screw	
38450	" " " " Crank (forked) with 159E	
159E	" " " " " Clamping Screw	
38451	" " " " " Slide Block	
46043	" " " " Hinge Pin	
1508E	" " " " " " Nut	
129E	" " " " " " Set Screw	
38452	" Eccentric with two 465C	
465C	" " Set Screw	
1143C	" Set Screw	
38453	" Shaft	
52553	" " Bracket	
123E	" " " Screw	
391D	" " " Screw	
38393	" Thread Guard	
590D	" " " Screw	
38455	Needle Bar (hollow) with 857H	
38456	" " Bushing	
1133E	" " " Set Screw	
38458	" " Connecting Link	
38459	" " " " Hinge Stud	
1520E	" " " " " " Nut	
38460	" " " Stud with two 391E	
391E	" " " " Clamping Screw	
46050	" Guard	
190D	" " Screw	
857H	" Set Screw	
17540	Presser Bar	
38464	" " Bushing (lower)	
1133E	" " " " Set Screw	
38456	" " " (upper)	
1133E	" " " " Set Screw	
17541	" " Lifter	
17542	" " " Hinge Pin	
38466	" " Lifting Bracket with 453C and 892C	
892C	" " " " Adjusting Screw	
453C	" " " " Set Screw	
38467	" " Spring (flat)	
38468	" " " Stud	
52802	" Foot	
52803	" " Guide	

725J	Presser Foot Guide Screw.....
<b>52804</b>	Presser Foot complete, Nos. 197D, 52802, 52810 and two each 725J and 52803.....
190D	Presser Foot Screw.....
574D	Pressure Regulating Thumb Screw.....
1539D	" " " " Lock Nut.....
<b>52805</b>	Ruffling Arm (lower).....
38179	" " (upper) with two 190D.....
175D	" " Adjusting Screw.....
2291	" " " " Washer.....
190D	" " Clamping Screw.....
<b>52806</b>	" " (adjustable) Nos. 2291, 38179, 52805 and two 175D.....
<b>52807</b>	Ruffling Arm (adjustable) complete, Nos. 226D, 1550H, 24203, 24206, 24581, 52806, 52808, 52809 and two 665D.....
<b>52808</b>	Ruffling Blade.....
24203	" " Holder.....
226D	" " " Cap Screw.....
24206	" " " Hinge Stud.....
1550H	" " " " " Nut.....
24581	" " " Spring.....
<b>52809</b>	" " " " Stop.....
665D	" " " Screw.....
<b>52810</b>	" " " Tripping Arm for 52804.....
197D	" " " " Screw.....
<b>52811</b>	" " Regulator with 662D.....
<b>52812</b>	" " " Connecting Rod with 38184 and two 896E.....
*38184	Ruffling Regulator Connecting Rod Cap.....
896E	" " " " " " Screw.....
2049	" " " Pin.....
1038C	" " Regulating Screw Stud.....
7070	" " " " " Bushing.....
662D	" " " " " Stop Screw.....
1730J	" " " " " Thumb Nut.....
<b>52813</b>	" " Shaft.....
<b>52814</b>	" " " Bracket (left).....
190D	" " " " " Screw.....
<b>52815</b>	" " " " (right).....
129E	" " " " " Screw.....
21506	" " " Collar with 457C.....
457C	" " " " Set Screw.....
46034	Slack Thread Controller.....
46035	" " " " Clamp.....
190D	" " " " " Screw.....
38472	" " " Regulator.....
38473	" " " " Bracket with 172C and 1823...



172c	Slack Thread Regulator Bracket Clamping Screw.....
38474	" " " Bushing.....
1823	" " " Roller and Stud.....
50062D	" " " Screw.....
1620E	" " " " Nut.....
2102	Tension (under thread) Disc.....
1560C	" " " Regulating Thumb Nut.....
916F	" " " Screw Stud.....
10148	" " " Spring.....
17547	" " " Thread Guide.....
2102	" (upper thread) Disc.....
1560C	" " " Regulating Thumb Nut.....
916F	" " " Screw Stud.....
2103	" " " Spring.....
17547	" " " Thread Guide.....
38225	Thread (under) Eyelet (back).....
190D	" " " " Screw.....
38284	" " " (front).....
46049	" " Nipper Cam with 465c.....
465C	" " " " Set Screw.....
38210	" " " Spring (lower).....
38211	" " " " (upper).....
46247	" " " " " Stop.....
176D	" " " " " Screw.....
38475	" " Take-up with 465c.....
465C	" " " Set Screw.....
38478	" " " Staple with two each 590D and 38481.....
46040	Thread (under) Take-up Staple Bracket with 910c.....
690D	" " " " " Screw.....
46041	" " " " " Spring.....
190D	" " " " " Screw.....
910C	" " " " " Stop Screw.....
38481	" " " " " Thread Guard.....
590D	" " " " " " " Screw.....
38482	" " " " " Stripper.....
207D	" " " " " Screw.....
38476	" " " " " Thread Guard (left).....
207D	" " " " " " " Screw.....
38477	" " " " " " (right).....
207D	" " " " " " " Screw.....
38483	" (upper) Controller.....
206F	" " " " " Screw.....
38484	" " " Eyelet.....
190D	" " " " " Screw.....
38485	" " " Take-up with 457c.....
457C	" " " " " Set Screw.....
52816	Throat Plate for 52801.....
691F	" " " " " Screw.....

## ACCESSORIES

4718	Machine Cushion (felt).....
2015	“ “ (rubber).....
—	1¾ in. Wood Screws No. 16, to secure machine to table.
36563	Oiler (copper plated) with 36564.....
36564	“ Spout, 5 in. long.....
26026	Screw Driver (large).....
26485	“ “ (small).....
38487	Threading Wire.....
35095	Tweezers, 6 in.....
8908	Wrench for 1520, 1620, 1706, 1708 and 1709.....
19221	“ “ 1619.....
22003	“ “ 1550.....
23766	“ “ 1508 and 1636.....

## EDGE FOLDER

36627	Edge Folder (left hand) on Slide with separating blade and left hand upper guide.....
35998	Holder with 8505 and 18116.....
18116	“ Spring.....
8505	“ “ Rivet.....
1460H	“ Screw.....

## STRIP FOLDER

36631	Ruffling Blade Tripping Arm.....
197D	“ “ “ “ Screw.....
36628	Strip Folder.....
36629	“ “ Foot.....
2818	“ “ Friction Washer.....
76D	“ “ Hinge Screw.....
36630	Strip Folder with Presser Foot complete, for folding the top edging of casket lining, Nos. 76D, 197D, 2818, 36628, 36629 and 36631.....



## FOOT LIFTER PARTS

6439 Chain, 36 in. to 45 in. ....

NOTE: When ordering No. 6439 give length required.

4879	Chain Connecting Link for 4885. ....
23759	Lifting Lever. ....
802D	" " Hinge Screw. ....
23761	" " Spring. ....
1002D	" " Stop Screw. ....
4881	Treadle. ....
4882	" Shaft. ....
4883	" Spring. ....
4884	" Stand. ....
4885	Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16. ....
23769	Foot Lifter complete, Nos. 802D, 1002D, 4885, 6439, 23759 and 23761. ....

## KNEE LIFTER PARTS

23759	Lifting Lever. ....
23760	" " Connecting Rod for 23768. ....
38384	" " " " " 38385. ....
802D	" " Hinge Screw. ....
23761	" " Spring. ....
1002D	" " Stop Screw. ....
2763	Rock Shaft. ....
12242	" " Hanger with two wood screws 1 in. No. 10. ....
6335	" " Knee Arm. ....
6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335. ....
2766	Rock Shaft Knee Arm Hub with 356c. ....
356c	" " " " " Set Screw. ....
2767	" " " " " Plate with 356c. ....
356c	" " " " " Set Screw. ....
6337	" " Lifting Bracket with two 356c. ....
7125	" " " " " Hook. ....
356c	" " " " " Set Screw. ....
356c	" " " " " Set Screw. ....
2770	" " Stop Dog with 356c. ....
356c	" " " " " Set Screw. ....
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242. ....
23768	Knee Lifter complete (power table) Nos. 802D, 1002D, 23759 to 23761 and 23767. ....
38385	Knee Lifter complete (bench stand) Nos. 802D, 1002D, 23759, 23761, 23767 and 38384. ....

**TAPE HOLDER**

(8 INCH DISC)

26912	Bracket Wire.....
26913	Bracket Wire complete, Nos. 26912, 26915 and 26919..
26915	Disc.....
26069	“ Hub.....
26070	“ “ Rivet.....
26917	Disc complete, Nos. 26069, 26915 and three 26070.....
26919	Tape Guide.....
26073	Tension Adjusting Collar with 286b.....
286b	“ “ “ Thumb Screw.....
13211	“ “ Spring.....
28809	Tape Holder (straight) 8 in. disc, complete, Nos. 13211, 26073, 26913 and 26917.....
736b	Tape Holder Set Screw.....

**THREAD UNWINDER**

**FOR TWO LARGE SPOOLS OR TWO LARGE CONES  
OF THREAD**

27623	Spool Pin.....
155c	“ “ Set Screw.....
41530	“ Rest.....
41531	“ “ 41530 with 1149c and two each 155c and 27623.....
1149c	Spool Rest Set Screw.....
27940	“ Stand with 453c.....
41514	“ Weight, 4 in. diam., with 41515.....
41515	“ “ Centre Pin.....
27739	Thread Cone (wood).....
41631	“ Guard with 208E and two 41569.....
41569	“ “ Eyelet.....
41637	“ “ Rod (lower).....
41638	“ “ “ (upper).....
41639	“ “ “ Coupling with two 456c.....
456c	“ “ “ “ Set Screw.....
41640	Thread Guard Rod complete, 30 in. long, Nos. 41637 to 41639.....
453c	Thread Guard Rod Set Screw.....
208E	“ “ Screw.....
41533	Thread Unwinder complete, Nos. 27940, 41531, 41631, 41640, two each 27739, 41514 and three wood screws 1 in. No. 12.....





# LIST OF PARTS COMPLETE FOR NO. 62-30 MACHINE

For Knit Goods and other fabrics. Has one needle,  
one looper. Has vertical trimmer, adjustable to  
trim from  $\frac{1}{16}$  to  $\frac{3}{16}$  inch from needle by  
compression between two moving  
surfaces.

## SUPERSEDES NO. 62-9 MACHINE

*46320	Arm, upper and lower (solid).....
23702	" Rock Shaft.....
38411	" " " Crank (back) with two 1497c.....
1497c	" " " " " Set Screw.....
38412	" " " " (front) with 443c.....
23724	" " " " " Pin.....
443c	" " " " " Set Screw.....
38413	" Rotary Shaft.....
38329	" " " Collar with two 457c.....
457c	" " " " " Set Screw.....
23872	" " " Flanged Bushing.....
159F	" " " " " Screw.....
4784	" " " Oil Pad (felt).....
144D	" " " Screw.....
17509	" Side Cover (lower).....
286D	" " " Thumb Screw.....
23933	" " " (upper).....
286D	" " " Thumb Screw.....
23873	Balance Wheel with two 430c.....
430c	" " " Set Screw.....
46321	Cloth Plate.....
691F	" " " Screw (left).....
1094F	" " " " (right).....
46322H	" " " Slide (left).....
38419	" " " " " Spring.....
725H	" " " " " Screw.....
46323H	Cloth Plate Slide (left) complete, Nos. 38419, 46322H and two 725H.....
38296H	Cloth Plate Slide (right) with 1602H.....
286D	" " " " " Thumb Screw.....
1602H	" " " " " " Bushing....



<b>46324</b>	Cloth Plate complete, Nos. 286D, 38296H, 46321 and 46323H.....
38422	Crank Connecting Rod with 38423 and two 158E...
*38423	" " " Cap.....
158E	" " " " Screw.....
372C	" " " Hinge Screw.....
1518E	" " " " " Nut.....
<b>46325</b>	Cutting Lever.....
<b>46326</b>	" " Adjusting Slide.....
190D	" " " " Screw.....
1389F	" " " Screw.....
<b>46327</b>	" " Cap.....
207F	" " " Screw.....
<b>46328</b>	" " Connection.....
1099F	" " " Hinge Screw.....
1247C	" " Hinge Screw.....
38150	" Plate.....
1246C	" " Adjusting Screw.....
1643D	" " " " Thumb Nut.....
38152	" " " Slide.....
207F	" " " " Screw.....
<b>46329</b>	" " Bracket.....
14026	" " " Dowel Pin.....
<b>46330</b>	" " " Holder.....
134D	" " " " Screw.....
176D	" " " Screw (lower).....
176D	" " " " (upper).....
38155	" " Friction Plate.....
1247C	" " " " Screw.....
87F	" " Hinge Screw.....
<b>46331</b>	Cutting Plate Bracket complete, Nos. 87F, 1246C, 1389F, 1643D, 38150, 38152, 38155, 46325 to 46327, 46329, two each 190D, 1247C and four 207F.....
46110	Face Plate.....
46111	" " Pin.....
286D	" " Thumb Screw.....
<b>46332</b>	Feed Bar with 231C.....
<b>46333</b>	" " Bushing.....
23726	" " Hinge Pin.....
231C	" " Set Screw.....
38426	" " Slide Block.....
38427	" Connecting Rod with 23865 and three 1057E..
*23865	" " " Cap.....
1057E	" " " " Screw.....
23866	" " " Hinge Pin (eccentric).....
1057E	" " " " Clamping Screw...
<b>46334</b>	" Dog.....
191C	" " Screw.....

*38127	Feed Eccentric.....								
*23729	"	"	Body.....						
443C	"	"	"	Set Screw.....					
21331	"	"	Pressure Spring.....						
21332	"	"	"	"	Cap.....				
934D	"	"	"	"	"	Screw.....			
196F	"	"	Set Screw.....						
38128	Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103C, 21331, 21332, 23729, 38127 and two 443C.....								
38429	Feed Lifting Eccentric with two 465C.....								
465C	"	"	"	Set Screw.....					
1103C	"	Regulating Screw.....							
38431	"	Rocking Frame.....							
38432	"	"	"	Bracket with two 465C.....					
123E	"	"	"	"	Screw.....				
38433	"	"	"	Hinge Pin.....					
465C	"	"	"	"	"	Set Screw.....			
<b>46335</b>	Looper with 590D and 38393.....								
38435	"	Bell Crank.....							
38436	"	"	"	Hinge Stud.....					
443C	"	"	"	"	"	Set Screw.....			
46101	"	"	"	Pitman with 46102, 46103 and four 187D.....					
777C	Looper Bell Crank Pitman Ball Screw Stud (lower)								
1636E	"	"	"	"	"	"	"	"	"
	Nut.....								
777C	Looper Bell Crank Pitman Ball Screw Stud (upper)								
1636E	"	"	"	"	"	"	"	"	"
	Nut.....								
*46102	Looper Bell Crank Pitman Cap (lower).....								
187D	"	"	"	"	"	"	"	Screw.....	
*46103	"	"	"	"	"	"	"	(upper).....	
187D	"	"	"	"	"	"	"	Screw.....	
38439	"	Carrier with 1143C and two 1147C.....							
38440	"	Hinge Pin.....							
1147C	"	"	"	Set Screw.....					
38441	Looper Carrier Pitman complete, Nos. 1697C, 1698C and 38445 to 38447.....								
50016C	Looper Carrier Pitman Ball Screw Stud (right).....								
1518E	"	"	"	"	"	"	"	"	Nut
38442	"	"	"	"	"	"	"	Stud (left).....	
1147C	"	"	"	"	"	"	"	Set Screw..	
*42525	"	"	"	Cap (left).....					
187D	"	"	"	"	"	"	"	Screw.....	
*42524	"	"	"	"	"	"	"	(right).....	
187D	"	"	"	"	"	"	"	Screw.....	
*38443	"	"	"	End Bearing (left).....					
*38444	"	"	"	"	"	"	"	(right).....	



38445	Looper Carrier Pitman Head (left) Nos. 38442, 38443, 42525 and two 187D.....
38446	Looper Carrier Pitman Head (right) Nos. 38444, 42524, 50016c and two 187D.....
38447	Looper Carrier Pitman Rod.....
1697C	" " " " Nut (left).....
1698C	" " " " " (right).....
46042	" " Rock Shaft with two 175D.....
175D	" " " " Adjusting Screw.....
38450	" " " " Crank (forked) with 159E.....
159E	Looper Carrier Rock Shaft Crank Clamping Screw.....
38451	" " " " " Slide Block.....
46043	" " " " Hinge Pin.....
1508E	" " " " " Nut.....
129E	" " " " " Set Screw.....
38452	" Eccentric with two 465C.....
<b>46336H</b>	" " Cover.....
335D	" " " Screw.....
465C	" " Set Screw.....
46104	" Needle Guard with 46105.....
46105	" " " Pin.....
229D	" " " Screw.....
1143C	" Set Screw.....
38453	" Shaft.....
38454	" " Bracket.....
123E	" " " Screw.....
391D	" " " Screw.....
38393	" Thread Guard.....
590D	" " " Screw.....
38008	Needle Bar (hollow) with 857H.....
38456	" " Bushing.....
1133E	" " " Set Screw.....
38458	" " Connecting Link.....
38459	" " " " Hinge Stud.....
1520E	" " " " " " Nut.....
38460	" " " Stud with two 391E.....
391E	" " " " Clamping Screw.....
<b>46337</b>	" Guard.....
190D	" " Screw.....
857H	" Set Screw.....
46092	Presser Bar.....
<b>46338</b>	" " Bushing (lower).....
1133E	" " " " Set Screw.....
38456	" " " (upper).....
1133E	" " " " Set Screw.....
17541	" " Lifter.....
17542	" " " Hinge Pin.....

38466	Presser Bar Lifting Bracket with 453c and 892c...
892C	" " " " Adjusting Screw.....
453C	" " " " Set Screw.....
38467	" " Spring (flat).....
38468	" " Stud.....
15261	" " Stop Collar with 237F.....
237F	" " " " Set Screw.....
11833	" Foot Hinge Pin.....
38043	" " Plate.....
23907	" " Shank.....
38044	Presser Foot (hinged) complete, Nos. 11833, 23907 and 38043.....
190D	Presser Foot Screw.....
574D	Pressure Regulating Thumb Screw.....
1539D	" " " " Lock Nut.....
46169	Slack Thread Controller.....
460C	" " " " Set Screw.....
2102	Tension (under thread) Disc.....
1560C	" " " " Regulating Thumb Nut....
916F	" " " " Screw Stud.....
10148	" " " " Spring.....
17547	" " " " Thread Guide.....
2102	" (upper thread) Disc.....
1560C	" " " " Regulating Thumb Nut....
916F	" " " " Screw Stud.....
2103	" " " " Spring.....
17547	" " " " Thread Guide.....
38225	Thread (under) Eyelet (back).....
190D	" " " " Screw.....
38284	" " " (front).....
46049	" " Nipper Cam with 465C.....
465C	" " " " Set Screw.....
38210	" " " " Spring (lower).....
38211	" " " " (upper).....
46247	" " " " " Stop.....
176F	" " " " " Screw.....
38475	" " Take-up with 465C.....
465C	" " " " Set Screw.....
38478	" " " " Staple with two each 590D and 38481.....
46040	Thread (under) Take-up Staple Bracket with 910C.
690D	" " " " " Screw.....
46041	" " " " " Spring.....
190D	" " " " " Screw.....
910C	" " " " " Stop Screw.....
38481	" " " " " Thread Guard.....
590D	" " " " " " " Screw
38482	" " " " " Stripper.....



207D	Thread (under) Take-up Stripper Screw.....
38476	" " " Thread Guard (left).....
207D	" " " " " " Screw
38477	" " " " " (right).....
207D	" " " " " " Screw
38483	" (upper) Controller.....
206F	" " " Screw.....
46311	" " Eyelet.....
190D	" " " Screw.....
46312	" " Take-up with 223D.....
223D	" " " Clamping Screw.....
<b>46339</b>	Throat Plate for 46334.....
691F	" " Screw.....

## ACCESSORIES

2015	Machine Cushion (rubber).....
—	1¾ in. Wood Screw No. 16, to secure machine to table.....
35859	Oiler with Cap and 35861.....
35860	" 35859 filled with oil.....
35861	" Spout, 3½ in. long.....
26026	Screw Driver.....
38487	Threading Wire.....
35095	Tweezers, 6 in.....
8908	Wrench for 1520.....
23766	" " 1508, 1518 and 1636.....
4822	" " 1697 and 1698.....

## FOOT LIFTER PARTS

6439	Chain, 38 in. to 45 in.....
------	-----------------------------

NOTE.—When ordering 6439 give length required.

4879	Chain Connecting Link for 4885.....
23759	Lifting Lever.....
802D	" " Hinge Screw.....
23761	" " Spring.....
1002D	" " Stop Screw.....
4881	Treadle.....
4882	" Shaft.....
4883	" Spring.....
4884	" Stand.....
4885	Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16.....
23769	Foot Lifter complete, Nos. 802D, 1002D, 4885, 6439, 23759 and 23761.....

## KNEE LIFTER PARTS

23759	Lifting Lever.....	
23760	" " Connecting Rod for 23768.....	
38384	" " " " " 38385.....	
802D	" " Hinge Screw.....	
23761	" " Spring.....	
1002D	" " Stop Screw.....	
2763	Rock Shaft.....	
12242	" " Hanger with two wood screws 1 in. No. 10.....	
6335	Rock Shaft Knee Arm.....	
6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335.....	
2766	Rock Shaft Knee Arm Hub with 356C.....	
356C	" " " " " Set Screw.....	
2767	" " " Plate with 356C.....	
356C	" " " " Set Screw.....	
6337	" " Lifting Bracket with two 356C.....	
7125	" " " " Hook.....	
356C	" " " " " Set Screw.....	
356C	" " " " Set Screw.....	
2770	" " Stop Dog with 356C.....	
356C	" " " " Set Screw.....	
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242.....	
23768	Knee Lifter complete (power table) Nos. 802D, 1002D, 23759 to 23761 and 23767.....	
38385	Knee Lifter complete (bench stand) Nos. 802D, 1002D, 23759, 23761 23767 and 38384.....	

## THREAD UNWINDER

FOR TWO LARGE SPOOLS OR TWO LARGE CONES  
OF THREAD

27623	Spool Pin.....	
155C	" " Set Screw.....	
41530	" Rest.....	
41531	" " 41530 with 1149C and two each 155C and 27623.....	
1149C	Spool Rest Set Screw.....	
27940	" Stand with 453C.....	
41514	" Weight, 4 in. diam., with 41515.....	
41515	" " Centre Pin.....	
27739	Thread Cone (wood).....	

41532	Thread Guard.....
41437	" " Rod, 30 in. long, with 735c.....
453C	" " " Set Screw.....
735C	" " Set Screw.....
41533	Thread Unwinder complete, Nos. 27940, 41437, 41531, 41532, two each 27739, 41514 and three wood screws 1 in. No. 12.....



