

62-41

NUMBERING DEPARTMENT
OCTOBER 4, 1910

LIST OF PARTS COMPLETE



No. 62-41 Machine

THE SINGER MANUFACTURING COMPANY

LIST OF PARTS COMPLETE FOR NO. 62-41 MACHINE

For leather, hemming the tops of gloves, etc. Two
needles, one looper, gauges from $\frac{1}{32}$ in. to $\frac{1}{16}$ in.
Alternating presser.

FORMERLY 62 S. V. 36

*46279	Arm, upper and lower (solid).....
46291	" Rock Shaft.....
38411	" " " Crank (back) with two 1497c....
1497c	" " " " " Set Screw.....
46280	" " " " (front) with 443c.....
23724	" " " " " Pin.....
443c	" " " " " Set Screw.....
38413	" Rotary Shaft.....
38329	" " " Collar with two 457c.....
457c	" " " " " Set Screw.....
23872	" " " Flanged Bushing.....
159F	" " " " " Screw.....
4784	" " " Oil Pad (felt).....
144D	" " " Screw.....
17509	" Side Cover (lower).....
286D	" " " " Thumb Screw.....
23933	" " " (upper).....
286D	" " " " Thumb Screw.....
23873	Balance Wheel with two 430c.....
430c	" " " Set Screw.....
38414	Cloth Plate.....
691F	" " " Screw (left).....
1094F	" " " (right).....
38415	" " " Slide (large) with 1602E.....
38416	" " " " Spring.....
725H	" " " " " Screw.....
38417	Cloth Plate Slide (large) complete, Nos. 38415, two 38416 and four 725H.....
38418	Cloth Plate Slide (small).....
38419	" " " " Spring.....
725H	" " " " " Screw.....
38420	Cloth Plate Slide (small) complete, Nos. 38418, 38419 and two 725H.....
38421	Cloth Plate complete, Nos. 38414, 38417 and 38420

38422	Crank Connecting Rod with 38423 and two 158E..
*38423	" " " Cap.....
158E	" " " Screw.....
372C	" " " Hinge Screw.....
1518E	" " " " " Nut.....
46281	Face Plate with 735C and 46289.....
171D	" " Screw.....
38425	Feed Bar with 231C and 460C.....
23716	" " Bushing.....
23726	" " Hinge Pin.....
231C	" " Set Screw.....
38426	" " Slide Block.....
38427	" Connecting Rod with 23865 and three 1057E..
*23865	" " " Cap.....
1057E	" " " " Screw.....
23866	" " " Hinge Pin (eccentric).....
1057E	" " " " " Clamping Screw...
46164	" Dog.....
898D	" " Screw.....
460C	" " Stop Screw.....
*38127	" Eccentric.....
*23729	" " Body.....
443C	" " " Set Screw.....
21331	" " Pressure Spring.....
21332	" " " " Cap.....
934D	" " " " " Screw.....
196F	" " Set Screw.....
38128	Feed Eccentric (adjustable) complete, Nos. 196F, 934D, 1103C, 21331, 21332, 23729, 38127 and two 443C.....
38429	Feed Lifting Eccentric with two 465C.....
46113	" " " Cover.....
335D	" " " " Screw.....
465C	" " " Set Screw.....
1103C	" Regulating Screw.....
38431	" Rocking Frame.....
38432	" " " Bracket with two 465C.....
123E	" " " " Screw.....
38433	" " " Hinge Pin.....
465C	" " " " " Set Screw.....
46072	Lifting Presser Bar.....
46073	" " " Bushing (lower).....
1133E	" " " " " Set Screw.....
38456	" " " " (upper).....
1133E	" " " " " Set Screw.....
17541	" " " Lifter.....
17542	" " " " Hinge Pin.....
46282	" " " Lifting Bracket with 704C and 892C.....

892C	Lifting Presser Bar Lifting Bracket Adjusting Screw
704C	" " " " " Clamping Screw
38467	" " " Spring (flat).....
38468	" " " Stud.....
46283	" " Foot.....
190D	" " Screw.....
46066	Looper with 590D and 38393.....
38435	" Bell Crank.....
38436	" " " Hinge Stud.....
443C	" " " " " Set Screw.....
46101	" " " Pitman with 46102, 46103 and four 187D.....
777C	Looper Bell Crank Pitman Ball Screw Stud (lower)
1636E	" " " " " " " " "
	Nut.....
777C	Looper Bell Crank Pitman Ball Screw Stud (upper)
1636E	" " " " " " " " "
	Nut.....
*46102	Looper Bell Crank Pitman Cap (lower).....
187D	" " " " " " Screw.....
*46103	" " " " " " (upper).....
187D	" " " " " " Screw.....
38439	" Carrier with 1143C and two 1147C.....
38440	" " Hinge Pin.....
1147C	" " " " Set Screw.....
38441	Looper Carrier Pitman complete, Nos. 1697C, 1698C and 38445 to 38447.....
50016C	Looper Carrier Pitman Ball Screw Stud (right).....
1518E	" " " " " " " " Nut
38442	" " " " " Stud (left).....
1147C	" " " " " " Set Screw..
*42525	" " " Cap (left).....
187D	" " " " " Screw.....
*42524	" " " " (right).....
187D	" " " " " Screw.....
*38443	" " " End Bearing (left).....
*38444	" " " " " (right).....
38445	" " " Head (left) Nos. 38442, 38443, 42525 and two 187D.....
38446	Looper Carrier Pitman Head (right) Nos. 38444, 42524, 50016C and two 187D.....
38447	Looper Carrier Pitman Rod.....
1697C	" " " " Nut (left).....
1698C	" " " " " (right).....
46042	" " Rock Shaft with two 175D.....
175D	" " " " Adjusting Screw.....
38450	" " " " Crank (forked) with 159E
159E	" " " " " Clamping Screw..

38451	Looper Carrier Rock Shaft Crank Slide Block.....
46043	" " " " Hinge Pin.....
1508E	" " " " " " Nut.....
129E	" " " " " " Set Screw....
38452	" Eccentric with two 465C.....
465C	" " Set Screw.....
46104	" Needle Guard with 46105.....
46105	" " " Pin.....
229D	" " " Screw.....
1143C	" Set Screw.....
38453	" Shaft.....
38454	" " Bracket.....
123E	" " " Screw.....
391D	" " " Screw.....
38393	" Thread Guard.....
590D	" " " Screw.....
46292	Needle Bar (hollow) with 2269 for $\frac{1}{32}$ in. to $\frac{1}{16}$ in. gauge.....
46293	Needle Bar complete, Nos. 46292 and 46294.....

NOTE.—When ordering 46292 or 46293 state gauge
required.

38456	Needle Bar Bushing.....
1133E	" " " Set Screw.....
38458	" " Connecting Link.....
38459	" " " " Hinge Stud.....
1520E	" " " " " " Nut.....
38460	" " " Stud with two 391E.....
391E	" " " " Clamping Screw.....
46294	Needle Clamp with 46295 and 50078F.....
50078F	" " Screw.....
46295	" " Thread Guard.....
46050	" Guard.....
190D	" " Screw.....
2269	" Stop Pin.....
46002	Oil Cup (tension) double with two 38463.....
38463	" " " Packing (felt).....
225F	" " " Screw.....
574D	Pressure Regulating Thumb Screw.....
1539D	" " " " Lock Nut.....
46169	Slack Thread Controller.....
460C	" " " Set Screw.....
2102	Tension (under thread) Disc.....
1560C	" " " Regulating Thumb Nut.....
916F	" " " Screw Stud.....
10148	" " " Spring.....
17547	" " " Thread Guide.....
2102	" (upper thread) Disc.....

1560C	Tension (upper thread)	Regulating Thumb Nut....
916F	"	" " Screw Stud.....
13710	"	" " Spring.....
17547	"	" " Thread Guide.....
38225	Thread (under) Eyelet (back).....	
190D	"	" " " Screw.....
38284	"	" " " (front).....
46049	"	" " Nipper Cam with 465C.....
465C	"	" " " Set Screw.....
38210	"	" " " Spring (lower).....
38211	"	" " " (upper).....
46247	"	" " " " Stop.....
176F	"	" " " " Screw.....
38475	"	" " Take-up with 465C.....
465C	"	" " " Set Screw.....
38478	"	" " " Staple with two each 590D and 38481.....
46040	Thread (under) Take-up Staple Bracket with 910C.	
690D	"	" " " " " Screw.....
46041	"	" " " " " Spring.....
190D	"	" " " " " Screw.....
910C	"	" " " " " Stop Screw.....
38481	"	" " " " " Thread Guard.....
590D	"	" " " " " " " Screw
38482	"	" " " " " Stripper.....
207D	"	" " " " " " " Screw.....
38476	"	" " " " " Thread Guard (left).....
207D	"	" " " " " " " " Screw
38477	"	" " " " " " (right).....
207D	"	" " " " " " " " Screw
38483	"	" (upper) Controller.....
206F	"	" " " " " Screw.....
46170	"	" " " Eyelet.....
190D	"	" " " " " Screw.....
46171	"	" " " Take-up with 223D.....
223D	"	" " " " " Clamping Screw.....
46172	Throat Plate with 665D and 46075 for 46164.....	
691F	"	" " " " " Screw.....
46075	"	" " " Thread Retainer.....
665D	"	" " " " " " " Screw.....
46286	Vibrating Presser Bar.....	
212F	"	" " " " " Cap Screw.....
46287	"	" " " " " Lifting Bell Crank.....
212F	"	" " " " " " " Cap Screw
46284	"	" " " " " " " Driving Arm with 157D, 602D and 46285.....
157D	Vibrating Presser Bar Lifting Bell Crank Driving Arm Clamping Screw.....	

46285	Vibrating Presser Bar Lifting Bell Crank Driving Arm Slide Block.....
602D	Vibrating Presser Bar Lifting Bell Crank Driving Arm Slide Block Cap Screw.....
46288	Vibrating Presser Bar Spring.....
46289	" " " Stop (raw hide).....
735C	" " " " Adjusting Screw.....
46290	" " " Foot.....
203D	" " " Screw.....

ACCESSORIES

2015	Machine Cushion (rubber).....
—	1¾ in. Wood Screw No. 16, to secure machine to table.....
35859	Oiler with Cap and 35861.....
35860	" 35859 filled with oil.....
35861	" Spout, 3½ in. long.....
26026	Screw Driver.....
38487	Threading Wire.....
35095	Tweezers, 6 in.....
8908	Wrench for 1520.....
23766	" " 1508, 1518 and 1636.....
4822	" " 1697 and 1698.....

FOOT LIFTER PARTS

6439	Chain, 36 in. to 45 in.....
-------------	-----------------------------

NOTE.—When ordering No. 6439 give length required.

4879	Chain Connecting Link for 4885.....
23759	Lifting Lever.....
802D	" " Hinge Screw.....
23761	" " Spring.....
1002D	" " Stop Screw.....
4881	Treadle.....
4882	" Shaft.....
4883	" Spring.....
4884	" Stand.....
4885	Treadle complete, Nos. 4879, 4881 to 4884 and two wood screws 1 in. No. 16.....
23769	Foot Lifter complete, Nos. 802D, 1002D, 4885, 6439, 23759 and 23761.....

KNEE LIFTER PARTS

23759	Lifting Lever.....	23759
23760	" " Connecting Rod for 23768.....	23760
38384	" " " " 38385.....	38384
802D	" " Hinge Screw.....	802D
23761	" " Spring.....	23761
1002D	" " Stop Screw.....	1002D
2763	Rock Shaft.....	2763
12242	" " Hanger with two wood screws 1 in. No. 10.....	12242
6335	Rock Shaft Knee Arm.....	6335
6336	Rock Shaft Knee Arm complete, Nos. 2766, 2767 and 6335.....	6336
2766	Rock Shaft Knee Arm Hub with 356C.....	2766
356C	" " " " " Set Screw.....	356C
2767	" " " Plate with 356C.....	2767
356C	" " " " Set Screw.....	356C
6337	" " Lifting Bracket with two 356C.....	6337
7125	" " " " Hook.....	7125
356C	" " " " " Set Screw.....	356C
356C	" " " " Set Screw.....	356C
2770	" " Stop Dog with 356C.....	2770
356C	" " " " Set Screw.....	356C
23767	Rock Shaft complete, Nos. 2763, 2770, 6336, 6337, 7125 and two 12242.....	23767
23768	Knee Lifter complete (power table) Nos. 802D, 1002D, 23759 to 23761 and 23767.....	23768
38385	Knee Lifter complete (bench stand) Nos. 802D, 1002D, 23759, 23761, 23767 and 38384.....	38385

THREAD UNWINDER

FOR THREE LARGE SPOOLS OR THREE LARGE CONES OF THREAD

27623	Spool Pin.....	
155c	" " Set Screw.....	
41434	" Rest.....	
41435	" " 41434 with 1149c and three each 155c and 27623.....	
1149c	Spool Rest Set Screw.....	
27940	" Stand with 453c.....	
41514	" Weight, 4 in. diam., with 41515.....	
41515	" " Centre Pin.....	
27739	Thread Cone (wood).....	
41436	" Guard.....	
41437	" " Rod, 30 in. long, with 735c.....	
453c	" " " Set Screw.....	
735c	" " " Set Screw.....	
41438	Thread Unwinder complete, Nos. 27940, 41435 to 41437 and three each 27739, 41514 and wood screws 1 in. No. 12.....	

