

## SINGER 81B6




# SINGER\*

546535 — 2

81B6





## NUMERICAL LIST OF PARTS FOR MACHINE 81B6


PART NO.	DESCRIPTION .	PART NO.	DESCRIPTION		
2102	Tansion (Looper left hand) Disc (2)	545180	Presser Foot Chaining-Off Finger Screw		
2102 2102	Tension (looper, left hand) Disc (2) Tension (needle thread) Disc (2)	545181	Presser Foot Plate Spring Adjusting Pin Set Screw		
2102	Tension (looper, right hand) Disc (2)	545237	Feed Eccentric Set Screw (2)		
154983	Feed (front) Regulating Rod Hinge Screw Nut	545406	Needle Clamp Nut		
154983	Feed (front) Connecting Rod Hinge Screw Nut	545408	Feed (front) Regulating Screw Stud Nut		
154983	Looper (left hand) Lever Connecting Link Hinge	545411	Cloth Plate Hinge Screw Nut		
	Screw Nut (2)	545451	Presser Lever Screw Stud Nut		
154983	Knife (movable) Lever Connection Hinge Screw Nut	545451	Lifting Lever Stop Sprew Nut (2)		
504007	Needle Bar Bushing Set Screw (2)	546504	Needle Bar Crank Shaft		
504007	Needle Bar Crank Shaft Bushing Set Screw (2)	546506	Needle Bar Crank Shaft Bushing (front and back)		
504007	Feed (front) Lifting Eccentric Set Screw (2)		(2)		
504007	Thread (looper, left hand) Tube Set Screw	546508	Needle Bar Crank (front) with two 545068		
504010	Chip Guard Screw (2)	546509	Thread (needle) Take-up		
504010	Feed Eccentric Cover Screw (2)	546511	Needle Bar with 545406		
504010	Feed (back) Dog Screw	546512	Needle Bar Connecting Bracket with 545071		
504010	Knife (stationary) Position Plate Screw	546513-001	Needle Bar Bushing (lower)		
504078	Frame Back Cover Bracket Screw (3)	546513-002	Needle Bar Bushing (upper)		
504089	Frame Top Cover Screw	546514 546515	Needle Bar Connecting Link		
504095	Feed (front) Rock Shaft Hinge Pin Bushing (right) Set Screw	546518	Needle Bar Connecting Link Hinge Pin (2) Frame Rotary Shaft		
504095	Feed (front) Rock Shaft Hinge Pin Bushing (left)	546519	Feed (front) Lifting Eccentric Connection		
001000	Set Screw	546520	Feed (front) Lifting Eccentric with two 504007		
504095	Looper (right hand) and Spreader Lever Hinge Pin	546521	Frame Rotary Shaft Crank with 545076, 546522		
• • • • • • • • • • • • • • • • • • • •	Bushing Set Screw (2)		and 549049		
504095	Frame Rotary Shaft Bushing Set Screw (2)	546522	Frame Rotary Shaft Crank Oil Pad (felt)		
504101	Needle Bar Crank (back) Ball Stud Set Screw (3)	546525	Feed (front) Bar		
504132	Presser Lever Hinge Stud Set Screw	546527	Feed (front) Rock Shaft		
504145	Frame Side Cover Screw (2)	546528	Feed (front) Rock Shaft Hinge Pin		
504145	Frame Side Cover Screw (2)	546529	Feed (front) Bar Hinge Pin		
545068	Needle Bar Crank (front) Set Screw (2)	546530	Thread (needle) Eyelet		
545071 545072	Needle Bar Connecting Bracket Clamping Screw Needle Bar Connecting Link Hinge Pin Set Screw	546532	Tension (needle thread) Thread Guide		
545072	Feed (front) Bar Hinge Pin Collar Set Screw	546533	Tension (logner left hand) Regulating Thunk Nut		
545073	Needle Bar Connecting Link Hinge Pin Set Screw	546535 546535	Tension (looper, left hand) Regulating Thumb Nut Tension (needle thread) Regulating Thumb Nut		
545076	Frame Rotary Shaft Crank Position Screw	546535	Tension (looper, right hand) Regulating Thumb Nu:		
545077	Needle Bar Connecting Rod with Cap Screw (4)	546536	Tension (needle thread) Screw Stud		
545077	Looper (right hand) and Spreader Lever Connection	546539	Needle Bar Thread Retainer Disc (2)		
	Cap Screw (4)	546540	Needle Bar Thread Retainer Spring		
545079	Feed (front) Regulator Connection Hinge Screw	546541	Needle Bar Crank (back) with three 504101		
545079	Feed (front) Connecting Rod Hinge Screw	546542	Looper (right hand) and Spreader Lever Ball Stud		
545079	Knife (movable) Lever Connection Hinge Screw	546542	Needle Bar Crank (back) Ball Stud		
545080 545081	Feed (front) Bar Hinge Pin Set Screw Feed (back) Connecting Link Hinge Screw	546543	Needle Bar Connecting Rod with two Cap and four		
545081	Feed (back) Connecting Dink Hinge Screw Feed (back) Regulator Hinge Screw	546544	545077  Looper (right hand) and Spreader Lever Connection		
545082	Feed (back) Regulator Set Screw	010011	Guide		
545083	Feed (back) Regulator Thumb Screw	546544	Looper (right hand) and Spreader Lever Connection		
545084	Thread (needle) Eyelet Screw		Guide		
545084	Thread (looper, right hand) Staple Screw	546545	Frame Rotary Shaft Bushing (back)		
545085	Needle Bar Thread Retainer Screw	546546	Frame Rotary Shaft Bushing (front)		
545086	Needle Bar Thread Retainer Bracket Screw	546548	Looper (right hand) and Spreader Lever Hinge Pin		
545086	Needle Bar Thread Retainer Bracket Screw (2)		Bushing (2)		
545091 545094	Presser Regulating Thumb Screw Feed (front) Regulator Set Screw (2)	546548	Feed (front) Rock Shaft Hinge Pin Bushing (left) Presser Lever Spring		
545095	Feed (front) Rock Shaft Crank Clamping Screw	546550 546551	Feed (back) Regulator		
545096	Feed (front) Regulator Connection Adjusting	546552	Feed (front) Dog		
040000	Screw	546554	Feed (back) Dog		
545097	Feed (front) Regulating Screw Stud	546555	Feed (front) Regulator Hinge Stud		
545098	Knife (movable) Lever Hinge Stud Set Screw	546556	Feed (front) Regulator with two 545094		
545099	Looper (right hand) and Spreader Lever Connection	546557	Feed (front) Rock Shaft Crank with 545095		
	Guide Screw	546558	Feed (front) Regulator Connection with 545096		
545099	Needle Guard Screw	546559	Knife (movable) Lever		
545099	Looper (right hand) and Spreader Lever Connection	546560	Knife (movable) Lever Hinge Stud		
545100	Guide Screw Knife (movable) Holder Guide Plate Screw (2)	546562	Knife (movable) Holder Guide Plate		
545100	Knife (movable) Holder Guide Plate Screw (2) Knife (movable) Holder Guide Screw	546563 546564	Knife (movable) Holder Guide with 545101 Knife (movable) Holder		
545102	Knife (stationary) Holder Screw	546564 546565	Knife (movable) Gib		
545104	Knife (stationary) Holder Regulating Thumb Screw	546566	Knife (movable) Holder Spring		
545107	Thread (looper, left hand) Eyelet Screw	546567	Knife (movable)		
545108	Looper (right hand) and Spreader Lever Ball Stud	546570	Knife (stationary) with Stud		
	Set Screw	546571	Needle Guard		
545109	Looper (right hand) Screw	546572	Looper (right hand) and Spreader Lever		
545109	Looper (right hand) Screw	546573	Looper (right hand) and Spreader Lever Hinge Pin		
545112 545112	Looper (left hand) Clamping Screw Looper (left hand) Lever Connecting Link Hinge	546574	Thread (looper, left hand) Eyelet		
545113	Screw (2)	546576 546578	Looper (right hand) Looper (left hand) Lever		
545115	Throat Plate Screw (2)	546578 546579	Looper (left hand) Lever Looper (left hand) Lever Hinge Stud		
545117	Presser Lever Screw Stud (eccentric)	546580	Thread (looper, right hand) Take-up		
545118	Presser Foot Screw	546581	Looper (left hand)		
545119	Lifting Lever Bracket Screw (2)	546582	Looper (left hand) Lever Connecting Link		
545120	Lifting Lever Hinge Screw	546584	Thread (looper, right hand) Staple		
545121	Presser Lever Lifter Hinge Screw	546585	Tension (looper, right hand) Thread Guide		
545122	Lifting Lever Stop Screw (2)	546586	Tension (looper, right hand) Screw Stud		
545123 545124	Feed Eccentric Cover Holder Thumb Screw	546586 546587	Tension (looper, left hand) Screw Stud		
545124 545125	Balance Wheel Set Screw Balance Wheel Position Screw	546587 546589	Tension (looper, left hand) Thread Guide Throat Plate		
545134	Feed (back) Bar Hinge Screw	546591	Presser Lever		
Fitom the library of Superior Sewing Machine & Supply Live Complete					

## NUMERICAL LIST OF PARTS FOR MACHINE 81B6

PART NO.	DESCRIPTION	PART NO.	DESCRIPTION
546594	Presser Foot Screw Washer		ACCESCODIES
546595	Lifting Lever Bracket		ACCESSORIES
546596	Lifting Lever Spring		
546597	Presser Lever Lifter	E41514	Company (per all)
546602	Lifting Lever with two each 545122 and 545451	541514 545074	Screw Driver (small)
546606	Chip Guard	545074	Machine Base Screw
546608	Needle Bar Cover Complete	546517	Wood Screw (3) Machine Base Screw Washer
546611	Frame Top Cover	546656	Tweezers
546612A	Frame Side Cover (right) Complete	546657	Wrench
546612B	Frame Side Cover (left) Complete	546660	Foot Lifter Chain
546617	Cloth Plate Complete	546663	Foot Lifter Tradle
546619	Frame Back Cover Complete	546692	Screw Driver (medium)
546665	Feed (front) Rock Shaft Hinge Pin Bushing (right)	546704	Thread Unwinder Complete (for three spools)
546667	Feed (front) Regulating Screw Stud Nut Washer	546906	Oil "C" Type 50 cc
546668	Feed (front) Bar Hinge Pin Collar with 545072	547088	Threading Wire (2)
546669	Feed Eccentric Cover Holder Thumb Screw Washer	CAT.6120-01	Needle#12 (5)
546677	Feed (front) Connecting Rod	CA1.0120-01	Needle#12 (5)
546678	Knife (stationary) Holder		
54667 <del>9</del>	Knife (stationary) Position Plate		
546687	Thread (looper, left hand) Tube		
546688	Tension (looper, right hand) Spring		
546688	Tension (looper, left hand) Spring		
546699	Needle Bar Connecting Link Hinge Pin Oil Wick (2)		
546702	Knife (movable) Lever Connection		
546705	Feed (back) Bar		
546706	Feed (back) Connecting Link		
546707	Needle Bar Thread Retainer Bracket		
546709	Knife (movable) Holder Cap		
546710	Knife (movable) Holder Screw Extension Pin		
546711	Presser Foot Chaining-Off Finger		
546712	Presser Foot Plate Spring Adjusting Pin		
546713	Presser Foot Plate Spring		
546720	Balance Wheel with 545124 and 545125		
547009	Frame Rotary Shaft Bushing (back) Oil Pad		
547032 549045	Machine Cushion (4)		
549045	Knife (movable) Holder Cap Screw (2)		
549049	Knife (movable) Holder Screw		
549049	Frame Rotary Shaft Crank Set Screw		
549336	Feed (front) Dog Screw Needle Bar Cover Set Screw (2)		
549406	Feed Eccentric		
549412	Feed Eccentric Cover Holder		
549437	Looper (right hand) and Spreader Lever Connection		
010101	with four 545077		
549491	Feed Eccentric Cover		
549503	Machine Base		
549513	Thread (looper, left hand) Guide Bracket		
549514	Thread (looper, left hand) Guide		
549515	Thread (looper, left hand) Guide Bracket Screw (2)		
549516	Frame Side Cover (right) Catch Spring		
549517	Frame Side Cover (right) Catch Spring Washer		
549518	Frame Back Cover Catch Bracket		
549519	Frame Back Cover Catch Bracket Screw (2)		
549520	Presser Lever Spring Pin		
549521	Tension (looper, left hand) Disc Felt		
549521	Tension (looper, right hand) Disc Felt		
549521	Tension (needle thread) Disc Felt		
CAT.6120-01	Needlc#12		

## Alteration in MACHINE PARTS CHART for Model 81B6

Thread Unwinder Complete (for three thread) P/N 546704 has been changed as follows.



No.	QTY.	Description
1	1	Thread Eyelet Platen
2	1	Thread Eyelet Pallet
3	3	Thread Eyelet
4	1	Thread Stand Rod (upper)
5	1	Thread Stand Rod (lower)
6	3	Spool Pin
7	3	Spool Stopper
8	3	Spool Seat Disc
9	1	Spool Pin Joint
10	1	Thread Stand Base
11	2	Hexagon Nut
12	3	Headless Set Screw
13	1	Headless Set Screw
14	1	Ball Head Cap Screw
15	1	Ball Head Cap Screw
16	3	Counter Sunk Head Wood Screw
17	1	Washer

#### Alteration in MACHINE PARTS CHART for Model 81B6

Thread Unwinder Complete (for three thread) P/N 546704 has been changed as follows.

