Form 19240 (439) Printed in U. S. A.

# LIST

OF

# **PARTS**



FOR
SERIES S38 AND S48 MOTORS
AND
S 59 AND S 69 ELECTRIC
TRANSMITTERS

THE SINGER MANUFACTURING COMPANY

From the library of: Superior Sewing Machine & Supply LLC

Copyright, U. S. A., 1937 and 1939 by The Singer Manufacturing Co. All Rights Reserved for all Countries

## **INDEX**

	age
Capacitor and Switch Parts	95
Chart for Series S 38 and S 48 Direct Current Singer Sewing	
Motors	10
Chart for Series S 38 and S 48 Single Phase, Alternating	
Current, Repulsion Type, Singer Sewing Motors	19
	19
Chart for Series S 38 and S 48 Poly Phase, Alternating	
Current, Singer Sewing Motors	26
Chart for Series S 59 and S 69 Direct Current Singer Elec-	
tric Transmitters	42
Chart for Series S 59 and S 69 Single Phase, Alternating	
Current, Capacitor Type, Singer Electric Transmitters	54
Chart for Series S 59 and S 69 Poly Phase, Alternating	01
, ,	-
Current, Singer Electric Transmitters	68
Chart for Series S 59 Single Phase, Alternating Current,	
Repulsion Start, Induction Type, Singer Electric Trans-	
mitter	91
Cord and Wire Connections	98
Explanation of Variety Numbers of Singer Motors and Elec-	
tric Transmitters	9
	_
Grease Guns	95
Machine Driving Pulleys	100
Machine Driving Pulley Cover	
Motor Bracket S 38 and S 48 Motors	103
Motor Brackets S 59 and S 69 Electric Transmitters	104
Motor Bracket (Auxiliary)	103
Motor Spacing Block	104
Numerical List of Parts	111
NUMERICAL LIST OF PARTS	111
Pitman and Treadle Parts	105
Pulleys (Grooved)	107
Speed Reducer	106
Series S 38 and S 48 Direct Current	
S 383000-N Motor	12
S 383001-N Motor	11
S 383002-N Motor	12
S 383005-N Motor	12
S 383006-N Motor	13
S 383007-N Motor	13
S 383008-N Motor	13
S 383009-N Motor	14
S 482001-N Motor	14
C 40000EN Mater	
S 482007-N Motor	14
S 483000-N Motor	16
S 483001-N Motor	15
S 483002-N Motor	16
S 483005-N Motor	16
S 483006-N Motor	17 -
S 483007-N Motor	17
	17
2 483008-N PROLOT	
8 483009-N Motor	18

		Page
Series S	38 and S 48 Single Phase,	
Alternati	ng Current, Repulsion Type	
S 383141 and S 383141-N	Motors	20
	Motors	21
S 383143-N	Motor	21
	Motors	21
	Motors	21
S 383152 and S 383152-N	Motors	22
S 383153-N	Motor	22
	Motors	22
	Motors	23
	Motors	24
	Motor	24
	Motors	24
	Motors	24
	Motors	25
	Motors	25
- 100100 and 5 100100-11	1.0001	20
Series S 38 and S	48 Poly Phase, Alternating Current	
201100 0 00 and 0 4	to toly thate, alternating our lent	
\$ 382341 and \$ 382341_N	Motors	29
	Motor	29
	Motors	
	Motors	29
		29
	Motor	29
	Motors	30
	Motors	30
	Motor	30
	Motors	30
	Motors	30
	Motor	31
	Motors	31
	Motors	31
	Motor	31
	Motor	31
	Motors	32
	Motor	32
	Motors	32
	Motor	32
S 383341 and S 383341-N	Motors	32
S 383345 and S 383345-N	Motors	33
S 383347 and S 383347-N	Motors	33
S 383348	Motor	33
S 383351 and S 383351-N	Motors	33
	Motors	33
S 383353 and S 383353-N	Motors	34
S 383356 and S 383356-N	Motors	34
S 383357 and S 383357-N	Motors	34
	Motors	34
	Motor	34
	Motor	35
	Motors	28
	Motors	35
	Motors	35
	Motor	35
	Motor	35
		JO

	I	age
S 482267 and S 482267-N	Motors	36
8 482268	Motor	36
S 482357 and S 482357-N	Motors	36
S 482358	Motor	36
S 48235X-N	Motor	36
S 482361 and S 482361-N	Motors	37
S 482366 and S 482366-N	Motors	37
S 482367 and S 482367-N	Motors	37
S 482368	Motor	37
S 48236Y-N	Motor	37
S 483251	Motor	38
S 483257	Motor	38
8 483258	Motor	38
	Motor	38
S 483267	Motor	38
S 483268	Motor	39
	Motor	39
S 483352	Motor	39
S 483353	Motor	39
S 483356	Motor	39
\$ 483357	Motor	40
S 483358	Motor	40
S 483361	Motor	40
S 483366	Motor	40
S 483367	Motor	40
S 483368	Motor	41
Series S	59 and S 69 Direct Current	
	Electric Transmitter	46
	Electric Transmitter	43
	Electric Transmitter	46
	Electric Transmitter	46
	Electric Transmitter	47
	Electric Transmitter	47
	Electric Transmitter	47
	Electric Transmitter	48
	Electric Transmitter	48
	Electric Transmitter	48
	Electric Transmitter	51
	Electric Transmitter	49
	Electric Transmitter	52
	Electric Transmitter	52
	Electric Transmitter	52
	Electric Transmitter	53
	Electric Transmitter	53
S 693009-N	Electric Transmitter	53
0-min = 0 1	EO and S 60 Single Phase	
	59 and S 69 Single Phase, ng Current, Capacitor Type	
Arternati	ng ourient, capacitor lype	
S 503116 and S 503116-M	Electric Transmitters	57
S 503141 and S 503141-N	Electric Transmitters	58
	Electric Transmitters	59
		_

						Pa	age
S	593152	and	S	593152-N	Electric	Transmitters	59
S	593153	and	S	593153-N	Electric	Transmitters	59
S	593156	and	S	593156-N	Electric	Transmitters	60
S	593157	and	S	593157-N	Electric	Transmitters	60
S	593158	and	S	593158-N	Electric	Transmitters	60
S	593161	and	S	593161-N	Electric	Transmitters	55
S	593162	and	S	593162-N	Electric	Transmitters	61
S	593165	and	S	593165-N	Electric	Transmitters	61
S	593166	and	S	593166-N	Electric	Transmitters	61
S	593167	and	S	593167-N	Electric	Transmitters	61
S	593168	and	S	593168-N	Electric	Transmitters	62
S	593186	and	S	593186-N	Electric	Transmitters	62
S	692151	and	S	692151-N	Electric	Transmitters	62
S	692157	and	S	692157-N	Electric	Transmitters	62
S	692158	and	8	692158-N	Electric	Transmitters	63
S	692161	and	S	692161-N	Electric	Transmitters	63
S	692162	and	S	692162-N	Electric	Transmitters	63
S	692167	and	S	692167-N	Electric	Transmitters	63
S	692168	and	S	692168-N	Electric	Transmitters	64
S	693150				Electric	Transmitter	64
						Transmitter	64
S	693152				Electric	Transmitter	64
S	693156				Electric	Transmitter	65
S	693157			• • • • • • • • • • • • • • • • • • • •	Electric	Transmitter	65
S	693158				Electric	Transmitter	65
S	693161				Electric	Transmitter	65
S	693162				Electric	Transmitter	66
S	693165				Electric	Transmitter	66
S	693166		. <b>-</b> -	·	Electric	Transmitter	66
S	693167				Electric	Transmitter	66
S	693168				Electric	Transmitter	67
	Ser:	les S	3 5	9 and S	69 Poly Pi	nase, Alternating Current	
_	500045					_	
						Transmitter	72
-						Transmitters	73
						Transmitter	73
-			8	59235Y-N	Electric	Transmitter	73
2	592367				Electric	Transmitter	73
2	593221	and	S	593221-N	Electric	Transmitters	74
2	593227	and	S	593227-N	Electric	Transmitters	74
2	593228				Electric	Transmitter	74
2	593241	and	S	593241-N	Electric	Transmitters	74
8	593247	and	S	593247-N	Electric	Transmitters	75
						Transmitter	75
						Transmitters	75
2	593257	and	S	593257-N	Electric	Transmitters	75
2	593258				Electric	Transmitter	75
5	593261	and	S	593261-N	Electric	Transmitters	76
2	593267	and	ಶ	593267-N	Electric	Transmitters	76
S	<b>595268</b>				Llectric	Transmitter	76
	E0770:		<b>ა</b>	59326Y-N	Llectric	Transmitter	76
٥	503300	ana	3	593521-N	Liectric	Transmitters	76
0	50220C				Electric	Transmitter	77
9	502200	and	3	ಎ೪ಎಎ27-N	Liectric	Transmitters	77
J	090000				PT6CfL1C	Transmitter	77

			•	~50
			Transmitters	78
	S 593345 and S 593345-N	Electric	Transmitters	78
	S 593347 and S 593347-N	Electric	Transmitters	78
	S 593348	Electric	Transmitter	78
	S 593351 and S 593351-N	Electric	Transmitters	78
	S 593352 and S 593352-N	Electric	Transmitters	79
	S 593353 and S 593353-N	Electric	Transmitters	79
	S 593356 and S 593356-N	Electric	Transmitters	79
	S 593357 and S 593357-N	Electric	Transmitters	79
	S 593358 and S 593358-N	Electric	Transmitters	80
	S 59335X-N	Electric	Transmitter	80
	S 59335Y-N	Electric	Transmitter	80
			Transmitters	70
	S 593366 and S 593366-N	Electric	Transmitters	80
	S 593367 and S 593367-N	Electric	Transmitters	80
	S 593368	Electric	Transmitter	81
	S 59336Y-N	Electric	Transmitter	81
	S 692258	Electric	Transmitter	81
	S 692267 and S 692267-N	Electric	Transmitters	81
	S 692268	Electric	Transmitter	82
	S 69226Y-N	Electric	Transmitter	82
	S 692357 and S 692357-N	Electric	Transmitters	82
	S 692358	Electric	Transmitter	82
	S 69235X-N	Electric	Transmitter	83
	S 69235Y-N	Electric	Transmitter	83
	S 692361 and S 692361-N	Electric	Transmitters	83
	S 692366 and S 692366-N	Electric	Transmitters	84
	S 692367 and S 692367-N	Electric	Transmitters	84
			Transmitter	84
	S 69236Y-N	Electric	Transmitter	85
			Transmitter	85
•	S 693257	Electric	Transmitter	85
			Transmitter	86
			Transmitter	86
			Transmitter	86
			Transmitter	87
			Transmitter	87
			Transmitter	87
			Transmitter	88
			Transmitter	88
			Transmitter	88
			Transmitter	89
			Transmitter	89
			Transmitter	89
			Transmitter	90
			Transmitter	90
	S 69336Y-N	Electric	Transmitter	90
			, Alternating Current,	
	Repulsion	n Start,	Induction Type	
	0 500101 1 0 500101 **	73 a s 4 J -	Management to the man	00
	5 593121 and S 593121-N	FIECTI1C	Transmitters	300
	Table Belt Guide	and Acco	mh] { n m	104
	Tools for Disassembling	and wase	mbling	100
	Wine Adentese with Com	nd Connec	tion	TOE
	Wile Adapters with Grou	iir connec		105

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

A.A-Buffed and Chromium Plated

A.B-Hardened, Polished, Buffed and Chromium Plated

B-Polished, Nickel Plated and Buffed

C-Hardened Only

C.R-Hardened and Merlized

D-Polished Only

E-Soft, Not Polished

F-Hardened and Polished

F.J-Hardened, Polished and Nickel Plated

G-Bright Rumbled and Nickel Plated

H-Blued

J-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M-Oxidized

N-Japanned, Dull

P-Japanned, Bright

P.P-Wrinkle Finish

R-Merlized

S-Cadmium Plated

T-Copper Plated

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed

T.B-Copper and Nickel Plated and Polished T.J-Copper and Nickel Plated Only

T.K-Hardened, Copper and Nickel Plated

T.L-Copper and Brass Plated

T.M-Copper Plated and Oxidized

U-Zinc Plated V-Silver Plated

W-Polished and Nickel Plated

X-Black Oxide, for Iron and Steel

X.C-Hardened and Black Oxide, for Iron or Steel

Y-Black Nickel Plated Only

Z-Chromium Plated

Z.A-Hardened, Polished, Nickel Plated, Buffed and Chromium Plated

Z.B-Polished, Nickel Plated, Buffed and Chromium Flated

Z.C-Hardened and Chromium Flated

Z.D-Polished and Chromium Plated

Z.G-Bright Rumbled, Nickel Plated, Bright Rumbled and Chromium Flated

Z.J-Nickel and Chromium Plated

Z.T-Copper and Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000

are Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers

1801 to 2000 and 51801 to 52000 are Roller Numbers 2001 to 50000 and 52001 to 140000 and 142001 to

190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (\*) are furnished only when repairs are made at factory.

# EXPLANATION OF VARIETY NUMBERS OF SINGER MOTORS AND ELECTRIC TRANSMITTERS

	<u>\$59</u> <u>3</u>	3 6 7		
Series	Horse Power	Phase	Cycles	Volts
38 = Motor 48 = " 59 = Electric Transmitter 69 = "	2 = 1/2 3 = 1/3	1 = Single 2 = Two 3 = Three	1 = 100 2 = 25 4 = 40 5 = 50 6 = 60 8 = 80	0 = 95 - 105 1 = 105 - 115 2 = 115 - 125 3 = 125 - 135 4 = 130 - 145 5 = 150 - 165 6 = 190 - 210 7 = 210 - 230 8 = 230 - 250 9 = 250 - 270 X = 380 Y = 440

NOTE: The Suffix letter "N" denotes the Motor

or Electric Transmitter is not equipped
From the library and least end of the standard of the Supply LLC

# SERIES S 38 AND S 48 DIRECT CURRENT SINGER SEWING MOTORS

Catalog No.	H.P.	Volts	R.P.M.
8 383000-N	1/3	95-105	1725
8 383001-N	1/3	105-115	1725
8 383002-N	1/3	115-125	1725
S 383005-N	1/3	150-165	1725
8 383006-N	1/3	190-210	1725
8 383007-N	1/3	210-230	1725
8 383008-N	1/3	230-250	1725
8 383009-N	1/3	250-270	1725
S 482001-N	1/2	105-115	3000
S 482007-N	1/2	210-230	3000
S 483000-N	1/3	95-105	3000
8 483001-N	1/3	105-115	3000
S 483002-N	1/3	115-125	3000
S 483005-N	1/3	150-165	3000
8 483006-N	1/3	190-210	3000
S 483007-N	1/3	210-230	3000
8 483008-N	1/3	230-250	3000
S 483009-N	1/3	250-270	3000

# LIST OF PARTS COMPLETE FOR

## S 38300I-N MOTOR

mplete
aft Ball Bearing (commutator
-
aft Ball Bearing (commutator
pacing Washer
aft Ball Bearing (pulley end)
n n n
Washer
aft Ball Bearing Friction
aft Dust Cap
Nut:
" Lock Washer
ete
r Cap
" 799858 with 140122
" Screw (brass)
Lead complete with Termi-
Dodd complete with ionini
r Ring with Brush Tubes
Screw
" Nut
r complete, Nos. 798874 and
977
complete
commutator end)
oulley end)
butteh eug)
tud
•
tud
tud " Nut
tud "Nut " "Lock Washer
tud " Nut " " Lock Washer (lower)
tud " Nut " " Lock Washer (lower) (upper)
tud " Nut " " Lock Washer (lower) (upper) Retaining Pin
tud " Nut " " Lock Washer (lower) (upper) Retaining Pin " " Insulation
rud " Nut " " Lock Washer (lower) (upper) Retaining Pin " " Insulation complete
" Nut " Lock Washer (lower) (upper) Retaining Pin " Insulation complete Ing (alemite) for greasing e Shaft Ball Bearing
rud " Nut " " Lock Washer (lower) (upper) Retaining Pin " " Insulation complete Ing (alemite) for greasing E Shaft Ball Bearing
" Nut " Lock Washer (lower) (upper) Retaining Pin " Insulation complete Ing (alemite) for greasing e Shaft Ball Bearing over
" Nut " Lock Washer (lower) (upper) Retaining Pin " Insulation complete Ing (alemite) for greasing e Shaft Ball Bearing over

No.	Plate	Name
1778R	20232	Motor Bolt Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Motor to table, Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach-
		ing Motor to table, Nos. 51429R and
		126150
<b>*</b> 899595		Name Plate
876066		" " Drive Screw
67702	20218	Terminal
796865	20218	" Box Cover
50671R	20218	" " ScreW
50647R	20218	" Screw
1785	20218	" " Nut (brass)

### S 383000-N MOTOR

This Motor is the same as S 383001-N Motor with the following exception:

No.	Plate			Name
799072		Armature	complete	

### S 383002-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799069		Armature complete
799087		Field Coil (lower)
799086		" " (upper)

### S 383005-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799070		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799089		Field Coil (lower)
799088		" (upper)

From the library of: Superior Sewing Machine & Supply LLC

### S 383006-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799066		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and two 799977
~~~		
798480		Commutator complete
798385		Field Coil (lower)
798384		" (upper)

### S 383007-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
798878		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
798385		Field Coil (lower)
798384		" " (upper)

### S 383008-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799073		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
798480		Commutator complete
799091		Field Coil (lower)
799090		" " (upper)

### S 383009-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799071		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799091		Field Coil (lower)
799090		" " (upper)

### S 48200I-N MOTOR

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799067		Armature complete
799083		Field Coil (lower)
799082		" " (upper)

### **S 482007-N MOTOR**

This Motor is the same as S 383001-N Motor with the following exceptions:

No.	Plate	Name
799068		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799085		Field Coil (lower)
799084		" (upper)

# LIST OF PARTS COMPLETE FOR

## S 48300I-N MOTOR

No.	Plate	Name
804569		Armature complete
797421	20218	" Shaft Ball Bearing (commutator
		end)
701971	20218	Armature Shaft Ball Bearing (commutator
		end) Spacing Washer
797422	20218	Armature Shaft Ball Bearing (pulley end)
701963		n n n n n n
		Spacing Washer
804407		Armature Shaft Ball Bearing Friction
		Washer
931146		Armature Shaft Ball Bearing Friction
		Washer Spacing Washer (thick)
931149		Armature Shaft Ball Bearing Friction
		Washer Spacing Washer (thin)
796290		Armature Shaft Dust Cap
1633R	20218	" " Nut
701350	20218	" " Lock Washer
798876	20218	Brush complete
799858	20218	" Holder Cap
799977		" " 799858 with 140122
140122	20218	" " Screw (brass)
799857	20218	Brush Holder Lead complete with Termi-
		nals
798874	20218	Brush Holder Ring with Brush Tubes
50658R	20218	" " Screw
1784E	20218	" " Nut
798873		Brush Holder complete, Nos. 798874 and
		two 799977
798481		Commutator complete
798883	20218	End Cover (commutator end)
798101	20218	(burrea eug)
898795		2000
51626R	20218	NUC
701679	20218	" " Lock wasner
804588		Field Coil (lower)
804587		(upper)
799629		verguing bill
798895		Insulation
804299	00010	Field Core complete
808943	20218	Grease Fitting (alemite) for greasing
706216	20218	Armature Shaft Ball Bearing
796216 50636R	20218	Hand Hole Cover
Mocooc	<b>SONTO</b>	" " Screw

No.	Plate	Name
797887		Housing
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Motor to table, Nos. 51428R and
		126150
69354	20232	Motor Bolt (short) complete, for attach-
		ing Motor to table, Nos. 51429R and
		126150
<b>*</b> 899595		Name Plate
876066		" " Drive Screw
67702	20218	Terminal
796865	20218	" Box Cover
50671R	20218	" " Screw
50647R	20218	" Screw
1785	20218	" " Nut (brass)

### **S 483000-N MOTOR**

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804568		Armature complete
804586		Field Coil (lower)
804585		" " (upper)

### S 483002-N MOTOR

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804570		Armature complete
804590		Field Coil (lower)
804589		" (upper)

### S 483005-N MOTOR

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804571		Armature complete
798379		Brush complete

#### S 483005-N Motor - Continued

No.	Plate	Name
798377		Brush Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and two 799977
798480		Commutator complete
804592		Field Coil (lower)
804591		" (upper)

### **S 483006-N MOTOR**

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804572		Armature complete
798379		Brush complete
798377		". Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804594		Field Coil (lower)
804593		" (upper)

### **S 483007-N MOTOR**

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804573		Armature complete
798379		Brush complete
798377		Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804596		Field Coil (lower)
804595		" " (upper)

### S 483008-N MOTOR

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804574		Armature complete
798379		Brush complete

#### S 483008-N Motor - Continued

No.	Plate	Name
798377		Brush Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799962		Field Coil (lower)
799961		" (upper)

### S 483009-N MOTOR

This Motor is the same as S 483001-N Motor with the following exceptions:

No.	Plate	Name
804575		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804598		Field Coil (lower)
804597		" (upper)

## SERIES S 38 AND S 48 SINGLE PHASE, ALTERNATING CURRENT, REPULSION TYPE SINGER SEWING MOTORS

NOTE: The Suffix letter "N" denotes the Motor is not equipped with leads for lighting fixture.

				•	D D 12
Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 383141 and S 383141-N	1/3	1	<b>4</b> 0	105-115 210-230	2250
S 383142 and S 383142-N	1/3	1	40	115-125 230-250	2250
S 383143-N	1/3	1	<del>4</del> 0	125-135 250-270	2250
S 383150 and S 383150-N	1/3	1	50	95-105 190-210	1425
S 383151 and S 383151-N	1/3	1	50	105-115 210-230	1425
S 383152 and S 383152-N	1/3	ı	50	115-125 230-250	1425
S 383153-N	1/3	1	50	125-135 250-270	1425
S 383160 and S 383160-N	1/3	1	60	95-105 190-210	1725
S 383161 and S 383161-N	1/3	1	60	105-115 210-230	1725
S 383162 and S 383162-N	1/3	1	60	115-125 230-250	1725
S 383165	1/3	1	60	150-165	1725
S 482151 and S 482151-N	1/2	1	50	105-115 210-230	2900
S 482152 and S 482152-N	1/2	1	50	115-125 230-250	2900
S 482161 and S 482161-N	1/2	1	60	105-115 210-230	3450
8 482162 and 8 482162-N	1/2	1	60	115-125 230-250	3450

From the library of: Superior Sewing Machine & Supply LLC

# LIST OF PARTS COMPLETE FOR

## S 383141 AND S 383141-N MOTORS

No.	Plate	· Name
798395		Brush with lead and terminal
50644R		" Screw
796189	20219	" Spring
797754		Commutator complete
798011		End Cover (commutator end)
798101		" (pulley end)
898334	20219	" " Stud
51626R	20219	" " Nut
701679	20219	" " " Lock Washer
808943	20219	Grease Fitting (alemite) for greasing
		Rotor Shaft Ball Bearing
796216	20219	Hand Hole Cover
50636R	20219	" " " Screw
727511	20219	Lead Bushing (rubber) for lighting unit
		leads
190328	20219	Lead Bushing (rubber) for motor leads
`51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
1778R	20232	" "Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Motor to table, Nos. 51428R and
		126150
69354	20232	Motor Bolt (short) complete, for attach-
•		ing Motor to table, Nos. 51429R and
		126150
<b>*</b> 899526		Name Plate
876067		" " Drive Screw
798005		Rocker Ring
798004		" 798005 with two 796189
798394		rocactus abittis
798396		Rotor complete
797421	20219	" Shaft Ball Bearing (commutator
mam 4.00		end)
797422	20219	Rotor Shaft Ball Bearing (pulley end)
701963	20219	
700007	00010	Spacing Washer
798887	20219	Rotor Shaft Ball Bearing Friction Washer
796290	00010	Dust cap (commutator end)
1633R	20219	Nuc
701350 797771	20219	DOCK MSPILET.
797771		Short Circuiter
131116		" Retaining Ring

No.	Plate	Name
809779		Stator Wound with Housing for S 383141
799975		" " " " S 383141-N
796865		Terminal Box Cover for Motor without tap
		for light
798159	20219	Terminal Box Cover for Motor with tap
		for light
964270	20219	Terminal Box Cover Bushing (rubber) for
		798159
50671R	20219	Terminal Box Cover Screw

### S 383142 AND S 383142-N MOTORS

These Motors are the same as S 383141 and S 383141-N Motors with the following exceptions:

No.	Plate				Name			
943967		Stator	Wound	with	Housing	for	S	383142
943968		. 11	Ħ	11	ti .	Ħ	S	383142-N

### S 383143-N MOTOR

This Motor is the same as S 383141-N Motor with the following exception:

No.	Plate		Name
943969		Stator Wound with	Housing

### S 383150 AND S 383150-N MOTORS

These Motors are the same as S 383161 and S 383161-N Motors with the following exceptions:

No.	Plate				Name			. •	
809635		Stator	Wound	with	Housing	for	\$	383150	
797707		- п	41	ti	tt	u	S	383150-	N

### S 383151 AND S 383151-N MOTORS

These Motors are the same as S 383161 and S 383161-N Motors with the following exceptions:

No.	Plate				Name			
798552		Stator	Wound	with	Housing	for	S	383151
797995		ţı	tt	t1	tt	ti	S	383151-N

### S 383152 AND S 383152-N MOTORS

These Motors are the same as S 383161 and S 383161-N Motors with the following exceptions:

No.	Plate				Name			
799140		Stator	Wound	with	Housing	for	s	383152
798698		Ħ	tt	Ħ	sı .	ti	S	383152-N

### S 383153 -N MOTOR

This Motor is the same as S 383161-N Motor with the following exception:

No.	Plate		Name
798271		Stator Wound with	Housing

### S 383160 AND S 383160-N MOTORS

These Motors are the same as S 383161 and S 383161-N Motors with the following exceptions:

140.	Plate				Name			
962043		Stator	Wound	with	Housing	for	s	383160
798566		II .	11	n	tt	Ħ	S	383160-N

# LIST OF PARTS COMPLETE FOR

## \$383161 AND \$383161-N MOTORS

No.	Plate	Name
796212	20219	Brush (double) with lead
796189	20219	" Spring
796344		Commutator complete
797868	20219	End Cover (commutator end)
796138	20219	" " (pulley end)
898334	20219	" " Stud
51626R	20219	" " Nut
701679	20219	" " " Lock Washer
808943	20219	Grease Fitting (alemite) for greasing
		Rotor Shaft Ball Bearing
796216	20219	Hand Hole Cover
50636R	20219	" " Screw
727511	20219	Lead Bushing (rubber) for lighting unit leads
190328	20219	Lead Bushing (rubber) for motor leads
51428R	20232	
51429R	20232	Motor Bolt (long) with 1778R, for 69353
1778R	20232	" (short) with 1778R, for 69354 " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
03000	20202	ing Motor to table, Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach-
		ing Motor to table, Nos. 51429R and 126150
<b>*</b> 899594		Name Plate
876066		" Drive Screw
796188		Rocker Ring
796217	20219	"
796190		" " Locating Spring
797389	20219	Rotor complete
797421	20219	" Shaft Ball Bearing (commutator
201.021	00010	end)
701971	20219	Rotor Shaft Ball Bearing (commutator
202400	00010	end) Spacing Washer
797422	20219	Rotor Shaft Ball Bearing (pulley end)
701963	20219	Spacing Washer
798887	20219	Rotor Shaft Ball Bearing Friction Washer
796290		" Dust Cap (commutator end)
1633R	20219	" Nut
701350	20219	" " Lock Washer
796211	20219	Short Circuiter

### 24 SERIES S 38 AND S 48 I PH. A. C. REPULSION TYPE - Continued

No.	Plate	Name
791283	20219	Short Circuiter Retaining Ring
798710	20219	Stator Wound with Housing for S 383161
797707		" " " " S 383161-N
796865		Terminal Box Cover for Motor without tap for light
798159	20219	Terminal Box Cover for Motor with tap for light
964270	20219	Terminal Box Cover Bushing (rubber) for 798159
50671R	20219	Terminal Box Cover Screw

### S 383162 AND S 383162-N MOTORS

These Motors are the same as S 383161 and S 383161-N Motors with the following exceptions:

No.	Plate				Name			
799138		Stator	Wound	with	Housing	for	S	383162
798443		Ħ	Ħ	. 11	#	Ħ	8	383162-N

### S 383165 MOTOR

This Motor is the same as S 383161 Motor with the following exception:

No.	Plate		Name
942119		Stator Wound with	Housing

### S 482151 AND S 482151-N MOTORS

These Motors are the same as S 383141 and S 383141-N Motors with the following exceptions:

No.	Plate	Name
798595		Rotor complete
943016		Stator Wound with Housing for S 482151
798398		" " " " S 482151-N

### S 482152 AND S 482152-N MOTORS

These Motors are the same as S 383141 and S 383141-N Motors with the following exceptions:

No.	Plate				Name			
798595		Rotor	comple	te				
943017		Stator	Wound	with	Housing	for	S	482152
808459		Ħ	Ħ	ø	E7	17	S	482152-N

## S 482161 AND S 482161-N MOTORS

These Motors are the same as S 383141 and S 383141-N Motors with the following exceptions:

No.	Plate				Name			
797999		Rotor	comple	te				
804910	<b>,</b>	Stator	Wound	with	Housing	for	8	482161
798030		a	n	17		tt.	8	482161-N

### S 482162 AND S 482162-N MOTORS

These Motors are the same as S 383141 and S 383141-N Motors with the following exceptions:

No.	Plate	Name	
797999		Rotor complete	
943970		Stator Wound with Housing for S 482162	
798398		" " " " S 482162-N	J

## SERIES S 38 AND S 48 POLY PHASE ALTERNATING CURRENT SINGER SEWING MOTORS

NOTE: The Suffix letter "N" denotes the Motor is not equipped with leads for lighting fixture.

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 382341 and S 382341-N	1/2	3	40	105-115	2250
S 382348	1/2	3	40	230-250	2250
S 383221 and S 383221-N	1/3	2	25	105-115	1425
S 383227 and S 383227-N	1/3	2	25	210-230	1425
S 383228	1/3	2	25	230-250	1425
S 383241 and S 383241-N	1/3	2	40	105-115	2250
S 383247 and S 383247-N	1/3	2	40	210-230	2250
S 383248	1/3	2	40	230-250	2250
S 383251 and S 383251-N	1/3	2	50	105-115	1425
S 383257 and S 383257-N	1/3	2	50	210-230	1425
S 383258	1/3	2	50	230-250	1425
S 383261 and S 383261-N	1/3	2	60	105-115	1725
S 383267 and S 383267-N	1/3	2	60	210-230	1725
S 383268	1/3	2	60	230-250	1725
S 38326Y-N	1/3	2	60	440	1725
8 383321 and S 383321-N	1/3	3	25	105-115	1425
S 383326	1/3	3	25	190-210	1425
S 383327 and S 383327-N	1/3	3	25	210-230	1425
S 383328	1/3	3	25	230-250	1425
S 383341 and S 383341-N	1/3	3	40	105-115	2250
S 383345 and S 383345-N	1/3	3	40	150-165	2250
S 383347 and S 383347-N	1/3	3	40	210-230	2250
S 383348	1/3	3	40	230-250	2250
S 383351 and S 383351-N	1/3	3	50	105-115	1425
S 383352 and S 383352-N	1/3	3	50	115-125	1425
S 383353 and S 383353-N	1/3	3	50	125-135	1425
S 383356 and S 383356-N	1/3	3	50	190-210	1425
S 383357 and S 383357-N	1/3	3	50	210-230	1425
S 383358 and S 383359-N	1/3	3	50	230-250	1425
S 38335X-N	1/3	3	50	380	1425
S 38335Y-N	1/3	3	50	440	1425
S 383361 and S 383361-N	1/3	3	60	105-115	1725
S 383366 and S 383366-N	1/3	3	60	190-210	1725
S 383367 and S 383367-N	1/3	3	60	210-230	1725
S 383368	1/3	3	60	230-250	1725
S 38336Y-N	1/3	3	60	440	1725
S 482267 and S 482267-N	1/2	2	60	210-230	3500
S 482268	1/2	2	60	230-250	3500
S 482357 and S 482357-N	1/2	3	50	210-230	2900
S 482358	1/2	3	50	230-250	2900
From the library of: S	1/2.	r Sew	ing Mad	380 chine & S	2900 <b>Supply</b> LI

# SERIES S 38 AND S 48 POLY PHASE, ALTERNATING CURRENT SINGER SEWING MOTORS - Continued

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 482361 and S 482361-N	1/2	3	60	105-115	3500
S 482366 and S 482366-N	1/2	3	60	190-210	3500
S 482367 and S 482367-N	1/2	3	60	210-230	3500
S 482368	1/2	3	60	230-250	3500
S 48236Y-N	1/2	3	60	440	3500
S 483251	1/3	2	50	105-115	2900
S 483257	1/3	2	50	210-230	2900
S 483258	1/3	2	50	230-250	2900
S 483261	1/3	2	60	105-115	3400
S 483267	1/3	2	60	210-230	3400
\$ 483268	1/3	2	60	230-250	3400
S 483351	1/3	3	50	105-115	2900
S 483352	1/3	3	50	115-125	2900
S 483353	1/3	3	50	125-135	2900
S 483356	1/3	3	50	190-210	2900
S 483357	1/3	3	50	210-230	2900
S 483358	1/3	3	50	230-250	2900
S 483361	1/3	3	60	105-115	3400
S 483366	1/3	3	60	190-210	3400
S 483367	1/3	3	60	210-230	3400
S 483368	1/3	3	60	230-250	3400

# LIST OF PARTS COMPLETE FOR .

## S 383361 AND S 383361-N MOTORS

No.	Plate	Name
796138	20220	End Cover (pulley end)
797868	20220	" (terminal box end)
898334	20220	" " Stud
51626R	20220	" Nut
701679	20220	" " Lock Washer
808943	20220	Grease Fitting (alemite) for greasing
		Rotor Shaft Ball Bearing
796216	20220	Hand Hole Cover
50636R	20220	" " Screw
727511	20220	Lead Bushing (rubber) for lighting unit leads
190328	20220	Lead Bushing (rubber) for motor leads
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" " (short) with 1778R, for 69354
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Motor to table, Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach- ing Motor to table, Nos. 51429R and 126150
<b>*</b> 899594		Name Plate
876066		" Drive Screw
798257	20220	Rotor complete
797422	20220	" Shaft Ball Bearing (pulley end)
701963	20220	
		Spacing Washer
797421	20220	Rotor Shaft Ball Bearing (terminal box end)
701971	20220	Rotor Shaft Ball Bearing (terminal box end) Spacing Washer
798887	20220	Rotor Shaft Ball Bearing Friction Washer
796290		" Dust Cap (terminal box end)
1633R	20220	" Nut
701350	20220	" " Lock Washer
799656	20220	Stator Wound with Housing for S 383361
798078		" " " S 383361-N
796865		Terminal Box Cover for Motor without tap
		for light
798159	20220	Terminal Box Cover for Motor with tap for light
964270	20220	Terminal Box Cover Bushing (rubber) for 798159
50671R	20220	Terminal Box Cover Screw
From the	library o	of: Superior Sewing Machine & Supply LL

## S 382341 AND S 382341-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943971		Stator	Wound	with	Housing	for	S	382341
962038		tt.	a	tı	ti.	ti -	S	382341-N

### S 382348 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate		Name
943972		Stator Wound with	Housing

### S 383221 AND S 383221-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
798123		Rotor	comple	te				
943973		Stator	Wound	with	Housing	for	S	383221
943974		. #	a	88	tt .	Ħ	S	383221-N

### S 383227 AND S 383227-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
798123		Rotor	comple	te				
943975		Stator	Wound	with	Housing	for	S	383227
943976		a	17	17	a	Ħ	S	383227-N

#### S 383228 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

,	No.	Plate	Name
	798123		Rotor complete
	943977		Stator Wound with Housing

### S 383241 AND S 383241-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943979		Stator	Wound	with	Housing	for	S	383241
943980		ø	tı	tt	#	n	S	383241-N

### S 383247 AND S 383247-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943981		Stator	Wound	with	Housing	for	S	383247
943982		tı	u	ti	tt	ħ	S	383247-N

### S 383248 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate		Name
943983		Stator Wound with	Housing

### S 383251 AND S 383251-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943984		Stator	Wound	w1th	Housing	for	S	383251
962044		Ħ	tt	\$1	Ħ	Ħ	S	383251-N

### S 383257 AND S 383257-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943985		Stator	Wound	with	Housing	for	S	383257
798253		tı	Ħ	#	tt	17	S	383257-N

### S 383258 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate		Name
943993		Stator Wound wit	th Housing

## S 383261 AND S 383261-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
962045		Stator	Wound	with	Housing	for	S	383261
943994		u	#	Ħ	n	Ħ	S	383261-N

### S 383267 AND S 383267-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
798260		Stator	Wound	with	Housing	for	s	383267
797986		87	Ħ	tt	ti	12	s	383267-N

### S 383268 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate		Name
962031		Stator Wound with	1 Housing

### **S 38326Y-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exception:

No.	Plate		Name
962042		Stator Wound with	Housing

### S 383321 AND S 383321-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
798123		Rotor	comple	te				
809776		Stator	Wound	with	Housing	for	S	383321
943995		Ħ	u		17	a	S	383321-N

### S 383326 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
798123		Rotor complete
809898		Stator Wound with Housing

### S 383327 AND S 383327-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
798123		Rotor	comple	te				
804079		Stator	Wound	with	Housing	for	S	383327
798166		μ	ta ta	Ħ	n	#	S	383327-N

### S 383328 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
798123		Rotor complete
943996		Stator Wound with Housing

### S 383341 AND S 383341-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943997		Stator	Wound	with	Housing	for	S	383341
943998		11	11		ti .	•	S	383341-N

### S 383345 AND S 383345-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943999		Stator	Wound	with	Housing	for	S	383345
798086		u	tt	ts	tı	ţţ	S	383345-N

### S 383347 AND S 383347-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
943790		Stator	Wound	with	Housing	for	s	383347
944000		a	a	tı	a	ts	s	383347-N

### S 383348 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate		Name
943987		Stator Wound with	Housing

### S 383351 AND S 383351-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
808275		Stator	Wound	with	Housing	for	ន	383351
798080		tı	Ħ	21	tt	Ħ	S	383351-N

### S 383352 AND S 383352-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
942731		Stator	Wound	with	Housing	for	S	383352
962005		a	n	a	Ħ	17	S	383352-N

### S 383353 AND S 383353-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
962006		Stator	Wound	with	Housing	for	S	383353
962007		tt	Ħ	Ħ			S	383353-N

### S 383356 AND S 383356-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name				
808917		Stator	Wound	with	Housing	for	S	383356	
798082		a	tı	Ħ	ti	ø	S	383356-N	

### S 383357 AND S 383357-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
808060		Stator	Wound	with	Housing	for	S	383357
798009		a	u		#	Ħ	S	383357-N

### S 383358 AND S 383358-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
962008		Stator	Wound	with	Housing	for	S	383358
962009		Ħ	a	Ħ	u	ti	S	383358-N

### **S 38335X-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exception:

No.	Plate		Name
962010		Stator Wound with	Housing

### **S 38335Y-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exception:

No.	Plate	Name
797981		Stator Wound with Housing

### S 383366 AND S 383366-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
799252		Stator	Wound	with	Housing	for	S	383366
797984		#	tt	u	17	u	S	383366-N

### S 383367 AND S 383367-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			•
798801		Stator	Wound	with	Housing	for	S	383367
797984		ţs	n		a	Ħ	8	383367-N

### S 383368 MOTOR

This Motor is the same as S 383361 Motor with the following exception:

No.	Plate				Name
962011		Stator	Wound	with	Housing

### **S 38336Y-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exception:

No.	Plate		Name
797981		Stator Wound wit	th Housing

### S 482267 AND S 482267-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
804839		Rotor	comple	te				
943347		Stator	Wound	with	Housing	for	8	482267
798084		ti	tı	11	Ħ	Ħ	s	482267-N

### S 482268 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804839		Rotor complete
962012		Stator Wound with Housing

### S 482357 AND S 482357-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
804839		Rotor	comple	te				
962013		Stator	Wound	with	Housing	for	S	482357
943105		t)	11	11	Ħ	t1	S	482357-N

#### S 482358 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804839		Rotor complete
962014		Stator Wound with Housing

### **S 48235X-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exceptions:

No.	Plate	Name
804839		Rotor complete
798134		Stator Wound with Housing

#### S 482361 AND S 482361-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
804839		Rotor	comple	te				
962015		Stator	Wound	with	Housing	for	ន	482361
798088		a	ţı		ti .	tt	S	482361-N

#### S 482366 AND S 482366-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
804839		Rotor	comple	te				
809300		Stator	Wound	with	Housing	for	S	482366
962037		ģţ	ø	tt	tt	11	S	482366-N

#### S 482367 AND S 482367-N MOTORS

These Motors are the same as S 383361 and S 383361-N Motors with the following exceptions:

No.	Plate				Name			
804839		Rotor (	comple	te				
798803		Stator	Wound	with	Housing	for	S	482367
962037		u	u	Ħ	n	11	s	482367-N

#### **S 482368 MOTOR**

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804839		Rotor complete
799841		Stator Wound with Housing

# **S 48236Y-N MOTOR**

This Motor is the same as S 383361-N Motor with the following exceptions:

No.	Plate	Name
804839		Rotor complete
798090		Stator Wound with Housing
From the lib	rary of:	Superior Sewing Machine & Supply LLC

#### S 483251 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962016		Stator Wound with Housing

#### S 483257 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962017		Stator Wound with Housing

#### S 483258 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962018		Stator Wound with Housing

# S 483261 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962019		Stator Wound with Housing

#### S 483267 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962046		Stator Wound with Housing

#### S 483357 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No. Plate Name
804552 ---- Rotor complete
962024 ---- Stator Wound with Housing

#### S 483358 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No. Plate Name
804552 ---- Rotor complete
962025 ---- Stator Wound with Housing

#### S 483361 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No. Plate Name 804552 ---- Rotor complete 962026 ---- Stator Wound with Housing

### S 483366 MOTOR

This Motor is the same as S 383361 Motor with the following exceptions:

No. Plate Name 804552 ---- Rotor complete 962027 ---- Stator Wound with Housing

#### **S 483367 MOTOR**

This Motor is the same as S 383361 Motor with the following exceptions:

No. Plate Name
804552 ---- Rotor complete
962028 ---- Stator Wound with Housing

#### S 483368 MOTOR


This Motor is the same as S 383361 Motor with the following exceptions:

No.	Plate	Name
804552		Rotor complete
962029		Stator Wound with Housing

# SERIES S 59 AND S 69 DIRECT CURRENT SINGER ELECTRIC TRANSMITTERS

Catalog No.	н.Р.	Volts	R.P.M.
8 593000-N	1/3	95-105	1725
S 593001-N	1/3	105-115	1725
S 593002-N	1/3	115-125	1725
S 593005-N	1/3	150-165	1725
8 593006-N	1/3	190-210	1725
S 593007-N	1/3	210-230	1725
S 593008-N	1/3	230-250	1725
8 593009-N	1/3	250-270	1725
S 692001-N	1/2	105-115	3000
S 692007-N	1/2	210-230	3000
8 693000-N	1/3	95-105	3000
8 693001-N	1/3	105-115	3000
S 693002-N	1/3	115-125	3000
S 693005-N	1/3	150-165	3000
8 693006-N	1/3	190-210	3000
S 693007-N	1/3	210-230	3000
8 693008-N	1/3	230-250	3000
S 693009-N	1/3	250-270	3000

# LIST OF PART COMPLETE FOR



# S 59300I-N ELECTRIC TRANSMITTER

No.	Plate	Name
808856	20221	Armature complete
808728	20222	" Shaft Ball Bearing
808815	20222	" " " Retainer
931221	20222	" " " Thrust Washer
*796446		" Bushing
747148	20221	" " Cap
51680R	20221	" Nut
67255	20221	" " Cotter Pin
798876	20221	Brush complete
799858	20221	" Holder Cap
799977		" " 799858 with 140122
140122	20221	" " Screw (brass)
799857	20221	Brush Holder Lead complete with termi-
		nals
798874	20221	Brush Holder Ring with Brush Tubes
50658R	20221	" " Screw
1784E	20221	" " Nut
798873		Brush Holder complete, Nos. 798874 and two 799977
798481		Commutator complete
797821	20221	End Cover (terminal box end)
798381		" " 797821 with 796446
51488R	20221	" " Bolt
51626R	20221	" " Nut
701679	20221	" " Lock Washer
798872	20221	Field Coil (lower)

44.7

```
Plate
  No.
                                       Name
798871
           20221
                    Field Coil (upper)
798386
                            Ħ
                               Retaining Pin
                      42
                                           " Insulation
798895
                    Field Core complete
798382
           20222
                    Grease Fitting (alemite) for greasing
808943
                        Armature Shaft Ball Bearing
                    Hand Hole Cover
 67481
           20221
           20221
 50647R
                                    Screw
          20232
                    Motor Bolt (long) with 1778R, for 69353
 51428R
                               (short) with 1778R, for 69354
 51429R
          20232
  1778R
          20232
                               Nut
          20232
                                    Lock Washer
126150
                    Motor Bolt (long) complete, for attach-
 69353
           20232
                        ing Electric Transmitter to table,
                        Nos. 51428R and 126150
 69354
           20232
                    Motor Bolt (short) complete, for attach-
                        ing Electric Transmitter to table,
                        Nos. 51429R and 126150
#899598
                    Name Plate
700871
                               Rivet
           ----
797097
           20221
                    011 Well Cap
           20221
 67702
                    Terminal
796865
           20221
                             Box Cover
 50671R
           20221
                                       Screw
 50647R
           20221
                             Screw
                                   Nut (brass)
   1785
           20221
                    Transmitter Brake (thermoid)
 943590
           20222
           20222
                                       Holder
 809098
           20222
                    Transmitter Brake Holder complete, Nos.
 943588
                        809098, 943590 and two 943978
                    Transmitter Brake Adjusting Screw
 140228C
           20222
                                                      140228C
 943978
           ----
                        with 1637C
   1637C
           20222
                    Transmitter Brake Adjusting Screw Lock
           20222
                    Transmitter Brake Screw Stud
 69246
   1670R
           20222
                                                  Nut
                                 Fly Wheel
 808818
           20222
 808819
           20222
                                           808818 with 69255,
                         809764 and four 69256
  69415
           20222
                    Transmitter Fly Wheel Guard (back) with
                        Bracket
  69413
           20222
                    Transmitter Fly Wheel Guard (front) with
                        Bracket
                    Transmitter Fly Wheel Guard Bracket
  51382R
           20222
                        Screw for rear guard
  67357
           20221
                    Transmitter Fly Wheel Key
                                 Frame and End Cover
*808817
 808816
           20222
                                            23
                                                 17
                                                      808817
                        with 51421R, 51422R, 69270, 69271,
                         69344 and 69345
```

No.	Plate	Name
*808822		Transmitter Friction Pulley
809764	20222	" " Friction Disc
		Cork
69255	20222	Transmitter Friction Pulley Friction
		Disc Retaining Ring
69256	20222	Transmitter Friction Pulley Friction Disc Stud
941097		Transmitter Friction Pulley Pin
<b>*</b> 808902		" Shaft
808821	20222	" 808902 with 808822 and
		941097
808820		Transmitter Shaft 808821 with 1633R, 69268, 69269, 69427 and two each 797421 and 931191
797421	20222	Transmitter Shaft Ball Bearing
69268	20222	" " " Spacing
00.000	~~~~	Collar
931191	20222	Transmitter Shaft Ball Bearing Thrust Washer
69269	20222	Transmitter Shaft Bushing and Brake Cam
*69270		a u u a u
		Cap
69271		Transmitter Shaft Bushing and Brake Cam Cap Position Pin
808943	20222	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite)
808944	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite) (For Agents only)
1517J	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting Lock Nut
No	te: Nos.	808944 and 1517J to be used when the
		itter is used to drive a left hand Machine
51421R	20222	Transmitter Shaft Bushing and Brake Cam-
		Screw (long)
69345	20222	Transmitter Shaft Bushing and Brake Cam
53.400D	00000	Screw (long) Spacing Collar
51422R	20222	Transmitter Shaft Bushing and Brake Cam Screw (short)
1633R	20222	Transmitter Shaft Lock Nut
1633R	20222	" Nut
701350	20222	" " Lock Washer
69426	20222	" Starting Lever with 115R
69427		" 69426 With 2762
		and 69428
115R	20222	Transmitter Starting Lever Clamping Screw
69428	20222	Transmitter Starting Lever Extension
2762	20222	" " Collar
		with 3620

No.	Plate		Nar	ne		
362C	20222	Transmitter Collar S	Starting Set Screw	Lever	Extens	lon
69274	20222	Transmitter	Starting	Lever	Spring	
69275	20222	tt	ti	tt	tt	Arm
50823R	20222	n	u	tı	ti	17
		Screw				
2718	20222	Transmitter Screw Wa	•	Lever	Spring	Arm

#### S 593000-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exception:

No.	Plate			Name
808855		Armature	complete.	

#### S 593002-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808857		Armature complete
799087		Field Coil (lower)
799086		" " (upper)

#### S 593005- N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808858		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799089		Field Coil (lower)
799088		" " (upper)

#### S 593006-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808859		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
798385		Field Coil (lower)
798384		" (upper)

#### S 593007-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808860		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
798385		Field Coil (lower)
798384		" " (upper)

#### S 593008-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808861		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799091		Field Coil (lower)
799090		" " (upper)

#### S 593009-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808862		Armature complete
798379		Brush complete
798377		Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799091		Field Coil (lower)
799090		" " (upper)

#### S 692001-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808863		Armature complete
799083		Field Coil (lower)
799082		" " (upper)

#### S 692007-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808864		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799085		Field Coil (lower)
799084		" (upper)

# LIST OF PART COMPLETE FOR

# S 69300I-N ELECTRIC TRANSMITTER

No.	Plate	Name
808844		Armature complete
808728	20222	" Shaft Ball Bearing
808815	20222	" " " Retainer
931221	20222	" " " Thrust Washe:
<b>#</b> 796446		" Bushing
747148	20221	" " Cap
51680R	20221	" " Nut
67255	20221	" " Cotter Pin
798876	20221	Brush complete
799858	20221	" Holder Cap
799977		" " 799858 with 140122
140122	20221	" " Screw (brass)
799857	20221	Brush Holder Lead complete with Termi-
		nals
798874	20221	Brush Holder Ring with Brush Tubes
50658R	20221	" " Screw
1784E	20221	" " Nut
798873		Brush Holder complete, Nos. 798874 and two 799977
798481		Commutator complete
797821	20221	End Cover (terminal box end)
798381		" " 797821 with 796446
51398R		" " Bolt
51626R	20221	" " Nut
701679	20221	" " " Lock Washer
804588		Field Coil (lower)
804587		" " (upper)
799629		" Retaining Pin
798895		" " " " Insulation
799869		Field Core complete
808943	20222	Grease Fitting (alemite) for greasing
		Armature Shaft Ball Bearing
67481	20221	Hand Hole Cover
50647R	20221	" " Screw
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Electric Transmitter to table,
	00070	Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach- ing Electric Transmitter to table,

```
No.
           Plate
                                      Name
*899598
                    Name Plate
           ----
700871
                               Rivet
                    Oil Well Cap
797097
           20221
 67702
           20221
                    Terminal
796865
           20221
                             Box Cover
           20221
 50671R
                                       Screw
 50647R
           20221
                             Screw
  1785
           20221
                                   Nut (brass)
                    Transmitter Brake (thermoid)
943590
           20222
140228C
           20222
                                      Adjusting Screw
                                                      140228C
943978
                        with 1637C
                    Transmitter Brake Adjusting Screw Lock
   1637C
           20222
                        Nut
           20222
                    Transmitter Brake Holder
809098
943588
           20222
                    Transmitter Brake Holder complete, Nos.
                        809098, 943590 and two 943978
           20222
                    Transmitter Brake Screw Stud
 69246
  1670R
           20222
                                Fly Wheel
 808759
 808887
                                           808759 with 69255,
                        809764 and four 69256
  69415
           20222
                    Transmitter Fly Wheel Guard (back) with
                        Bracket
                    Transmitter Fly Wheel Guard (front) with
  69413
           20222
                        Bracket
           20222
                    Transmitter Fly Wheel Guard Bracket
 51382R
                        Screw, for rear guard
                    Transmitter Fly Wheel Key
  67357
           20221
                                Frame and End Cover
*808817
                                           67
                                                11
           20222
                                                     808817
 808816
                        with 51421R,51422R,69270,69271,69344
                        and 69345
                    Transmitter Friction Pulley
*808822
 809764
           20222
                                                 Friction
                        Disc (cork)
                    Transmitter Friction Pulley Friction
  69255
           20222
                        Disc Retaining Ring
                    Transmitter Friction Pulley Friction
           20222
  69256
                        Disc Stud
                    Transmitter Friction Pulley Pin
 941097
                                Shaft
*808902
 808821
                                       808902 with 808822 and
                        941097
                    Transmitter Shaft 808821 with 1633R.
 808820
                        69268, 69269, 69427 and two each
                        797421 and 931191
           20222
                    Transmitter Shaft Ball Bearing
 797421
                                                    Spacing
  69268
           20222
```

Collar

No.	Plate	Name
931191	20222	Transmitter Shaft Ball Bearing Thrust Washer
69269	20222	Transmitter Shaft Bushing and Brake Cam
#69270		a a a a a
		Cap
69271		Transmitter Shaft Bushing and Brake Cam Cap Position Pin
808943	20222	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite)
808944	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite) (For Agents only)
1517J	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting Lock Nut
Not	te: Nos.	808944 and 1517J to be used when the
		itter is used to drive a left hand Machine
51421R	20222	Transmitter Shaft Bushing and Brake Cam
		Screw (long)
69345	20222	Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar
51422R	20222	Transmitter Shaft Bushing and Brake Cam
		Screw (short)
1633R	20222	Transmitter Shaft Lock Nut
1633R	20222	" " Nut
701350	20222	" " Lock Washer
69426	20222	" Starting Lever with 115R
69427		" " 69426 with
		2762 and 69428
115R	20222	Transmitter Starting Lever Clamping Screw
69428	20222	Transmitter Starting Lever Extension
2762	20222	" " " Collar
		with 3620
362C	20222	Transmitter Starting Lever Extension
		Collar Set Screw
69274	20222	Transmitter Starting Lever Spring
69275	20222	a u u a Arm
50823R	20222	a n ti ii ti
		Screw
2718	20222	Transmitter Starting Lever Spring Arm

#### S 693000-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No. Plate Name 808843 ---- Armature complete

From the library of: Superior Sewing Machine & Supply LLC

#### S 693000-N Electric Transmitter - Continued

No.	Plate			Name
804586		Field	Coil	(lower)
804585		tI	n	(upper)

#### S 693002-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808845		Armature complete
804590		Field Coil (lower)
804589		" (upper)

#### S 693005-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808846		Armature complete
798379		Brush complete ·
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804592		Field Coil (lower)
804591		" " (upper)

#### S 693006-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808847		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804594		Field Coil (lower)
804593		" " (upper)

# S 693007-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808848		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804596		Field Coil (lower)
804595		" " (upper)

#### S 693008-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808850		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
799962		Field Coil (lower)
799961		" " (upper)

# S 693009-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 693001-N Electric Transmitter with the following exceptions:

No.	Plate	Name
808849		Armature complete
798379		Brush complete
798377		" Holder Ring with Brush Tubes
798376		Brush Holder complete, Nos. 798377 and
		two 799977
798480		Commutator complete
804598		Field Coil (lower)
804597		" " (upper)

# SERIES S 59 AND S 69 SINGLE PHASE, ALTERNATING CURRENT, CAPACITOR TYPE SINGER ELECTRIC TRANSMITTERS

NOTE: The Suffix letter "N" denotes the Transmitter is not equipped with leads for lighting fixture.

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 593116 and S 593116-N	1/3	1	100	190-210	1900
S 593141 and S 593141-N	1/3	1	40	105-115	2250
S 593147 and S 593147-N	1/3	1	40	210-230	2250
8 593148 and S 593148-N	1/3	1	40	230-250	2250
S 593150 and S 593150-N	1/3	1	50	95-105	1425
S 593151 and S 593151-N	1/3	1	50	105-115	1425
S 593152 and S 593152-N	1/3	1	50	115-125	1425
S 593153 and S 593153-N	1/3	1	50	125-135	1425
S 593156 and S 593156-N	1/3	1	50	190-210	1425
S 593157 and S 593157-N	1/3	1	50	210-230	1425
S 593158 and S 593158-N	1/3	1	50	230-250	1425
S 593161 and S 593161-N	1/3	1	60	105-115	1725
S 593162 and S 593162-N	1/3	1	60	115-125	1725
S 593165 and S 593165-N	1/3	1	60	150-165	1725
S 593166 and S 593166-N	1/3	1	60	190-210	1725
S 593167 and S 593167-N	1/3	1	60	210-230	1725
S 593168 and S 593168-N	1/3	1	60	230-250	1725
S 593186 and S 593186-N	1/3	1	80	190-210	2250
8 692151 and 8 692151-N	1/2	1	50	105-115	2900
S 692157 and S 692157-N	1/2	1	50	210-230	2900
S 692158 and S 692158-N	1/2	1	50	230-250	2900
S 692161 and S 692161-N	1/2	1	60	105-115	3400
8 692162 and S 692162-N	1/2	1	60	115-125	3400
S 692167 and S 692167-N	1/2	1	60	210-230	3400
S 692168 and S 692168-N	1/2	1	60	230-250	3400
S 693150	1/3	ī	50	95-105	2830
S 693151	1/3	1	50	105-115	2830
8 693152	1/3	1	50	115-125	2830
S 693156	1/3	1	50	190-210	2830
8 693157	1/3	1	50	210-230	2830
S 693158	1/3	1	50	230-250	2830
8 693161	1/3	1	60	105-115	3400
8 693162	1/3	1	60	115-125	3400
8 693165	1/3	1	60	150-165	3400
S 693166	1/3	1	60	190-210	3400
8 693167	1/3	1	60	210-230	3400
S 693168	1/3	] 1	60	230-250	3400

# LIST OF PARTS COMPLETE FOR S 593161 AND S 593161-N **ELECTRIC TRANSMITTERS**

No.	Plate	Name
796111	20223	End Cover (terminal box end)
796733		" " 796111 with 796446
51398R	20223	" Bolt
51626R	20223	" " " Nut
701679	20223	" " " Lock Washer
808943	20224	Grease Fitting (alemite) for greasing
		Rotor Shaft Ball Bearing
727511	20223	Lead Bushing (rubber) for lighting unit leads
190328	20223	Lead Bushing (rubber) for motor leads
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Electric Transmitter to table,
		Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach-
		ing Electric Transmitter to table,
		Nos. 51429R and 126150
#899868		Name Plate
700871		" " Rivet
797097	20223	Oil Well Cap
808880	20223	Rotor complete
808728	20224	Shaft Ball Bearing
808815	20224	" " " Retainer
931221	20224	" " " Thrust Washer
<b>*</b> 796446		" Bushing
747148	20223	" " Cap
51680R	20223	" Nut
67255	20223	" " Cotter Pin
798485	20223	Stator, for S 593161
797189		" S 593161-N
797689	20223	" Shield
796865		Terminal Box Cover for Transmitters
		without tap for light
798159	20223	Terminal Box Cover for Transmitters with
		tap for light
964270	20223	Terminal Box Cover Bushing, for 798159

# 56 SERIES S 59 AND S 69 I PH. A. C. CAPACITOR TYPE - Continued

No.	Plate	Name
50671R	20223	Terminal Box Cover Screw
943590	20224	Transmitter Brake (thermoid)
140228C	20224	" Adjusting Screw
943978		" " 140228C
		with 1637C
1637C	20224	Transmitter Brake Adjusting Screw Lock Nut
809098	20224	Transmitter Brake Holder
943588	20224	Transmitter Brake Holder complete, Nos. 809098, 943590 and two 943978
69246	20224	Transmitter Brake Screw Stud
1670R	20224	" " " Nut
. 808818	20224	" Fly Wheel
808819	20224	" " 808818 with 69255,
		809764 and four 69256
69415	20224	Transmitter Fly Wheel Guard (back) with Bracket
69413	20224	Transmitter Fly Wheel Guard (front) with Bracket
51382R	20224	Transmitter Fly Wheel Guard Bracket Screw for rear guard
67357	20223	Transmitter Fly Wheel Key
<b>*808817</b>		" Frame and End Cover
808816	20224	" " " " 808817
000010		with 51421R, 51422R, 69270, 69271, 69344 and 69345
#808822		Transmitter Friction Pulley
809764	20224	" " Friction Disc
69255	20224	Transmitter Friction Pulley Friction
00200	20201	Disc Retaining Ring
69256	20224	Transmitter Friction Pulley Friction Disc Stud
941097		Transmitter Friction Pulley Pin
#808902		" Shaft
808821	20224	" " 808902 with 808822 and
		941097
808820		Transmitter Shaft 808821 with 1633R, 69268, 69269, 69427 and two each 797421 and 931191
797421	20224	Transmitter Shaft Ball Bearing
69268	20224	g g g Spacing
		Collar
931191	20224	Transmitter Shaft Ball Bearing Thrust Washer
69269	20224	Transmitter Shaft Bushing and Brake Cam
69270		n n n n n n
		Cap
69271		Transmitter Shaft Bushing and Brake Cam Cap Position Pin

No.	Plate	Name
808943	20224	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting (alemite)
808944	20227	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting (alemite) (For
		Agents only)
1517J	20227	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting Lock Nut
Not		808944 and 1517J to be used when the
•	Transmi	tter is used to drive a left hand Machine
51421R	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (long)
69345	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (long) Spacing Collar
51422R	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (short)
1633R	20224	Transmitter Shaft Lock Nut
1633R	20224	" " Nut
701350	20224	" " Lock Washer
69426	20224	" Starting Lever with 115R
69427		" " 69426 with 2762
		and 69428
115R	20224	Transmitter Starting Lever Clamping
		Screw
69428	20224	Transmitter Starting Lever Extension
2762	20224	" " " Collar
		with 362C
362C	20224	Transmitter Starting Lever Extension
		Collar Set Screw
69274	20224	Transmitter Starting Lever Spring
69275	20224	m a a Arm
50823R	20224	<b>A H</b> 11 11
		Screw
2718	20224	Transmitter Starting Lever Spring Arm Screw Washer

# S 593116 AND S 593116-N ELECTRIC TRANSMITTERS

No.	Plate				Name
798968		Stator	for	S	593116
799011		Ħ	#	S	593116-N

#### S 593141 AND S 593141-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808883		Rotor complete
798961		Stator for S 593141
797489		" " S 593141-N

#### S 593147 AND S 593147-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808883		Rotor complete
798962		Stator for S 593147
799009		" " S 593147-N

#### S 593148 AND S 593148-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808883		Rotor complete
799863		Stator for S 593148
804562		" " S 593148-N

#### S 593150 AND S 593150-N ELECTRIC TRANSMITTERS

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
798960		Stator for S 593150
799008		" " S 593150-N

# S 593151 AND S 593151-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
798549		Stator for S 593151
797195		" " S 593151-N

#### S 593152 AND S 593152-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782P
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
798713		Stator for S 593152
797480		"

# S 593153 AND S 593153-N ELECTRIC TRANSMITTERS

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
799336		Stator for S 593153
799058		"

#### S 593156 AND S 593156-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
798914		Stator for S 593156
797474		" " S 593156-N

### S 593157 AND S 593157-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
798683		Stator for S 593157
797468		" " S 593157-N

## S 593158 AND S 593158-N ELECTRIC TRANSMITTERS

No.	Plate	Name
799746		End Cover 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
799649		Stator for S 593158
797471		" " S 593158-N

# S 593162 AND S 593162-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798607		Stator	for	S	593162
797192		Ħ	87	S	593162-N

### S 593165 AND S 593165-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798971		Stator	for	S	593165
799052		a	a	s	593165-N

# S 593166 AND S 593166-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798914		Stator	for	S	593166
799053		n	27	8	593166-N

#### S 593167 AND S 593167-N ELECTRIC TRANSMITTERS

No.	Plate				Name
798756		Stator	for	8	593167
797456		tī	a	S	593167-N

# S 593168 AND S 593168-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate				Name
799764		Stator	for	S	593168
804561		ti	t1	S	593168-N

#### S 593186 AND S 593186-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798967		Stator	for	S	593186
799010		tt	Ħ	S	593186-N

#### S 692151 AND S 692151-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808883		Rotor complete
798686		Stator for S 692151
797320		" " S 692151-N

#### S 692157 AND S 692157-N ELECTRIC TRANSMITTERS

No.	Plate	Name
808883		Rotor complete
798798		Stator for S 692157
797486		" " S 692157-N

# S 692158 AND S 692158-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808883		Rotor complete
799587		Stator for S 692158
804564		" " S 692158-N

# S 692161 AND S 692161-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808868		Rotor complete
798686		Stator for S 692161
797483		" " S 692161-N

## S 692162 AND S 692162-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808868		Rotor complete
798969		Stator for S 692162
797198		" " S 692162-N

# S 692167 AND S 692167-N ELECTRIC TRANSMITTERS

No.	Plate	Name
808868		Rotor complete
798798		Stator for S 692167
798127		" " S 692167-N

# S 692168 AND S 692168-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593161 and S 593161-N Electric Transmitters with the following exceptions:

No.	Plate	Name
808868		Rotor complete
799804		Stator for S 692168
804563		" " S 692168-N

#### S 693150 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799407		Stator	
799341		" Shield	

#### S 693151 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799409		Stator	
799341		Shield	

#### S 693I52 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799411		Stator	
799341		" Shield	

#### S 693156 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No. 140124R 808878	Plate	End Cover Bolt Rotor complete	Name
799413 799341		Stator "Shield	

#### S 693157 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799415		Stator	
799341		" Shield	

#### S 693158 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808878		Rotor complete
804560		Stator
799341		" Shield

#### S 693161 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799395		Stator	
799341		" Shield	

#### S 693162 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799397		Stator	
799341		" Shield	

#### S 693165 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799399		Stator	
799341		" Shield	

#### S 693166 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
799401		Stator	
799341		" Shield	

# S 693167 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808878		Rotor complete
799403		Stator
799341		" Shield

# S 693168 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593161 Electric Transmitter with the following exceptions:

No.	Plate		Name
140124R		End Cover Bolt	
808878		Rotor complete	
804559		Stator	
799341		" Shield	

# SERIES S 59 AND S 69 POLY PHASE, ALTERNATING CURRENT, SINGER ELECTRIC TRANSMITTERS

NOTE: The Suffix letter "N" denotes the Transmitter is not equipped with leads for lighting fixture.

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 592248	1/2	2	40	230-250	2250
S 592341 and S 592341-N	1/2	3	40	105-115	2250
S 592348	1/2	3	40	230-250	2250
S 59235Y-N	1/2	3	50	440	1425
S 592367	1/2	3	60	210-230	1725
S 593221 and S 593221-N	1/3	2	25	105-115	1425
8 593227 and S 593227-N	1/3	2	25	210-230	1425
S 593228	1/3	2	25	230-250	1425
S 593241 and S 593241-N	1/3	2	40	105-115	2250
S 593247 and S 593247-N	1/3	2	40	210-230	2250
8 593248	1/3	2	40	230-250	2250
8 593251 and S 593251-N	1/3	2	50	105-115	1425
S 593257 and S 593257-N	1/3	2	50	210-230	1425
S 593258	1/3	2	50	230-250	1425
S 593261 and S 593261-N	1/3	2	60	105-115	1725
S 593267 and S 593267-N	1/3	2	60	210-230	1725
S 593268	1/3	2	60	230-250	1725
S 59326Y-N	1/3	2	60	440	1725
S 593321 and S 593321-N	1/3	3	25	105-115	1425
S 593326	1/3	3	25	190-210	1425
8 593327 and S 593327-N	1/3	3	25	210-230	1425
S 593328	1/3	3	25	230-250	1425
S 593341 and S 593341-N	1/3	3	40	105-115	2250
S 593345 and S 593345-N	1/3	3	40	150-165	2250
S 593347 and S 593347-N	1/3	3	40	210-230	2250
S 593348	1/3	3	40	230-250	2250
S 593351 and S 593351-N	1/3	3	50	105-115	1425
8 593352 and S 593352-N	1/3	3	50	115-125	1425
S 593353 and S 593353-N	1/3	3	50	125-135	1425
S 593356 and S 593356-N	1/3	3	50	190-210	1425
S 593357 and S 593357-N	1/3	3	50	210-230	1425
8 593358 and 8 593358-N	1/3	3	50	230-250	1425
S 59335X-N	1/3	3	50	380	1425
S 59335Y-N	1/3	3	50	440	1425
S 593361 and S 593361-N	1/3	3	60	105-115	1725
S 593366 and S 593366-N	1/3	3	60	190-210	
S 593367 and S 593367-N	1/3	3	60	210-230	1725
S 593368	1/3	3	60	230-250	1725
S 59336Y-N	1/3	3	60	440	1725
		_			

# SERIES S 59 AND S 69 POLY PHASE, ALTERNATING CURRENT SINGER ELECTRIC TRANSMITTERS - Continued

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 692258	1/2	2	50	230-250	2900
S 692267 and S 692267-N	1/2	2	60	210-230	3500
S 692268	1/2	2	60	230-250	3500
S 69226Y-N	1/2	2	60	440	3500
S 692357 and S 692357-N	1/2	3	50	210-230	2900
S 692358	1/2	3	50	230-250	2900
S 69235X-N	1/2	3	50	380	2900
S 69235Y-N	1/2	3	50	440	2900
S 692361 and S 692361-N	1/2	3	60	105-115	3500
S 692366 and S 692366-N	1/2	3	60	190-210	3500
S 692367 and S 692367-N	1/2	3	60	210-230	3500
S 692368	1/2	3	60	230-250	3500
S 69236Y-N	1/2	3	60	<del>44</del> 0	3500
S 693251	1/3	2	50	105-115	2900
S 693257	1/3	2	50	210-230	2900
S 693258	1/3	2	50	230-250	2900
S 693261	1/3	2	60	105-115	3400
8 693267	1/3	2	60	210-230	3400
S 693268	1/3	2	60	230-250	3400
S 693351	1/3	3	50	105-115	2900
S 693352	1/3	3	50	115-125	2900
8 693353	1/3	3	50	125-135	2900
S 693356	1/3	3	50	190-210	2900
S 693357	1/3	3	50	210-230	2900
S 693358	1/3	3	50	230-250	2900
S 693361	1/3	3	60	105-115	3400
S 693366	1/3	3	60	190-210	3400
S 693367	1/3	3	60	210-230	3400
S 693368	1/3	3	60	230-250	3400
s 69336Y-N	1/3	3	60	440	3400

# LIST OF PARTS COMPLETE FOR

# S 593361 AND S 593361-N SINGER ELECTRIC TRANSMITTERS

No.	Plate	Name
796111	20223	End Cover (terminal box end)
796733		" " 796111 with 796446
51397R		" " Bolt
51626R	20223	" " Nut
701679	20223	" " " Lock Washer
808943	20224	Grease Fitting (alemite) for greasing
270712		Rotor Shaft Ball Bearing
727511	20223	Lead Bushing (rubber) for lighting unit
,,,,,,,,,		leads
190328	20223	Lead Bushing (rubber) for motor leads
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69353	20232	Motor Bolt (long) complete, for attach-
		ing Electric Transmitter to table,
		Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete, for attach-
		ing Electric Transmitter to table,
		Nos. 51429R and 126150
<b>*</b> 899868		Name Plate
700871		" " Rivet
797097	20223	011 Well Cap
808840		Rotor complete
808728	20224	" Shaft Ball Bearing
808815	20224	" " " Retainer
931221	20224	" " " Thrust Washer
<b>*</b> 796446		" " Bushing
747148	20223	" " " Cap
51680R	20223	" " Nut
67255	20223	" " Cotter Pin
798984		Stator, for S 593361
797396		" " S 593361-N
797691		" Shield
796865		Terminal Box Cover for Electric Trans-
		mitter without tap for light
798159	20223	Terminal Box Cover for Electric Trans-
		mitter with tap for light
964270	20223	Terminal Box Cover Bushing (rubber) for
		798159
50671R	20223	Terminal Box Cover Screw

No.	Plate	Name
943590	20224	Transmitter Brake (thermoid)
140228C	20224	" Adjusting Screw
943978		" " 140228C
		with 1637C
1637C	20224	Transmitter Brake Adjusting Screw Lock Nut
809098	20224	Transmitter Brake Holder
943588	20224	Transmitter Brake Holder complete, Nos. 809098, 943590 and two 943978
69246	20224	Transmitter Brake Screw Stud
1670R	20224	" " " Nut
808818	20224	" Fly Wheel
808819	20224	" " 808818 with 69255,
		809764 and four 69256
69415	20224	Transmitter Fly Wheel Guard (back) with Bracket
69413	20224	Transmitter Fly Wheel Guard (front) with Bracket
51382R	20224	Transmitter Fly Wheel Guard Bracket Screw for rear guard
67357	20223	Transmitter Fly Wheel Key
#808817		" Frame and End Cover
808816	20224	" " " " 808817
		with 51421R,51422R,69270,69271,69344 and 69345
808822		Transmitter Friction Pulley
809764	20224	" " Friction Disc
		(cork)
69255	20224	Transmitter Friction Pulley Friction Disc Retaining Ring
69256	20224	Transmitter Friction Pulley Friction Disc Stud
941097		Transmitter Friction Pulley Pin
*808902		" Shaft
808821	20224	" " 808902 with 808822 and
		941097
808820		Transmitter Shaft 808821 with 1633R, 69268, 69269, 69427 and two each 797421 and 931191
797421	20224	Transmitter Shaft Ball Bearing
69268	20224	" " " " Spacing Collar
931191	20224	Transmitter Shaft Ball Bearing Thrust Washer
69269	20224	Transmitter Shaft Bushing and Brake Cam
69270		ti ti ti ti ti
		Cap
69271		Transmitter Shaft Bushing and Brake Cam Cap Position Pin
808943	20224	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite)

No.	Plate	Name
808944	20227	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting (alemite) (For
		Agents only)
1517J	20227	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting Lock Nut
Note	e: Nos.	808944 and 1517J to be used when the
	Transmi	tter is used to drive a left hand Machine
51421R	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (long)
69345	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (long) Spacing Collar
51422R	20224	Transmitter Shaft Bushing and Brake Cam
		Screw (short)
1633R	20224	Transmitter Shaft Lock Nut
1633R	20224	" " Nut
701350	20224	" " Lock Washer
69426	20224	" Starting Lever with 115R
69427		" " " 69426 with 2762
		and 69428
115R	20224	Transmitter Starting Lever Clamping
		Screw
69428	20224	Transmitter Starting Lever Extension
2762	20224	" " " Collar
		with 362C
362C	20224	Transmitter Starting Lever Extension
		Collar Set Screw
69274	20224	Transmitter Starting Lever Spring
69275	20224	" " " Arm
50823R	20224	n . u u u u
		Screw
2718	20224	Transmitter Starting Lever Spring Arm
		Screw Washer

#### S 592248 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No.	Plate		Name
804558		Stator	

#### S 592341 AND S 592341-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798994		Stator	for	S	592341
799023		11	tt	S	592 <b>341-</b> N

## S 592348 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No.	Plate		Name
804556		Stator	

# S 59235Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exceptions:

No.	Plate		Name
51398R		End Cover Bolt	
808870		Rotor complete	
943718		Stator	
797689		" Shield	

#### S 592367 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
51398R		End Cover Bolt
799746		" " 796733 with 799744 and two
		50782R
799744		End Cover Air Baffle
50782R		" " " Screw
808982		Rotor complete
804936		Stator
797689		" Shield

#### S 59322I AND S 59322I-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
51424R		End Cover Bolt
808875		Rotor complete
798982		Stator for S 593221
797990		" " S 593221-N
797686		" Shield

#### S 593227 AND S 593227-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
51424R		End Cover Bolt
808875		Rotor complete
798983		Stator for S 593227
799017		" " \$ 59 <b>3</b> 227-N
797686		" Shield

#### S 593228 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate		Name
51424R		End Cover Bolt	
808875		Rotor complete	
799849		Stator	
797686		" Shield	

#### S 593241 AND S 593241-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798980		Stator	for	S	593241
799015		ti	tı	S	593241-N

#### S 593247 AND S 593247-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798981 Stator for S 593247 " S 593247-N 799016

#### S 593248 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No. Plate Name 799859 Stator

#### S 593251 AND S 593251-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798978 Stator for S 593251 " S 593251-N 799014

### S 593257 AND S 593257-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798979 Stator for S 593257 " S 593257-N 798023

### S 593258 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No. Plate Name 799855 Stator

#### S 593261 AND S 593261-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798977		Stator	for	S	593261
799013		II.	u	S	593261-N

#### S 593267 AND S 593267-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798258		Stator	for	S	593267
797182		Ħ	tt	s	593267-N

#### S 593268 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No.	Plate		Name
799853		Stator	

#### S 59326Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No.	Plate		Name
797760		Stator	

#### S 593321 AND S 593321-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate		Name
51424R		End Cover Bolt	
808875		Rotor complete	

From the library of: Superior Sewing Machine & Supply LLC

S 593321 and S 593321-N Electric Transmitters - Continued

Ro.	Plate				Name
798990		Stator	for	S	593321
793130		ti	11	S	593321-N
797686		:1	Shi	elo	i

#### S 593326 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate		Name
51424R		End Cover Bolt	
808875		Rotor complete	
809913		Stator	
797686		" Shield	

#### S 593327 AND S 593327-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
51424R		End Cover Bolt
808875		Rotor complete
798744		Stator for S 593327
797459		" " S 593327-N
797686		" Shield

#### S 593328 ELECTRIC TRANSMITTER

No.	Plate		Name
51424R		End Cover Bolt	
808875		Rotor complete	
799847		Stator	
797686		" Shield	

#### S 593341 AND S 593341-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798988 ---- Stator for S 593341 799020 ---- " " S 593341-N

#### S 593345 AND S 593345-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798987 ---- Stator for S 593345 798093 ---- " S 593345-N

#### S 593347 AND S 593347-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name 798989 ---- Stator for S 593347 799021 ---- " " S 593347-N

#### S 593348 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No. Plate Name 799845 ---- Stator

#### S 593351 AND S 593351-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Nam 798985 ---- Stator for S 593351

#### S 593352 AND S 593352-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798986		Stator	for	S	593352
799049		ti	Ħ	S	593352-N

#### S 593353 AND S 593353-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798603		Stator	for	S	593353
799335		n	17	s	593353-N

#### S 593356 AND S 593356-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798769		Stator	for	S	593356
797402		Ħ	#	S	593356-N

# S 593357 AND S 593357-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798764		Stator	for	8	593357
797173		ti	11	S	593357-N

7

# S 593358 AND S 593358-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
799839		Stator	for	S	593358
799018		, tt	CI	s	593358-N

#### S 59335X-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exception:

No.	Plate		Name
799019		Stator	

#### S 59335Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exception:

No.	Plate		Name
797398		Stator	

#### S 593366 AND S 593366-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798601		Stator	for	S	593366
797402		tf	t1	S	593366-N

#### S 593367 AND S 593367-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate				Name
798281		Stator	for	S	593367
797171		4	Ħ	s	593367-N

#### S 593368 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No. Plate Name 799800 ---- Stator

#### S 59336Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exception:

No. Plate Name 797398 ---- Stator

#### S 692258 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No. Plate Name 140124R End Cover Bolt 804557 Stator ----808759 ----Transmitter Fly Wheel 17 808887 808759 with 69255. ----809764 and four 69256

#### S 692267 AND S 692267-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No. Plate Name

140124R ---- End Cover Bolt

798354 ---- Stator for S 692267

797184 ---- " " S 692267-N

808759 ---- Transmitter Fly Wheel

808887 ---- " " 808759 with 69255,

809764 and four 69256

#### S 692268 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
799861		Stator
808759		Transmitter Fly Wheel
808887		" " # 808759 with 69255,
		809764 and four 69256

#### S 69226Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
804337		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692357 AND S 692357-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
798993		Stator for S 692357
798132		" " S 692357-N
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692358 ELECTRIC TRANSMITTER

No.	Plate		Name
140124R		End Cover Bolt	

#### S 692358 Electric Transmitter - Continued

No.	Plate	Name
799837		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 69235X-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
799022		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

# S 69235Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
943513		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692361 AND S 692361-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
798991		Stator for S 692361
797609		" " S 692361-N
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692366 AND S 692366-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
798992		Stator for S 692366
797177		"
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692367 AND S 692367-N ELECTRIC TRANSMITTERS

These Electric Transmitters are the same as S 593361 and S 593361-N Electric Transmitters with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
<i>∽</i> . 798541		Stator for S 692367
797177		" " S 692367-N
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 692368 ELECTRIC TRANSMITTER

No.	Plate	Name
140124R		End Cover Bolt
799802		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 69236Y-N ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361-N Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
797700		Stator
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693251 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No. Plate	Name
140124R	End Cover Bolt
808839	Rotor complete
799377	Stator
799341	" Shield
808759	Transmitter Fly Wheel
808887	" " 808759 with 69255,
	809764 and four 69256

#### S 693257 ELECTRIC TRANSMITTER

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799379		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693258 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
804555		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693261 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799373		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693267 ELECTRIC TRANSMITTER

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799375		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693268 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
804554		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693351 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799385		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693352 ELECTRIC TRANSMITTER

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799387		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

Plate

No.

#### S 693353 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

NO.	Plate	Mane
140124R		End Cover Bolt
808839		Rotor complete
799389		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693356 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799391		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693357 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

140124R	 End Cover Bolt
808839	 Rotor complete
799393	 Stator
799341	 " Shield
808759	 Transmitter Fly Wheel
808887	 " " 808759 with 69255,
	809764 and four 69256

Name

#### S 693358 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
804553		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693361 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799381		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693366 ELECTRIC TRANSMITTER

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799383		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

No.

No.

Plate

Plate

#### S 693367 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

No.	Plate	Name
140124R		End Cover Bolt
808839		Rotor complete
799339		Stator
799341		" Shield
808759		Transmitter Fly Wheel
808887		" " 808759 with 69255,
		809764 and four 69256

#### S 693368 ELECTRIC TRANSMITTER

This Electric Transmitter is the same as S 593361 Electric Transmitter with the following exceptions:

140124R	 End Cover Bolt
808839	 Rotor complete
799875	 Stator
799341	 " Shield
808759	 Transmitter Fly Wheel
808887	 " " 808759 with 69255,
	809764 and four 69256

Name

Name

#### S 69336Y-N ELECTRIC TRANSMITTER

140124R	 End Cover Bolt
808839	 Rotor complete
799710	 Stator
799341	 " Shield
808759	 Transmitter Fly Wheel
808887	 " " 808759 with 69255,
	809764 and four 69256

# SERIES S 59, SINGLE PHASE, ALTERNATING CURRENT REPULSION START, INDUCTION TYPE SINGER ELECTRIC TRANSMITTER

NOTE: The Suffix letter "N" denotes the Transmitter is not equipped with leads for lighting fixture.

Catalog No.	H.P.	Phase	Cycles	Volts	R.P.M.
S 593121 and S 593121-N	1/3	1	25	105-115 210-230	1425

# LIST OF PARTS COMPLETE FOR S 593121 AND S 593121-N ELECTRIC TRANSMITTERS

No.	Plate	Name
798098	3 20225	Brush with lead and terminal
51330	OR 20225	" Screw
792595	5 20225	" Spring
796776	20225	" " Stud
798324	<u></u>	Commutator complete
79790	1 20225	End Cover (commutator end)
50669	PR 20225	" " " Screw
701799	20225	" " Lock
		Washer
, 808943	3 20225	Grease Fitting (alemite) for greasing Rotor Shaft Ball Bearing
797778	3 20225	Hand Hole Cover
50636	SR 20225	" " " Screw
797900	20225	Housing
72751	1 20225	Lead Bushing (rubber) for lighting unit
		leads
190328	3 20225	Lead Bushing (rubber) for motor leads
51428	BR 20232	Motor Bolt (long) with 1778R for 69353
51429	OR 20232	"
1778	3R 20232	" " Nut
126150	20232	" " Lock Washer
69353	3 20232	Motor Bolt (long) complete for attach-
		ing Electric Transmitter to table,
		Nos. 51428R and 126150
69354	1 20232	Motor Bolt (short) complete for attach-
		ing Electric Transmitter to table,
		Nos. 51429R and 126150
*899526		Name Plate
876060	-	" " Drive Screw
797773		Rocker Ring complete
797774	ł	" 797773 with 745839 and two
70007	,	796037
796037		Rocker Ring Brush Box
797775		DISC
745839		indicator
700170	_	VIAGO
50826		per porew
809236	_	Rotor complete
79742	L 20225	" Shaft Ball Bearing (commutator end)
50494	IR 20225	Rotor Shaft Ball Bearing (commutator end) Grease Plug
From th	ne library of	: Superior Sewing Machine & Supply LLC
*		

No.	Plate	Name
808728	20226	Rotor Shaft Ball Bearing (pulley end)
808815	20226	" " " Retainer
931221	20226	" " " Thrust Washer
51680R	20225	" " Nut
67255	20225	" " Cotter Pin
808098	20225	Short Circuiter
797772	20225	" Retaining Ring
808983	20225	Stator for S 593121
808099		"
796865		Terminal Box Cover for Transmitters
		without tap for light
798159	20225	Terminal Box Cover for Transmitters with
		tap for light
964270	20225	Terminal Box Cover Bushing (rubber) for
		798159
50671R	20225	Terminal Box Cover Screw
943590	20226	Transmitter Brake (thermoid)
140228C	20226	" " Adjusting Screw
943978		" " " 140228C
		with 1637C
1637C	20226	Transmitter Brake Adjusting Screw Lock Nut
809098	20226	Tranşmitter Brake Holder
943588	20226	Transmitter Brake Holder complete, Nos.
		809098, 943590 and two 943978
69246	20226	Transmitter Brake Screw Stud
1670R	20226	" " " Nut
808818	20226	" Fly Wheel
808819	20226	" " 808818 with 69255,
		809764 and four 69256
69415	20226	Transmitter Fly Wheel Guard (back) with
00437	00000	Bracket
69413	20226	Transmitter Fly Wheel Guard (front) with Bracket
51382R	20226	Transmitter Fly Wheel Guard Bracket
		Screw for rear guard
67357	20225	Transmitter Fly Wheel Key
#809524		Frame and End Cover
809529	20226	009024
		with 51421R,51422R,69270,69271,69344
7.4004.0D	00005	and 69345
140246R	20225	Transmitter Frame and End Cover Screw " " " " " Lock
701799	20225	Washer
808822		Transmitter Friction Pulley
809764	20226	" " " Friction Disc
00970#	LULLU	(cork)
69255	20226	Transmitter Friction Pulley Friction
09200	20220	Disc Retaining Ring
69256	20226	Transmitter Friction Pulley Friction
00200	20220	Transmitted fitted four ratter fitted

From the library of: Superior Sewing Machine & Supply LLC

No.	Plate	Name
941097		Transmitter Friction Pulley Pin
<b>*</b> 808902		" Shaft
808821	20226	" " 808902 with 808822 and
000021	20220	941097
000000		
808820		Transmitter Shaft 808821 with 1633R,
		69268, 69269, 69427 and two each
		797421 and 931191
797421	20226	Transmitter Shaft Ball Bearing
69268	20226	" " " " Spacing
		Collar
931191	20226	Transmitter Shaft Ball Bearing Thrust
		Washer
69269	20226	Transmitter Shaft Bushing and Brake Cam
*69270		n n n n n
		Cap
69271		Transmitter Shaft Bushing and Brake Cam
		Cap Position Pin
808943	20226	Transmitter Shaft Bushing and Brake Cam
000010	ಎಂಎಎಂ	Grease Fitting (alemite)
808944	20227	Transmitter Shaft Bushing and Brake Cam
000344	20221	Grease Fitting (alemite) (For
35357	00000	Agents only)
1517J	20227	Transmitter Shaft Bushing and Brake Cam
		Grease Fitting Lock Nut
37.4		
Not		808944 and 1517J to be used when the
	Transm	808944 and 1517J to be used when the itter is used to drive a left hand Machine
Not 51421R		808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam
51421R	Transm 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)
	Transm	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam
51421R	Transm 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar
51421R	Transm 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam
51421R 693 <b>4</b> 5	Transm: 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar
51421R 693 <b>4</b> 5	Transm: 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut
51421R 69345 51422R	Transm. 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short)
51421R 69345 51422R 1633R	Transm: 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut
51421R 69345 51422R 1633R 1633R	Transm: 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " Nut
51421R 69345 51422R 1633R 1633R 701350	Transm: 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer
51421R 69345 51422R 1633R 1633R 701350 69426	Transm: 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut  " Nut  " " Lock Washer  " Starting Lever with 115R
51421R 69345 51422R 1633R 1633R 701350 69426	Transm: 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762 and 69428
51421R 69345 51422R 1633R 1633R 701350 69426 69427	Transm: 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long) Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar Transmitter Shaft Bushing and Brake Cam Screw (short) Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R	Transm: 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762 and 69428  Transmitter Starting Lever Clamping Screw
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R	Transm. 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R	Transm: 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " Collar
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762	Transm. 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " Collar with 362C
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R	Transm. 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " " Collar with 362C  Transmitter Starting Lever Extension
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762 362C	Transm: 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " " Collar with 362C  Transmitter Starting Lever Extension Collar Set Screw
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762 362C 69274	Transm. 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " Collar with 362C  Transmitter Starting Lever Extension Collar Set Screw  Transmitter Starting Lever Spring
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762 362C 69274 69275	Transm: 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " " Collar with 362C  Transmitter Starting Lever Extension  Collar Set Screw  Transmitter Starting Lever Extension  Collar Set Screw  Transmitter Starting Lever Extension
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762 362C 69274	Transm. 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " Collar with 362C  Transmitter Starting Lever Extension  Collar Set Screw  Transmitter Starting Lever Spring  " " Arm  " " " Arm  " " " " Arm
51421R 69345 51422R 1633R 1633R 701350 69426 69427 115R 69428 2762 362C 69274 69275	Transm: 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226 20226	808944 and 1517J to be used when the itter is used to drive a left hand Machine Transmitter Shaft Bushing and Brake Cam Screw (long)  Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar  Transmitter Shaft Bushing and Brake Cam Screw (short)  Transmitter Shaft Lock Nut  " " Nut  " " Lock Washer  " Starting Lever with 115R  " " 69426 with 2762  and 69428  Transmitter Starting Lever Clamping Screw  Transmitter Starting Lever Extension  " " " Collar with 362C  Transmitter Starting Lever Extension  Collar Set Screw  Transmitter Starting Lever Extension  Collar Set Screw  Transmitter Starting Lever Extension

Screw Washer

# **GREASE GUNS**

No.	Plate	Name
121587	20227	Grease Gun (3 oz. capacity) for Fittings Nos. 808943 and 808944
121588	20227	Grease Gun (1/2 lb. capacity) for Fit-
		tings Nos. 808943 and 808944
193642	20227	Tube (filled with 4 ozs. of Singer Ball
		Bearing Lubricant) packed in Carton
No	ote: This	Lubricant is also furnished in 1 lb. and

# CAPACITOR AND SWITCH PARTS

4 lb. tins

Capacitor, Capacitor Box and Switch Complete No. 797303 For Series S 59 and S 69 Electric Transmitters For  $\frac{1}{2}$  H. P.

No.	Plate	Name
798647	20228	Capacitor (only)
798666	20228	Capacitor complete, Nos. 797351, 798647
		and two 796295
898999	20228	Capacitor Box Cover
50671R	20228	" " Screw
50671 <b>J</b>	20228	" " Ground Wire Screw
67218	20228	" " " " Washer
#899523		" Name Plate
964419		" " " Screw
797353		" " Packing (bottom)
797352		" " (side)
798665		" " (top)
898996	20228	Capacitor Box (box only) complete,
797351	20228	Capacitor Lead with Terminal Clip
796295	20228	" " Insulating Nipple
797336	20228	Switch
50511R	20228	" Screw
797303	20228	Capacitor, Capacitor Box and Switch com-
		plete, Nos. 50671J, 50671R, 67218,
		797336,797353,798665,798666,898996,
		898999, 899523, two each 50511R,
		797352, 964419 and four wood screws
		3/4 in. No. 12 R.H.

# Capacitor, Capacitor Box and Switch Complete No. 797304 For Series S 59 and S 69 Electric Transmitters For ½ H. P.

This Capacitor, Capacitor Box and Switch complete is the same as 797303 with the following exceptions:

No.	Plate	Name
*899522		Capacitor Box Name Plate
797337		Switch
797304		Capacitor, Capacitor Box and Switch com- plete, Nos. 50671J, 50671R, 67218, 797337,797353,798665,798666,898996, 898999, 899522, two each 50511R, 797352, 964419 and four wood screws 3/4 in. No. 12 R.H.

# Switch Box with Switch Complete No. 797305 For ½ H. P. For Ratings Under 270 Volts

No.	Plate	Name
797334	20228	Switch
876002	20228	" Box with Bracket
876004	20228	" " Cover
50671R	20228	" " Screw
50671J	20228	" " Ground Wire Screw
67218	20228	" " " " Washer
#899524		" Name Plate
964419		" " " Screw
876021	20228	" Handle Spacer
51 <b>393</b> J	20228	" " Screw
1550J	20228	n n n Nut
931033	20228	" " " " Lock
		Washer
50511R	20228	Switch Screw
797305	20228	Switch Box with Switch complete, Nos.
		1550J,50671J,51393J,67218,876002,
		876004,876021,899524,931033,two each
		50671R,797334,964419,wood screws 3/4
		in. No. 12 R.H. and four 50511R
		THE MO. TO WINE GIRL TORK DOUTTLE

# Switch Box with Switch Complete No. 797306 For ½ H. P. For Ratings Under 270 Volts

This Switch Box with Switch complete is the same as 797305 with the following exceptions:

No. Plate Name
797335 ---- Switch
\*899522 ---- " Box Name Plate
797306 ---- Switch Box with Switch complete, Nos.
1550J,5067lJ,51393J,67218,876002,
876004,876021,899522,931033,two each
50671R,797335,964419,wood screws 3/4
in. No. 12 R.H. and four 50511R

Switch Box with Switch (four pole) Complete No. 809411

For 1/3 and 1/2 H. P.

For Ratings above 270 Volts

No. Plate Name
809411 20228 Switch Box with Switch (four pole) complete with four wood screws 3/4 in.
No. 12 R.H.

Switch Box with Switch (three pole) Complete No. 797711 For ½ and ½ H. P. For Ratings above 270 Volts

No. Plate
797711 ---- Switch Box with Switch (three pole) complete with two wood screws 3/4 in.
No. 12 R.H.

Switch Box with Switch Complete No. 797307 For  $\frac{1}{3}$  H. P.

No. Plate Name 797336 20228 Switch 876013 ---- Box with Bracket Switch Box with Switch complete No. 797307 - Continued

No.	Plate	Name
876004	20228	Switch Box Cover
50671R	20228	" " Screw
50671J	20228	" " Ground Wire Screw
67218	20228	" " " " Washer
*899789		" Name Plate
964419		" " " Screw
50511R	20228	" Screw
797307		Switch Box with Switch complete, Nos.
		50671J,67218,797336,876004,876013,
		899789, two each 50511R, 50671R,
		964419 and wood screws 3/4 in. No.12
		R.H.

# Switch Box with Switch Complete No. 797308 For ½ H. P.

This Switch Box with Switch complete is the same as 797307 with the following exceptions:

NO.	Plate	Name
797337		Switch
797308		Switch Box with Switch complete, Nos.
		50671J,67218,797337,876004,876013,
		899522, two each 50511R, 50671R,
		964419 and wood screws 3/4 in. No.12
		R.H.

# CORD AND WIRE CONNECTIONS

No.	Plate	Name
67934		Cord (two strand) 8 ft. long, for 67930
191407		" (three strand) 8 ft.3 in. long, for 191406
898828		Cord (four strand) 8 ft. 3 in. long, for 898827
898780	20229	Cord Insulating Bushing with 50771, for 67930, 191406 and 898827
50771	20229	Cord Insulating Bushing Clamping Screw, for 898780
67932	20229	Cord Screw Plug
67933	20229	" " Cap
67931	20229	Cord Screw Plug, 660 watt, complete, for 67930, Nos. 67932 and 67933

No.	Plate	Name
67930	20229	Cord and Plug, 660 watt, complete, for stand, for one or two phase motors,
		Nos. 67931, 67934 and 898780
No	te: Two	No. 67930 are required for use with two
		motors.
191406	20229	Cord complete, for three phase motors, Nos. 191407 and 898780
898827	20229	Cord with ground wire complete, for three phase motors, Nos. 898780 and 898828
744765	20230	Wire, 45 in. long (two strand B.X.Cable) for 67630
7 <b>44</b> 766	20230	Wire, 45 in.long (three strand B.X. Cable) for 67632
744764	20230	Wire, 45 in.long (four strand B.X.Cable) for 67631
744760	20230	Wire Conduit Connector
744761	20230	" " 90 degrees
744762		" " Insulating Bushing, for 67630 and 67632
744763		Wire Conduit Connector Insulating Bush- ing, for 67631
190566	20230	Wire Conduit Strap
67630	20230	Wire Connection complete, for stand, from motor to switch, single phase A.C. Motors, 110 and 220 volts and D.C. Motors 115 and 230 volts, Nos. 744760, 744761, 744765 and two each 190566, 744762 and wood screws 3/4 in. No. 9 R.H.
67631	20230	Wire Connection complete, for stand, from motor to switch, two phase A.C. Motors 110 and 220 volts, Nos.744760, 744761, 744764 and two each 190566, 744763 and wood screws 3/4 in. No.9 R.H.
67632	20230	Wire Connection complete, for stand, from motor to switch, three phase A.C. Motors, 110, 220 and 440 volts, Nos. 744760,744761,744766 and two each 190566, 744762 and wood screws 3/4 in. No. 9 R.H.

# WIRE ADAPTERS WITH GROUND CONNECTION

No.	Plate			Name
744717	20229	Adapter	for	744716
744749	20229	n	Ħ	744748

100	WIDE ADAPTERS	WITH GROUND	CONNECTION

No.	Plate	Name				
744718	20229	Adapter Lead with 67702				
67702		" Terminal				
192541	20229	" Screw Base for 744748				
898780	20229	Lead Cord Insulating Bushing with 50771				
50771	20229	" " " Clamping Screw				
67702		" Terminal for 744711				
50671R	20229	" " Screw for 744711				
51522R	20229	" " " Nut for 744711				
744713	20229	" " Three Pin Plug				
744711	20229	Lead Cord, 8 ft. long, with ground con-				
	nection complete, for one or two					
		phase motors, Nos. 50671R, 51522R,				
		67702, 744713 and 898780				
No-	te: Two	No. 744711 are required for use with two				
	phase	motors				
744716	20229	Wire Adapter (tandem blade type) with				
		ground connection complete, Nos.				
		744717 and 744718				
744748	20229	Wire Adapter (parallel blade type) with				
		ground connection complete, Nos.				

# MACHINE DRIVING PULLEYS

192541, 744718 and 744749

# FLANGED

No.	Plate	Name
69277		Machine Driving Pulley, 1 1/4 in. face,
		1 1/4 in. diam.
69278		Machine Driving Pulley, 1 1/4 in. face,
		1 1/2 in. diam.
69279		Machine Driving Pulley, 1 1/4 in. face,
		1 3/4 in. diam.
69280		Machine Driving Pulley, 1 1/4 in. face,
		2 in. diam.
69281		Machine Driving Pulley, 1 1/4 in. face,
		2 1/4 in. diam.
69282		Machine Driving Pulley, 1 1/4 in. face,
		2 1/2 in. diam.
69283		Machine Driving Pulley, 1 1/4 in. face,
		2 3/4 in. diam.
69284		Machine Driving Pulley, 1 1/4 in. face,
		3 in. diam.
69285		Machine Driving Pulley, 1 1/4 in. face,
		3 1/4 in. diam.
69286		Machine Driving Pulley, 1 1/4 in. face,
		3 1/2 in. diam.
69287		Machine Driving Pulley, 1 1/4 in. face,
		3 3/4 in. diam.

No.	Plate	Name
69288		Machine Driving Pulley, 1 1/4 in. face, 4 in. diam.
69289		Machine Driving Pulley, 1 1/4 in. face, 4 1/4 in. diam.
69290		Machine Driving Pulley, 1 1/4 in. face, 4 1/2 in. diam.
69291		Machine Driving Pulley, 1 1/4 in. face, 4 3/4 in. diam.
69292		Machine Driving Pulley, 1 1/4 in. face, 5 in. diam.
69293		Machine Driving Pulley, 1 1/4 in. face, 5 1/4 in. diam.
69294		Machine Driving Pulley, 1 1/4 in. face, 5 1/2 in. diam.
69295		Machine Driving Pulley, 1 1/4 in. face, 5 3/4 in. diam.
69296		Machine Driving Pulley, 1 1/4 in. face, 6 in. diam.
69411		Machine Driving Pulley, 3 in. face, 2 in. diam.

# **DOUBLE GROOVED**

No.	Plate			Name				
69297		Machine	Driving	Pulley,	1	1/4	in.	diam.
69298		ti	tı	B	1	1/2	in.	diam.
69299		#		Ħ	1	3/4	in.	diam.
69300		tt	tı	a	2		in.	diam.
69301		ti	Ħ	Ħ	2	1/4	in.	diam.
69302		Ħ	Ħ	tt	2	1/2	in.	diam.
69303		£1	Ħ	a	2	3/4	in.	diam.
69304		tt	Ħ	ø	3		in.	diam.
69305		t1	u	17	3	1/4	in.	diam.
69306		tt	tt	tr	3	1/2	in.	diam.
69307		Ħ	tt	a	3	3/4	in.	diam.
69308		Ħ	ti	11	4		in.	diam.
69309		Ħ	n	ħ	4	1/4	in.	diam.
69310		#	tt	11	4	1/2	in.	diam.
69311		ti	tt	17	4	3/4	in.	diam.
69312		a	n	#	5		in.	diam.
69313		11	11	ti	5	1/4	in.	diam.
69314		tt	a	u	5	1/2	in.	diam.
69315		11	17	ø	5	3/4	in.	diam.
69316		.0	Ħ	#	6		in.	diam.

#### SINGLE GROOVED

No.	Plate			Name		
808537	LTGCO	Machine	Driving		1	in. diam.
69317		t MICHING	ti Di iailik	n u		in. diam.
69318		sı	Ħ	ti	-	in. diam.
69319		ti	tt	u		in. diam.
69320			11	t7	2	in. diam.
808415				EF		in. diam.
69321		Ħ	Ħ	#		in. diam.
808416		et	tt	tt		in. diam.
69322	20222		tt	tt	•	in. diam.
808417		#	tt	tt	•	in. diam.
69323		a	Ħ	n		in. diam.
808418			tt	ø		in. diam.
69324		Ħ	tt	tt		in. diam.
808419		n	į)	p	_	in. diam.
69325		п	Ħ	Ħ		in. diam.
808420		n	II.	a		in. diam.
69326		tı	tt	n		in. diam.
69327		es	a	ti	•	in. diam.
69328		Ħ	Ħ	\$1	•	in. diam.
69329		<b>\$1</b>	ti	· er	_	in. diam.
69330		ø	ŧŧ	ti		in. diam.
69331		pt pt		11		in. diam.
69332			tt	tt	•	in diam.
69333		II .	tt	p		in. diam.
69334	20218	a	n	ti		in. diam.
69335		tt .	п	U		in. diam.
69336		n	ţı	tt	6	in. diam.
1633R	20218	tr	ti	tt	Lock N	
701350	20218	ti	ti	п	DOCK I	" Lock
, 52000	20210	Wasi	ner			LOCK
1633R	20218		Driving	Pulley	Nut	

# MACHINE DRIVING PULLEY COVER

No.	Plate	Name
69258	20218	Machine Driving Pulley Cover
67327	20218	" " " Belt Guard
225R	20218	11 11 11 11 11
		Screw
22436	20218	Machine Driving Pulley Cover Belt Guard Screw Washer
69259	20218	Machine Driving Pulley Cover Bracket
51423R	20218	" " " Hinge Screw,
		for Series S 38 and S 48 Motors

No.	Plate		Name			
69344	20218	Machine Drivin	g Pulley	Cover	Hinge	Stud
199R	20218	u u	ti	ti	Screw	
931326		ti ti	ti	tt	ţı	Lock
		Washer				
69261	20218	Machine Drivin	g Pulley	Cover	Screw	Wash-
		er				
69346	20218	Machine Drivin	g Pulley	Cover	Spring	g, for
		Series S 3	8 and S	48 Mot	ors	
69262	20222	Machine Drivin	g Pulley	Cover	Spring	g, for
		Series S 5	9 and S	69 Elec	ctric ?	Trans-
		mitters				

# MOTOR BRACKET

# FOR TROUGH TABLES WHEN FASTENED TO TROUGH FOR MACHINE RUN HEAD-ON FOR SERIES S 38 AND S 48 MOTORS

No.	Plate	Name
51430R	20231	Motor Bolt with 1778R
1778R	20231	" " Nut
9842	20231	" " Washer
69351	20231	" Bracket
67875 ·	20231	" Clamping Plate
50734P	20231	" " Bolt with
		1778E
1778E	20231	Motor Bracket Clamping Plate Bolt Nut
126150	20231	
		Lock Washer
9842	20231	Motor Bracket Clamping Plate Bolt Nut
		Washer
67876		Motor Bracket Clamping Plate Bolt com-
		plete, Nos. 9842, 50734P and 126150
69352	20231	Motor Bracket complete, Nos. 69351, two
		67875, four each 9842,51430R and six
		67876

# MOTOR BRACKET (Auxiliary)

### FOR SERIES S 38 AND S 48 MOTORS FOR NOS. 146-30 AND 146-31 MACHINES

No.	Plate			Name	
69393	20231	Motor	Bracket	(auxiliary)	
51461R	20231	Ħ	8	Ħ	Screw

104	MOTOR	BRACKET	(Auviliary)
TO-	MUTUK	DKACKEI	( Muximary)

No.	Plate	Name
1062R	20231	Motor Screw
9842	20231	" " Washer
69394	20231	Motor Bracket (auxiliary) complete, Nos.
		69393 and four each 1062R, 9842 and
		51461 <b>R</b>

# MOTOR SPACING BLOCK

# FOR SERIES S 38 AND S 48 MOTORS FOR CLASS 99W MACHINES FOR STAND NO. 25297

No.	Plate			Na	ame		
69405	20231	Motor	Spacing	Block			
50621R	20231	ti	ti	11	Bolt	with	1778R
1778R	20231	#	"	ti	ţı	Nut	
126150	20231	Ħ	\$1	()	ţı	Ħ	Lock Washer
2807	20231	11	<b>\$1</b>	11	11	Ħ	Washer
69406	20231	Motor	Spacing	Block	comp	lete,	Nos. 69405
		aı	nd two ea	ach 280	07, 5	0621R	and 126150

# MOTOR BRACKETS

# FOR SERIES S 59 AND S 69 ELECTRIC TRANSMITTERS FOR TROUGH TABLES

No.	Plate	Name
50894R	20232	Motor Bolt
1778R	20232	" " Nut
126150	20232	" " Lock Washer
69339	20232	" Bracket
51473R	20232	" Bolt with 1778R
1778R	20232	" " Nut
126150	20232	" " " Lock Washer
69402		Motor Bracket Bolt complete, Nos. 51473R and 126150
69341	20232	Motor Bracket (left hand) complete, Nos. 69339, 69402 and two each 1778R, 50894R and 126150
69340	20232	Motor Bracket (right hand) complete, Nos.

#### FOR DEEP TROUGH TABLES

No.	Plate	Name
69348	20232	Motor Bracket
69349	20232	Motor Bracket (left hand) complete, Nos.
		1778R,50894R,69348,69354 and 126150
69350	20232	Motor Bracket (right hand) complete, Nos.
		69348, 69354 and two each 1778R,
		50894R and 126150

# UNIVERSAL MOTOR BRACKET

#### FOR SERIES S 59 AND S 69 ELECTRIC TRANSMITTERS

No.	Plate			Nai	ne
490R	20232	Universal	Motor	Bolt	with 1600R
1600R	20232	tt	ti	tt	Nut
126079	20232	Ħ	et	Ħ	" Lock Washer
69404	20232	ti	Ħ	tt	Spacing Collar
69397	20232	a	#	Brack	ket
140146R	20232	n	n	11	Bolt with 1778R
1778R	20232	a	tı	a	" Nut
126150	20232	tt	ti	ti	" " Lock
		Washe:	r		
69398	20232	69397	, three	e eac	ket complete, Nos. h 126150, 140146R OR, 69404 and 126079

# PITMAN AND TREADLE PARTS

# FOR SERIES S 59 AND S 69 ELECTRIC TRANSMITTERS

No.	Plate	Name
27639	20227	Pitman Rod (lower)
69337	20227	" (upper)
2762	20227	" " Collar with 3620
362C	20227	" " " Set Screw
150208	20227	" " Spring
23250	20227	" " " Washer
80223	20227	" Clamp with 361C
361C	20227	g g Screw
69338	20227	Pitman Rod complete, Nos. 23250, 27639,
		69337, 80223, 150208 and two 2762
126036	20227	Treadle
126037		<pre>126036 with 2718, 50581R and</pre>
		126038
126205	20227	Treadle Bracket (left)

106	PITMAN AND TREADLE	<b>PARTS</b>
100	PILMAN AND IREADLE	

**-	Diana	Nama
No.	Plate	Name
126206		Treadle Bracket (left) complete, Nos.
		23258,126205,126207,126208 and two
		wood screws 1 in. No. 14
126207	20227	Treadle Bracket (left) Hook
23258	20227	" " " Friction Wash-
		er
126208	20227	Treadle Bracket (left) Hook Rivet
46681		"
60502	20227	" " 46681 with two
		wood screws 1 in. No. 14
126038	20227	Treadle Extension
50581R	20227	" " Screw
2718	20227	" " Washer
126211	20227	Treadle complete, Nos. 60502, 126037 and
		126206

# SPEED REDUCER

No.	Plate	Name
126322	20233	Belt Guard
	20200	
126323		" 126322 with 515R, 126324 and
		four 60084
126324	20233	Belt Guard Hub
60084	20233	" " Rivet
515R	20233	" " Thumb Screw
126409	20233	Bracket with two 362C and three wood
		screws 1 1/4 in. No. 12 R.H.B.
60493	20233	Pulley (grooved) 5 in. diam.
60870	20233	" Hub
50512E	20233	" Screw
#126929		" Shaft
126325	20233	" " 126929 with 60739, 60740,
		61148 and two 60741
60739		Pulley Shaft Oiling Wick
60740		" " " Cover (leather)
60741		" " " " Plug
		(leather)
61148		Pulley Shaft Plug
362C	20233	" " Set Screw
60814	20233	" Washer
126344	20233	Speed Reducer complete, Nos.60814,60870,
		126323,126325,126409, two 60493 and
		eight 50512E

Note: When ordering No. 126344, state size of pulleys required.

# PULLEYS (Grooved)

# FOR SPEED REDUCER NO. 126344 AND TABLE BELT GUIDE NO. 150064

No.	Plate			1	Name		
60483		Pulley	(grooved)	2	1/2	in.	diam.
60484		ti	11				diam.
60485		tt	tt	3	•		diam.
60486		Ħ	S#	3	1/4		diam.
60487		11	tt				diam.
60488		c)	tt				diam.
60489		II.	g	4			diam.
60490		ţţ	tt	4	1/4		diam.
60491		67	II				diam.
60492		tt	\$I				diam.
60493	20233	sı	ti .				diam.
60494		17	12	5			diam.
60495		\$F	H .				diam.
60496		\$1	cı				diam.
60497		ρ	tt.	6	-, -		diam.
60498		tt	ŧı	6	1/4		diam.
60499		ţ1	67				diam.
126082		67	ti				diam.
50512E	20233	Ħ	Screw		-, -	•	

# TABLE BELT GUIDE

#### (INTERMEDIATE)

No.	Plate	Name	
126409	20233	Bracket with two 362C and three wood	
		screws 1 1/4 in. No. 12 R.H.B.	
60493	20233	Pulley (grooved) 5 in. diam.	
60870	20233	" Hub	
50512 <b>E</b>	20233	" Screw	
60765	20233	" Shaft with 60739,60740,61148 and	i
		two 60741	
60739		Pulley Shaft Oiling Wick	
60740		" " " Cover (leather	(٠)
60741		n n n n Plug	•
(leather)			
61148		Pulley Shaft Plug	
362C	20233	" Set Screw	
60814	20233	" Washer	

No.	Plate	Name
150064		Table Belt Guide (intermediate) complete
		for 60871, Nos. 60765, 60814, 60870,
		126409 and eight 50512E
60871	20233	Table Belt Guide (intermediate) 150064
		with two $60493$

Note: When ordering No. 60871, state size of pulleys required.

# **WRENCHES**

		**
No.	Plate	Name
69357	20234	Socket Wrench for 1633 and 1670
69359	20234	" " 51421 and 51422
876584	20235	" " 1633 and 51680
150421	20234	Spanner Wrench Body with 50563C and two
		150425
50563C	20234	Spanner Wrench Body Set Screw
150422	20234	" Extension (for use with
		hand brace)
150423	20234	Spanner Wrench Key
150425	20234	" " Pin
150424		Spanner Wrench complete, for 51428 and
		51429, Nos. 150421 to 150423
8908	20234	Wrench for 51626
25086	20234	"
69355	20234	" (offset) for 50823

# TOOLS FOR DISASSEMBLING AND ASSEMBLING SERIES S 59 AND S 69 ELECTRIC TRANSMITTERS

No.	Plate	Name
876648	20235	Mallet
876649	20235	Rotor Shaft Ball Bearing Assembling Tool for 876652
876650	20235	Rotor Shaft Ball Bearing Ejector (for frame and end cover)
876651	20235	Rotor Shaft Ball Bearing Retainer Ejector
876652	20235	Rotor Shaft Ball Bearing Retainer Injector for 876649
876653	20235	Rotor Shaft Ejector for 876654
876654	20235	" " Guide for 876653
876655	20235	Screw Driver
876656	20235	Transmitter Brake Setting Gauge
876657	20235	" Fly Wheel Wedge

No.	Plate	Name
876658	20235	Transmitter Shaft Ball Bearing (rear) Assembling Tool for 876663
876659	20235	Transmitter Shaft Ball Bearing Puller Frame with 876661
876660	20235	Transmitter Shaft Ball Bearing Puller Plate (for ball bearing) for 876659
876661	20235	Transmitter Shaft Ball Bearing Puller Screw Stud
876662	20235	Transmitter Shaft Ball Bearing Puller Screw Stud Extension for 876661
876663	20235	Transmitter Shaft Ball Bearing (rear) Retainer Injector for 876658
876664	20235	Transmitter Shaft Bushing Puller Plate (for bushing) for 876659
876665	20235	Transmitter Shaft Bushing and Brake Cam
876666	20235	Ball Bearing Ejector (front) Transmitter Shaft Fly Wheel Key Replacement Tool
876584 124162	20235 20235	Socket Wrench for 1633 and 51680 Wrench for 876653 and 876661

No.	Plate	Name
115R	20222	Transmitter Starting Lever Clamping Screw for 69425
199R	20218	Machine Driving Pulley Cover Screw
225R	20218	" " " Belt Guard
	20210	Screw
361C	20227	Pitman Rod Clamp Screw for 30223
362C	20227	" " (upper) Collar Set Screw for 2762
362C	20233	Speed Reducer Pulley Shaft Set Screw for 126409
362C	20233	Table Belt Guide Pulley Shaft Set Screw for 126409
362C	20222	Transmitter Starting Lever Extension Collar Set Screw for 2762
490R	20232	Universal Motor Bolt with 1600R, for 69398
515R	20233	Speed Reducer Belt Guard Thumb Screw for 126323
1062R	20231	Motor Screw for 69394
1517J	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting Lock Nut for use with 808944
1550J	20228	Switch Handle Spacer Screw Nut for 797305 and 797306
1600R	20232	Universal Motor Bolt Nut for 490R
1633R	20218	Armature Shaft Nut for Series S 38 and S 48 D.C. Motors
1633R	20218	Machine Driving Pulley Lock Hut
1633R	20218	" " Nut
1633R	20219	Rotor Shaft Nut for Series S 38 and S 48 A.C. Motors
1633R	20222	Transmitter Shaft Lock Nut for Series S 59 and S 69 Electric Transmitters
·1633R	20222	Transmitter Shaft Nut for 808820
1637C	20222	" Brake Adjusting Screw Lock Nut for 943978
1670R	20222	Transmitter Brake Screw Stud Nut for Series S 59 and S 69 Electric Trans- mitters
1778R	20232	Motor Bolt Nut for 51428R,51429R,51430R, 69340, 69341, 69349 and 69350
1778R	20232	Motor Bracket Bolt Nut for 51473R
1778E	20231	" " Clamping Plate Bolt Mut for 50734P

No. 1778R	Plate 20231	Name Motor Spacing Block Bolt Nut for 50621R
1778R	20232	Universal Motor Bracket Bolt Nut for 140146R
1784E	20218	Brush Holder Screw Nut for Series S 38 and S 48 D.C. Motors and Series S 59
		and S 69 D.C. Electric Transmitters
1785	20218	Terminal Screw Nut (brass) for Series S 38 and S 48 D.C. Motors and Series S 59 and S 69 D.C. Electric Trans- mitters
2718	20222	Transmitter Starting Lever Spring Arm Screw Washer for Series S 59 and S 69 Electric Transmitters
2718	20227	Treadle Extension Screw Washer for 126037
2762	20227	Pitman Rod (upper) Collar with 362C, for 69338
2762	20222	Transmitter Starting Lever Extension Collar with 362C, for 69427
2807	20231	Motor Spacing Block Bolt Nut Washer for 69406
8908	20234	Wrench for 51626
9842	20231	Motor Bolt Nut Washer for 69352
9842	20231	" Bracket Clamping Plate Bolt Nut Washer for 67876
9842	20231	Motor Screw Washer for 69394
22436	20218	Machine Driving Pulley Cover Belt Guard Screw Washer
23250	20227	Pitman Rod (upper) Spring Washer for 69338
23258	20227	Treadle Bracket (left) Hook Friction Washer for 126206
25086	20234	Wrench for 1670
27639	20227	Pitman Rod (lower) for 69338
46681		Treadle Bracket (right) for 60502
50494R	20225	Rotor Shaft Ball Bearing (commutator end) Grease Plug for S 593121 and S 593121-N Electric Transmitters
50511R	20228	Switch Screw for 797303 to 797308
50512E	20233	Speed Reducer Pulley Screw for 126344
50512E	20233	Table Belt Guide Pulley Screw for 150064
50563C	20234	Spanner Wrench Body Set Screw for 150421
50581R	20227	Treadle Extension Screw for 126037
50621R	20231	Motor Spacing Block Bolt with 1778R for 69406
50636R	20218	Hand Hole Cover Screw for Series S 38 and S 48 Motors and S 593121 and S 593121-N Electric Transmitters
50644R		Brush Screw for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N, and Series S 48 Single Phase, A.C.
m the li	brary of	: Superior Stand Transly Inc.

No.	Plate	Name
50647R	20221	Hand Hole Cover Screw for Series S 59 and S 69 D.C. Electric Transmitters
50647R	20218	Terminal Screw for Series S 38 and S 48 D.C. Motors and Series S 59 and S 69 D.C. Electric Transmitters
50658R	20218	Brush Holder Screw for Series S 38 and S 48 D.C. Motors and Series S 59 and S 69 D.C. Electric Transmitters
50669R	20225	End Cover (commutator end) Screw for S 593121 and S 593121-N Electric Transmitters
50671R	20228	Capacitor Box Cover Screw for 797303 and 797304
50671 <b>J</b>	20228	Capacitor Box Ground Wire Screw for 797303 and 797304
50671R	20229	Lead Cord Terminal Screw for 744711
50671R	20228	Switch Box Cover Screw for 797305 to 797308
50671 <b>J</b>	20228	Switch Box Ground Wire Screw for 797305 to 797308
50671R	20218	Terminal Box Cover Screw
50734P	20231	Motor Bracket Clamping Plate Bolt with 1778E, for 67876
50771	20229	Cord Insulating Bushing Clamping Screw for 898780
50771	20229	Lead Cord Insulating Bushing Clamping Screw for 898780
50782R		End Cover Air Baffle Screw for 799746
50823R	20222	Transmitter Starting Lever Spring Arm Screw for Series S 59 and S 69 Elec- tric Transmitters
50826R	20225	Rocker Ring Set Screw for S 593121 and S 593121-N Electric Transmitters
50894R	20232	Motor Bolt for 69340, 69341, 69349 and 69350
51330R	20225	Brush Screw for S 593121 and S 593121-N Electric Transmitters
51382R	20222	Transmitter Fly Wheel Guard Bracket Screw for rear guard for Series S 59 and S 69 Electric Transmitters
5139 <b>3J</b>	20228	Switch Handle Spacer Screw for 797305 and 797306

		·~
No.	Plate	Name
51 <b>3</b> 97R		End Cover Bolt for S 592248, S 592341,
		S 592341-N, S 592348, S 593241,
		S 593241-N, S 593247, S 593247-N,
		S 593248, S 593251, S 593251-N,
		S 593257, S 593257-N, S 593258,
		S 593261, S 593261-N, S 593267,
		S 593267-N, S 593268, S 59326Y-N,
		S 593341, S 593341-N, S 593345,
		S 593345-N, S 593347, S 593347-N,
		S 593348, S 593351, S 593351-N,
		S 593352, S 593352-N, S 593353,
		S 593353-N, S 593356, S 593356-N,
		S 593357, S 593357-N, S 593358,
		S 593358-N, S 59335X-N, S 59335Y-N,
		S 593361, S 593361-N, S 593366,
		S 593366-N, S 593367, S 593367-N,
		S 593368 and S 59336Y-N Electric
		Transmitters
51398R	20223	End Cover Bolt for Series S 59 Single
		Phase A.C. Capacitor Type, Series
		S 69 D.C. (except S 692001-N,
		S 692007-N) S 59235Y-N, S 592367,
		S 692151, S 692151-N, S 692157,
		S 692157-N, S 692158, S 692158-N,
		S 692161, S 692161-N, S 692162,
		S 692162-N, S 692167, S 692167-N,
		S 692168 and S 692168-N Electric
·		Transmitters
	20222	Transmitter Shaft Bushing and Brake Cam Screw (long) for 808816 and 809529
- 51422R	20222	Transmitter Shaft Bushing and Brake Cam Screw (short) for 808816 and 809529
51423R	20218	Machine Driving Pulley Cover Hinge Screw
		for Series S 38 and S 48 Motors
51424R		End Cover Bolt for S 593221, S 593221-N,
		S 593227, S 593227-N S 593228,
		S 593321, S 593321-N, S 593326,
-		S 593327, S 593327-N and S 593328
		Electric Transmitters
51428R	20232	Motor Bolt (long) with 1778R, for 69353
51429R	20232	" (short) with 1778R, for 69354
51430R	20231	" with 1778R, for 69352
51461R	20231	" Bracket (auxiliary) Screw for 69394
51473R	20232	Motor Bracket Bolt with 1778R, for 69402
51488R	20221	End Cover Bolt for Series S 59 D. C., S 692001-N and S 692007-N Electric
		Transmitters
51522R	20229	Lead Cord Terminal Screw Nut for 744711

No.	Plate	Name
51626R	20221	End Cover Bolt Nut for Series S 59 and
		S 69 Electric Transmitters except
		S 593121 and S 593121-N
51626R	20218	End Cover Stud Nut for Series S 38 and
		S 48 Motors
51680R	20221	Armature Shaft Nut for Series S 59 and
		S 69 D.C. Electric Transmitters
51680R	20223	Rotor Shaft Nut for Series S 59 and S 69
		A.C. Electric Transmitters
60084	20233	Speed Reducer Belt Guard Rivet for
		126323

Nos. 60483 to 60499 for Speed Reducer No. 126344 and Table Belt Guide No. 150064

60483		Pulley (grooved) 2 1/2 in. diam.
60484		" 23/4 in. diam.
60485		" 3 in. diam.
60486		" " 3 1/4 in. diam.
60487		" 3 1/2 in. diam.
60488		" 3 3/4 in. diam.
60489		" " 4 in. diam.
60490		" 4 1/4 in. diam.
60491		" 4 1/2 in. diam.
60492		" 43/4 in. diam.
60493	20233	# 5 in. diam.
60494		" 5 1/4 in. diam.
60495		" 5 1/2 in. diam.
60496		" 5 3/4 in. diam.
60497		" " 6 in. diam.
60498		" 6 1/4 in. diam.
60499		" 6 1/2 in. diam.
60502	20227	Treadle Bracket (right) 46681 with two
		wood screws 1 in. No. 14 for 126211
60739		Speed Reducer Pulley Shaft Oiling Wick
		for 126325
60739		Table Belt Guide Pulley Shaft Oiling
		Wick for 60765
60740		Speed Reducer Pulley Shaft Oiling Wick
		Cover (leather) for 126325
60740		Table Belt Guide Pulley Shaft Oiling
		Wick Cover (leather) for 60765
60741		Speed Reducer Pulley Shaft Oiling Wick
		Cover Plug (leather) for 126325
60741		Table Belt Guide Pulley Shaft Oiling
		Wick Cover Plug (leather) for 60765
60765	20233	Table Belt Guide Pulley Shaft with
		60739,60740,61148 and two 60741, for
		150064
60814	20233	Speed Reducer Pulley Washer for 126344

No.	Plate	Name
60814	20233	Table Belt Guide Pulley Washer for 150064
60870	20233	Speed Reducer Pulley Hub for 126344
60870	20233	Table Belt Guide Pulley Hub for 150064
60871	20233	" " (intermediate) 150064
		with two 60493
61148		Speed Reducer Pulley Shaft Plug for 126325
61148		Table Belt Guide Pulley Shaft Plug for 60765
67218	20228	Capacitor Box Ground Wire Screw Washer for 797303 and 797304
67218	20228	Switch Box Ground Wire Screw Washer for 797305 to 797308
67255	20221	Armature Shaft Nut Cotter Pin for Series S 59 and S 69 D.C. Electric Trans- mitters
67255	20223	Rotor Shaft Nut Cotter Pin for Series S 59 and S 69 A.C. Electric Trans- mitters
67327	20218	Machine Driving Pulley Cover Belt Guard
67357	20221	Transmitter Fly Wheel Key for Series
		S 59 and S 69 Electric Transmitters
67481	20221	Hand Hole Cover for Series S 59 and S 69 D.C. Electric Transmitters
67630	20230	Wire Connection complete for stand, from motor to switch, single phase, A.C. Motors, 110 and 220 volts and D.C. Motors, 115 and 230 volts, Nos. 744760, 744761, 744765 and two each 190566, 744762 and wood screws 3/4 in. No. 9 R.H.
67631	20230	Wire Connection complete for stand, from motor to switch, two phase, A.C. Motors, 110 and 220 volts, Nos. 744760, 744761, 744764 and two each 190566, 744763 and wood screws 3/4 in. No. 9 R.H.
67632	20230	Wire Connection complete for stand, from motor to switch, three phase, A.C.
		motor to switch, three phase, A.C. Motors, 110, 220 and 440 volts, Nos.
		744760, 744761, 744766 and two each
		190566, 744762 and wood screws 3/4 in. No. 9 R.H.
67702		Adapter Lead Terminal for 744718
67702		Lead Cord Terminal for 744711
67702	20218	Terminal for Series S 38 and S 48 D.C.
0.700		Motors and Series S 59 and S 69 D.C. Electric Transmitters
67875	20231	Motor Bracket Clamping Plate for 69352

	No.	Plate	Name
	67876		Motor Bracket Clamping Plate Bolt complete for 69352, Nos. 9842, 50734P
			and 126150
	67930	20229	Cord and Plug 660 watt complete for
			stand, for one or two phase motors, Nos. 67931, 67934 and 898780
	67931	20229	Cord Screw Plug 660 watt complete for 67930, Nos. 67932 and 67933
	67932	20229	Cord Screw Plug for 67931
	67933	20229	" " Cap for 67931
	67934		" (two strand) 8 ft. long for 67930
	69246	20222	Transmitter Brake Screw Stud for Series
			S 59 and S 69 Electric Transmitters
1	69255	20222	Transmitter Friction Pulley Friction
			Disc Retaining Ring for 808819 and 808887
	69256	20222	Transmitter Friction Pulley Friction
			Disc Stud for 808819 and 808887
	69258	20218	Machine Driving Pulley Cover
	69259	20218	" " " Bracket
	69261	20218	" " " Screw Wash-
	69262	20222	Machine Driving Pulley Cover Spring for
			Series S 59 and S 69 Electric Trans- mitters
	69268	20222	Transmitter Shaft Ball Bearing Spacing
			Collar for 808820
	69269	20222	Transmitter Shaft Bushing and Brake Cam for 808820
*	69270		Transmitter Shaft Bushing and Brake Cam Cap for 808816 and 809529
	69271		Transmitter Shaft Bushing and Brake Cam
	00011		Cap Position Pin for 808816 and 809529
	69274	20222	Transmitter Starting Lever Spring for
	00271		Series S 59 and S 69 Electric Trans- mitters
	69275	20222	Transmitter Starting Lever Spring Arm
			for Series S 59 and S 69 Electric
			Transmitters
	69277		Machine Driving Pulley (flanged) 1 1/4
			in. face, 1 1/4 in. diam.
	69278		Machine Driving Pulley (flanged) 1 1/4 in. face, 1 1/2 in. diam.
	69279		Machine Driving Pulley (flanged) 1 1/4
			in. face, 1 3/4 in. diam.
	69280		Machine Driving Pulley (flanged) 1 1/4
			in. face, 2 in. diam.
	69281		Machine Driving Pulley (flanged) 1 1/4
	N. Control of the Con		in. face, 2 1/4 in. diam.

No.	Plate	Name
69282	riace	Machine Driving Pulley (flanged) 1 1/4
ಎಂಎಕರ		in. face, 2 1/2 in. diam.
60007		Machine Driving Pulley (flanged) 1 1/4
69283		in. face, 2 3/4 in. diam.
00004		
69284		Machine Driving Pulley (flanged) 1 1/4
00000		in. face, 3 in. diam.
69285		Machine Driving Pulley (flanged) 1 1/4
00000		in. face, 3 1/4 in. diam.
69286		Machine Driving Pulley (flanged) 1 1/4
00000		in. face, 3 1/2 in. diam.
69287		Machine Driving Pulley (flanged) 1 1/4
****		in. face, 3 3/4 in. diam.
69288		Machine Driving Pulley (flanged) 1 1/4
00000		in. face, 4 in. diam.
69289		Machine Driving Pulley (flanged) 1 1/4
		in. face, 4 1/4 in. diam.
69290		Machine Driving Pulley (flanged) 1 1/4
		in. face, 4 1/2 indiam.
69291		Machine Driving Pulley (flanged) 1 1/4
		in. face, 4 3/4 in. diam.
69292		Machine Driving Pulley (flanged) 1 1/4
		in. face, 5 in. diam.
69293		Machine Driving Pulley (flanged) 1 1/4
		in. face, 5 1/4 in. diam.
69294		Machine Driving Pulley (flanged) 1 1/4
		in. face, 5 1/2 in. diam.
69295		Machine Driving Pulley (flanged) 1 1/4
		in. face, 5 3/4 in. diam.
69296		Machine Driving Pulley (flanged) 1 1/4
00000		in. face, 6 in. diam.
69297		Machine Driving Pulley (double grooved)
		1 1/4 in. diam.
69298		Machine Driving Pulley (double grooved)
		1 1/2 in. diam.
69299		Machine Driving Pulley (double grooved)
00500		1 3/4 in. diam.
69300		Machine Driving Pulley (double grooved)
00503		2 in. diam.
69301		Machine Driving Pulley (double grooved)
00700		2 1/4 in. diam.
69302		Machine Driving Pulley (double grooved)
00505		2 1/2 in. diam.
69303		Machine Driving Pulley (double grooved)
00704		2 3/4 in. diam.
69304		Machine Driving Pulley (double grooved)
60205		3 in. diam.
69305		Machine Driving Pulley (double grooved)
C070C		3 1/4 in. diam.
69306		Machine Driving Pulley (double grooved)
		3 1/5 in. diam.

No.	Plate	Name		
69307		Machine Driving Pulley	(double	grooved)
		3 3/4 in. diam.		
69308		Machine Driving Pulley	(double	grooved)
		4 in. diam.		
69309		Machine Driving Pulley	(double	grooved)
		4 1/4 in. diam.	_	
69310		Machine Driving Pulley	(double	grooved)
		4 1/2 in. diam.		
69311		Machine Driving Pulley	(double	grooved)
00000		4 3/4 in. diam.		
69312		Machine Driving Pulley	(double	grooved)
CO217		5 in. diam.	1	
69313		Machine Driving Pulley	(donote	grooved)
69314		5 1/4 in. diam.	/daub1a	
09014		Machine Driving Pulley 5 1/2 in. diam.	(donote	grooved)
69315		Machine Driving Pulley	(double	( bostoorm
00010		5 3/4 in. diam.	(donote	grooved)
69316		Machine Driving Pulley	(double	grooved)
417		6 in. diam.	(404010	61001047
69317	.95	Machine Driving Pulley	(single	grooved)
		1 1/4 in. diam.	,	g=,
69318	. 24	Machine Driving Pulley	(single	grooved)
	2	1 1/2 in. diam.		•
69319	.95.	Machine Driving Pulley	(single	grooved)
		1 3/4 in. diam.		•
69320	.96	Machine Driving Pulley	(single	grooved)
	95	2 in. diam.		
69321	.49.	Machine Driving Pulley	(single	grooved)
	20222	2 1/4 in. diam.		. •
69322	20222	Machine Driving Pulley	(single	grooved)
00000		2 1/2 in. diam.	,	
69323		Machine Driving Pulley	(single	grooved)
69324		2 3/4 in. diam.	(-41-	
03024		Machine Driving Pulley 3 in. diam.	(STURTS	RIJOONED)
69325		Machine Driving Pulley	(single	( herrorra
00020		3 1/4 in. diam.	(DINETO	grooved,
69326		Machine Driving Pulley	(single	grooved)
		3 1/2 in. diam.	,	0,
69327		Machine Driving Pulley	(single	grooved)
		3 3/4 in. diam.		
69328		Machine Driving Pulley	(single	grooved)
		4 in. diam.		
69329		Machine Driving Pulley	(single	grooved)
•		4 1/4 in. diam.		
69330		Machine Driving Pulley	(single	grooved)
		4 1/2 in. diam.		
69331		Machine Driving Pulley	(single	grooved)
		4 3/4 in. diam.		

No.	Plate	Name
69332		Machine Driving Pulley (single grooved) 5 in. diam.
69333		Machine Driving Pulley (single grooved) 5 1/4 in. diam.
69334	20218	Machine Driving Pulley (single grooved) 5 1/2 in. diam.
69335		Machine Driving Pulley (single grooved) 5 3/4 in. diam.
69336		Machine Driving Pulley (single grooved) 6 in. diam.
69337	20227	Pitman Rod (upper) for 69338
69338	20227	Pitman Rod complete for Series S 59 and S 69 Electric Transmitters, Nos. 23250, 27639, 69337, 80223, 150208 and two 2762
69339	20232	Motor Bracket for 69340 and 69341
69340	20232	Motor Bracket (right hand) complete for Trough Tables, for Series S 59 and S 69 Electric Transmitters, Nos. 1778R,50894R,69339,69402 and 126150
69341	20232	Motor Bracket (left hand) complete for Trough Tables, for Series S 59 and S 69 Electric Transmitters, Nos. 69339, 69402 and two each 1778R, 50894R and 126150
69344	20218	Machine Driving Pulley Cover Hinge Stud for 808816 and 809529
69345	20222	Transmitter Shaft Bushing and Brake Cam Screw (long) Spacing Collar for 808816 and 809529
69346	20218	Machine Driving Pulley Cover Spring for Series S 38 and S 48 Motors
69348	20232	Motor Bracket for 69349 and 69350
69349	20232	Motor Bracket (left hand) complete for deep Trough Tables, for Series S 59 and S 69 Electric Transmitters, Nos. 1778R,50894R,69348,69354 and 126150
69350	20232	Motor Bracket (right hand) complete for deep Trough Tables, for Series S 59 and S 69 Electric Transmitters, Nos. 69348, 69354 and two each 1778R, 50894R and 126150
69351	20231	Motor Bracket for 69352
69352	20231	Motor Bracket complete for Trough Tables, when fastened to Trough, for Ma- chines run head-on, for Series S 38 and S 48 Motors, Nos. 69351, two 67875, four each 9842, 51430R and six 67876

No.	Plate	Name
69353	20232	Motor Bolt (long) complete for attaching
03000	20202	Motor and Electric Transmitter to
		table, Nos. 51428R and 126150
69354	20232	Motor Bolt (short) complete for 69349
0900#	LULUL	and 69350 for attaching Motor and
		Electric Transmitter to table, Nos.
		51429R and 126150
69355	20234	Wrench (offset) for 50823
69357	20234	Socket Wrench for 1633 and 1670
69359	20234	" 51421 and 51422
69393	20231	Motor Bracket (auxiliary) for 69394
69394	20231	Motor Bracket (auxiliary) complete for
		Nos. 146-30 and 146-31 Machines, for
		Series S 38 and S 48 Motors, Nos.
		69393 and four each 1062R, 9842 and
		51461R
69397	20232	Universal Motor Bracket for 69398
69398	20232	Universal Motor Bracket complete for
		Series S 59 and S 69 Electric Trans-
		mitters, Nos. 69397, three each
		126150, 140146R and four each 490R,
00400		69404 and 126079
69402		Motor Bracket Bolt complete for 69340
60404	00070	and 69341, Nos. 51473R and 126150
69404	20232	Universal Motor Bolt Spacing Collar for 69398
69405	20231	Motor Spacing Block for 69406
69406	20231	Motor Spacing Block complete for Series
		S 38 and S 48 Motors for Class 99w
		Machines, for Stand No. 25297, Nos.
		69405 and two each 2807, 50621R and
00477		126150
69411		Machine Driving Pulley (flanged) 3 in. face, 2 in. diam.
69413	20222	Transmitter Fly Wheel Guard (front) with
		Bracket for Series S 59 and S 69
		Electric Transmitters
69415	20222	Transmitter Fly Wheel Guard (back) with
		Bracket for Series S 59 and S 69
		Electric Transmitters
69426	20222	Transmitter Starting Lever with 115R, for
		69427
69427		Transmitter Starting Lever 69426 with
00400	00000	2762 and 69428, for 808820
69428	20222	Transmitter Starting Lever Extension for 69427
80223	20227	Pitman Rod Clamp with 361C, for 69338
121587	20227	Grease Gun (3 oz. capacity) for Fittings
		Nos. 808943 and 808944
121588	20227	Grease Gun (1/2 lb. capacity) for Fit-
		tings Nos. 808943 and 808944

No.	Plate	Name
124162	20235	Wrench for 876653 and 876661
126036	20227	Treadle for 126037
126037		" 126036 with 2718, 50581R and 126038, for 126211
126038	20227	Treadle Extension for 126037
126079	20232	Universal Motor Bolt Nut Lock Washer for 69398
126082		Pulley (grooved) 7 1/2 in. diam. for 126344 and 150064
126150	20232	Motor Bolt Nut Lock Washer for 69340, 69341,69349,69350,69353 and 69354
126150	20232	Motor Bracket Bolt Nut Lock Washer for 69402
126150	20231	Motor Bracket Clamping Plate Bolt Nut Lock Washer for 67876
126150	20231	Motor Spacing Block Bolt Nut Lock Washer for 69406
126150	20232	Universal Motor Bracket Bolt Nut Lock Washer for 69398
126205	20227	Treadle Bracket (left) for 126206
126206		Treadle Bracket (left) complete for 126211, Nos. 23258, 126205, 126207, 126208 and two wood screws 1 in. No. 14
126207	20227	Treadle Bracket (left) Hook for 126206
126208	20227	Treadle Bracket (left) Hook Rivet for 126206
126211	20227	Treadle complete for Series S 59 and S 69 Electric Transmitters, Nos. 60502, 126037 and 126206
126322	20233	Speed Reducer Belt Guard for 126323
126323		" " 126322 with 515R, 126324 and four 60084, for 126344
126324	20233	Speed Reducer Belt Guard Hub for 126323
126325	20233	" Pulley Shaft 126929 with
20000		60739,60740,61148 and two 60741, for 126344
126344	20233	Speed Reducer complete, Nos.60814,60870, 126323,126325,126409, two 60493 and eight 50512E
126409	20233	Speed Reducer Bracket with two 362C and three wood screws 1 1/4 in. No. 12 R.H.B. for 126344
126409	20233	Table Belt Guide Bracket with two 3620 and three wood screws 1 1/4 in. No. 12 R.H.B. for 150064
*126929		Speed Reducer Pulley Shaft for 126325
140122	20218	Brush Holder Cap Screw (brass) for

799977

No.	Plate	Name
140124R		End Cover Bolt for S 693150 to S 693152, S 693156 to S 693158, S 693161, S 693162, S 693165 to S 693168 and
		Series S 69 Poly Phase, A.C. Electric Transmitters
140146R	20232	Universal Motor Bracket Bolt with 1778R, for 69398
140228C	20222	Transmitter Brake Adjusting Screw for 943978
140246R	20225	Transmitter Frame and End Cover Screw for S 593121 and S 593121-N Electric Transmitters
150064		Table Belt Guide (intermediate) complete for 60871, Nos. 60765, 60814, 60870, 126409 and eight 50512E
150208	20227	Pitman Rod (upper) Spring for 69338
150421	20234	Spanner Wrench Body with 50563C and two 150425, for 150424
150422	20234	Spanner Wrench Extension (for use with hand brace) for 150424
150423	20234	Spanner Wrench Key for 150424
150424		Spanner Wrench complete for 51428 and 51429, Nos. 150421 to 150423
150425	20234	Spanner Wrench Pin for 150421
190328	20219	Lead Bushing (rubber) for motor leads, for all A.C. Motors and Electric
100500	00070	Transmitters
190566	20230	Wire Conduit Strap for 67630 to 67632
191406	20229	Cord complete for three phase motors, Nos. 191407 and 898780
191407		Cord (three strand) 8 ft. 3 in. long for 191406
192541	20229	Adapter Screw Base for 744748
193642	20227	Tube (filled with 4 ozs. of Singer Ball Bearing Lubricant) packed in Carton
700170	20225	Rocker Ring Indicator Rivet for S 593121 and S 593121-N Electric Transmitters
700871		Name Plate Rivet for Series S 59 and S 69 Electric Transmitters except S 593121 and S 593121-N
701350	20218	Armature Shaft Nut Lock Washer for Series S 38 and S 48 D.C. Motors
701350	20218	Machine Driving Pulley Lock Nut Lock Washer
701350	20219	Rotor Shaft Nut Lock Washer for Series S 38 and S 48 A.C. Motors
701350	20222	Transmitter Shaft Nut Lock Washer for Series S 59 and S 69 Electric Trans- mitters

124	
-----	--

No.	Plate	Name
701679	20221	End Cover Bolt Nut Lock Washer for
		Series S 59 and S 69 Electric Trans-
		mitters except S 593121 and S 593121-N
701679	20218	End Cover Stud Nut Lock Washer for Series S 38 and S 48 Motors
701799	20225	End Cover (commutator end) Screw Lock
701799	20220	Washer for 8 593121 and 8 593121-N
		Electric Transmitters
701799	20225	Transmitter Frame and End Cover Screw
		Lock Washer for S 593121 and
707.007		S 593121-N Electric Transmitters Armature Shaft Ball Bearing (pulley end)
701963		Spacing Washer for Series S 48 D.C.
		Motors except S 482001-N and
		S 482007-N
701963	20219	Rotor Shaft Ball Bearing (pulley end)
		Spacing Washer for Series S 38 and
		S 48 A.C. Motors
701971	20218	Armature Shaft Ball Bearing (commutator end) Spacing Washer for Series S 38
		and S 48 D.C. Motors
701971	20219	Rotor Shaft Ball Bearing (commutator
		end) Spacing Washer for Series S 38
		Single Phase, A.C. Repulsion Type
		Motors, except S 383141, S 383141-N,
BO1 0B1	20220	S 383142, S 383142-N, S 383143-N Rotor Shaft Ball Bearing (terminal box
701971	20220	end) Spacing Washer for Series S 38
		and S 48 Poly Phase, A.C. Motors
727511	20219	Lead Bushing (rubber) for lighting unit
		leads for all A.C. Motors and Elec-
		tric Transmitters
744711	20229	Lead Cord 8 ft. long with ground connec- tion complete for one or two phase
		motors, Nos. 50671R, 51522R, 67702,
		744713 and 898780
744713	20229	Lead Cord Three Pin Plug for 744711
744716	20229	Wire Adapter (tandem blade type) with
		ground connection complete, Nos.
744717	20229	744717 and 744718 Adapter for 744716
744718	20229	Adapter Lead with 67702, for 744716 and
,		744748
744748	20229	Wire Adapter (parallel blade type) with
		ground connection complete, Nos.
744740	20220	192541, 744718 and 744749 Adapter for 744748
744749 744760	20229 20230	Wire Conduit Connector for 67630 to
122100	20000	67632

		•
.ن.	Plate	Name
±4761	20230	Wire Conduit Connector 90 degrees for 67630 to 67632
744762		Wire Conduit Connector Insulating Bush- ing for 67630 and 67632
744763		Wire Conduit Connector Insulating Bushing for 67631
744764	20230	Wire, 45 in. long (four strand B.X. Cable) for 67631
744765	20230	Wire, 45 in. long (two strand B.X.Cable) for 67630
744766	20230	Wire, 45 in. long (three strand B.X. Cable) for 67632
745839	20225	Rocker Ring Indicator for 797774
747148	20221	Armature Shaft Bushing Cap for Series S 59 and S 69 D.C. Electric Trans- mitters
747148	20223	Rotor Shaft Bushing Cap for Series S 59 and S 69 A.C. Electric Transmitters except S 593121 and S 593121-N
791283	20219	Short Circuiter Retaining Ring for Series S 38 Single Phase, A.C. Re- pulsion Type Motors except S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N
792595	20225	Brush Spring for S 593121 and S 593121-N Electric Transmitters
796037	20225	Rocker Ring Brush Box for 797774
796111	20223	End Cover (terminal box end) for 796733
796138	20219	End Cover (pulley end) for Series S 38 Single Phase A.C. Repulsion Type (except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N) and Series S 38 and S 48 Poly Phase A.C. Motors
796188		Rocker Ring for 796217
796189	20219	Brush Spring for 796217 and 798004
796190		Rocker Ring Locating Spring for Series S 38 Single Phase, A.C. Repulsion Type Motors except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N
796211	20219	Short Circuiter for Series S 38 Single Phase, A.C. Repulsion Type Motors except S 383141,S 383141-N,S 383142, S 383142-N and S 383143-N
796212	20219	Brush (double) with lead for Series S 38 Single Phase, A. C. Repulsion Type Motors except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N
796216	20218	Hand Hole Cover for Series S 38 and S 48 Motors

No.	Plate	Name
796217	20219	Rocker Ring 796188 with four 796189 for Series S 38 Single Phase, A.C. Re- pulsion Type Motors except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N
796290		Armature Shaft Dust Cap for Series S 38 and S 48 D.C. Motors
796290		Rotor Shaft Dust Cap (commutator end) for Series S 38 and S 48 Single Phase, A.C. Repulsion Type Motors
796290		Rotor Shaft Dust Cap (terminal box end) for Series S 38 and S 48 Poly Phase, A.C. Motors
796295	20228	Capacitor Lead Insulating Nipple for 798666
796344		Commutator complete for Series S 38 Single Phase A.C. Repulsion Type Motors except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N
*796446		Armature Shaft Bushing for 798381
*796446		Rotor Shaft Bushing for 796733
796733		End Cover 796111 with 796446 for Series S 59 and S 69 A.C. Electric Trans- mitters except S 593121 and S 593121-N, for 799746
796776	20225	Brush Spring Stud for S 593121 and S 593121-N Electric Transmitters
796865	20218	Terminal Box Cover (for Motors and Elec- tric Transmitters without tap for light)
797097	20221	Oil Well Cap for Series S 59 and S 69 Electric Transmitters except S 593121 and S 593121-N
797171		Stator for S 593367-N Electric Trans- mitter
797173		Stator for S 593357-N Electric Trans- mitter
797177		Stator for S 692366-N and S 692367-N Electric Transmitter
797182		Stator for S 593267-N Electric Trans- mitter
797184		Stator for S 692267-N Electric Trans- mitter
797189		Stator for S 593161-N Electric Trans- mitter
797192		Stator for S 593162-N Electric Trans- mitter
797195		Stator for S 593151-N Electric Trans- mitter
797198		Stator for S 692162-N Electric Trans-

No.	Plate	Name
797303	20228	Capacitor, Capacitor Box and Switch com-
		plete for Series S 59 and S 69 Elec-
		tric Transmitters for 1/3 H.P., Nos.
		50671J,50671R,67218,797336,797353,
		798665,798666,898996,898999,899523,
		two each 50511R, 797352, 964419 and
	•	four wood screws 3/4 in. No. 12 R.H.
797304		Capacitor, Capacitor Box and Switch com-
		plete for Series S 59 and S 69 Elec-
		tric Transmitters for 1/2 H.P., Nos.
		50671J,50671R,67218,797337,797353,
		798665,798666,898996,898999,899522,
		two each 50511R, 797352, 964419 and
		four wood screws 3/4 in. No. 12 R.H.
797305	20228	Switch Box with Switch complete for 1/3
,,,,,,,	~~~~	H.P. for ratings under 270 volts,
		Nos. 1550J, 50671J, 51393J, 67218,
		876002,876004,876021,899524,931033,
		two each 50671R,797334,964419, wood
		screws 3/4 in. No. 12 R.H. and four
		50511R
797306		Switch Box with Switch complete for 1/2
		H.P. for ratings under 270 volts,
		Nos. 1550J, 50671J, 51393J, 67218,
		876002,876004,876021,899522,931033,
		two each 50671R,797335,964419, wood
		screws 3/4 in. No. 12 R.H. and four
		50511R
797307		Switch Box with Switch complete for 1/3
		H.P., Nos. 50671J, 67218, 797336,
		876004, 876013, 899789, two each
		50511R,50671R,964419 and wood screws
		3/4 in. No. 12 R.H.
797308		Switch Box with Switch complete for 1/2
		H.P., Nos. 50671J, 67218, 797337,
		876004, 876013, 899522, two each
		50511R,50671R,964419 and wood screws
		3/4 in. No. 12 R.H.
797320		Stator for S 692151-N Electric Trans-
		mitters
797334	20228	Switch for 797305
797335		" " 797306
797336	20228	" 797303 and 797307
797337		" " 797304 and 797308
797351	20228	Capacitor Lead with Terminal Clip for
		798666
797352		Capacitor Box Packing (side) for 797303
		and 797304
797353		Capacitor Box Packing (bottom) for
		797303 and 797304

From the library of: Superior Sewing Machine & Supply LLC

40

٦	20
ı	.20

No. 797389	Plate	Name
797369	20219	Rotor complete for Series S 38 Single Phase, A.C. Repulsion Type Motors except S 383141, S 383141-N,S 383142, S 383142-N and S 383143-N
797396		Stator for S 593361-N Electric Trans- mitter
797398		Stator for S 59335Y-N and S 59336Y-N Electric Transmitters
797400		Stator for S 593351-N Electric Trans- mitters
797402		Stator for S 593356-N and S 593366-N Electric Transmitters
797421	20218	Armature Shaft Ball Bearing (commutator end) for Series S 38 and S 48 D.C. Motors
797421	20219	Rotor Shaft Ball Bearing (commutator end) for Series S 38 and S 48 Single Phase A.C. Motors and S 593121 and S 593121-N Electric Transmitters
797421	20220	Rotor Shaft Ball Bearing (terminal box end) for Series S 38 and S 48 Poly Phase A.C. Motors
797421	20222	Transmitter Shaft Ball Bearing for 808820
797422	20218	Armature Shaft Ball Bearing (pulley end) for Series S 38 and S 48 D.C. Motors
797422	20219	Rotor Shaft Ball Bearing (pulley end) for Series S 38 and S 48 A.C. Motors
797456		Stator for S 593167-N Electric Trans- mitter
797459		Stator for S 593327-N Electric Trans- mitter
797468		Stator for S 593157-N Electric Trans- mitter
797471		Stator for S 593158-N Electric Trans- mitter
797474		Stator for S 593156-N Electric Trans- mitter Stator for S 593152-N Electric Trans-
797480 797483		mitter Stator for S 692161-N Electric Trans-
797486		mitter Stator for S 692157-N Electric Trans-
797489		mitter Stator for S 593141-N Electric Trans-
797609		mitter Stator for S 692361-N Electric Trans-
131003		mitter

No.	Plate	Name
797686		Stator Shield for S 593221, S 593221-N,
		S 593227, S 593227-N S 593228, S 593321, S 593321-N, S 593326,
		S 593327, S 593327-N and S 593328
		Electric Transmitter
797689	20223	Stator Shield for Series S 59 Single
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		Phase, A.C. Capacitor Type and
		S 59235Y-N, S 592367, S 692151,
		S 692151-N, S 692157, S 692157-N,
		S 692158, S 692158-N, S 692161,
		S 692161-N, S 692162, S 692162-N,
		S 692167, S 692167-N, S 692168 and
		S 692168-N Electric Transmitters
797691		Stator Shield for S 592248, S 592341,
		S 592341-N, S 592348, S 593241,
		S 593241-N, S 593247, S 593247-N,
		S 593248, S 593251, S 593251-N,
		S 593257, S 593257-N, S 593258,
		S 593261, S 593261-N, S 593267,
		S 593267-N, S 593268, S 59326Y-N,
		S 593341, S 593341-N, S 593345,
		S 593345-N, S 593347, S 593347-N,
		S 593348, S 593351, S 593351-N,
		8 593352, 8 593352-N, 8 593353,
		S 593353-N, S 593356, S 593356-N,
		S 593357, S 593357-N, S 593358,
		S 593358-N, S 59335X-N, S 59335Y-N,
		S 593361, S 593361-N, S 593366, S 593366-N, S 593367, S 593367-N,
		S 593368, S 59336Y-N, S 692258,
		S 692267, S 692267-N, S 692268,
		S 69226Y-N, S 692357-N,
		S 692358, S 69235X-N, S 69235Y-N,
		S 692361, S 692361-N, S 692366,
		S 692366-N, S 692367, S 692367-N,
		S 692368 and S 69236Y-N Electric
		Transmitters
797700		Stator for S 69236Y-N Electric Trans-
		mitter
797707		Stator Wound with Housing for S 383150-N and S 383161-N Motors
797711		Switch Box with Switch (three pole) com-
701711		plete with two wood screws 3/4 in.
		No. 12 R.H. for 1/3 and 1/2 H.P. for
		ratings above 270 volts
797754		Commutator complete for S 383141,
•		S 383141-N, S 383142, S 383142-N,
		S 383143-N and Series S 48 Single
		Phase, A.C. Repulsion Type Motors
797760		Stator for S 59326Y-N Electric Trans-
		mitter

No.	Plate	Name
797771		Short Circuiter for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Re-
797772		pulsion Type Motors  Short Circuiter Retaining Ring for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase A.C. Repulsion Type Motors and S 593121 and S 593121-N Electric Transmitters
797773		Rocker Ring complete for 797774
797774		Rocker Ring 797773 with 745839 and two 796037, for S 593121 and S 593121-N Electric Transmitters
797775	20225	Rocker Ring Disc for S 593121 and S 593121-N Electric Transmitters
797778	20225	Hand Hole Cover for S 593121 and S 593121-N Electric Transmitters
797821	20221	End Cover (terminal box end) for 798381
797868	20219	" (commutator end) for Series S 38 Single Phase, A.C. Repulsion
		Type Motors except S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N
797868	20220	End Cover (terminal box end) for Series S 38 and S 48 Poly Phase, A.C.
797887		Housing for Series S 48 D.C. Motors except S 482001-N and S 482007-N
797900	20225	Housing for S 593121 and S 593121-N Electric Transmitters
797901	20225	End Cover (commutator end) for S 593121 and S 593121-N Electric Transmitters
797981		Stator Wound with Housing for S 38335Y-N and S 38336Y-N Motors
797984		Stator Wound with Housing for S 383366-N and S 383367-N Motors
797986		Stator Wound with Housing for S 383267-N Motor
797990		Stator for S 593221-N Electric Trans- mitter
797995		Stator Wound with Housing for S 383151-N Motor
797999		Rotor complete for S 482161, S 482161-N, S 482162 and S 482162-N Motors
798004		Rocker Ring 798005 with two 796189, for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors

No.	Plate	Name
798005		Rocker Ring for 798004
798009		Stator Wound with Housing for S 383357-N Motor
798011		End Cover (commutator end) for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors
798023		Stator for S 593257-N Electric Trans- mitter
798030		Stator Wound with Housing for S 482161-N Motor
798078		Stator Wound with Housing for S 383361-N Motor
798080		Stator Wound with Housing for S 383351-N Motor
798082		Stator Wound with Housing for S 383356-N Motor
798084		Stator Wound with Housing for S 482267-N Motor
798086		Stator Wound with Housing for S 383345-N Motor
798088		Stator Wound with Housing for S 482361-N Motor
798090		Stator Wound with Housing for S 48236Y-N Motor
798093 798098	00005	Stator for S 593345-N Electric Trans- mitter
798098	20225	Brush with lead and terminal for S 593121 and S 593121-N Electric Transmitters
798101	20218	End Cover (pulley end) for Series S 38 and S 48 D.C. and S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors
798123		Rotor complete for S 383221, S 383221-N, S 383227, S 383227-N, S 383228, S 383321, S 383321-N, S 383326, S 383327, S 383327-N and S 383328 Motors
798127		Stator for S 692167-N Electric Trans- mitter
798130		Stator for S 593321-N Electric Trans- mitter
798132		Stator for S 692357-N Electric Trans- mitter
798134		Stator Wound with Housing for S 48235X-N Motor
798159	20219	Terminal Box Cover (for Motors and Elec- tric Transmitters with tap for light)

No.	Plate	Name
798166		Stator Wound with Housing for S 383327-N Motor
798253		Stator Wound with Housing for S 383257-N Motor
798257	20220	Rotor complete for Series S 38 Poly Phase, A.C. Motors except S 383221, S 383221-N, S 383227, S 383227-N, S 383228, S 383321, S 383321-N, S 383326, S 383327, S 383327-N and S 383328
798258		Stator for S 593267 Electric Trans- mitter
798260		Stator Wound with Housing for S 383267 Motor
798271		Stator Wound with Housing for S 383153-N Motor
798281		Stator for S 593367 Electric Transmitter
798324		Commutator complete for S 593121 and S 593121-N Electric Transmitters
798354		Stator for S 692267 Electric Transmitter
798376		Brush Holder complete for S 383005-N to S 383009-N, S 482007-N, S 483005-N
		to S 483009-N Motors and Series S 59 and S 69 D.C. Electric Transmitters except S 593000-N to S 593002-N, S 692001-N and S 693000-N to S 693002-N, Nos. 798377 and two 799977
798377		Brush Holder Ring with Brush Tubes for 798376
798379		Brush complete for S 383005-N to S 383009-N, S 482007-N, S 483005-N to S 483009-N Motors and Series S 59 and S 69 D.C. Electric Transmitters except S 593000-N to S 593002-N, S 692001-N and S 693000-N to S 693002-N
798381		End Cover 797821 with 796446, for Series S 59 and S 69 D.C. Electric Trans- mitters
798382		Field Core complete for Series S 59 D.C. and S 692001-N and S 692007-N Elec- tric Transmitters
798384		Field Coil (upper) for S 383006-N, S 383007-N Motors and S 593006-N and S 593007-N Electric Transmitters
798385		Field Coil (lower) for S 383006-N, S 383007-N Motors and S 593006-N and S 593007-N Electric Transmitters

No.	Plate	Name
798386		Field Coil Retaining Pin for Series S 38 D.C., S 482001-N, S 482007-N Motors and Series S 59 D.C., S 692001-N and S 692007-N Electric Transmitters
798394		Rocker Ring Locating Spring for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors
798395		Brush with lead and terminal for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors
798396		Rotor complete for S 383141, S 383141-N, S 383142, S 383142-N and S 383143-N Motors
798398		Stator Wound with Housing for S 482151-N and S 482162-N Motor
798443	*	Stator Wound with Housing for S 383162-N Motor
798480		Commutator complete for S 383005-N to S 383009-N, S 482007-N, S 483005-N to S 483009-N Motors and Series S 59 and S 69 D.C. Electric Transmitters, except S 593000-N to S 593002-N, S 692001-N and S 693000-N to S 693002-N
798481		Commutator complete for S 383000-N to S 383002-N, S 482001-N, S 483000-N to S 483002-N Motors and S 593000-N to S 593002-N, S 692001-N and S 693000-N to S 693002-N Electric
	00007	Transmitters Stator for S 593161 Electric Transmitter
798485	` 20223	" S 692367 Electric Transmitter
1,798541 798549		" S 593151 Electric Transmitter
798552		" Wound with Housing for S 383151
790002		Motor
798566		Stator Wound with Housing for S 383160-N Motor
798595		Rotor complete for S 482151, S 482151-N, S 482152 and S 482152-N Motors
798601		Stator for S 593366 Electric Transmitter
798603		" S 593353 Electric Transmitter
798607		" S 593162 Electric Transmitter
798647	20228	Capacitor (only) for 798666
798665		* Box Packing (top) for 797303 and 797304
798666	20228	Capacitor complete for 797303 and 797304, Nos. 797351, 798647 and two 796295

No.	Plate	Name
798683		Stator for S 593157 Electric Transmitter
798686		" S 692151 and S 692161 Elec-
<b>700000</b>		tric Transmitters
798698		Stator Wound with Housing for S 383152-N Motor
798710	20219	Stator Wound with Housing for S 383161 Motor
798713		Stator for S 593152 Electric Transmitter
798744		" S 593327 Electric Transmitter
798756		" S 593167 Electric Transmitter
798764		" S 593357 Electric Transmitter
798769		" S 593356 Electric Transmitter
798798		" " S 692157 and S 692167 Electric Transmitters
798801		Stator Wound with Housing for S 383367 Motor
798803		Stator Wound with Housing for S 482367 Motor
798871	20218	Field Coil (upper) for S 383000-N, S 383001-N Motors and S 593000-N and S 593001-N Electric Transmitters
798872	20218	Field Coil (lower) for S 383000-N, S 383001-N Motors and S 593000-N and S 593001-N Electric Transmitters
798873		Brush Holder complete for S 383000-N to S 383002-N, S 482001-N, S 483000-N to S 483002-N Motors and S 593000-N to S 593002-N, S 692001-N and S 693000-N to 693002-N Electric Transmitters, Nos. 798874 and two 799977
798874	20218	Brush Holder Ring with Brush Tubes for 798873
798876	20218	Brush complete for S 383000-N to S 383002-N, S 482001-N, S 483000-N to S 483002-N Motors and S 593000-N to S 593002-N, S 692001-N and S 693000-N to S 693002-N Electric Transmitters
798878		Armature complete for S 383007-N Motor
798883	20218	End Cover (commutator end) for Series S 38 and S 48 D.C. Motors
798885		Field Core complete for Series S 38 D.C., S 482001-N and S 482007-N Motors
798886	20218	Armature complete for S 383001-N Motor
798887	20218	" Shaft Ball Bearing Friction Washer for Series S 38 D.C., S 482001-N and S 482007-N Motors
798887	20219	Rotor Shaft Ball Bearing Friction Washer for Series S 38 and S 48 A.C. Motors

No.	Plate	Name
798895		Field Coil Retaining Pin Insulation for
700000		Freid Corr Recarning Fin Insulation for
		Series S 38, S 48 D.C. Motors and
		S 59 and S 69 D.C. Electric Trans-
		mitters
798905	20218	Housing for Series S 38 D.C., S 482001-N
		and S 482007-N Motors
798914		Stator for S 593156 and S 593166 Elec-
		tric Transmitters
798960		Stator for S 593150 Electric Transmitter
798961		" S 593141 Electric Transmitter
798962		" S 593147 Electric Transmitter
798967		" S 593186 Electric Transmitter
798968		" S 593116 Electric Transmitter
798969		" S 692162 Electric Transmitter
798971		
798977		p partos Frecult Lightlifter
		o oboxol Electric Transmitter
798978		5 595251 Liectric Transmitter
798979		p 99050/ Frecult Hausmittel.
798980		5 595241 Fiethic Hausmitter
798981		" S 593247 Electric Transmitter
798982		" S 593221 Electric Transmitter
798983		" S 593227 Electric Transmitter
798984		" S 593361 Electric Transmitter
798985		" S 593351 Electric Transmitter
798986		" S 593352 Electric Transmitter
798987		" S 593345 Electric Transmitter
798988		" S 593341 Electric Transmitter
798989		" S 593347 Electric Transmitter
798990		" S 593321 Electric Transmitter
798991		" S 692361 Electric Transmitter
798992		" S 692366 Electric Transmitter
798993		" S 692357 Electric Transmitter
798994		" S 592341 Electric Transmitter
799008		" S 593150-N Electric Trans-
		mitter
799009		Stator for S 593147-N Electric Trans-
755555		mitter
799010		Stator for S 593186-N Electric Trans-
799010		mitter
799011	•	
799011		Stator for S 593116-N Electric Trans-
P00037		mitter
799013		Stator for S 593261-N Electric Trans-
maaaa 4		mitter
799014		Stator for S 593251-N Electric Trans-
		mitter
799015		Stator for S 593241-N Electric Trans-
		mitter
799016		Stator for S 593247-N Electric Trans-
		mitter
799017		Stator for S 593227-N Electric Trans-
		mitter

No.	Plate	Name
799018		Stator for S 593358-N Electric Trans-
799010		mitter
799019		Stator for S 59335X-N Electric Trans- mitter
799020		Stator for S 593341-N Electric Trans- mitter
799021		Stator for S 593347-N Electric Trans- mitter
799022		Stator for S 69235X-N Electric Trans- mitter
799023		Stator for S 592341-N Electric Trans- mitter
799049		Stator for S 593352-N Electric Trans- mitter
799052		Stator for S 593165-N Electric Trans- mitter
799053		Stator for S 593166-N Electric Trans- mitter
799058		Stator for S 593153-N Electric Trans- mitter
799066		Armature complete for S 383006-N Motor
799067		Armature complete for S 482001-N Motor
799068		Armature complete for S 482007-N Motor
799069		Armature complete for S 383002-N Motor
799070		Armature complete for S 383005-N Motor
799071		Armature complete for S 383009-N Motor
799072		Armature complete for S 383000-N Motor
799073		Armature complete for S 383008-N Motor
799082		Field Coil (upper) for S 482001-N Motor
		and S 692001-N Electric Transmitter
799083		Field Coil (lower) for S 482001-N Motor and S 692001-N Electric Transmitter
799084		Field Coil (upper) for S 482007-N Motor and S 692007-N Electric Transmitter
799085		Field Coil (lower) for S 482007-N Motor and S 692007-N Electric Transmitter
799086		Field Coil (upper) for S 383002-N Motor and S 593002-N Electric Transmitter
799087		Field Coil (lower) for S 383002-N Motor and S 593002-N Electric Transmitter
799088		Field Coil (upper) for S 383005-N Motor and S 593005-N Electric Transmitter
799089		Field Coil (lower) for S 363005-N Motor and S 593005-N Electric Transmitter
799090		Field Co11 (upper) for S 383008-N, S 383009-N Motors and S 593008-N and S 593009-N Electric Transmitters
799091		Field Coil (lower) for S 383008-N, S 383009-N Motors and S 593008-N and S 593009-N Electric Transmitters

No.	Plate	Name
799138		Stator Wound with Housing for S 383162
		Motor
799140		Stator Wound with Housing for S 383152
		Motor
799252		Stator Wound with Housing for S 383366
100000		Motor
799335		Stator for S 593353-N Electric Trans-
799000		
700776		mitter
799336		Stator for S 593153 Electric Transmitter
799339		5 095507 Electric Transmitter
799341		" Shield for S 693150 to S 693152,
		S 693156 to S 693158, S 693161,
		S 693162, S 693165 to S 693168 and
		Series S 69 Poly Phase A.C. Electric
		Transmitters except S 692258,
		S 692267, S 692267-N, S 692268,
		S 69226Y-N, S 692357, S 692357-N,
		S 692358, S 69235X-N, S 69235Y-N,
		S 692361, S 692361-N, S 692366,
		S 692366-N, S 692367, S 692367-N,
		S 692368 and S 69236Y-N
799373		Stator for S 693261 Electric Transmitter
799375		" S 693267 Electric Transmitter
799377		" S 693251 Electric Transmitter
799379		" S 693257 Electric Transmitter
799381		" S 693361 Electric Transmitter
799383		" " S 693366 Electric Transmitter
799385		" S 693351 Electric Transmitter
799387		
799389		o oboode electric ilgushiffel.
-		p 690000 FIECUIC Transmitter
799391		p osoco piecelic ilsusuiffeel
799393		n 090001 Frectific Haushifffer
799395		5 695161 Electric Transmitter
799397		" 5 693162 Electric Transmitter
799399		1900100 PIECCLIC LIAUSUITCEL
799401		5 693166 Electric Transmitter
799403		" 5 693167 Electric Transmitter
799407		" S 693150 Electric Transmitter
799409		" S 693151 Electric Transmitter
799411		" S 693152 Electric Transmitter
799413		" S 693156 Electric Transmitter
799415		" S 693157 Electric Transmitter
799587		" S 692158 Electric Transmitter
799629		Field Coil Retaining Pin for Series S 48
		D.C. Motors (except S 482001-N and
		S 482007-N) and S 69 D.C. Electric
		Transmitters except S 692001-N and
		S 692007-N
799649		Stator for S 593158 Electric Transmitter
799656	20220	" Wound with Housing for S 383361
		Motor

No.	Plate	Name
799710		Stator for S 69336Y-N Electric Trans-
		mitter
799744		End Cover Air Baffle for 799746
799746		" " 796733 with 799744 and two
		50782R, for S 592367, S 593150,
		S 593150-N, S 593151, S 593151-N,
		S 593152, S 593152-N, S 593153,
		S 593153-N, S 593156, S 593156-N,
		S 593157, S 593157-N, S 593158 and
		S 593158-N Electric Transmitters
799764		Stator for S 593168 Electric Transmitter
799800		" 5 595568 Electric Transmitter
799802		2 095200 FIECTLIC LISURGICCEL
799804		P 095100 FIECULE LIGHTENET
799837		D USECOU ELECTIC Transmitutor
799839		2 232220 FIECULO ILGUSHICCEL
799841		" Wound with Housing for S 482368 Motor
799845		Stator for S 593348 Electric Transmitter
799847		" " S 593328 Electric Transmitter
799849		" " S 593228 Electric Transmitter
799853		" S 593268 Electric Transmitter
799855		" S 593258 Electric Transmitter
799857	20218	Brush Holder Lead complete with Terminal
		for Series S 38 and S 48 D.C. Motors
		and S 59 and S 69 D.C. Electric
		Transmitters
799858	20218	Brush Holder Cap for 799977
799859		Stator for S 593248 Electric Transmitter
799861		2 032208 FIECTLIC ILGUSMITTEL
799863		2 292148 FIEGELIG HAUSHIFFEL
799869		Field Core complete for Series S 69 D.C.
		Electric Transmitters except S 692001-N and S 692007-N
799875		Stator for S 693368 Electric Transmitter
799961		Field Coil (upper) for S 483008-N Motor
755501		and S 693008-N Electric Transmitter
799962		Field Coil (lower) for S 483008-N Motor
		and S 693008-N Electric Transmitter
799975		Stator Wound with Housing for S 383141-N
		Motor
799977		Brush Holder Cap 799858 with 140122, for
		798376 and 798873
804079		Stator Wound with Housing for S 383327
		Motor
804299		Field Core complete for Series S 48 D.C.
		Motors except S 482001-N and
		S 482007-N
804337		Stator for S 69226Y-N Electric Trans-
		mitter

NT-	D2 - 4 -	
No.	Plate	Name
804407		Armature Shaft Ball Bearing Friction
		Washer for Series S 48 D.C. Motors
004550		except S 482001-N and S 482007-N
804552		Rotor complete for S 483251, S 483257,
		S 483258, S 483261, S 483267,
		S 483268, S 483351 to S 483353,
		S 483356 to S 483358, S 483361 and
804553		S 483366 to S 483368 Motors
		Stator for S 693358 Electric Transmitter
804554		5 695268 Electric Transmitter
804555		5 090208 Flectric Transmitter
804556		5 592048 Electric Transmitter
804557		5 692258 Electric Transmitter
804558		5 592248 Electric Transmitter
804559		5 690168 Electric Transmitter
804560		" S 693158 Electric Transmitter
804561		5 595168-N Electric Trans-
804562		mitter
300400		Stator for S 593148-N Electric Trans- mitter
804563		Stator for S 692168-N Electric Trans-
•		mitter
804564		Stator for S 692158-N Electric Trans-
		mitter
804568		Armature complete for S 483000-N Motor
804569		Armature complete for S 483001-N Motor
804570		Armature complete for S 483002-N Motor
804571		Armature complete for S 483005-N Motor
804572		Armature complete for S 483006-N Motor
804573		Armature complete for S 483007-N Motor
804574		Armature complete for S 483008-N Motor
804575		Armature complete for S 483009-N Motor
804585		Field Coil (upper) for S 483000-N Motor
		and S 693000-N Electric Transmitter
804586		Field Coil (lower) for S 483000-N Motor
		and S 693000-N Electric Transmitter
804587		Field Coil (upper) for S 483001-N Motor
		and S 693001-N Electric Transmitter
804588		Field Coil (lower) for S 483001-N Motor
		and S 693001-N Electric Transmitter
804589		Field Coil (upper) for S 483002-N Motor
		and S 693002-N Electric Transmitter
804590		Field Coil (lower) for S 483002-N Motor
004503		and S 693002-N Electric Transmitter
804591		Field Coil (upper) for S 483005-N Motor
004500		and S 693005-N Electric Transmitter
804592		Field Coil (lower) for S 483005-N Motor
004507		and S 693005-N Electric Transmitter
804593		Field Coil (upper) for S 483006-N Motor
		and S 693006-N Electric Transmitter

140

No.	Plate	Name
804594		Field Coil (lower) for S 483006-N Motor
204505		and S 693006-N Electric Transmitter Field Coil (upper) for S 483007-N Motor
804595		and S 693007-N Electric Transmitter
804596		Field Coil (lower) for S 483007-N Motor
		and S 693007-N Electric Transmitter
804597		Field Coil (upper) for S 483009-N Motor and S 693009-N Electric Transmitter
804598		Field Coil (lower) for S 483009-N Motor
		and S 693009-N Electric Transmitter
804839		Rotor complete for S 482267, S 482267-N,
		S 482268, S 482357, S 482357-N, S 482358, S 48235X-N, S 482361,
		s 482361-N, s 482366, s 482366-N,
		S 482367, S 482367-N, S 482368 and
		S 48236Y-N Motors
804910		Stator Wound with Housing for S 482161
		Motor _
804936		Stator for S 592367 Electric Transmitter
808060		Wound with Housing for S 383357 Motor
808098	20225	Short Circuiter for S 593121 and
000030	20220	S 593121-N Electric Transmitters
808099		Stator for S 593121-N Electric Trans-
		mitter
808275		Stator Wound with Housing for S 383351 Motor
808415		Machine Driving Pulley (single grooved)
000110		2 1/8 in. diam.
808416		Machine Driving Pulley (single grooved)
		2 3/8 in. diam.
808417		Machine Driving Pulley (single grooved) 2 5/8 in. diam.
808418		Machine Driving Pulley (single grooved)
000110		2 7/8 in. diam.
808419		Machine Driving Pulley (single grooved)
		3 1/8 in. diam.
808420		Machine Driving Pulley (single grooved) 3 3/8 in. diam.
808459		Stator Wound with Housing for S 482152-N
000100		Motor
808537		Machine Driving Pulley (single grooved)
000000	00000	l in. diam. Armature Shaft Ball Bearing for Series
808728	20222	S 59 and S 69 D.C. Electric Trans-
		mitters
808728	20224	Rotor Shaft Ball Bearing for Series S 59
		and S 69 A.C. Electric Transmitters
		except S 593121 and S 593121-N

No.	Plate	Name
808728	20226	Rotor Shaft Ball Bearing (pulley end) for S 593121 and S 593121-N Electric
		Transmitters
808759		Transmitter Fly Wheel for 808887
808815	20222	Armature Shaft Ball Bearing Retainer for
		Series S 59 and S 69 D.C. Electric
		Transmitters
808815	20222	Rotor Shaft Ball Bearing Retainer for
		Series S 59 and S 69 A.C. Electric
		Transmitters
808816	20222	Transmitter Frame and End Cover 808817
		with 51421R, 51422R, 69270, 69271,
		69344 and 69345 for Series S 59 and
		S 69 Electric Transmitters except
		S 593121 and S 593121-N
*808817		Transmitter Frame and End Cover for
		808816
808818	20222	Transmitter Fly Wheel for 808819
808819	20222	" " 808818 with 69255,
		809764 and four 69256, for Series
		S 59 and for Series S 69 Single
000000		Phase, A.C. Electric Transmitters
028808		Transmitter Shaft 808821 with 1633R,
		69268, 69269, 69427 and two each
		797421 and 931191, for Series S 59 and S 69 Electric Transmitters
808821	20222	Transmitter Shaft 808902 with 808822 and
130000	auaaa .	941097, for 808820
*808822		Transmitter Friction Pulley for 808821
808839		Rotor complete for S 693251, S 693257,
		S 693258, S 693261, S 693267,
		S 693268, S 693351 to S 693353,
		S 693356 to S 693358, S 693361,
		S 693366 to S 693368 and S 69336Y-N.
		Electric Transmitters

No.	Plate	Name
808840		Rotor complete for S 592248, S 592341,
000010		S 592341-N, S 592348, S 593241,
		S 593241-N, S 593247, S 593247-N,
		S 593248, S 593251, S 593251-N,
		S 593257, S 593257-N, S 593258,
		S 593261, S 593261-N, S 593267,
		S 593267-N, S 593268, S 59326Y-N,
		S 593341, S 593341-N, S 593345,
		S 593345-N, S 593347, S 593347-N,
		S 593348, S 593351, S 593351-N,
		S 593352, S 593352-N, S 593353,
		S 593353-N, S 593356, S 593356-N,
		S 593357, S 593357-N, S 593358,
		S 593358-N, S 59335X-N, S 59335Y-N,
		S 593361, S 593361-N, S 593366,
		S 593366-N, S 593367, S 593367-N,
		S 593368, S 59336Y-N, S 692258,
		S 692267, S 692267-N, S 692268,
		S 69226Y-N, S 692357, S 692357-N,
		S 692358, S 69235X-N, S 69235Y-N,
		S 692361, S 692361-N, S 692366,
		S 692366-N, S 692367, S 692367-N,
		S 692368 and S 69236Y-N Electric
		Transmitters
808843		Armature complete for S 693000-N Elec-
000010		tric Transmitter
808844		Armature complete for S 693001-N Elec-
000011		tric Transmitter
808845		Armature complete for S 693002-N Elec-
000010		tric Transmitter
808846		Armature complete for S 693005-N Elec-
909940		tric Transmitter
000047		Armature complete for S 693006-N Elec-
808847		tric Transmitter
000040		Armature complete for S 693007-N Elec-
808848		tric Transmitter
000040		Armature complete for S 693009-N Elec-
808849		tric Transmitter
200050		
808850		Armature complete for S 693008-N Elec- tric Transmitter
200055		Armature complete for S 593000-N Elec-
808855		
000050	00007	tric Transmitter Armature complete for S 593001-N Elec-
808856	20221	
200058		tric Transmitter
808857		Armature complete for S 593002-N Elec-
		tric Transmitter
808858		Armature complete for S 593005-N Elec-
		tric Transmitter
808859		Armature complete for S 593006-N Elec-
		tric Transmitter

No.	Plate	Name
808860		Armature complete for S 593007-N Elec-
000001		tric Transmitter
808861		Armature complete for S 593008-N Electric Transmitter
808862		Armature complete for S 593009-N Elec- tric Transmitter
808863		Armature complete for S 692001-N Elec- tric Transmitter
808864		Armature complete for S 692007-N Electric Transmitter
808868		Rotor complete for S 692161, S 692161-N, S 692162, S 692162-N, S 692167, S 692167-N, S 692168 and S 692168-N Electric Transmitters
808870		Rotor complete for S 59235Y-N Electric Transmitter
808875		Rotor complete for S 593221, S 593221-N, S 593227, S 593227-N, S 593228, S 593321, S 593321-N, S 593326, S 593327, S 593327-N and S 593328 Electric Transmitters
808878		Rotor complete for S 693150 to S 693152, S 693156 to S 693158, S 693161, S 693162 and S 693165 to S 693168 Electric Transmitters
808880	20223	Rotor complete for \$ 593116, \$ 593116-N, \$ 593161, \$ 593161-N, \$ 593162, \$ 593162-N, \$ 593165-N, \$ 593162-N, \$ 593166, \$ 593166-N, \$ 593166, \$ 593166-N, \$ 593168-N, \$ 593186 and \$ 593186-N Electric Transmitters
808883		Rotor complete for S 593141, S 593141-N, S 593147, S 593147-N, S 593148, S 593148-N, S 692151, S 692151-N, S 692157, S 692157-N, S 692158 and S 692158-N Electric Transmitters
808887		Transmitter Fly Wheel 808759 with 69255, 809764 and four 69256 for Series S 69 Electric Transmitters except Series S 69 Single Phase, A.C.
#808902		Transmitter Shaft for 808821
808917		Stator Wound with Housing for S 383356
808943	20218	Motor Grease Fitting (alemite) for greasing Armature Shaft Ball Bearing for Series S 38 and S 48 D.C. Motors and Series S 59 and S 69 D.C. Electric Transmitters

No.	Plate	Name
808943	20219	Grease Fitting (alemite) for greasing Rotor Shaft Ball Bearing for Series S 38 and S 48 A.C. Motors and Series
		S 59 and S 69 A.C. Electric Trans- mitters
908943	20222	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite) for Series S 59 and S 69 Electric Transmitters
808944	20227	Transmitter Shaft Bushing and Brake Cam Grease Fitting (alemite) for Series S 59 and S 69 Electric Transmitters (For Agents only) to be used when the Transmitter is used to drive a left hand Machine
808982		Rotor complete for S 592367, S 593150, S 593150-N, S 593151, S 593151-N, S 593152, S 593152-N, S 593153, S 593153-N, S 593156, S 593156-N, S 593157-N, S 593158 and S 593158-N Electric Transmitters
808983	20225	Stator for S 593121 Electric Transmitter
809098	20222	Transmitter Brake Holder for 943588
809236	20225	Rotor complete for S 593121 and S 593121-N Electric Transmitters
809300		Stator Wound with Housing for S 482366 Motor
809411	20228	Switch Box with Switch (four pole) com- plete with four wood screws 3/4 in. No. 12 R.H., for 1/3 and 1/2 H.P. for ratings above 270 volts
*809524		Transmitter Frame and End Cover for 809529
809529	20226	Transmitter Frame and End Cover 809524 with 51421R,51422R,69270,69271,69344 and 69345, for S 593121 and S 593121-N Electric Transmitters
809635		Stator Wound with Housing for S 383150 Motor
809764	20222	Transmitter Friction Pulley Friction Disc Cork for 808819 and 808887
809776		Stator Wound with Housing for S 383321 Motor
809779		Stator Wound with Housing for S 383141 Motor
809898		Stator Wound with Housing for S 383326 Motor
809913		Stator for S 593326 Electric Transmitter
876002	20228	Switch Box with Bracket for 797305 and . 797306
876004	20228	Switch Box Cover for 797305 to 797308

No.	Plate	Name
876013		Switch Box with Bracket for 797307 and
0.0020		797308
876021	20228	Switch Handle Spacer for 797305 and 797306
876066		Name Plate Drive Screw for Series S 38 and S 48 D.C., S 38 Single Phase, A.C. Repulsion Type (except S 383141, S 383141-N, S 383142-N, S 383143-N) and Series S 38 and S 48 Poly Phase, A.C. Motors and S 593121 and S 593121-N Electric Transmitters
876067		Name Plate Drive Screw for S 383141, S 383141-N, S 383142, S 383142-N, S 383143-N and Series S 48 Single Phase, A.C. Repulsion Type Motors
876584	20235	Socket Wrench for 1633 and 51680
876648	20235	Mallet
876649	20235	Rotor Shaft Ball Bearing Assembling Tool for 876652 for Series S 59 and S 69 Electric Transmitters
876650	20235	Rotor Shaft Ball Bearing Ejector (for frame and end cover) for Series S 59 and S 69 Electric Transmitters
876651	20235	Rotor Shaft Ball Bearing Retainer Ejec- tor for Series S 59 and S 69 Elec- tric Transmitters
876652	20235	Rotor Shaft Ball Bearing Retainer Injec- tor for 876649 for Series S 59 and S 69 Electric Transmitters
876653	20235	Rotor Shaft Ejector for 876654 for Series S 59 and S 69 Electric Trans- mitters
876654	20235	Rotor Shaft Ejector Guide for 876653 for Series S 59 and S 69 Electric Trans- mitters
876655	20235	Screw Driver for Series S 59 and S 69 Electric Transmitters
876656	20235	Transmitter Brake Setting Gauge for Series S 59 and S 69 Electric Trans- mitters
876657	20235	Transmitter Fly Wheel Wedge for Series S 59 and S 69 Electric Transmitters
876658	20235	Transmitter Shaft Ball Bearing (rear) Assembling Tool for 876663 for Series S 59 and S 69 Electric Transmitters
876659	20235	Transmitter Shaft Ball Bearing Puller Frame with 876661 for Series S 59 and S 69 Electric Transmitters

No.	Plate	Name
876660	20235	Transmitter Shaft Ball Bearing Puller Plate (for ball bearing) for 876659 for Series S 59 and S 69 Electric Transmitters
876661	20235	Transmitter Shaft Ball Bearing Puller Screw Stud for 876659
876662	20235	Transmitter Shaft Ball Bearing Puller Screw Stud Extension for 876661 for Series S 59 and S 69 Electric Trans- mitters
876663	20235	Transmitter Shaft Ball Bearing (rear) Retainer Injector for 876658 for Series S 59 and S 69 Electric Trans- mitters
876664	20235	Transmitter Shaft Bushing Puller Plate (for bushing) for 876659 for Series S 59 and S 69 Electric Transmitters
876665	20235	Transmitter Shaft Bushing and Brake Cam Ball Bearing Ejector (front) for Series S 59 and S 69 Electric Trans- mitters
876666	20235	Transmitter Shaft Fly Wheel Key Replace- ment Tool for Series S 59 and S 69 Electric Transmitters
898334	20218	End Cover Stud for Series S 38 D.C., S 482001-N, S 482007-N and Series S 38 and S 48 A.C. Motors
898780	20229	Cord Insulating Bushing with 50771, for 67930, 191406 and 898827
898780	20229	Lead Cord Insulating Bushing with 50771, for 744711
898795		End Cover Stud for Series S 48 D.C. Motors except S 482001-N and S 482007-N
898827	20229	Cord with ground wire complete for three phase motors, Nos. 898780 and 898828
898828		Cord (four strand) 8 ft. 3 in. long for 898827
898996	20228	Capacitor Box (box only) complete for 797303 and 797304
898999	20228	Capacitor Box Cover for 797303 and 797304
#899522		Capacitor Box Name Plate for 797304
<b>*</b> 899522		Switch Box Name Plate for 797306 and 797308
*899523		Capacitor Box Name Plate for 797303
*899524		Switch Box Name Plate for 797305

No.	Plate	Name
<b>*899526</b>		Name Plate for S 383141, S 383141-N,
		S 383142, S 383142-N, S 383143-N,
		Series S 48 Single Phase, A.C. Re-
		pulsion Type Motors and S 593121 and
		S 593121-N Electric Transmitters
*899594		Name Plate for Series S 38 Single Phase,
		A.C. Repulsion Type (except S 383141,
		S 383141-N, S 383142, S 383142-N,
		S 383143-N and Series S 38 and S 48
		Poly Phase A.C. Motors
<b>*</b> 899595		Name Plate for Series S 38 and S 48 D.C.
		Motors
*899598		Name Plate for Series S 59 and S 69 D.C.
		Electric Transmitters
<b>*</b> 899789		Switch Box Name Plate for 797307
<b>*899868</b>		Name Plate for Series S 59 and S 69 A.C.
		Electric Transmitters except
		S 593121 and S 593121-N
931033	20228	Switch Handle Spacer Screw Nut Lock
		Washer for 797305 and 797306
931078	20218	Armature Shaft Ball Bearing (pulley end)
		Spacing Washer for Series S 38 D.C.
		S 482001-N and S 482007-N Motors
931146		Armature Shaft Ball Bearing Friction
		Washer Spacing Washer (thick) for
		Series S 48 D.C. Motors except
931149		S 482001-N and S 482007-N Armature Shaft Ball Bearing Friction
901149		Washer Spring Washer (thin) for
		Series S 48 D.C. Motors except
		S 482001-N and S 482007-N
931191	20222	Transmitter Shaft Ball Bearing Thrust
001101	20222	Washer for 808820
931221	20222	Armature Shaft Ball Bearing Thrust
		Washer for Series S 59 and S 69 D.C.
		Electric Transmitters
931221	20222	Rotor Shaft Ball Bearing Thrust Washer
		for Series S 59 and S 69 A.C. Elec-
		tric Transmitters
931326		Machine Driving Pulley Cover Screw Lock
		Washer
941097		Transmitter Friction Pulley Pin for
		808821
942119		Stator Wound with Housing for S 383165
		Motor
942731		Stator Wound with Housing for S 383352
		Motor
943016		Stator Wound with Housing for S 482151
		Motor
943017		Stator Wound with Housing for S 482152
		Motor


No.	Plate	Name
943105		Stator Wound with Housing for S 482357-N Motor
943347		Stator Wound with Housing for S 482267 Motor
943513		Stator for S 69235Y-N Electric Trans- mitter
943588	20222	Transmitter Brake Holder complete for Series S 59 and S 69 Electric Trans-
		mitters, Nos. 809098, 943590 and two 943978
943590	20222	Transmitter Brake (thermoid) for 943588
943718		Stator for S 59235Y-N Electric Trans- mitter
943790		Stator Wound with Housing for S 383347 Motor
943967		Stator Wound with Housing for S 383142 Motor
943968		Stator Wound with Housing for S 383142-N Motor
943969		Stator Wound with Housing for S 383143-N Motor
943970		Stator Wound with Housing for S 482162 Motor
943971		Stator Wound with Housing for S 382341 Motor
943972		Stator Wound with Housing for S 382348 Motor
943973		Stator Wound with Housing for S 383221 Motor
943974		Stator Wound with Housing for S 383221-N Motor
943975		Stator Wound with Housing for S 383227 Motor
943976		Stator Wound with Housing for S 383227-N Motor
943977		Stator Wound with Housing for S 383228 Motor
943978		Transmitter Brake Adjusting Screw 140228C with 1637C, for 943588
943979		Stator Wound with Housing for S 383241 Motor
943980		Stator Wound with Housing for S 383241-N Motor
943981		Stator Wound with Housing for S 383247 Motor
943982		Stator Wound with Housing for S 383247-N Motor
943983		Stator Wound with Housing for S 383248 Motor
943984		Stator Wound with Housing for S 383251 Motor
From the	library of	: Superior Sewing Machine & Supply LLC


No.	Plate	Name
943985		Stator Wound with Housing for S 383257 Motor
943987		Stator Wound with Housing for S 383348 Motor
943993		Stator Wound with Housing for S 383258 Motor
943994		Stator Wound with Housing for S 383261-N Motor
943995		Stator Wound with Housing for S 383321-N Motor
943996		Stator Wound with Housing for S 383323 Motor
943997		Stator Wound with Housing for S 383341 Motor
943998		Stator Wound with Housing for S 383341-N Motor
943999		Stator Wound with Housing for S 383345 Motor
944000		Stator Wound with Housing for S 383347-N Motor
962005		Stator Wound with Housing for S 383352-N Motor
962006		Stator Wound with Housing for S 383353 Motor
962007		Stator Wound with Housing for S 383353-N Motor
962008		Stator Wound with Housing for S 383358 Motor
962009		Stator Wound with Housing for S 383358-N Motor
962010		Stator Wound with Housing for S 38335X-N Motor
962011		Stator Wound with Housing for S 383368 Motor
962012		Stator Wound with Housing for S 482268 Motor
962013		Stator Wound with Housing for S 482357 Motor
962014		Stator Wound with Housing for S 482358 Motor
962015		Stator Wound with Housing for S 482361 Motor
962016		Stator Wound with Housing for S 483251 Motor
962017		Stator Wound with Housing for S 483257 Motor
962018		Stator Wound with Housing for S 483258 Motor
962019		Stator Wound with Housing for S 483261 Motor


No.	Plate	Name
962020		Stator Wound with Housing for S 483351 Motor
962021		Stator Wound with Housing for S 483352 Motor
962022		Stator Wound with Housing for S 483353 Motor
962023		Stator Wound with Housing for S 483356 Motor
962024		Stator Wound with Housing for S 483357
962025		Stator Wound with Housing for S 483358 Motor
962026		Stator Wound with Housing for S 483361 Motor
962027		Stator Wound with Housing for S 483366
962028		Stator Wound with Housing for S 483367 Motor
962029		Stator Wound with Housing for S 483368 Motor
962030		Stator Wound with Housing for S 483268 Motor
962031		Stator Wound with Housing for S 383268 Motor
962037		Stator Wound with Housing for S 482366-N and S 482367-N Motors
962038		Stator Wound with Housing for S 382341-N Motor
962042		Stator Wound with Housing for S 38326Y-N Motor
962043		Stator Wound with Housing for S 383160 Motor
962044		Stator Wound with Housing for S 383251-N Motor
962045		Stator Wound with Housing for S 383261 Motor
962046		Stator Wound with Housing for S 483267 Motor
964270	20219	Terminal Box Cover Bushing (rubber) for 798159
964419		Capacitor Box Name Plate Screw for 797303 and 797304
964419		Switch Box Name Plate Screw for 797305


## OF PARTS




























From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC






From the library of: Superior Sewing Machine & Supply LLC


20231 - 1/4




From the library of: Superior Sewing Machine & Supply LLC




From the library of: Superior Sewing Machine & Supply LLC





From the library of: Superior Sewing Machine & Supply LLC

20234 - 2/3



From the library of: Superior Sewing Machine & Supply LLC



From the library of: Superior Sewing Machine & Supply LLC

