

Form 18908, Revised
(237)
Printed in U. S. A.

LIST OF PARTS



MACHINE No. 175-32

THE SINGER MANUFACTURING COMPANY

INSTRUCTIONS FOR OILING

THE MACHINE SHOULD BE OILED ONCE DAILY

Remove the two knurled thumb nut and remove the large arm side cover from the front side of the machine.

Apply oil at all oil holes and at all points where parts are in movable contact at the top as well as inside the arm.

Replace the large arm side cover and tighten the two thumb nuts.

Lay the machine on its rear side and apply oil to all oiling points in the machine bed.

Turn down the hinged cover beneath the looper and apply oil to the cam on the looper shaft, then close the hinged cover.

Use only Singer "Manufacturing Sewing Machine Oil (Cloth and Leather)" for general use, or "Manufacturing Sewing Machine Oil (Stainless for White Goods)" where a stainless oil is desired.

Copyright, U. S. A., 1935 and 1937,
by The Singer Manufacturing Co.
All Rights Reserved for all Countries

INDEX

	Page
Accessories.....	17
Belt and Pulley Guard (Hinged).....	18
Machine Base.....	17
Machine No. 175-32.....	5
Starting Lever and Foot Lifter Parts.....	18
Table Belt Guide.....	19
Thread Unwinder (for one spool).....	19

INSTRUCTIONS FOR ORDERING

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine Part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

A-Hardened, Polished, Nickel Plated and Buffed

B-Polished, Nickel Plated and Buffed

C-Hardened Only

D-Polished Only

E-Soft, Not Polished

F-Hardened and Polished

F.J-Hardened, Polished and Nickel Plated

G-Bright Rumbled and Nickel Plated

H-Blued

J-Nickel Plated Only

K-Hardened and Nickel Plated

L-Brass Plated

M-Oxidized

N-Japanned, Dull

P-Japanned, Bright

R-Merlized

S-Cadmium Plating

T-Copper Plated

T.A-Hardened, Polished, Copper and Nickel Plated and Buffed

T.B-Copper and Nickel Plated and Polished

T.J-Copper and Nickel Plated Only

T.K-Hardened, Copper and Nickel Plated

T.M-Copper Plated and Oxidized

T.L-Copper and Brass Plated

U-Zinc Plated

V-Silver Plated

W-Polished and Nickel Plated

Y-Black Nickel Plated Only

Z-Chromium Plated

Z.B-Polished, Nickel Plated, Buffed and Chromium Plated

Z.J-Nickel and Chromium Plated

These letters MUST BE USED when they appear in the list; and AFTER the number as in the list.

In this series:

1 to 1500, 50001 to 51500 and 140001 to 142000 are Screw Numbers

1501 to 1800 and 51501 to 51800 are Nut Numbers

1801 to 2000 and 51801 to 52000 are Roller Numbers


2001 to 50000 and 52001 to 140000 and 142001 to

190000 are Sewing Machine Parts, 190001 and upward are numbers of Electrical Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (*) are furnished only when special orders are made at factory.

LIST OF PARTS COMPLETE FOR



MACHINE No. 175-32

For Sewing Buttons on Shirts, Dresses, Underwear, Etc. For four hole flat buttons. Makes cross stitches with two straight parallel cross-over stitches, one from each pair of holes, laying the tie stitch at the base of the pile of stitches, where it is protected. Makes sixteen stitches, including the two parallel cross-over and knotting stitches. Needle bar and clamp vibration. Needle bar stroke $1 \frac{5}{8}$ inches. Button clamp for buttons from 10 to 36 ligne, equipped with special center finger. Fitted with thread breaker or clamp, automatic and constant tensions, thread positioning finger and automatic nipper and cutter blade which holds the starting end of the thread, and later in the sewing operation cuts this end off; also has a second constant tension between the take-up and needle. The thread is broken at the completion of the operation by raising the button clamp. Speed 1000 R. P. M.

No.	Plate	Name
•175230	-----	Arm with 15404 and two 15405.....
175002	21901	" Dowel Pin.....
•175003	-----	" Rock Shaft.....
175004	21902	" " " 175003 with 175006 and

No.	Plate	Name
175005	21901	Arm Rock Shaft Crank (back) with 1177E, 1521J and 140016E.....
1177E	21901	Arm Rock Shaft Crank (back) Clamping Screw.....
140016E	21901	Arm Rock Shaft Crank (back) Position Screw.....
1521J	21901	Arm Rock Shaft Crank (back) Position Screw Lock Nut.....
*175006	-----	Arm Rock Shaft Crank (front).....
175007	21901	" " " " " Pin.....
140017E	21901	" Screw (long).....
870E	21901	" (short).....
175008	21901	" Side Cover (left).....
230J	21901	" " " " " Screw.....
175231	-----	" " " " (right).....
175010	21902	" " " " " Screw Stud.....
51649E	21901	" " " " " " Lock Nut
51650B	21901	" " " " " Thumb Nut.....
*175232	-----	Bed.....
175013	21902	" End Cover (bottom).....
175751	-----	" " " " " 175013 with 175016.
175014	21901	" " " " " Hinge Pin (left)...
175015	21901	" " " " " " (right)...
175016	21901	" " " " " Spring.....
175017	21905	" " " " " Hook.....
175233	21902	" Top Cover.....
140019F	21905	" " " " " Screw.....
*175422	-----	Button Clamp (left).....
175418	-----	" " " " " 175422 with 175023 and 175622.....
175419	21902	Button Clamp (left) 175418 with 228J, 140021C and 175420.....
*175023	-----	Button Clamp (left) Button Stop.....
140020C	21905	" " " " " Hinge Screw.....
1498C	21905	" " " " " " Lock Screw
140021C	21905	" " " " " Screw Stud.....
175420	21905	" " " " " Spring.....
228J	21905	" " " " " Screw.....
175622	21905	" " " " " Steady Pin...
*175423	-----	" " (right).....
175516	-----	" " " " " 175423 with 175029 and 175622.....
175517	21902	Button Clamp (right) 175516 with 228J, 140021C and 175518.....
*175029	-----	Button Clamp (right) Button Stop.....
140020C	21905	" " " " " Hinge Screw.....
1498C	21905	" " " " " " Lock Screw
140021C	21905	" " " " " Screw Stud.....
175518	21905	" " " " " Spring.....
228J	21905	" " " " " " Screw.....
175622	21905	" " " " " Steady Pin..
175031	21902	" " " " " Adjusting Lever...

No.	Plate	Name
680W	21905	Button Clamp Adjusting Lever Thumb Screw
175032	21905	" " " " " "
		Washer.....
175226	21902	Button Clamp Arm.....
175034	21902	" " " Hinge Pin.....
175035	21902	" " " " " Bracket.....
160J	21905	" " " " " " Screw.
175036	21902	" " " " " " Shim
		(.003 in. thick).....
175037	-----	Button Clamp Arm Hinge Pin Bracket Shim
		(.005 in. thick).....
175038	-----	Button Clamp Arm Hinge Pin Bracket Shim
		(.007 in. thick).....
175039	-----	Button Clamp Arm Hinge Pin Bracket Shim
		(.015 in. thick).....
175040	21904	Button Clamp Closing Spring.....
175041	21902	" " Lifting Arm with 190J, 190K
		and 1259C.....
1259C	21905	Button Clamp Lifting Arm Set Screw.....
175042	21904	" " " Chain, 4 1/4 in. long.
190K	21905	" " " " " Screw (lower).
190K	21905	" " " " " " (upper).
190J	21905	" " " " " " "
		Lock Screw.....
175043	21904	Button Clamp Lifting and Thread Pull-off
		Holder Shaft.....
175047	21904	Button Clamp Lifting Rod.....
175048	21902	" " " " " Arm with 160E
		and 50269C.....
160E	21905	Button Clamp Lifting Rod Arm Clamping
		Screw.....
50269C	21905	Button Clamp Lifting Rod Arm Position
		Screw.....
175049	21905	Button Clamp Lifting Rod Arm Stop Plate.
160J	21905	" " " " " " "
		Screw.....
175032	21905	Button Clamp Lifting Rod Arm Stop Plate
		Screw Washer.....
42830	21905	Button Clamp Lifting Rod Cotter Pin.....
175050	21904	" " " " " Spring.....
175051	21902	" " " " " " Stop Col-
		lar with 160C.....
160C	21905	Button Clamp Lifting Rod Spring Stop
		Collar Set Screw.....
175052	21904	Button Clamp Presser Bar.....
175053	21908	" " " " " Collar with
		458C.....
458C	21905	Button Clamp Presser Bar Collar Set
		Screw.....
175054	21903	Button Clamp Presser Bar Screw Bearing..
175055	21904	" " " " " Spring.....

No.	Plate	Name
175074	21907	Feed Plate Carrier Driving Arm with 458C and 51923.....
175069	21903	Feed Plate Carrier Driving Arm Pin.....
51923	21903	" " " " " Roller and Screw Stud.....
458C	21905	Feed Plate Carrier Driving Arm Set Screw
175246	21907	" " " Guide Block (left)...
140050W	21905	" " " " " Screw
175247	21907	" " " " " (right) with two 66018.....
140050W	21905	Feed Plate Carrier Guide Block (right) Screw.....
66018	21905	Feed Plate Carrier Guide Block (right) Steady Pin.....
51667C	21909	Feed Plate Carrier Regulating Nut with 175549.....
175548	21909	Feed Plate Carrier Regulating Nut Screw Stud.....
175078	21909	Feed Plate Carrier Regulating Handle Screw Stud Slide Block.....
175549	21909	Feed Plate Carrier Regulating Nut Tightening Handle.....
140051C	21909	Feed Plate Carrier Regulating Stop Screw Stud.....
51657J	21909	Feed Plate Carrier Regulating Stop Screw Stud Nut.....
175242	21909	Feed Plate Carrier Regulating Stop Screw Stud Nut Washer.....
*175080	-----	Feed Plate Carrier Regulator.....
175081	21907	" " " " 175080 with 228J and 175082.....
175627	-----	Feed Plate Carrier Regulator 175081 with 175069 and 175074 (For Agents Only).
*175657	-----	Feed Plate Carrier Regulator 175081 with 175074 (For Factory Use Only).....
*175082	-----	Feed Plate Carrier Regulator Shaft.....
175083	21909	" " " " " Spring.....
160J	21905	" " " " " Screw (bed end).....
228J	21905	Feed Plate Carrier Regulator Spring Screw (regulator end).....
227J	21905	Feed Plate Screw.....
175251	21909	Knife (movable).....
175252	21910	" " " Bar.....
175253	21910	" " " Guide (left).....
175254	21910	" " " " (right).....
51657E	21909	" " " Nut.....
175281	21905	" " " Screw Stud.....
51657E	21909	" " " " " Nut.....
175242	21909	" " " " " Washer.
175255	21906	" " " Cam.....
175256	21906	" " " " " Screw.....

No.	Plate	Name
175032	21909	Knife (movable) Cam Screw Washer.....
175258	21910	" " Driving Lever with 51924
175257	21910	" " " " Arm.....
140053C	21905	" " " " " Hinge
		Screw.....
175258	21910	Knife (movable) Driving Lever Extension.
191E	21909	" " " " " "
		Screw.....
175032	21905	Knife (movable) Driving Lever Extension
		Screw Washer.....
140054C	21909	Knife (movable) Driving Lever Hinge
		Screw.....
1620E	21909	Knife (movable) Driving Lever Hinge
		Screw Nut.....
175259	21910	Knife (movable) Driving Lever Plate.....
160E	21905	" " " " " Screw.
51924	21909	" " " " " Roller and
		Screw Stud with 1521E.....
1521E	21901	Knife (movable) Driving Lever Roller and
		Screw Stud Nut.....
140097E	21909	Knife (movable) Screw.....
*175260	21909	" (stationary) lower.....
175545	-----	" " " " 175260 with
		175261 and 175262.....
175261	21905	Knife (stationary) lower, Steady Pin.....
175262	21909	" " (upper).....
230E	21901	" " Screw.....
175085	21908	Looper.....
175086	21910	" Driving Shaft.....
175087	21906	" " " Bushing.....
51183E	21905	" " " " Clamping Screw
*175088	-----	" " " " Crank with 435C and
		1285C.....
175525	21906	Looper Driving Shaft Crank 175088 with
		175090.....
175089	21908	Looper Driving Shaft Crank Connecting
		Link.....
175660	-----	Looper Driving Shaft Crank Connecting
		Link 175089 with 175525 and 175529..
*175090	-----	Looper Driving Shaft Crank Connecting
		Link Hinge Stud.....
1285C	21908	Looper Driving Shaft Crank Position
		Screw.....
435C	21908	Looper Driving Shaft Crank Set Screw....
175091	21908	" " " " Gear.....
175092	21908	" " " " Pin.....
458C	21905	" Set Screw.....
175093	21910	" Shaft with 458C.....
*175528	-----	" " " " Crank with two 140027C.....
175529	21906	" " " " 175528 with 175133...
140027C	21908	" " " " Set Screw.....
175133	-----	" " " " " "

No.	Plate	Name
175096	21908	Machine Rest Stud.....
458C	21905	" " " Set Screw.....
204383	21910	Needle Bar (hollow) with 200125F, 200175D and 204250.....
175098	21910	Needle Bar Connecting Link.....
140028C	21908	" " " " Hinge Screw...
1722J	21903	" " " " " " Nut
175099	21910	" " " " " Stud with 160E.....
175629	-----	Needle Bar Connecting Link Hinge Stud 175099 with 1492J, 175100 and 175101.
160E	21905	Needle Bar Connecting Link Hinge Stud Clamping Screw.....
175100	21905	Needle Bar Connecting Link Hinge Stud Thread Guide Plate.....
1492J	21917	Needle Bar Connecting Link Hinge Stud Thread Guide Plate Screw.....
175101	21917	Needle Bar Connecting Link Hinge Stud Thread Guide Roller.....
175102	21910	Needle Bar Connecting Stud (lower).....
1681J	21909	" " " " " Nut....
51652J	21909	" " " " " Lock Nut.....
175103	21909	Needle Bar Connecting Stud (lower) Wash- er.....
175104	21910	Needle Bar Connecting Stud (upper).....
1681J	21909	" " " " " Nut....
51652J	21909	" " " " " Lock Nut.....
175103	21909	Needle Bar Connecting Stud (upper) Wash- er.....
175105	21906	Needle Bar Eccentric with 140027C.....
175106	21913	" " " Connecting Rod with 1521J, 140024E, 175535 and two 140029E
140029E	21908	Needle Bar Eccentric Connecting Rod Cap Screw.....
140024E	21905	Needle Bar Eccentric Connecting Rod Clamping Screw.....
1521J	21901	Needle Bar Eccentric Connecting Rod Clamping Screw Nut.....
140031C	21908	Needle Bar Eccentric Connecting Rod Hinge Screw.....
51653E	21908	Needle Bar Eccentric Connecting Rod Hinge Screw Nut.....
175535	21905	Needle Bar Eccentric Connecting Rod Oil Pad (felt).....
175108	21912	Needle Bar Eccentric Pawl with 175114...
175109	-----	Needle Bar Eccentric Pawl complete, Nos. 175108 and 175110 to 175112.....
175110	21912	Needle Bar Eccentric Pawl Bracket.....
134E	21912	" " " " " Screw...

No.	Plate	Name
175111	21912	Needle Bar Eccentric Pawl Bracket Steady Pin.....
175112	21912	Needle Bar Eccentric Pawl Hinge Pin.....
175113	21912	" " " " Spring.....
175114	21912	" " " " Stud....
175119	21912	" " " Pin.....
140027C	21908	" " " Set Screw.....
204250	21912	" " Thread Guide.....
200175D	21912	" " " Screw.....
175265	21906	" " Vibrating Cam with 175272 and 175395.....
175119	21912	Needle Bar Vibrating Cam Pin.....
175120	21913	" " " Lever.....
175121	21912	" " " Adjusting Bracket with 186C, 458C and 175124...
140032C	21912	Needle Bar Vibrating Lever Adjusting Bracket Hinge Screw.....
186C	21912	Needle Bar Vibrating Lever Adjusting Bracket Hinge Screw Set Screw.....
175124	21912	Needle Bar Vibrating Lever Adjusting Bracket Hinge Screw Set Screw Locking Disc.....
175122	21911	Needle Bar Vibrating Lever Adjusting Bracket Hinge Screw Slide.....
51654K	21911	Needle Bar Vibrating Lever Adjusting Bracket Lock Nut.....
175123	21911	Needle Bar Vibrating Lever Adjusting Bracket Lock Nut Screw Stud.....
458C	21905	Needle Bar Vibrating Lever Adjusting Bracket Lock Nut Screw Stud Set Screw.....
175125	21911	Needle Bar Vibrating Lever Adjusting Bracket Lock Nut Washer.....
175126	21913	Needle Bar Vibrating Lever Arm with 51923.....
140033C	21915	Needle Bar Vibrating Lever Arm Hinge Screw.....
51923	21903	Needle Bar Vibrating Lever Arm Roller and Screw Stud.....
140024E	21905	Needle Bar Vibrating Lever Arm Screw....
175032	21905	" " " " " Washer
140034C	21911	" " " " Hinge Screw..
140035C	21911	" " " " " "
		Lock Screw.....
175127	21911	Needle Bar Vibrating Lever Hinge Screw Slide.....
*175421	-----	Needle Guide.....
*175591	-----	" " 175421 with 175547 and two 218D.....
175546	21902	Needle Guide 175591 with 175131 and 175136.....
175130	21911	Needle Guide Cam with two 175136.....

No.	Plate	Name
1259C	21905	Needle Guide Cam Set Screw.....
175131	21911	" " Pin.....
175132	21911	" " Oscillating Crank with 140159E and 175134.....
140159E	21911	Needle Guide Oscillating Crank Clamping Screw.....
175134	21911	Needle Guide Oscillating Crank Spring Hook (crank end).....
175135	21911	Needle Guide Oscillating Crank Spring Hook (bed end).....
175136	-----	Needle Guide Shaft.....
175094	21911	" " " Bushing.....
458C	21905	" " " Set Screw....
175547	21911	" " Thread Finger.....
218D	21911	" " " Screw.....
175268	21904	" Plate.....
140019F	21905	" " Screw.....
200125F	21912	" Set Screw.....
*175139	-----	Pulley.....
175140	21913	" 175139, 2 3/4 in. diam., with 51655D 140037C, 175141 and 175147.....
Note: Pulley No. 175140 is regularly furnished with the machine.		
*175633	-----	Pulley.....
175634	-----	" 175633, 3 1/4 in. diam., with 51655J, 140037C, 175141 and 175147.....
*175635	-----	Pulley.....
175636	-----	" 175635, 3 3/4 in. diam., with 51655J, 140037C, 175141 and 175147.....
140037C	21914	Pulley Engaging Screw.....
51655J	21914	" " " Nut.....
175141	21914	" Oil Pad (wick).....
175142	21913	" Shaft.....
175595	-----	" 175142 with 175069, 175105, 175143, 175144, 175150, 175294 and two 175119.....
175143	21908	Pulley Shaft Gear.....
175144	21908	" " " Pin.....
175145	21914	" Shifter.....
175146	21913	" " Holder with 51649J and 140078C.....
140078C	21914	Pulley Shifter Holder Set Screw.....
51649J	21901	" " " " " Lock Nut.
*175147	-----	" " Ring (V grooved).....
1178E	21914	" " Screw.....
175268	21910	Slack Thread Regulator Lever with 175017 and 175065.....
175269	-----	Slack Thread Regulator Lever 175268 with 185J, 140056C, 175062, 175063 and 202098.....
140055C	21908	Slack Thread Regulator Lever Hinge Screw
175271	21908	" " " " " Spring.....

No.	Plate	Name
175017	21905	Slack Thread Regulator Lever Spring Hook
175512	21908	" " " " Stop.....
160J	21905	" " " " " Screw.
175513	21908	" " " " " "
		Plate.....
140056C	21908	Slack Thread Regulator Releasing Screw (Lever End).....
175272	21917	Slack Thread Regulator Releasing Stud (Cam End).....
175062	21903	Slack Thread Regulator Thread Guide Plate.....
185J	21903	Slack Thread Regulator Thread Guide Plate Screw.....
175063	21903	Slack Thread Regulator Thread Guide Plate Screw Spacing Collar.....
202098	21903	Slack Thread Regulator Thread Guide Roller.....
175065	21903	Slack Thread Regulator Thread Guide Roller Pin.....
175148	21913	Starting Crank with 1747J and 140039E...
175630	-----	" " 175148 with 175149 and 175155.....
140039E	21914	Starting Crank Adjusting Screw.....
1747J	21914	" " " " Nut.....
175149	21914	" " Pin.....
175150	21904	Stop Dog.....
175151	21914	" " Cushion Spring.....
175152	21904	" " " " Holder with 50581C 175151 and two 140040C.....
50581C	21914	Stop Dog Cushion Spring Holder Set Screw
140040C	21914	" " " " Set Screw.....
175119	21912	" " Pin.....
175153	21914	" Motion Retaining Collar.....
1186E	21908	" " " " Screw.....
175154	21914	" " " " Stud..
882C	21914	" " " " " "
		Set Screw.....
175155	21910	Stop Motion Shaft.....
175156	21904	" " " Spring.....
175157	21904	" " " " Collar with 140041C.....
140041C	21914	Stop Motion Shaft Spring Collar Set Screw.....
175158	21904	Stop Motion Trip.....
175530	21904	" " " Block with 882C and 175154.....
140042C	21911	Stop Motion Trip Block Hinge Screw.....
51649E	21901	" " " " " Nut...
175113	21912	" " " " Spring.....
175229	21914	" " " Point.....
1186E	21908	" " " Screw.....
175032	21905	" " " " Washer

No.	Plate	Name
175180	21915	Tension (automatic) Disc.....
175161	21915	" " " Position Pin....
1580C	21915	" " " Regulating Thumb Nut
175162	21915	" " " Releasing Cam with two 140027C.....
140027C	21908	Tension (automatic) Releasing Cam Set Screw.....
175522	21915	Tension (automatic) Releasing Disc.....
175163	21910	" " " " Rod.....
1521J	21901	" " " " Adjust- ing Nut.....
1521J	21901	Tension (automatic) Releasing Rod Ad- justing Nut Lock Nut.....
175164	21910	Tension (automatic) Releasing Rod Spring
175165	21915	" " " " Wear- ing Sleeve.....
140043C	-----	Tension (automatic) Screw Stud.....
175166	-----	" " " " 140043C with 1580C.....
125314	21915	Tension (automatic) Spring.....
175167	21915	" " " Thread Eyelet.....
175168	-----	Tension (automatic) complete, Nos. 125314, 175166, 175522 and two 175160.....
175160	21915	Tension (stationary) Disc.....
175161	21915	" " " " Position Pin..
1580C	21915	" " " " Regulating Thumb Nut.....
140044C	21915	Tension (stationary) Screw Stud.....
175169	-----	" " " " 140044C with 1580C.....
13710	21915	Tension (stationary) Spring.....
175170	-----	Tension (stationary) complete, Nos. 13710 175169 and two 175160.....
175171	21915	Thread Eyelet (back).....
175167	21915	" " " (front).....
175173	21916	" " " Nipper Head.....
175174	21916	" " " Plate.....
160J	21905	" " " " Screw.....
175175	21916	" " " " Washer.....
140045K	21916	" " " " Releasing Head Screw.....
175531	21916	" " " " Lever.....
140046C	21916	" " " " " Hinge Screw
175177	21916	" " " " Rod.....
175178	-----	" " " " 175177 with 175173.....
175179	21916	Thread Nipper Releasing Rod Spring (lower).....
175180	21916	Thread Nipper Releasing Rod Spring (lower) Washer.....
175181	21916	Thread Nipper Releasing Rod Spring (upper).....
175182	21916	Thread Nipper Releasing Rod Spring Col- lar with 465C.....

No.	Plate	Name
465C	21916	Thread Nipper Releasing Rod Spring Col- lar Set Screw.....
175183	21916	Thread Nipper Releasing Screw Stud.....
1722J	21903	" " " " " Nut...
175184	21916	" " " " " Washer.....
175395	21916	Thread Nipper Releasing Stud (Cam End)..
175161	21915	" " Thread Guide Pin.....
175186	21907	" Pull-off (back).....
175167	21915	" " " Eyelet.....
175187	21917	" " " Holder with 160C and 1120C.....
160C	21905	Thread Pull-off (back) Holder Set Screw.
1120C	21917	" " " Set Screw.....
175273	21907	" " (front).....
175172	21915	" " " Eyelet.....
175274	21917	" " " Holder with 201C.
175275	21917	" " " Releasing Arm with 1186J.....
1186J	21908	Thread Pull-off (front) Releasing Arm Clamping Screw.....
208C	21909	Thread Pull-off (front) Set Screw.....
175279	21917	" " " Spring.....
230E	21901	" " " " Screw.....
175280	21917	" " " " Stud
*15404	-----	Trade Mark.....
15405	-----	" " Rivet.....

Genuine Singer Needles should be used
in Singer Machines.
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"For Singer Machines"
are not Singer made needles. 2

ACCESSORIES

No.	Plate	Name
175193	21918	Button Tray with three 175194.....
175194	21918	" " Hinge Screw Stud.....
160C	21905	" " " " " Set Screw for Machine Base
175195	21918	Hand Wheel with 1448C, for turning machine by hand.....
1448C	21908	Hand Wheel Set Screw.....
120342	21918	Oiler (copper plated) with 120343.....
120343	21918	" Spout, 3 1/2 in. long.....
26026	21918	Screw Driver.....
175197	21918	Wrench for 140026.....
175198	21918	" " 140027.....
8909	-----	"

MACHINE BASE

No.	Plate	Name
175199	-----	Machine Base with 175210
175200	21920	Machine Base complete, Nos. 145C, 160C, 1637J, 140047C, 140048C, 175032, 175199, 175208, 175209, 175425 and four wood screws 7/8 in. No. 14 R.H.....
140047	21919	Machine Locating Screw Stud.....
•175201	-----	" Lock Plate.....
175115	21919	" " " 175201 with 175202, 175205 and 175206.....
175202	21919	Machine Lock Plate Position Stud.....
•175205	21919	" " Stud.....
51656J	21919	" " Thumb Nut.....
175206	21919	" " " " Screw Stud.....
175207	21919	" " " " Spring.....
175536	21919	" " " " Washer.....
175425	-----	Machine Lock complete, Nos. 51656J, 175115, 175207 and 175536.....
175208	21919	Machine Starting Lever with 175424.....
140048C	21919	" " " Hinge Screw.....
175032	21905	" " " " " Washer
175209	21919	" " " Spring.....
175210	21919	" " " " Hook (long)
175424	21919	" " " " " (short)
145C	21919	" " " Stop Screw.....
1637J	21919	" " " " " Nut....

BELT AND PULLEY GUARD

(HINGED)

No.	Plate	Name
175537	21921	Belt and Pulley Guard.....
175538	21921	" " " " Fill-in Piece (metal) with two wood screws 3/4 in. No. 10 R.H., for Trough Power Tables
175539	21921	Belt and Pulley Guard Fill-in Piece (wood) with four wood screws 1 1/2 in. No. 12 F.H., for Flat Power Tables.....
175540	-----	Belt and Pulley Guard complete, for In- dividual Motor Table and for 175544, Nos. 42830, 175537, 175543 and two wood screws 1 in. No. 14 F.H.....
175541	21921	Belt and Pulley Guard Hinge Pin.....
175542	21921	" " " " " " Bracket.
175543	21921	" " " " " " "
		175542 with 175541.....
42830	21905	Belt and Pulley Guard Hinge Pin Cotter Pin.....
175544	-----	Belt and Pulley Guard with Fill-in Pieces complete, Nos. 175538 to 175540.....

STARTING LEVER AND FOOT LIFTER PARTS

No.	Plate	Name
175215	-----	Foot Lifter Chain, 37 in. long, with two 56865.....
56865	21917	Foot Lifter Chain Hook.....
175216	21920	" " Treadle.....
175217	21920	" " " Hinge Pin.....
175218	21920	" " " Stand.....
175219	21920	Foot Lifter Treadle complete, Nos. 175216 to 175218 and two wood screws 1 in. No. 14 F.H.....
175215	-----	Starting Lever Chain, 37 in. long, with two 56865.....
56865	21917	Starting Lever Chain Hook.....
175216	21920	" " Treadle.....
175217	21920	" " " Hinge Pin.....
175218	21920	" " " Stand.....
175219	21920	Starting Lever Treadle complete, Nos. 175216 to 175218 and two wood screws 1 in. No. 14 F.H.....

TABLE BELT GUIDE

No.	Plate	Name
175220	21920	Belt Guide (left) with 140035C.....
175221	21920	" " (right) with 140035C.....
140035C	21911	" " Set Screw.....
175222	21920	Pulley.....
175223	-----	" Shaft.....
175224	21920	" " 175223 with 1259E and 175227
175225	21920	" " Bracket with 444C.....
1259E	21905	" " Oil Plug Screw.....
175227	21920	" " Wick.....
444C	21908	" " Set Screw.....
175228	21920	Table Belt Guide complete, Nos. 175220, 175221, 175224, 175225 and two each 175222 and wood screws 7/8 in. No.14 R.H.....

THREAD UNWINDER

FOR ONE SPOOL

No.	Plate	Name
225259	21922	Spool Rest with 201018C.....
150203	21922	" " Cushion (felt).....
225388	21922	" " Rod.....
200383C	21917	" " Set Screw.....
201018C	21917	" " Set Screw.....
202490	21922	" Stand with 200383C.....
225391	21922	Thread Guide.....
201696J	21917	" " Lock Nut.....
225326	21917	" " Position Cup.....
225324	21922	" " Rod with 208E and 225322...
208E	21909	" " Screw.....
225322	21917	" " Washer.....
225260	21922	Thread Unwinder complete, Nos. 150203, 201696J, 202490, 225259, 225324, 225326, 225388, 225391 and three wood screws 7/8 in. No. 12 F.H.....
27739	21922	Thread Cone (wood) for large cones.....
225390	21922	" " Holder for inverted cones...

Note: Nos. 27739 and 225390 are used with, but not included in 225260.


Genuine Singer Needles should be used
in Singer Machines.
These Needles and their Containers
are marked with the
Company's Trade Mark "SIMANCO." 1

Needles in Containers marked
"For Singer Machines"
are not Singer made needles. 2


ILLUSTRATIONS
OF
PARTS

PLATE 21901 - FULL SIZE

175005
Page 6



175008
Page 6



1177
Page 6



140016
Page 6



140017
Page 6



670
Page 6



175007
Page 6



175002
Page 5



175016
Page 6




230
Page 6



1521
Page 6



51650
Page 6



51649
Page 6



175014
Page 6



175015
Page 6



PLATE 21902 - ONE-HALF SIZE

175004 175010 175226
Page 5 Page 6 Page 7

175013
Page 6







PLATE 21903 - FULL SIZE

175054
Page 7



140023
Page 8



120
Page 8



175066
Page 8



175062
Page 14



185
Page 14



202098
Page 14



175063
Page 14



175065
Page 14



1472
Page 8



140026
Page 8



175069
Page 8



1722
Page 8



127
Page 8



51923
Page 9



197
Page 8



175573
Page 8



PLATE 21904 - ONE-HALF SIZE


175043 175047 175050 175052 175055 175071
Page 7 Page 7 Page 7 Page 7 Page 7 Page 8




175040
Page 7



175057
Page 8




175056
Page 8




175042
Page 7




175266
Page 13



175156
Page 14



175152
Page 14




175150
Page 14



175158
Page 14



175530
Page 14



175157
Page 14



PLATE 21905 - FULL SIZE

175420

Page 6



175518

Page 6



175049

Page 7



175281

Page 9



175017

Page 6



42830

Page 7



175236

Page 8



66018

Page 9



175032

Page 7



51183

Page 10



140050

Page 9



160

Page 7



190

Page 7



228

Page 6



680

Page 7



140053

Page 10



140020

Page 6



140025

Page 8



140021

Page 6



140024

Page 8



1259

Page 7



1498

Page 6



140019

Page 6



50269

Page 7



175535 175100

Page 11 Page 11



227

Page 9



458

Page 7



175261

Page 10




175622

Page 6




PLATE 21906 - ONE-HALF SIZE


175241
Page 8



175255
Page 9




175265
Page 12



175294
Page 8




175243
Page 8



175105
Page 11



175525
Page 10



175529
Page 10



175087
Page 10




PLATE 21907 - ONE-HALF SIZE

175244
Page 8



175245
Page 8



175081
Page 9



175246
Page 9


175247
Page 9



175074
Page 9



175234
Page 8



175186
Page 16



175273
Page 16




PLATE 21908 - FULL SIZE

175085

Page 10



175089

Page 10




175091

Page 10



175143

Page 13



175092

Page 10



175144

Page 13



175513

Page 14



175512

Page 14



435

Page 10



1285

Page 10



175096

Page 11



140027

Page 10



1448

Page 17



444

Page 19



140056

Page 14



175271

Page 13



140029

Page 11



1186

Page 14




140031

Page 11



140028

Page 11



140055

Page 13



51653

Page 11



175053

Page 7



PLATE 21909 - FULL SIZE


175260
Page 10



175262
Page 10



175251
Page 9



175083
Page 9



51667
Page 9



175549
Page 9



175078
Page 9



175548
Page 9



140054
Page 10



175237
Page 8



175238
Page 8



175239
Page 8



175242
Page 9



140097
Page 10



208
Page 8



51924
Page 10



140049
Page 8



191
Page 10



1620
Page 10



51657
Page 9



140051
Page 9




1681
Page 11



51652
Page 11



175103
Page 11



175259 Page 10



175258 Page 10



175257 Page 10




175098 Page 11



175104 Page 11



175102 Page 11



175099 Page 11



175256 Page 10




175253 Page 9




175254 Page 9



175252 Page 9



175268 Page 13



204383 Page 11




175155 Page 14



175163 Page 15



175164 Page 15



175093 Page 10




175086 Page 10



PLATE 21911 - FULL SIZE


51654
Page 12



175122
Page 12



175125
Page 12



175123
Page 12



140042
Page 14



140034
Page 12




175127
Page 12



140035
Page 12



175131
Page 13



140159
Page 13



175132
Page 13



175134
Page 13



175135
Page 13



175094
Page 13



175547
Page 13



218
Page 13



175130
Page 12



PLATE 21912 - FULL SIZE

175108
Page 11



175110
Page 11



134
Page 11



175119
Page 12



175111
Page 12



175112
Page 12



175114
Page 12



175113
Page 12



204250
Page 12



200175
Page 12




200125
Page 13




186
Page 12



175121
Page 12



140032
Page 12




175124
Page 12




PLATE 21913 - ONE-HALF SIZE

175120
Page 12




175106
Page 11




175142
Page 13



175146
Page 13



175140
Page 13



175148
Page 14



175126
Page 12




PLATE 21914 - FULL SIZE


140078
Page 13




140037
Page 13



175141 175149
Page 13 Page 14



175145
Page 13



1178
Page 13




140039
Page 14



175153
Page 14



51655
Page 13



175151
Page 14



140041
Page 14



140040
Page 14




1747
Page 14



175229
Page 14



50581
Page 14



175154
Page 14




882
Page 14




PLATE 21915 - FULL SIZE

175160
Page 15



175522
Page 15



1560
Page 15



175161
Page 15



175165
Page 15



140033
Page 12



175171
Page 15



175167
Page 15



175172
Page 16



140043
Page 14



140044
Page 15



125314
Page 15



13710
Page 15



175162
Page 15





PLATE 21916 - FULL SIZE

175174
Page 15



175180
Page 15




175173
Page 15



140045
Page 15



175177
Page 15



175181
Page 15



175179
Page 15



140046
Page 15



175182
Page 15



465
Page 16



175184
Page 16



175183
Page 16



175175
Page 15



175395
Page 16



175531
Page 15




PLATE 21917 - FULL SIZE

175274
Page 16




175187
Page 16



175280
Page 16



175275
Page 16



175279 Page 16 175272 Page 14



225326
Page 19



56865
Page 18



1120
Page 16



1492
Page 11



175101
Page 11



225322
Page 19



201018
Page 19



200383
Page 19



201696
Page 19




PLATE 21918 - ONE-HALF SIZE

26026
Page 17


120342
Page 17

175197
Page 17


175198
Page 17



120343
Page 17



175195
Page 17



175194
Page 17



175193
Page 17





PLATE 21919 - FULL SIZE

175115
Page 17



175208
Page 17



175424
Page 17



140047
Page 17



140048
Page 17



175210
Page 17



175207
Page 17



175205
Page 17



51656
Page 17



175206
Page 17



175202
Page 17



175209
Page 17



175536
Page 17



1637
Page 17




145
Page 17



PLATE 21920 - ONE - FOURTH SIZE


175200
Page 17



175228
Page 19

175219
Page 18

175220
Page 19




175225
Page 19

175221
Page 19

175222
Page 19

175227
Page 19



175216
Page 18

175218
Page 18

175224
Page 19




175217
Page 18



PLATE 21921 - ONE - FOURTH SIZE


175537
Page 18



175539
Page 18



175538
Page 18



175543
Page 18



175542
Page 18

175541
Page 18

PLATE 21922 - ONE - FOURTH SIZE

