



List of Parts—Machines Nos. 648E3, 648E6 and 648E7

ATTACHMENT SET 171128



21906	Chainstitch Attachment Loop Retainer Disc
21913	Chainstitch Attachment Throat Plate
161133	Tube of Oil
161166	Zipper Foot
161168	Presser Foot for button sewing
161172	Seam Guide
161917	Presser Foot Plate (snap-on, plastic), for sewing Buttonholes
161919	Presser Foot Plate (snap-on), for Straight Sewing
163242-656	Spool Pin for two needle sewing
163455	Chainstitch Attachment Thread Guide
163483	Special Purpose Presser Foot
172185	Disc No. 1, for Arrowhead Stitch
172187	Disc No. 2, for Scallop Stitch
172189	Disc No. 3, for Diamond Stitch
172190	Disc No. 4, for Solid Scallop Stitch
172191	Disc No. 5, for Banner Stitch
172229	Disc No. 6, for Crescent Stitch
174527	Disc No. 9, for Multiple Zig-Zag Stitch
174528	Disc No. 8, for Blind Stitch
174529	Throat Plate for straight sewing
174533	Disc No. 10, for Ball Stitch
174534	Disc No. 12, for Domino Stitch
174536	Disc No. 14, for Comb Stitch
174538	Disc No. 18, for Solid Pyramid Stitch
174540	Disc No. 11, for Ribbon Stitch
174547	Disc No. 21, for Chevron Stitch
-----	Needle Cat. 2020, Size 14 (3)
-----	Needle Cat. 2020, Size 16 (3)
-----	Twin Needle Cat. 2028, Size 14 (1)
163131	Bobbin (3)

List of Parts—Machines Nos. 648E3, 648E6 and 648E7



List of Parts—Machines Nos. 648E3, 648E6 and 648E7

