


# BW201 PARTS LIST



1. Power Plug
2. Computer Control Facial Deck
3. Power Switch
4. Mono/Double Switch
5. Operating Pre-selected Key
6. LED Conditional Indicator
7. Digital Display
8. Upper Seat Handle
9. Thread Retainer
10. Switch of Thread Cut
11. Grooved Tube
12. Upper Copper Bush
13. Thread Real

14. Lower Copper Bush
15. Lower Screw
16. Thread Retainer Screw
17. Fuse
18. Thread Retainer Plate
19. Adjusting Nut
20. Motor
21. Small Pulley
22. Belt 18"0" Type
23. Large Pulley
24. Central Bracket
25. Torque Spring
26. Yarn Tube