


CM-16A PARTS LIST

TEXTILE CLEANING GUN

CM-16A

PARTS-LIST:



1. Gun housing
2. Gun housing cover
3. Coil
4. Trigger switch
5. Amature
6. Electric lead
7. Buffer part
8. Volume control knob

9. Volume control spring
10. Armature spring
11. Bolt A
12. Gun unit locking screw
13. Pump cylinder
14. Piston
15. Piston spring
16. Bolt B (4mm x 28mm)

17. Valve cone
18. Valve spring
19. Swirl head
20. Nozzle head
21. Container
22. Suction pipe
23. Pump unit locking screw
24. Terminal block

零件名稱：

1. 噴槍主體
2. 噴槍外殼
3. 馬達達
4. 開關片
5. 矽鋼片
6. 電線
7. 緩衝壁
8. 後調帽
9. 後調彈簧片
10. 彈簧片
11. 叉銷A
12. 槍體固定螺絲
13. 汽缸桿
14. 前擊桿
15. 擊桿彈簧
16. 叉銷B
- 17.-19. 分水活塞
20. 噴頭
21. 油壺管
22. 吸管
23. 汽缸固定螺絲
24. 接線板