

TAJIMA

TMEG-II

PARTS LIST

(9005)

TAJIMA

TMEG-II

PARTS LIST

(9005)

Table of Contents

[Explanation of Marks #'s and *'s at End of Part No.]

◇Please specify, in the following manner, your machine model, manufacturing number and embroidery space when you order us with the parts having* * * * at the end of the part No. :

Ex. : TMEF-H612 (450 X 275)S, No. 01234
 [Model] [Emb. Space] [Mfg. No.]


◇Please specify the number of needles on your machine's head in your parts order by changing the marks # # # # into one of the 4-digit numbers below :

Ex. : The part Number, EF012345 # # # #
 4-digit Numbers Machine Type
 0300..... 3-needle machine
 0400..... 4-needle machine
 0600..... 6-needle machine
 0900..... 9-needle machine

Note : Some Ref. Nos. are deleted when machines are upgraded,
 the discontinuation of the production of the parts. etc.

● TMEG GENERAL VIEW	E G - 1
● TMEG BOX A	E G - 2a
● TMEG BOX B (G-spec. Machine)	E G - 2b
● TMEG ROTARY HOOK BASE	E G - 3
● TMEG COLOR CHANGE SYSTEM	E G - 4
● TMEG ARM	E G - 5
● TMEG NEEDLE BAR CASE	E G - 6
● TMEG UPPER THREAD LOCKING DEVICE (E-SPEC.)	E G - 7
● TMEG UPPER THREAD HOLDER SET	E G - 8
● TMEG CAM DRIVER SET	E G - 9
● TMEG X-AXIS DRIVER 1	E G - 10-1
● TMEG X-AXIS DRIVER 2	E G - 10-2
● TMEG Y-AXIS DRIVER A-1	E G - 11a-1
● TMEG Y-AXIS DRIVER A-2	E G - 11a-2
● TMEG Y-AXIS DRIVER B-1	E G - 11b-1
● TMEG Y-AXIS DRIVER B-2	E G - 11b-2
● TMEG TENSION BASE & TENSION RELEASE SYSTEM A	E G - 12a
● TMEG TENSION BASE & TENSION RELEASE SYSTEM B	E G - 12b
● TMEG BAR SWITCH BOX	E G - 13
● TMEG EMBROIDERY FRAME	E G - 14
● TMEG OPERATION PANEL BOX	E G - 15
● TMEG POWER SUPPLY BOX A	E G - 16a
● TMEG POWER SUPPLY BOX (E-SPEC. MACHINE)	E G - 16b
● TMEG DRIVER BOX	E G - 17
● TMEG CONTROLLER BOX	E G - 18
● TMEG MAIN MOTOR CONTROL BOX	E G - 19

TMEG GENERAL VIEW EG-1



TAJIMA

(9 0 0 1)

TMEG GENERAL VIEW

EG-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Stand	E G 080102****		32	Countersunk Head Screw	S S 110412SD00	
3	Arm Support Square Pipe	E G 080300****		33	Shelf Plate	E F P 81500****	
4	No.1 Table Lid	E G 080400****		34	Main Shaft Motor	E F 6204D00000	
5	No.2 Table Lid	E G 080500****		35	Motor Pulley	E G 010700****	
6	Countersunk Head Wood Screw 3.1P*13L			36	Hexagon Nut, M10*P1.0		
7	No.101 Table Support	E G 100100****		37	Hexagon Bolt	S S 931035CC00	
8	No.102 Table Support	E G 100200****		38	Spring Washer, M10		
9	No.103 Table Support	E G 100300****		39	Plain Washer, M10		
10	No.4 Table Support	E F 100500****		40	Bar Switch Support	E F 1108000000	
11	Hexagon Socket Head Cap Screw	S S 620830CC00		41	Switch Bar	E F 110900****	
12	Spring Washer, M8			42	No.1 Wiring Cover	E G 0806A0****	
13	Plain Washer, M8			42	No.1 Wiring Cover (E-spec. Machine)	E G 0807A0****	
14	Counter Gear Box—side Side Plate Cover	E F 0807000000		43	No.2 Wiring Cover	E G 0806B0****	
15	Truss Head Screw	S S 010508SD00		43	No.2 Wiring Cover (E-spec. Machine)	E G 0807B0****	
16	No.105 Table Support	E G 100400****		44	Wiring Cover Stud	E F 0817000000	
17	Table Support Bracket R	E G 1005R0****		44	Wiring Cover Stud (E-spec. Machine)	E G 0808000000	
18	Table Support Stud	E F 100100****		45	Truss Head Screw	S M 010906SC00	
19	Hexagon Nut, M8			46	Hexagon Nut, M5		
20	Countersunk Head Screw	S S 110615SC00		47	N—Coupling	N 01501500000	
21	Round Head Wood Screw, 5.1P*25L			48	Slide Shaft A	E G 0813A0****	
22	Hexagon Socket Head Cap Screw	S S 620615CC00		49	Slide Shaft B	E G 0813B0****	
23	Spring Washer, M6			50	M6 Joint	E F 0827000000	
24	Plain Washer, M6			51	Hexagon Nut, M6		
25	Vibration—preventive Rubber A	E F 0833A00000		52	Hexagon Nut, counterclockwise M6		
26	Stand Stud Bolt	E F 0808000000		53	Needle Bar Drive Shaft A	E G 0812A0****	
27	Adjusting Bolt	E F 0809000000		54	Needle Bar Drive Shaft B	E G 0812B0****	
28	Hexagon Nut, M20			55	Rotary Hook Shaft Drive Shaft A	E G 0814A0****	
29	Vibration—preventive Base	E F 0810000000		56	Rotary Hook Shaft Drive Shaft B	E G 0814B0****	
30	Hexagon Socket Head Cap Screw	S S 620630CC00		57	Thread Trimming Shaft A	E G 0815A0****	
31	TAJIMA Brand Name Plate	E F 0814000000		58	Thread Trimming Shaft B	E G 0815B0****	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TMEG GENERAL VIEW

EG-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
62	Porcelain Enameled Set Screw	S S 8 2 0 6 0 8 T N 0 0					
63	Thread Stand Plate	E F 0 9 3 8 0 0 * * * *					
64	Thread Stand Stud	E F 0 9 3 7 0 0 * * * *					
65	Pan Head Screw	S S 4 1 0 4 1 0 S D 0 0					
66	Plain Washer, M4						
67	Thread Stand Stud	E F 0 9 3 9 0 0 0 0 0 0					
68	Plain Washer, M5						
69	Thread Stand Felt	E F 0 9 4 0 0 0 0 0 0 0					
70	Thread Course	E F 0 9 4 1 0 0 * * * *					
71	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 0 C C 0 0					
72	Thread Guide	E F 0 9 4 2 0 0 0 0 0 0					
73	Thread Course Thread Guide	E F 0 9 1 2 0 0 0 0 0 0					
74	Thread Course Tension Stud	E F 0 9 1 4 0 0 0 0 0 0					
75	Felt Packing	E F 0 9 0 4 0 0 0 0 0 0					
76	Thread Course Tension Disk	E F 0 9 1 3 0 0 0 0 0 0					
77	Thread Course Tension Spring	E F 0 9 1 5 0 0 0 0 0 0					
78	Square Pipe Blind Lid	E F 0 8 3 2 0 0 0 0 0 0					
79	Adjusting Screw	E F 0 9 0 9 0 0 0 0 0 0					
80	Hexagon Nut, 11/64*40						
81	Fluorescent Lamp	E G 7 4 0 1 0 0 * * * *					
82	Spring Washer, M5						
83	Rotary Encoder	E F 6 6 0 0 0 0 0 0 0 0					
84	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 8 C C 0 0					
85	Plain Washer, M3						
86	Vibration—preventive Rubber B	E F 0 8 3 3 B 0 0 0 0 0					
87	Hexagon Nut, M5						
88	Table	E G 0 8 0 2 0 3 * * * *					
89	Tension Base Bracket A	E F 0 9 2 5 A 1 0 0 0 0					
90	Tension Base Bracket B	E F 0 9 2 5 B 1 0 0 0 0					
91	Tension Base Bracket C	E F 0 9 2 5 C 1 0 0 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA


TMEG BOX A

EG-2a

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
2	Counter Gear Box	E F 0 1 0 2 0 0 0 0 0 0		34	Tension Roller	E G 0 1 1 8 0 0 0 0 0 0	
3	Hexagon Socket Head Cap Screw	S S 6 2 1 0 4 0 C C 0 0		35	Ball Bearing	6 2 0 2 Z Z 0 0 0 0 0 0	
4	Spring Washer, M10			36	Tension Bearing Case Bushing	E G 0 1 1 7 0 0 0 0 0 0	
5	Plain Washer, M10			37	Tension Bearing Case Shaft	E G 0 1 1 9 0 0 0 0 0 0	
6	No.1 Bearing Case A	E G 0 1 0 9 0 0 0 0 0 0		38	Porcelain Enameled Set Screw	S S 8 2 0 5 0 8 T N 0 0	
7	Hexagon Socket Head Cap Screw	S S 6 2 0 6 2 5 C C 0 0		39	Angle Pointer	E F 0 1 1 8 0 0 0 0 0 0	
8	Ball Bearing	6 0 0 4 Z Z 0 0 0 0 0 0		40	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 6 C C 0 0	
9	15mm Dia. Bearing Case Collar	E G 0 1 1 1 0 0 0 0 0 0		41	Plain Washer, M4		
10	Porcelain Enameled Set Screw	S S 8 2 0 6 0 8 T N 0 0		42	Bobbin Stand Base	E G 0 1 0 6 0 0 0 0 0 0	
11	Rotary Hook Shaft Drive Timing Pulley	E G 0 1 1 3 0 0 0 0 0 0		43	Bobbin Stand Shaft	E F 0 1 2 2 0 0 0 0 0 0	
13	Porcelain Enameled Set Screw	S S 8 2 0 8 0 8 T N 0 0		44	Spring Washer, M5		
14	No.1 Bearing Case B	E G 0 1 1 0 0 0 0 0 0 0		45	Hexagon Nut, M4		
15	Hexagon Socket Head Cap Screw	S S 6 2 0 6 2 0 C C 0 0		46	Hexagon Socket Head Cap Screw	S S 6 2 0 5 0 5 C C 0 0	
16	Driven Pulley	E G 0 1 0 8 0 0 0 0 0 0		47	Plain Washer, M5		
17	Hexagon Socket Head Cap Screw	S S 6 2 0 8 1 5 C C 0 0		48	Angle Indicator Disk	E F 0 1 2 3 0 0 0 0 0 0	
18	Rotary Hook Shaft Drive Shaft	E G 0 1 1 2 0 0 0 0 0 0		49	Main Gear Box Lid	E F 0 1 1 4 0 0 0 0 0 0	
19	Motor Belt	Y J 1 0 3 9 0 0 0 0 0 0		50	Operation Panel Stand Pipe	E G 0 1 0 2 0 0 0 0 0 0	
20	Counter Gear Box Cover	E F 0 1 1 4 0 0 0 0 0 0		51	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0	
21	Truss Head Screw	S S 0 1 0 5 0 8 C B 0 0		52	Operation Panel Bracket	E G 0 1 0 3 0 0 0 0 0 0	
22	No.2 Bearing Case	E F 0 1 0 4 0 0 0 0 0 0		53	Hexagon Socket Head Cap Screw	S S 6 2 0 5 0 8 C C 0 0	
23	15mm Dia. Bearing Case Collar	E F 0 1 0 6 0 0 0 0 0 0		54	Operation Panel Attaching Arm	E G 0 1 0 4 0 0 0 0 0 0	
24	Needle Bar Drive Shaft Timing Pulley	E G 0 1 1 4 0 0 0 0 0 0		55	Operation Panel Hinge Pin	E G 0 1 0 5 0 0 0 0 0 0	
26	Timing Belt	S 8 M 0 6 0 0 3 0 0 0 0		56	E-Ring, E-9		
27	Counter Gear Box Cover Side Plate	E F 0 1 1 6 0 0 0 0 0 0		57	Pan Head Screw	S S 4 1 0 5 1 2 S D 0 0	
28	Connecting Shaft Cover B	E F 0 8 1 8 B 0 * * * *		58	Knobbed Bolt, M10*20L		
29	Truss Head Screw	S M 0 1 0 9 0 4 C B 0 0		59	Main Gear Box	E G 0 1 0 1 0 3 0 0 0 0	
30	Tension Bearing Case Base	E G 0 1 1 6 0 0 0 0 0 0		59	Main Gear Box(Z-spec. Machine)	E G Z 1 0 1 0 3 0 0 0 0	
31	Spring Washer, M6						
32	Plain Washer, M6						
33	Tension Shaft Holder	E G 0 1 1 5 0 0 0 0 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TAJIMA

(9001)

TMEG BOX B (G-spec. Machine)

EG-2b

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
2	Counter Gear Box	E F G 1 0 2 0 0 0 0 0 0		34	Timing Belt	S 8 M 0 6 0 0 4 0 0 0 0	
3	Hexagon Socket Head Cap Screw	S S 6 2 1 0 4 0 C C 0 0		35	Tension Bearing Case Base	E G 0 1 1 6 0 0 0 0 0 0	
4	Spring Washer, M10			36	Spring Washer, M6		
5	Plain Washer, M10			37	Plain Washer, M6		
6	Square Pipe Support, Front	E G G 1 0 2 0 0 0 0 0 0		38	Tension Shaft Holder	E G 0 1 1 5 0 0 0 0 0 0	
7	Square Pipe Support, Front B	E F G 1 0 5 0 0 0 0 0 0		39	Tension Roller	E G G 1 0 7 0 0 0 0 0 0	
8	Square Pipe Support, Lower	E F G 1 0 3 0 0 0 0 0 0		40	Ball Bearing	6 2 0 2 Z Z 0 0 0 0 0 0	
9	No.1 Bearing Case A	E G G 1 0 3 0 0 0 0 0 0		41	Tension Bearing Case Bushing	E G 0 1 1 7 0 0 0 0 0 0	
10	Hexagon Socket Head Cap Screw	S S 6 2 0 6 3 5 C C 0 0		42	Tension Bearing Case Shaft	E G 0 1 1 9 0 0 0 0 0 0	
11	No.1 Bearing Presser	E G G 1 0 8 0 0 0 0 0 0		43	Porcelain Enameled Set Screw	S S 8 2 0 5 0 8 T N 0 0	
12	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0		44	Angle Pointer	E F 0 1 1 8 0 0 0 0 0 0	
13	Spring Washer, M4			45	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 6 C C 0 0	
14	Plain Washer, M4			46	Connecting Shaft Cover Attaching Base	E F G 1 1 2 0 0 0 0 0 0	
15	Ball Bearing	6 0 0 4 Z Z 0 0 0 0 0 0		47	Connecting Shaft Cover B	E F P 8 1 8 B 0 * * * *	
16	15mm Dia. Bearing Case Collar	E F 0 1 0 6 0 0 0 0 0 0		48	Truss Head Screw	S M 0 1 0 9 0 4 C B 0 0	
17	Porcelain Enameled Set Screw	S S 8 2 0 6 0 8 T N 0 0		49	Bobbin Stand Base	E G 0 1 0 6 0 0 0 0 0 0	
18	Rotary Hook Shaft Drive Timing Pulley	E G G 1 0 5 0 0 0 0 0 0		50	Bobbin Stand Shaft	E F 0 1 2 2 0 0 0 0 0 0	
20	Porcelain Enameled Set Screw	S S 8 2 0 8 0 8 T N 0 0		51	Hexagon Nut, M4		
21	No.1 Bearing Case B	E G 0 1 1 0 0 0 0 0 0 0		52	Spring Washer, M5		
22	Hexagon Socket Head Cap Screw	S S 6 2 0 6 2 0 C C 0 0		53	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 0 C C 0 0	
23	15mm Dia. Bearing Case Collar	E G 0 1 1 1 0 0 0 0 0 0		54	Plain Washer, M5		
24	Driven Pulley	E G 0 1 0 8 0 0 0 0 0 0		55	Angle Indicator Disk	E F 0 1 2 3 0 0 0 0 0 0	
25	Hexagon Socket Head Cap Screw	S S 6 2 0 8 1 5 C C 0 0		56	Main Gear Box Cover	E F G 1 0 8 0 0 0 0 0 0	
26	Rotary Hook Shaft Drive Shaft	E G G 1 0 4 0 0 0 0 0 0		57	Operation Panel Stand Pipe	E G 0 1 0 2 0 0 0 0 0 0	
27	Motor Belt	Y J 1 0 3 9 0 0 0 0 0 0		58	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0	
28	Counter Gear Box Cover	E F G 1 0 9 0 0 0 0 0 0		59	Operation Panel Bracket	E G 0 1 0 3 0 0 0 0 0 0	
29	Truss Head Screw	S S 0 1 0 5 0 8 C B 0 0		60	Hexagon Socket Head Cap Screw	S S 6 2 0 5 0 8 C C 0 0	
30	No.2 Bearing Case B Cover	E F G 1 1 0 0 0 0 0 0 0 0		61	Operation Panel Attaching Arm	E G 0 1 0 4 0 0 0 0 0 0	
31	No.2 Bearing Case	E F 0 1 0 4 0 0 0 0 0 0		62	Operation Panel Hinge Pin	E G 0 1 0 5 0 0 0 0 0 0	
32	Needle Bar Drive Shaft Timing Pulley	E G G 1 0 6 0 0 0 0 0 0		63	E-Ring, E-9		

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TMEG BOX B (G-spec. Machine)

E G - 2 b

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(9001)

TMEG ROTARY HOOK BASE

EG-3

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
3	Needle Plate Set Screw	S M 2 0 1 1 0 8 C A 0 0		35	M6 Joint	E F 0 8 2 7 0 0 0 0 0 0	
4	Spiral Bevel Gear A	E F 0 2 0 3 0 0 0 0 0 0		36	Hexagon Nut, M6		
5	Spiral Bevel Gear B	E F 0 2 0 4 0 0 0 0 0 0		37	Hexagon Nut, counterclockwise, M6		
6	Porcelain Enameled Set Screw	S S 8 2 0 6 0 6 T N 0 0		38	Thread Trimming Shaft	E F 0 8 2 5 0 0 * * * *	
7	Rotary Hook Shaft	E F 0 2 0 5 0 0 0 0 0 0		40	Plain Washer, M4		
8	Rotary Hook Shaft Bushing	E F 0 2 0 6 0 0 0 0 0 0		47	Knife Drive Arm	A T 0 2 0 5 0 0 0 0 0 0	
9	Rotary Hook Base Stud	E F 0 2 0 7 0 0 0 0 0 0		48	Knife Connecting Lever	A T 0 2 0 7 0 0 0 0 0 0	
10	Hexagon Nut, M8			57	Hexagon Nut, M3		
11	Plain Washer (Large), M8			61	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 5 C C 0 0	
12	Spring Washer, M8			63	Rotary Hook Base(Encoder not installed)	E G 0 2 0 1 A 0 0 0 0	
13	15mm Dia. Needle Collar	E F 0 2 0 8 0 0 0 0 0 0		63	Rotary Hook Base(Encoder installed)	E G 0 2 0 1 B 0 0 0 0	
14	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0		63	Rotary Hook Base (For Middle-sized Hook)	E G C 2 0 1 A 0 0 0 0	
15	7.94mm Dia. Collar	E F 0 2 0 9 0 0 0 0 0 0		63	Rotary Hook Base (For Middle-sized Hook)	E G C 2 0 1 B 0 0 0 0	
16	Porcelain Enameled Set Screw	S M 8 2 1 1 0 4 T N 0 0		64	Needle Plate	E G 0 2 0 2 1 0 * * * *	
17	Rotary Hook	M E 0 5 0 5 0 0 * * * *		65	Knife Base	E G 0 2 0 3 0 0 0 0 0 0	
18	Rotary Hook Set Screw, 11/64*40*4.3			66	Hexagon Socket Head Cap Screw	E G 0 2 1 9 0 0 0 0 0 0	
19	Rotary Hook Support	E F 0 2 1 0 0 0 * * * *		67	Fixed Knife	E G 0 2 4 0 0 0 0 0 0	EG 0204000000
20	Rotary Hook Shaft Set Screw	S M 6 0 1 1 0 9 S N 0 0		68	Knife Drive Shaft Set	E G 0 2 0 5 0 0 0 0 0 0	
21	Bobbin	M E 0 5 0 4 0 0 * * * *		69	Knife Drive Shaft	E G 0 2 0 5 1 0 0 0 0 0	
22	Bobbin Case	M E 0 5 0 3 0 0 * * * *		70	Knife Guide Pin	E G 0 2 0 5 2 0 0 0 0 0	
23	Needle Plate Hole Collar	E F 0 2 0 2 2 0 0 0 0 0		71	Under Thread Presser	E G 0 2 0 6 0 0 0 0 0 0	
24	Needle Plate Hole Seal	E F 0 2 0 2 3 0 * * * *		72	Pan Head Screw, M1.4*1.4L		
25	Needle Bearing	H K 0 1 8 1 2 0 0 0 0 0		73	Plain Washer, M1.4		
27	Porcelain Enameled Set Screw	S S 8 2 0 3 0 3 T N 0 0		74	Connecting Shaft Holder	E G 0 2 7 0 0 0 0 0 0	
29	Pan Head Screw	S S 4 1 0 3 0 6 M Z 0 0		75	Presser Bracket	E G 0 2 0 8 0 0 0 0 0 0	
30	Movable Knife	A T 0 2 0 4 0 0 0 0 0 0		76	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 4 C C 0 0	
31	Countersunk Head Screw	S S 1 1 0 3 0 8 M Z 0 0		77	Porcelain Enameled Set Screw	S S 8 2 0 6 0 5 T N 0 0	
32	Connecting Lever Pin	A T 0 2 0 6 0 0 0 0 0 0		78	Solenoid Cover	E G 0 2 1 0 0 0 0 0 0 0	
33	Connecting Stud	A T 0 2 0 8 0 0 0 0 0 0		79	Pan Head Screw	S S 4 1 0 3 0 4 M Z 0 0	
34	Hexagon Socket Head Cap Screw	S S 6 2 0 4 1 0 C C 0 0		80	Bushing	E G 0 2 1 1 0 0 0 0 0 0	


Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

* please follow our instructions on Table of Contents, in your parts order.

**TAJIMA**

(8906)

TMEG COLOR CHANGE SYSTEM

EG-4

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Color Change Box	M S 0 4 0 1 0 0 0 0 0 0		31	Dry Bearing	M B 0 1 0 1 0 D U 0 0 0	
2	Hexagon Socket Head Cap Screw	S S 6 2 0 8 3 0 C C 0 0		32	Tension Release Driven Pulley	E F 0 9 4 5 0 0 0 0 0 0	
3	Spring Washer, M8			33	Tension Release Driven Gear	M S 0 4 1 1 0 0 0 0 0 0	
4	Plain Washer, M8			34	Tension Release Drive Shaft	M S 0 4 0 4 0 0 # # # #	
5	Color Change Motor	E G 7 1 0 1 0 0 0 0 0 0		35	10mm Dia. Collar	E F 0 9 2 4 0 0 0 0 0 0	
6	Gear Head	3 G K 0 1 8 H K 0 0 0 0		36	Cam Shaft	M S 0 4 0 2 0 0 # # # #	
7	Pan Head Screw	S S 4 1 0 5 5 0 S D 0 0		37	Cam Shaft Bushing	E F 0 4 0 7 0 0 0 0 0 0	
8	Motor Gear	E F 0 4 1 0 0 0 0 0 0 0		38	Color Change Cam Set	E F 0 4 0 5 0 0 # # # #	
9	Porcelain Enameled Set Screw	S S 8 2 0 5 0 6 T N 0 0		39	Tension Release Drive Gear	M S 0 4 1 0 0 0 0 0 0 0	
10	Change Cover	E G 0 4 0 4 0 0 0 0 0 0		40	Hexagon Socket Head Cap Screw	S S 6 2 0 6 1 0 C C 0 0	
11	Truss Head Screw	S M 0 1 0 9 0 5 S A 0 0		41	Cam Pin	E F 0 4 0 3 0 0 0 0 0 0	
12	Rotary Switch Assembly	M S 7 1 0 2 0 0 0 0 0 0		42	Cam Roller	E F 0 4 0 4 0 0 0 0 0 0	
13	Rotary Switch Stay	M S 0 4 0 9 0 0 0 0 0 0		43	E-Ring, E-3		
14	Rotary Switch Pin	M S 0 4 0 7 0 0 0 0 0 0		44	Cam Roller Set	E F 0 4 0 4 S 0 0 0 0 0	
15	Porcelain Enameled Set Screw	S S 8 2 0 3 0 3 T N 0 0		45	Slide Boss	E F 0 4 0 2 0 0 0 0 0 0	
16	8mm Dia. Collar	E F 0 4 1 8 0 0 0 0 0 0		46	Slide Bearing	L M E 1 2 2 2 3 2 2 0 0	
17	Half-turn Gear Bushing	E F 0 4 1 5 0 0 0 0 0 0		47	Hexagon Nut, M6		
18	Porcelain Enameled Set Screw	S S 8 2 0 4 0 6 T N 0 0		48	Spring Washer, M6		
19	Half-turn Gear	E F 0 4 1 4 0 0 0 0 0 0		49	Belt Joint Plate	E F 0 4 2 9 0 0 0 0 0 0	
20	One-rotation Switch Collar	E G 0 4 0 1 0 0 0 0 0 0		50	Needle Position Indicator Belt	E F 0 4 2 6 0 0 # # # #	
21	Rotary Switch Gear	M S 0 4 0 8 0 0 0 0 0 0		51	Pan Head Screw	S S 4 1 0 4 0 6 S D 0 0	
22	Photo-interrupter Base	E G 0 4 0 2 0 0 0 0 0 0		52	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 5 C C 0 0	
23	Photo-interrupter Assembly	E G 7 1 0 2 0 0 0 0 0 0		53	Plain Washer, M3		
24	Round Head Screw	S S 3 1 0 3 0 8 S E 0 0		54	Base Split Collar	E F 0 4 3 0 0 0 0 0 0 0	
25	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0		55	Roller Base	E F 0 4 2 7 0 0 0 0 0 0	
26	Plain Washer, M4			56	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 6 C C 0 0	
27	Change Cover Stud	M S 0 4 1 4 0 0 0 0 0 0		57	Roller	E F 0 4 2 5 0 0 0 0 0 0	
28	Hexagon Nut, M5			58	Hexagon Socket Head Cap Screw	S S 6 2 0 3 1 5 C C 0 0	
29	Porcelain Enameled Set Screw	S S 8 2 0 4 0 4 T N 0 0		59	Roller Pin	E F 0 4 2 8 0 0 0 0 0 0	
30	Cover Base Stud	M S 0 9 0 5 0 0 0 0 0 0		60	Guide Shaft	E F 0 4 0 8 0 0 # # # #	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG COLOR CHANGE SYSTEM

E G - 4

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TMEG ARM

EG-5

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
2	Hexagon Socket Head Cap Screw	S S 6 2 0 8 3 0 C C 0 0		34	Bracket Base	E F 0 5 3 7 0 0 0 0 0 0	
3	Spring Washer, M8			35	Solenoid Bracket	E F 0 5 3 6 0 0 0 0 0 0	
4	Plain Washer, M8			36	Hexagon Nut, M9*P0.75		
5	Positioning Base Set Screw	E F 0 5 4 5 0 0 0 0 0 0		37	Jump Solenoid	E F 6 8 0 1 0 1 0 0 0 0	
6	Plain Washer, M4			38	Hexagon Socket Head Cap Screw	S S 6 2 0 4 1 0 C C 0 0	
7	Positioning Base	E F 0 5 4 3 0 0 0 0 0 0		39	Hexagon Socket Head Cap Screw	S M 6 2 1 1 1 5 C C 0 0	
8	Positioning Plate	E F 0 5 4 4 0 0 0 0 0 0		40	Round Countersunk Head Screw	S M 2 0 0 9 0 6 S D 0 0	
9	Flat Fillister Head Screw	S S 6 0 0 3 0 8 S C 0 0		41	Connecting Shaft Cover	E F 0 8 1 8 0 0 * * * *	
10	Positioning Plate Set Screw	E F 0 5 4 6 0 0 0 0 0 0		42	Truss Head Screw	S M 0 1 0 9 0 4 S D 0 0	
11	Truss Head Screw	S M 0 1 0 9 0 6 C D 0 0		43	Solenoid Cover Set	E F 0 5 3 8 S 0 0 0 0 0	
13	Flat Fillister Head Screw	S M 6 0 0 9 0 7 S C 0 0		44	Solenoid Cover	E F 0 5 3 8 0 0 0 0 0 0	
14	Take-up Lever Guide Rail	E F 0 5 1 4 0 0 # # # #		45	Clutch Pin	E F 0 5 4 0 0 0 0 0 0 0	
15	Take-up Lever Rail Holder L	E F 0 5 4 8 L 0 # # # #		46	Clutch Knurled Screw	E F 0 5 3 9 0 0 0 0 0 0	
16	Take-up Lever Rail Holder R	E F 0 5 4 8 R 0 # # # #		47	Porcelain Enameled Set Screw	S S 8 2 0 3 0 3 T N 0 0	
17	Hexagon Nut, 9/64*40			48	Stopper Plate Spring	E F 0 5 4 1 0 0 0 0 0 0	
18	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 6 C C 0 0		49	Pan Head Screw	S S 4 1 0 3 0 4 C D 0 0	
19	Hexagon Nut, M3			50	E-Ring, E-5		
20	Cord Cramp	E F 0 5 5 2 0 0 0 0 0 0		51	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 6 C C 0 0	
21	Flat Fillister Head Screw	S S 6 0 0 3 1 5 C B 0 0		52	Bearing Case	E F 0 5 0 2 0 0 0 0 0 0	
22	Porcelain Enameled Set Screw	S M 8 2 1 1 0 8 T N 0 0		53	Hexagon Socket Head Cap Screw	S S 6 2 0 5 0 8 C C 0 0	
23	Needle Bar Drive Shaft Collar	E F 0 5 4 7 0 0 0 0 0 0		54	Ball Bearing	6 0 0 4 Z Z 0 0 0 0 0 0	
24	Slotted Set Screw	S M 8 0 0 8 0 4 C C 0 0		55	C-shaped Hole Stopper Ring, 42		
25	Ball Bearing	6 8 9 0 0 0 0 0 0 0 0 0		56	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0	
26	Arm Front Cover	E F 0 5 2 3 0 0 0 0 0 0		57	Needle Bar Cam Tightening Collar	E F 0 5 0 8 0 0 0 0 0 0	
27	Flat Fillister Head Screw	S M 6 0 1 1 0 7 S C 0 0		58	Flat Fillister Head Screw, 11/64*11.5L		
28	Arm Rail, Upper	E F 0 5 2 6 0 0 # # # #		59	Take-up Lever Drive Lever Pin	E F 0 5 1 8 0 0 0 0 0 0	
29	Slide Roller	E F 0 5 5 3 0 0 # # # #		60	Take-up Lever Drive Lever A	E F 0 5 1 5 0 0 0 0 0 0	
30	Flat Fillister Head Screw	S M 6 0 1 1 1 2 S C 0 0		61	Plain Washer, M5		
31	Spring Pin, 3P*12L			62	Cam Roller Pin	E F 0 5 1 9 0 0 0 0 0 0	
32	Arm Side Cover B	E F 0 5 2 5 0 0 0 0 0 0		63	Cam Roller	E F 0 5 2 0 0 0 0 0 0 0	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TMEG ARM

EG-5

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
64	Take-up Lever Drive Lever B	E F 0 5 1 6 0 0 0 0 0 0		94	Stopper	E F 0 5 3 3 0 0 0 0 0 0	
65	Take-up Lever Drive Gear	E F 0 5 1 7 0 0 0 0 0 0		95	Flat Fillister Head Screw	S M 6 0 0 9 1 0 C C 0 0	
66	Pan Head Screw	S S 4 1 0 3 0 8 S D 0 0		96	Needle Bar Drive Shaft	E F 0 5 2 7 0 0 0 0 0 0	
67	8mm Dia. Collar	E F 0 4 1 8 0 0 0 0 0 0		97	Reciprocator Spacer	E F 0 5 5 4 0 0 0 0 0 0	
68	Porcelain Enameled Set Screw	S S 8 2 0 4 0 5 T N 0 0		98	Plain Washer, M3		
69	Needle Bar Driver Set	E F 0 5 0 4 S 0 0 0 0 0 0 或		99	Hexagon Nut, M5		
70	Needle Bar Drive Cam	E F 0 5 0 4 0 0 0 0 0 0 次		100	Spring Washer, M4		
71	Needle Cage	K 3 8 4 1 8 8 X 0 0 0 0		101	Oiling Hole Felt	E F 0 5 4 9 0 0 0 0 0 0	
72	Connecting Rod	E F 0 5 0 5 0 0 0 0 0 0		102	Needle Bar Drive Shaft Felt	E F 0 5 5 0 0 0 0 0 0 0	
73	Take-up Lever Cam Base	E F 0 5 0 7 0 0 0 0 0 0		104	Arm Side Cover A	E F 0 5 2 4 0 1 0 0 0 0	
74	Countersunk Head Screw	S M 1 0 0 9 1 0 S C 0 0		105	Arm	E F 0 5 0 1 0 1 0 0 0 0	
75	Take-up Lever Drive Cam	E F 0 5 0 6 0 0 0 0 0 0		106	Arm Top Cover	E F 0 5 2 1 0 1 0 0 0 0	
76	Cam Washer	E F 0 5 2 2 0 0 0 0 0 0					
77	Needle Bar Driver	E F 0 5 0 3 0 0 0 0 0 0					
78	Thrust Washer	E F 0 5 4 2 0 0 0 0 0 0					
79	Needle Cage	K 8 1 1 8 T 2 0 0 0 0 0					
80	No.2 Pin	E F 0 5 1 0 0 0 0 0 0 0					
81	No.1 Pin	E F 0 5 0 9 0 0 0 0 0 0					
82	No.3 Pin	E F 0 5 1 1 0 0 0 0 0 0					
83	Needle Bar Drive Connecting Rod	E F 0 5 1 3 0 0 0 0 0 0					
84	Flat Fillister Head Screw	S M 6 0 0 9 0 8 C C 0 0					
85	Needle Bar Reciprocator Set	E F 0 5 3 2 S 0 0 0 0 0					
86	Needle Bar Drive Shaft Bushing	E F 0 5 2 9 0 0 0 0 0 0					
87	Jump Spring	E F 0 5 3 0 0 0 0 0 0 0					
88	Spring Cradle	E F 0 5 3 1 0 0 0 0 0 0					
89	Needle Bar Reciprocator	E F 0 5 3 2 0 0 0 0 0 0					
90	Needle Bar Reciprocator Slide Block	E F 0 5 2 8 0 0 0 0 0 0					
91	No.4 Pin	E F 0 5 1 2 0 0 0 0 0 0					
92	Flat Fillister Head Screw	S M 6 0 0 8 0 6 C C 0 0					
93	Stopper Bracket	E F 0 5 3 4 0 0 0 0 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(9001)

TMEG NEEDLE BAR CASE

EG-6


Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Needle Bar Case	E F 0 6 0 1 0 0 # # # #		31	Cushion Rubber B	E F 0 6 2 7 0 0 # # # #	
2	Take-up Lever Shaft	E F 0 6 0 2 0 0 # # # #		32	Upper Thread Guide	E F 0 6 2 8 0 0 # # # #	
3	Take-up Lever	E F 0 6 0 4 0 0 0 0 0 0		33	Countersunk Head Screw	S S 1 1 0 3 0 6 S D 0 0	
4	Take-up Lever Adjusting Bushing	E F 0 6 0 5 0 0 0 0 0 0		34	Middle Thread Guide	E F 0 6 2 9 0 0 # # # #	
5	Take-up Lever Positioning Bushing	E F 0 6 0 6 0 0 0 0 0 0		35	Round Countersunk Head Screw	S M 2 0 0 9 0 4 S B 0 0	
6	Needle Bar Guide Rail	E F 0 6 0 7 0 0 # # # #		36	Lower Thread Guide	E F 0 6 3 0 0 0 # # # #	
7	Flat Fillister Head Screw	S M 6 0 0 9 0 5 S C 0 0		37	Round Countersunk Head Screw	S M 2 0 0 9 0 6 S D 0 0	
8	Color Change Bracket R	E F 0 6 0 8 R 0 0 0 0 0		38	Upper Thread Guide Bracket R	E F 0 6 3 2 R 0 0 0 0 0	
9	Hexagon Socket Head Cap Screw	S S 6 2 0 4 2 0 C C 0 0		39	Pan Head Screw	S S 4 1 0 3 0 5 S D 0 0	
10	Color Change Bracket L	E F 0 6 0 8 L 0 0 0 0 0		40	Upper Thread Guide Bracket L	E F 0 6 3 2 L 0 0 0 0 0	
11	Case Rail, Upper	E F 0 6 0 9 0 0 # # # #		41	Guide Roller Base	E F 0 6 3 3 0 0 # # # #	
12	Hexagon Socket Head Cap Screw	S S 6 2 0 5 2 3 C C 0 0		42	Top Cover	E F 0 6 3 4 0 0 # # # #	
13	Case Rail, Lower	E F 0 6 1 0 0 0 # # # #		43	Truss Head Screw	S M 0 1 0 9 0 6 S D 0 0	
14	Needle Bar	E F 0 6 1 1 0 0 0 0 0 0		44	Face Plate	E F 0 6 3 5 0 0 # # # #	
15	Needle Bar Connecting Stud	E F 0 6 1 2 0 0 0 0 0 0		45	Plain Washer, M4		
16	Flat Fillister Head Screw	S M 6 0 0 9 0 7 S C 0 0		46	Thread Suspender Attaching Screw	E F 0 6 3 6 0 0 0 0 0 0	
17	Presser Foot	E F 0 6 1 3 0 0 0 0 0 0		47	Thread Suspender Disk	E F 0 6 3 7 0 0 0 0 0 0	
18	Presser Foot Spring	E F 0 6 1 4 0 0 * * * *		48	Thread Suspender Spring Presser	E F 0 6 3 8 0 0 0 0 0 0	
19	Needle Set Screw	E F 0 6 1 5 0 0 0 0 0 0		49	Thread Suspender Spring	E F 0 6 3 9 0 0 0 0 0 0	
20	Needle Cramp	E F 0 6 1 6 0 0 0 0 0 0		50	Ball Bearing	L 9 4 0 Z Z 0 0 0 0 0 0	
21	Upper Dead Point Stopper	E F 0 6 1 7 0 0 0 0 0 0		51	E-Ring, E-3		
22	Flat Fillister Head Screw	S M 6 0 0 9 0 8 S C 0 0		52	Presser Foot Adjusting Rubber	E F 0 6 2 5 0 0 * * * *	
23	Needle Bar Holding Spring	E F 0 6 1 8 0 0 0 0 0 0		53	Thread Hook Spring	E F 0 6 3 1 0 0 # # # #	
24	Spring Shoe Washer	E F 0 6 1 9 0 0 0 0 0 0		54	Pan Head Screw	S S 4 1 0 4 0 8 S D 0 0	
25	Holding Spring Set Screw	E F 0 6 2 0 0 0 0 0 0 0		55	Pan Head Screw	S S 4 1 0 4 1 5 S D 0 0	
26	Needle Bar O-Ring	E F 0 6 2 1 0 0 0 0 0 0		56	Hexagon Nut, M4		
27	Presser Foot Positioning Spacer	E F 0 6 2 2 0 0 # # # #		57	Porcelain Enameled Set Screw	S S 8 2 0 5 0 6 T N 0 0	
28	Felt Packing	E F 0 6 2 3 0 0 # # # #		58	Flat Fillister Head Screw	S M 6 0 0 9 1 0 C C 0 0	
29	Cushion Rubber	E F 0 6 2 4 0 0 # # # #					
30	Cushion Rubber A	E F 0 6 2 6 0 0 # # # #					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG UPPER THREAD LOCKING DEVICE (E-SPEC.)

E G - 7



TAJIMA

(9001)


TMEG UPPER THREAD LOCKING DEVICE (E - SPEC.)

EG - 7

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Arm Side Cover A	E G 1101010000		35	Drive Shaft	E G 111402####	
2	Round Countersunk Head Screw	S M 200906SD00		36	Presser Shaft	E G 111502####	
3	Presser Base	E G 1107010000		37	Face Plate	E G 111701####	
4	Hexagon Socket Head Cap Screw	S S 620408CC00					
5	Spring Washer, M4						
6	Plain Washer, M4						
7	Upper Thread Locking Solenoid	A T 6804000000					
8	Solenoid Fixing Pipe	E G 1108010000					
9	Countersunk Head Screw	S S 110408SD00					
10	Solenoid Lever	E G 1109000000					
11	Hexagon Socket Head Cap Screw	S S 620308CC00					
12	Solenoid Lever Pin	S P 0311000000					
13	Presser Drive Arm	E G 1111000000					
14	Presser Arm	E G 1110010000					
15	Hexagon Socket Head Cap Screw	S S 620310CC00					
16	Shaft Support L	E G 1112L20000					
17	Shaft Support R	E G 1112R20000					
19	Hexagon Socket Head Button Screw	S S 320306CN00					
21	Thread Holder Bracket L	E G 1103020000					
22	Thread Holder Bracket R	E G 1104020000					
23	Shaft Screw	E G 1116000000					
24	Truss Head Screw	S M 010906SA00					
25	Thread Suspender Attaching Screw	A T 2311000000					
26	Thread Suspender Spring Presser	E F 0638000000					
27	Thread Suspender Spring	E F 0639000000					
28	Thread Suspender Disk Large	E F 0637000000					
29	Thread Presser Base	E G 1102000000					
30	Pan Head Screw	S S 410305MZ00					
32	Upper Thread Presser Rubber	E G 110602####					
34	Lower Thread Guide	E G 110504####					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(8906)

TMEG UPPER THREAD HOLDER SET

EG-8

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Upper Thread Holder Bracket R	A T 0 3 0 1 R 1 0 0 0 0		31	Assembly Base	A T 1 3 0 1 0 0 0 0 0 0	
2	Upper Thread Holder Bracket L	A T 0 3 0 1 L 1 0 0 0 0		32	Hexagon Nut, M3		
3	Truss Head Screw	S M 0 1 0 9 0 4 S A 0 0		33	Arm Cushion	A T 1 3 0 9 0 0 0 0 0 0	
4	Thread Suspender Disk	E F 0 6 3 7 0 0 0 0 0 0		34	Cushion Pin B	A T 1 3 0 6 0 0 0 0 0 0	
5	Thread Suspender Spring	E F 0 6 3 9 0 0 0 0 0 0		35	Upper Thread Holder Clutch	A T 1 3 0 5 0 0 0 0 0 0	
6	Thread Suspender Spring Presser	E F 0 6 3 8 0 0 0 0 0 0		36	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0	
7	Thread Suspender Attaching Screw	E F 0 6 3 6 0 0 0 0 0 0					
8	Pan Head Screw	S S 4 1 0 3 0 4 M Z 0 0					
9	Thread Presser Base	A T 0 3 0 2 0 0 0 0 0 0					
10	Pan Head Screw	S S 4 1 0 3 0 8 S A 0 0					
11	Thread Presser Spacer	A T 0 3 0 4 0 0 0 0 0 0					
12	Thread Presser Lid	A T 0 3 0 3 0 0 0 0 0 0					
13	Magic Tape	A T 0 3 0 5 0 0 0 0 0 0					
14	Lever Connecting Pin	A T 0 3 0 9 0 0 0 0 0 0					
15	Arm Connecting Rod	A T 0 3 0 6 0 0 0 0 0 0					
16	Special Nut	A T 0 3 0 7 0 0 0 0 0 0					
17	Upper Thread Hook	A T 1 3 0 3 0 0 0 0 0 0					
18	Base Lid A	A T 1 3 0 2 0 0 0 0 0 0					
19	Hook Cushion C	A T 1 3 0 7 0 0 0 0 0 0					
20	Hook Cushion D	A T 1 3 0 8 0 0 0 0 0 0					
21	Pan Head Screw	S S 4 1 0 3 0 6 S A 0 0					
22	Hexagon Nut, 9/64*40						
23	Thread Holding Solenoid	A T 6 8 0 1 A 0 0 0 0 0					
24	Hexagon Nut, M4						
25	Spring Washer, M4						
26	Solenoid Base	A T 1 3 0 4 0 0 0 0 0 0					
27	Pan Head Screw	S S 4 1 0 4 0 6 M Z 0 0					
28	Plain Washer, M4						
29	Solenoid Arm	A T 0 3 0 8 0 0 0 0 0 0					
30	Porcelain Enameled Set Screw	S S 8 2 0 4 0 4 T N 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG CAM DRIVER SET

EG-9

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
2	Cam Roller Return Spring	A T 0 1 0 8 0 0 0 0 0 0		32	Thread Trimming Base Shaft	A T 0 1 1 5 0 0 0 0 0 0	
3	Washer B	A T 0 1 2 2 0 0 0 0 0 0		33	Cushion Connecting Stud	A C 0 4 0 5 0 0 0 0 0 0	
4	Cushion Washer A	A T 0 1 0 7 0 0 0 0 0 0		34	O-Ring, S-10		
5	E-Ring, E-12			35	Cam	A T 0 1 0 3 0 0 0 0 0 0	
6	7.94mm Dia. Collar	E F 0 2 0 9 0 0 0 0 0 0		36	Cam Attaching Screw	A T 0 1 2 3 0 0 0 0 0 0	
7	Porcelain Enameled Set Screw	S S 8 2 0 4 0 4 T N 0 0		37	Cam Set Slotted Screw	S M 8 0 1 8 1 2 C C 0 0	
8	Cushion Washer B	A T 0 1 1 6 0 0 0 0 0 0		38	Cam Shaft	A T 0 1 0 2 0 0 0 0 0 0	
9	Solenoid Base	A T 1 1 0 5 0 0 0 0 0 0		39	Thrust Bearing Set, PL1528, S1528		
10	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 2 C C 0 0		40	15mm Dia. Sprocket	A T 0 1 0 4 0 0 0 0 0 0	
11	Spring Washer, M5			41	Hexagon Socket Head Cap Screw	S S 6 2 0 6 1 0 C C 0 0	
12	Thread Trimming Solenoid	A T 6 8 0 2 A 0 0 0 0 0		42	Roller Chain	A T 1 1 0 8 0 0 0 0 0 0	
13	Solenoid Cushion	A T 0 1 1 9 0 0 0 0 0 0		44	Tension Sprocket	A T 0 1 1 7 0 0 0 0 0 0	
14	Plunger Bracket	A T 0 1 2 0 0 0 0 0 0 0		45	Tension Pin	A T 0 1 1 8 0 0 0 0 0 0	
15	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0		46	Porcelain Enameled Set Screw	S S 8 2 0 5 0 6 T N 0 0	
16	Plunger Holder	A T 0 1 2 1 0 0 0 0 0 0		47	Hexagon Socket Head Cap Screw	S S 6 2 0 6 2 0 C C 0 0	
17	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0		48	Cam Base Cover	A T 1 1 0 3 0 0 0 0 0 0	
18	Spring Washer, M4			49	Truss Head Screw	S S 0 1 0 5 0 8 S D 0 0	
19	Plain Washer, M4			50	Hexagon Socket Head Cap Screw	S S 6 2 0 8 2 5 C C 0 0	
20	Cam Lever	A T 0 1 0 5 0 0 0 0 0 0		51	Spring Washer, M8		
21	Cam Pin	A T 0 1 1 0 0 0 0 0 0 0		52	Slant Washer, M8		
22	Cam Roller	A T 0 1 1 1 0 0 0 0 0 0		53	Cam Base Spacer	A T 1 1 0 7 0 0 * * * *	
23	Lid Screw	A T 0 1 1 2 0 0 0 0 0 0		54	Rotary Hook Shaft Holder	A T 1 1 0 4 0 0 0 0 0 0	
24	Hexagon Nut, M6			55	Spring Washer, M6		
25	Plain Washer, M6			56	Rotary Hook Base Shaft Holder	A T 1 1 0 6 0 0 0 0 0 0	
26	Lever Support Pin	A T 0 1 0 6 0 0 0 0 0 0		57	15mm Dia. Needle Collar	E F 0 2 0 8 0 0 0 0 0 0	
27	Lever Fixing Washer	A T 0 1 0 9 0 0 0 0 0 0		58	Porcelain Enameled Set Screw	S S 6 2 0 5 0 5 T N 0 0	
28	Sprocket Fixing Screw	A T 0 1 2 4 0 0 0 0 0 0		59	Porcelain Enameled Set Screw	S S 8 2 0 6 0 6 T N 0 0	
29	Guide Pin	A T 0 1 1 4 0 0 0 0 0 0		60	Chain Cover	E F 0 8 0 6 0 0 0 0 0 0	
30	Lever Drive Pin	A T 0 1 1 3 0 0 0 0 0 0		61	Countersunk Head Wood Screw, 3.1P*16L		
31	Hexagon Socket Head Cap Screw	S S 6 2 0 5 2 0 C C 0 0		62	Cam Base Bracket	A T 1 1 0 1 0 0 0 0 0 0	


Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

[illegible]

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(9001)

TMEG X - AXIS DRIVER

E G - 10 - 1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
3	Hexagon Socket Head Cap Screw	S S 6 2 0 8 3 5 C C 0 0		26	Tension Spacer	E G 0 7 1 2 0 0 0 0 0 0	
4	Spring Washer, M8			27	Tension Plate	E G 0 7 0 8 0 0 0 0 0 0	
5	Plain Washer, M8			27	Tension Plate (G-spec. Machine)	E G G 7 0 8 0 0 0 0 0 0	
6	Driver Spacer A	E F 0 8 2 9 0 0 * * * *		28	Plain Washer, M4		
7	X-axis Frame Rail A	E F 0 7 0 4 A 0 * * * *		29	Hexagon Bolt	S S 9 3 0 6 6 5 S D 0 0	
8	X-axis Frame Rail B	E F 0 7 0 4 B 0 * * * *		30	Hexagon Nut, M6		
9	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0		31	Slide Base	E G 0 7 2 6 0 0 * * * *	
10	Spring Pin, 4P*12L			32	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0	
11	Tension Base	E G 0 7 0 7 0 0 0 0 0 0		33	Fixture Base	E G 0 7 3 0 0 0 0 0 0	
11	Tension Base (G-spec. Machine)	E G G 7 0 7 0 0 0 0 0 0		34	Limit Switch Base R	E G 0 7 2 7 R 0 0 0 0 0	
12	Hexagon Bolt	S S 9 3 0 5 1 5 S D 0 0		35	Limit Switch Base L	E G 0 7 2 7 L 0 0 0 0 0	
13	Tension Liner	E G 0 7 1 0 0 0 0 0 0 0		36	Adjusting Knob	E G 0 7 3 1 0 0 0 0 0 0	
14	Tension Rivet Plate	E G 0 7 0 9 0 0 0 0 0 0		37	Limit Switch	M S 6 6 0 1 0 0 0 0 0 0	
14	Tension Rivet Plate (G-spec. Machine)	E G G 7 0 9 0 0 0 0 0 0		38	Actuator	M S 6 6 0 2 0 0 0 0 0 0	
15	Countersunk Head Screw	S S 1 1 0 4 1 0 S D 0 0		39	Pan Head Screw	S S 4 1 0 3 1 4 S D 0 0	
16	Tension Bearing Case B	E G 0 7 0 6 B 0 0 0 0 0		42	Hexagon Socket Head Cap Screw	S S 6 2 0 6 1 5 C C 0 0	
16	Tension Shaft Holder	E G G 7 0 6 0 0 0 0 0 0		46	Needle Bearing	H K 0 1 8 1 2 0 0 0 0 0	
17	Hexagon Bolt	S S 9 3 0 5 2 0 S D 0 0		47	15mm Dia. Needle Collar	E F 0 2 0 8 0 0 0 0 0 0	
18	Spring Washer, M5			48	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0	
19	Plain Washer, M5			49	Driver-side Timing Pulley	E F 0 7 0 5 0 0 0 0 0 0	
20	Tension Shaft	E G 0 7 1 1 0 0 0 0 0 0		49	Driver-side Timing Pulley (G-spec.)	E F G 7 0 5 0 0 0 0 0 0	
20	Tension Shaft (G-spec. Machine)	E G G 7 1 1 0 0 0 0 0 0		50	Porcelain Enameled Set Screw	S S 8 2 0 6 0 6 T N 0 0	
21	Porcelain Enameled Set Screw	S S 8 2 0 4 0 5 T N 0 0		51	Porcelain Enameled Set Screw	S S 8 2 0 6 0 5 T N 0 0	
22	Tension-side Timing Pulley Set	E F 0 7 0 6 S 0 0 0 0 0		54	Sensor Lock		
22	Tension-side Timing Pulley Set (G-spec.)	E F G 7 0 6 S 0 0 0 0 0		55	Pan Head Screw	S S 4 1 0 3 0 5 S D 0 0	
23	Tension-side Timing Pulley	E F 0 7 0 6 0 0 0 0 0 0		56	Plain Washer, M3		
23	Tension-side Timing Pulley (G-spec.)	E F G 7 0 6 0 0 0 0 0 0		57	Proximity Sensor	E G 6 6 0 1 0 0 0 0 0 0	
24	Tension Pulley Spacer	E F 0 7 0 7 0 0 0 0 0 0		58	Sensor Attaching Base	E G 0 7 3 2 0 0 0 0 0 0	
24	Tension Pulley Spacer (G-spec. Machine)	E F G 7 0 7 0 0 0 0 0 0		59	O-point Search Plate	E G 0 7 3 3 0 0 0 0 0 0	
25	Needle Bearing	H K 0 1 2 1 0 0 0 0 0 0		59	O-point Search Plate (G-spec. Machine)	E G G 7 3 2 0 0 0 0 0 0	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TMEG X - AXIS DRIVER I

EG-10-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
60	Hexagon Bolt	SS930306SD00		84	Bearing Case Plate BR	EGR705B10000	
61	X-axis Feed Plate A	EG0714A00000		85	Bearing Case Plate BL	EG L705B10000	
61	X-axis Feed Plate A (G-spec. Machine)	EGG714A00000		86	X-axis Drive Shaft	EG081903****	
62	X-axis Feed Plate B	EG0714B00000		86	X-axis Drive Shaft(G-spec. Machine)	EGG819030000	
62	X-axis Feed Plate B (G-spec. Machine)	EGG714B00000					
63	Flat Fillister Head Screw	SS600412SC00					
64	Belt Catcher Plate	EF0708000000					
64	Belt Catcher Plate (G-spec. Machine)	EGG7700000000					
65	No.1 Roller Set	EF0709000000					
66	No.1 Roller	EF0709100000					
67	Liner Plate	EF0709200000					
68	Ball Bearing	LF01280ZZ000					
69	Roller Set Screw	EF0710000000					
70	Timing Belt	T1025000****					
71	Fixing Roller Presser Screw	EG0722000000					
72	Plastic Roller Set	EG0721S00000					
73	Plastic Roller	EG0721000000					
74	Presser Roller Pin A	EG0716000000					
75	Roller Pin Spacer	EF072400****					
76	Presser Roller Pin B	EG0717000000					
77	Presser Roller Base	EG0715000000					
78	Roller Base Guide Pin	EG0718000000					
79	Hexagon Socket Head Cap Screw	SS620512CC00					
80	LS Dog Base	EG0729000000					
80	LS Dog Base (G-spec. Machine)	EGG728000000					
81	LS Dog	EG0728000000					
82	X-axis Driver Frame A	EG0702A1****					
82	X-axis Driver Frame A (G-spec. Machine)	EGG702A1****					
83	X-axis Driver Frame B	EG0702B1****					
83	X-axis Driver Frame B (G-spec. Machine)	EGG702B1****					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(9001)


TMEG X - AXIS DRIVER 2

EG-10-2

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
2	Hexagon Socket Head Cap Screw	SS620820CC00					
3	Rotary Hook Base Shaft Holder	AT1106000000					
4	Hexagon Socket Head Cap Screw	SS620620CC00					
5	Spring Washer, M6						
6	Plain Washer, M6						
7	Needle Bearing	HK0181200000					
8	15mm Dia. Needle Collar	EF0208000000					
9	Porcelain Enameled Set Screw	SS820505TN00					
10	Driven Timing Pulley	EG0755000000					
11	Porcelain Enameled Set Screw	SS820606TN00					
12	Porcelain Enameled Set Screw	SS820605TN00					
18	Spring Washer, M8						
20	Pulse (Stepping) Motor	EF6401010000					
20	Pulse (Stepping) Motor (G-spec. Machine)	EF6401A10000					
21	Hexagon Socket Head Cap Screw	SS620815CC00					
28	Driver-side Timing Pulley	EF7050000000					
29	Timing Belt	T10050040000					
35	Porcelain Enameled Set Screw	SS820608TN00					
36	X-axis Motor Base Bracket	EG0765000000					
37	X-axis Pulse(Stepping)Motor Base	EG0766000000					
38	Hexagon Bolt	SS930650SD00					
39	X-axis Driver Bearing Case Plate	EG0767000000					
40	Hexagon Socket Head Cap Screw	SS620615CC00					
41	Bracket Side Plate	EG0769000000					
42	Truss Head Screw	SS010506SD00					
43	Top Cover	EG0768000000					
44	Plain Washer, M8						

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(9 0 0 1)

TMEG Y-Axis DRIVER A-1

EG-11a-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
3	Hexagon Socket Head Cap Screw	SS620825CC00		33	Adjusting Knob	EG0731000000	
4	Spring Washer, M8			34	Limit Switch	MS6601000000	
5	Plain Washer, M8			35	Actuator	MS6602000000	
6	Driver Spacer B	EF083000****		36	Pan Head Screw	SS410314SD00	
7	Driver Spacer C	EF083100****		37	Sensor Lock		
8	Tension Base	EG0707000000		38	Pan Head Screw	SS410305SD00	
9	Porcelain Enameled Set Screw	SS820505TN00		39	Plain Washer, M3		
10	Tension Rivet Plate	EG0709000000		40	Proximity Sensor	EG6601000000	
11	Countersunk Head Screw	SS110410SD00		41	Sensor Attaching Base	EG0732000000	
12	Tension Bearing Case A	EG0706A00000		42	Y-axis Frame Rail A	EF0703A0****	
13	Hexagon Bolt	SS930520SD00		43	Y-axis Frame Rail B	EF0703B0****	
14	Spring Washer, M5			44	Spring Pin, 4P*12L		
15	Plain Washer, M5			46	15mm Dia. Needle Collar	EF0208000000	
16	Tension Shaft	EG0711000000		47	Needle Bearing	HK0181200000	
17	Porcelain Enameled Set Screw	SS820405TN00		49	Hexagon Socket Head Cap Screw	SS620615CC00	
18	Tension-side Timing Pulley Set	EF0706S00000		51	Hexagon Socket Head Cap Screw	SS620620CC00	
19	Tension-side Timing Pulley	EF0706000000		54	Driver-side Timing Pulley	EF0705000000	
20	Tension Pulley Spacer	EF0707000000		55	Porcelain Enameled Set Screw	SS820606TN00	
21	Needle Bearing	HK0121000000		56	Porcelain Enameled Set Screw	SS820605TN00	
22	Tension Spacer	EG0712000000		57	Driven Timing Pulley	EG0755000000	
23	Tension Plate	EG0708000000		58	Y-axis Drive Shaft Bearing Case	EG0752000000	
24	Hexagon Socket Head Cap Screw	SS620412CC00		59	Y-axis Driven Pulley Cover	EG0757000000	
25	Plain Washer, M4			60	Countersunk Head Wood Screw, 3.1P*16L		
26	Hexagon Bolt, M6*65L			61	N-Coupling	N01501500000	
27	Hexagon Nut, M6			63	Timing Belt	T1025000****	
28	Slide Base	EG072600****		64	Belt Catcher Plate	EF0708000000	
29	Hexagon Socket Head Cap Screw	SS620408CC00		65	No.1 Roller Set	EF0709000000	
30	Limit Switch Base R	EG0727R00000		66	No.1 Roller	EF0709100000	
31	Limit Switch Base L	EG0727L00000		67	Liner Plate	EF0709200000	
32	Fixture Base	EG0730000000		68	Ball Bearing	LF01280ZZ000	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


TMEG Y - AXIS DRIVER A-1

EG-11a-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
69	Roller Set Screw	E F 0 7 1 0 0 0 0 0 0 0		98	Wood Screw, 4.5P*20L		
70	Y-axis Feed Plate, Rear A	E G 0 7 1 3 A 0 0 0 0 0		99	Bearing Case	E F 0 7 2 0 0 0 0 0 0 0	
70	Y-axis Feed Plate, Rear B	E G 0 7 1 3 B 0 0 0 0 0		100	Roller	E F 0 7 2 2 0 0 0 0 0 0 0	
71	Flat Fillister Head Screw	S S 6 0 0 4 1 2 S C 0 0		101	Roller Pin	E F 0 7 2 3 0 0 0 0 0 0 0	
72	LS Dog Base	E G 0 7 2 9 0 0 0 0 0 0 0		102	E-Ring, E-5		
73	LS Dog	E G 0 7 2 8 0 0 0 0 0 0 0		103	Spring Washer, M4		
74	Hexagon Bolt	S S 9 3 0 3 0 6 S D 0 0		104	Bearing Case Base	E F 0 7 2 1 0 0 0 0 0 0 0	
75	O-point Search Plate	E G 0 7 3 3 0 0 0 0 0 0 0		106	Bearing Case Spacer	E G 0 7 5 9 0 0 * * * * *	
76	Presser Roller Base	E G 0 7 1 5 0 0 0 0 0 0 0		107	Porcelain Enameled Set Screw	S S 8 2 0 5 0 8 T N 0 0	
77	Roller Base Guide Pin	E G 0 7 1 8 0 0 0 0 0 0 0		108	Porcelain Enameled Set Screw	S S 8 2 0 6 0 8 T N 0 0	
78	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 2 C C 0 0		109	Y-axis Driver Frame A	E G 0 7 0 1 A 1 * * * * *	
79	Fixing Roller Presser Screw	E G 0 7 2 2 0 0 0 0 0 0 0		110	Y-axis Driver Frame B	E G 0 7 0 1 B 1 * * * * *	
80	Plastic Roller Set	E G 0 7 2 1 S 0 0 0 0 0		111	Bearing Case Plate B R	E G R 7 0 5 B 1 0 0 0 0	
81	Plastic Roller	E G 0 7 2 1 0 0 0 0 0 0 0		112	Bearing Case Plate B L	E G L 7 0 5 B 1 0 0 0 0	
82	Presser Roller Pin A	E G 0 7 1 6 0 0 0 0 0 0 0		113	Y-axis Drive Shaft A	E G 0 8 0 9 A 3 * * * * *	
83	Roller Pin Spacer	E G 0 7 2 4 0 0 * * * * *		114	Y-axis Drive Shaft B	E G 0 8 0 9 B 3 * * * * *	
84	Presser Roller Pin B	E G 0 7 1 7 0 0 0 0 0 0 0					
85	Y-axis Driver Connecting Plate	E G 0 7 2 5 0 0 * * * * *					
86	Countersunk Head Screw	S S 1 1 0 4 0 8 S D 0 0					
87	Y-axis Driver Plate, Front Set	E G 0 7 1 9 S 0 0 0 0 0					
88	Fixture-side Roller Base	E G 0 7 2 0 0 0 0 0 0 0 0					
89	Y-axis Driver Plate, Front	E G 0 7 1 9 0 0 0 0 0 0 0					
90	Roller Washer	E G 0 7 2 6 0 0 0 0 0 0 0					
91	Roller Guide	E G 0 7 2 5 0 0 0 0 0 0 0					
92	Round Fillister Head Screw	S M 7 0 0 9 0 5 S C 0 0					
93	Y-axis Rail, Front R	E F 0 7 1 4 R 0 * * * * *					
94	Y-axis Rail, Front L	E F 0 7 1 4 L 0 * * * * *					
95	Hexagon Socket Head Cap Screw	S S 6 2 0 4 1 5 C C 0 0					
96	Rail Spacer	E F 0 7 1 6 0 0 0 0 0 0 0					
97	Front Rail Holder	E F 0 7 1 5 0 0 * * * * *					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(8906)

TMEG Y - AXIS DRIVER A - 2


EG-11a-2

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Pulse (Stepping) Motor	E F 6 4 0 1 0 1 0 0 0 0					
1	Pulse (Stepping) Motor (G-spec. Machine)	E F 6 4 0 1 A 1 0 0 0 0					
2	Hexagon Socket Head Cap Screw	S S 6 2 0 8 1 5 C C 0 0					
3	Pulse (Stepping) Motor Base, Y-axis	E G 0 7 5 1 A 2 0 0 0 0					
4	Hexagon Socket Head Cap Screw	S S 6 2 0 8 3 0 C C 0 0					
5	Spring Washer, M8						
6	Plain Washer (Large), M8						
7	Motor Base Guide Plate	E G 0 7 6 3 0 2 0 0 0 0					
8	Hexagon Socket Head Cap Screw	S S 6 2 0 5 2 0 C C 0 0					
9	Tension Bracket A	E G 0 7 6 2 A 2 0 0 0 0					
10	Hexagon Socket Head Cap Screw	S S 6 2 0 6 1 5 C C 0 0					
11	Spring Washer, M6						
12	Plain Washer, M6						
13	Hexagon Bolt	S S 9 3 0 6 7 0 S D 0 0					
14	Hexagon Nut, M6						
15	Tension Block	E G 0 7 6 1 0 0 0 0 0 0					
16	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0					
17	Needle Bearing	H K 0 1 8 1 2 0 0 0 0 0					
18	15mm Dia. Needle Collar	E F 0 2 0 8 0 0 0 0 0 0					
19	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0					
20	Driver-side Timing Pulley	E F G 7 0 5 0 0 0 0 0 0					
21	Porcelain Enameled Set Screw	S S 8 2 0 6 0 6 T N 0 0					
22	Porcelain Enameled Set Screw	S S 8 2 0 6 0 5 T N 0 0					
23	Timing Belt	T 1 0 0 5 0 0 0 * * * *					
24	Y-axis Connecting Belt Cover	E G 0 7 5 6 0 2 * * * *					
25	Truss Head Screw	S S 0 1 0 5 0 8 C C 0 0					
26	Plain Washer, M5						
27	Spring Washer, M5						

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG Y-AXIS DRIVER B-1: E G-11b-1



TAJIMA

(9001)

TMEG Y - AXIS DRIVER B-1

EG-11b-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
3	Hexagon Socket Head Cap Screw	SS620825CC00		33	Needle Bearing	HK0121000000	
4	Spring Washer, M8			34	Tension Spacer	EG0712000000	
5	Plain Washer, M8			35	Y-axis Driver Pulley Cover	EG0742000000	
6	Driver Spacer C	EF083100****		36	Truss Head Screw	SS010508SD00	
7	Driver Spacer B	EF083000****		37	Sensor Lock		
8	Y-axis Frame Rail A	EG0703A0****		38	Pan Head Screw	SS410305SD00	
9	Y-axis Frame Rail B	EG0703B0****		39	Plain Washer, M3		
10	Hexagon Socket Head Cap Screw	SS620412CC00		40	Proximity Sensor	EG6601000000	
11	Spring Pin, 4P*12L			41	Sensor Attaching Base	EG0732000000	
12	Slide Base	EG072600****		44	Tension Roller Spacer	EG0739000000	
13	Hexagon Socket Head Cap Screw	SS620408CC00		45	Washer		
14	Plain Washer, M4			47	Hexagon Socket Head Cap Screw	SS620520CC00	
15	Limit Switch Base R	EG0727R00000		48	Lozenge-flange Unit	ASFB20200000	
16	Limit Switch Base L	EG0727L00000		49	Hexagon Socket Head Cap Screw	SS620620CC00	
17	Fixture Base	EG0730000000		50	Spring Washer, M6		
18	Adjusting Knob	EG0731000000		51	Plain Washer, M6		
19	Limit Switch	MS6601000000		52	Porcelain Enameled Set Screw	SS820506TN00	
20	Actuator	MS6602000000		53	Driver-side Timing Pulley	EF0705000000	
21	Pan Head Screw	SS410314SD00		54	Porcelain Enameled Set Screw	SS820606TN00	
22	Driver Reinforcing Shaft	EG0741000000		55	Porcelain Enameled Set Screw	SS820605TN00	
23	Hexagon Socket Head Cap Screw	SS620510CC00		57	Driven Timing Pulley	EG0755000000	
24	Y-axis Tension Base	EG0737000000		59	Bearing Case Spacer	EG075900****	
25	Hexagon Socket Head Cap Screw	SS620515CC00		60	Hexagon Socket Head Cap Screw	SS620625CC00	
26	Tension Shaft Holder	EG0736000000		61	Needle Bearing	HK0181200000	
27	Tension Bolt	EG0740000000		62	15mm Dia. Needle Collar	EF0208000000	
28	Tension Shaft	EG0711000000		63	Porcelain Enameled Set Screw	SS820505TN00	
29	Porcelain Enameled Set Screw	SS820404TN00		64	Y-axis Drive Shaft A	EG0809A2****	
30	16T Timing Pulley Set	EG0734S00000		65	N-Coupling	N15015000000	
31	16T Timing Pulley	EG0734000000		66	Y-axis Drive Shaft B	EG0809B2****	
32	Tension Pulley Spacer	EF0707000000		67	Timing Belt	T1025000****	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

IMEGY - AXIS DRIVER B-1

EG-11b-1

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
68	Belt Catcher Plate	E F 0 7 0 8 0 0 0 0 0 0		97	Round Fillister Head Screw	S M 7 0 0 9 0 5 S C 0 0	
69	No.1 Roller Set	E F 0 7 0 9 0 0 0 0 0 0		98	Y-axis Rail, Front R	E F 0 7 1 4 R 0 ****	
70	No.1 Roller	E F 0 7 0 9 1 0 0 0 0 0		99	Y-axis Rail, Front L	E F 0 7 1 4 L 0 ****	
71	Liner Plate	E F 0 7 0 9 2 0 0 0 0 0		100	Hexagon Socket Head Cap Screw	S S 6 2 0 4 1 5 C C 0 0	
72	Ball Bearing	L F 0 1 2 8 0 Z Z 0 0 0		101	Rail Spacer	E F 0 7 1 6 0 0 0 0 0 0	
73	Roller Set Screw	E F 0 7 1 0 0 0 0 0 0 0		102	Front Rail Holder	E F 0 7 1 5 0 0 0 0 0 0	
74	Y-axis Feed Plate, Rear A	E G 0 7 1 3 A 0 0 0 0 0		103	Wood Screw, 4.5P*20L		
74	Y-axis Feed Plate, Rear B	E G 0 7 1 3 B 0 0 0 0 0		104	Bearing Case	E F 0 7 2 0 0 0 0 0 0 0	
75	Flat Fillister Head Screw	S S 6 0 0 4 1 2 S C 0 0		105	Roller	E F 0 7 2 2 0 0 0 0 0 0	
76	LS Dog Base	E G 0 7 2 9 0 0 0 0 0 0		106	Roller Pin	E F 0 7 2 3 0 0 0 0 0 0	
77	LS Dog	E G 0 7 2 8 0 0 0 0 0 0		107	E-Ring, E-5		
78	Hexagon Bolt	S S 9 3 0 3 0 6 S D 0 0		108	Spring Washer, M4		
79	O-point Search Plate	E G 0 7 3 3 0 0 0 0 0 0		109	Bearing Case Base	E F 0 7 2 1 0 0 0 0 0 0	
80	Presser Roller Base	E G 0 7 1 5 0 0 0 0 0 0		110	Porcelain Enameled Set Screw	S S 8 2 0 6 0 8 T N 0 0	
81	Roller Base Guide Pin	E G 0 7 1 8 0 0 0 0 0 0		111	Y-axis Driver Frame A	E G 0 7 0 1 A 1 ****	
82	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 2 C C 0 0		112	Y-axis Driver Frame B	E G 0 7 0 1 B 1 ****	
83	Plain Washer, M5			113	Drive Shft Bearing Case Bracket	E G 0 7 3 5 0 1 0 0 0 0	
84	Fixing Roller Presser Screw	E G 0 7 2 2 0 0 0 0 0 0		114	Tension Roller Set	E G 0 7 3 8 S 1 0 0 0 0	
85	Plastic Roller Set	E G 0 7 2 1 S 0 0 0 0 0		115	Tension Roller	E G 0 7 3 8 0 1 0 0 0 0	
86	Plastic Roller	E G 0 7 2 1 0 0 0 0 0 0		116	Drive Shaft Bearing Case Cover	E G 0 7 4 5 0 1 0 0 0 0	
87	Presser Roller Pin A	E G 0 7 1 6 0 0 0 0 0 0		117	Y-axis Drive Shaft Bearing Case	E G 0 7 5 2 0 1 0 0 0 0	
88	Roller Pin Spacer	E G 0 7 2 4 0 0 ****					
89	Presser Roller Pin B	E G 0 7 1 7 0 0 0 0 0 0					
90	Y-axis Driver Connecting Plate	E G 0 7 2 5 0 0 ****					
91	Countersunk Head Screw	S S 1 1 0 4 0 8 S D 0 0					
92	Y-axis Driver Plate, Front Set	E G 0 7 1 9 S 0 0 0 0 0					
93	Fixture-side Roller Base	E G 0 7 2 0 0 0 0 0 0 0					
94	Y-axis Driver Plate, Front	E G 0 7 1 9 0 0 0 0 0 0					
95	Roller Washer	E F 0 7 2 6 0 0 0 0 0 0					
96	Roller Guide	E F 0 7 2 5 0 0 0 0 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG Y - AXIS DRIVER B-2

EG-11b-2


Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Pulse (Stepping) Motor	E F 6 4 0 1 0 1 0 0 0 0					
1	Pulse (Stepping) Motor (G-spec. Machine)	E F 6 4 0 1 A 1 0 0 0 0					
2	Hexagon Socket Head Cap Screw	S S 6 2 0 8 1 5 C C 0 0					
3	Pulse (Stepping) Motor Base, Y-axis	E G 0 7 5 1 A 2 0 0 0 0					
4	Hexagon Socket Head Cap Screw	S S 6 2 0 8 3 0 C C 0 0					
5	Spring Washer, M8						
6	Plain Washer (Large), M8						
7	Motor Base Guide Plate	E G 0 7 6 3 0 2 0 0 0 0					
8	Hexagon Socket Head Cap Screw	S S 6 2 0 5 2 0 C C 0 0					
9	Tension Bracket A	E G 0 7 6 2 A 2 0 0 0 0					
10	Hexagon Socket Head Cap Screw	S S 6 2 0 6 1 5 C C 0 0					
11	Spring Washer, M6						
12	Plain Washer, M6						
13	Hexagon Bolt	S S 9 3 0 6 7 0 S D 0 0					
14	Hexagon Nut, M6						
15	Tension Block	E G 0 7 6 1 0 0 0 0 0 0					
16	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 5 C C 0 0					
17	Needle Bearing	H K 0 1 8 1 2 0 0 0 0 0					
18	15mm Dia. Needle Collar	E F 0 2 0 8 0 0 0 0 0 0					
19	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0					
20	Driver-side Timing Pulley	E F G 7 0 5 0 0 0 0 0 0					
21	Porcelain Enameled Set Screw	S S 8 2 0 6 0 6 T N 0 0					
22	Porcelain Enameled Set Screw	S S 8 2 0 6 0 5 T N 0 0					
23	Timing Belt	T 1 0 0 5 0 0 5 0 0 0 0					
24	Y-axis Connecting Belt Cover	E G 0 7 5 6 0 0 0 0 0 0					
25	Truss Head Screw	S S 0 1 0 5 0 8 C C 0 0					
26	Plain Washer, M5						
27	Spring Washer, M5						

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG TENSION BASE & TENSION RELEASE SYSTEM A

E G - 12a



TAJIMA

(9001)

TMEG TENSION BASE & TENSION RELEASE SYSTEM A

EG-12a

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Tension Base	E G 0 9 0 1 0 0 * * * *		31	10mm Dia. Collar	E F 0 9 2 4 0 0 0 0 0 0	
2	Truss Head Screw	S M 0 1 0 9 0 8 S A 0 0		32	Porcelain Enameled Set Screw	S S 8 2 0 4 0 4 T N 0 0	
3	Round Countersunk Head Screw	S M 2 0 0 9 0 6 S D 0 0		33	Tension Release Collar	E G 0 9 0 2 S 0 0 0 0 0	
4	Thread Take-up Spring	E F 0 9 0 7 0 0 0 0 0 0		34	Tension Release Shaft A	E G 0 8 1 0 A 0 * * * *	
5	Tension Stud	E F 0 9 0 2 0 0 0 0 0 0		35	Tension Release Shaft B	E G 0 8 1 0 B 0 * * * *	
6	Insulation Plate	E F 0 9 0 3 0 0 0 0 0 0		36	10mm Dia. Joint	E F 0 8 2 6 0 0 0 0 0 0	
7	Felt Packing	E F 0 9 0 4 0 0 0 0 0 0		37	Porcelain Enameled Set Screw	S S 8 2 0 4 0 5 T N, 0 0	
8	Rotary Tension Disk	E F 0 9 0 5 0 0 0 0 0 0		38	No.1 Tension Base Foundation Plate	E G 0 9 0 5 A 0 * * * *	
9	Tension Collar	E F 0 9 0 6 0 0 0 0 0 0		39	No.2 Tension Base Foundation Plate	E G 0 9 0 5 B 0 * * * *	
10	Tension Spring	E F 0 9 0 8 0 0 0 0 0 0		40	Contact Point Spring	E G 0 9 0 3 0 0 * * * *	
11	Spring Hook	E F 0 9 1 0 0 0 0 0 0 0		41	Pan Head Screw	S S 4 1 0 3 0 5 S C 0 0	
12	Adjusting Screw	E F 0 9 0 9 0 0 0 0 0 0		42	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0	
13	Thread Course Tension Disk	E F 0 9 1 3 0 0 0 0 0 0		43	Contact Point Base	E G 0 9 0 4 0 0 * * * *	
14	Thread Course Tension Stud	E F 0 9 1 4 0 0 0 0 0 0		44	No.1 Tension Base Cover	E F 0 9 2 7 A 0 * * * *	
15	Thread Course Thread Guide	E F 0 9 1 2 0 0 0 0 0 0		45	No.2 Tension Base Cover	E F 0 9 2 7 B 0 * * * *	
16	Thread Course Tension Spring	E F 0 9 1 5 0 0 0 0 0 0		46	No.3 Tension Base Cover	E F 0 9 2 7 C 0 * * * *	
17	Tension Base Front Cover	E F 0 9 3 0 0 0 * * * *		47	Tension Base Side Bearing Case L	E G 0 9 0 6 0 0 0 0 0 0	
18	Tension Base Lower Thread Guide	E F 0 9 1 6 0 0 # # # #		48	Needle Bearing	H K 0 1 0 1 0 0 0 0 0 0	
19	Truss Head Screw	S M 0 1 0 9 0 6 S A 0 0		49	Tension Base Side Bearing Case A	E F 0 9 2 9 A 0 0 0 0 0	
20	Tension Base Card (PC Board)	E F 7 2 0 1 0 0 0 0 0 0		52	Tension Release Driven Pulley	E F 0 9 4 5 0 0 0 0 0 0	
21	Tension Release Pin	E F 0 9 1 1 0 0 0 0 0 0		53	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0	
22	Pan Head Screw	S S 4 1 0 3 0 6 M Z 0 0		55	Plain Washer, M4		
23	Contact Point Spring	E F 0 9 1 9 0 0 0 0 0 0		56	Belt Presser Plate	E F 0 9 3 6 0 0 0 0 0 0	
24	Plain Washer, M3			57	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 8 C C 0 0	
25	Hexagon Nut, M3			58	Belt Joint Metal Fittings R	E F 0 9 3 5 R 0 0 0 0 0	
26	Tension Release Shaft Bearing Case A	E F 0 9 2 1 A 0 0 0 0 0		59	Hexagon Nut, M4		
27	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 0 C C 0 0		60	Belt Joint Tension Nut	E F 0 9 3 4 0 0 0 0 0 0	
28	Plain Washer, M5			61	Hexagon Nut Counterclockwise, M4		
29	Cord Cramp, NK-*N			62	Belt Joint Metal Fittings L	E F 0 9 3 5 L 0 0 0 0 0	
30	Pan Head Screw	S S 4 1 0 3 0 8 S D 0 0		63	Tension Base Joint-2 Card (E-spec.)	E G 7 2 0 2 0 1 0 0 0 0	

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG TENSION BASE & TENSION RELEASE SYSTEM A


E G - 12 a[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG TENSION BASE & TENSION RELEASE SYSTEM B

E G - 12b



TAJIMA

(9001)

TMEG TENSION BASE & TENSION RELEASE SYSTEM B

E G - 12b

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Tension Base	E G 0 9 0 1 0 0 * * * *		31	Tension Release Shaft Connecting Gear	E F 0 9 4 6 0 0 0 0 0 0	
2	Truss Head Screw	S M 0 1 0 9 0 8 S A 0 0		32	Porcelain Enameled Set Screw	S S 8 2 0 5 0 5 T N 0 0	
3	Round Countersunk Head Screw	S M 2 0 0 9 0 6 S D 0 0		33	Tension Release Collar	E G 0 9 0 2 S 0 0 0 0 0	
4	Thread Take-up Spring	E F 0 9 0 7 0 0 0 0 0 0		34	Tension Release Shaft A	E G 0 8 1 0 A 0 * * * *	
5	Tension Stud	E F 0 9 0 2 0 0 0 0 0 0		35	Tension Release Shaft B	E G 0 8 1 0 B 0 * * * *	
6	Insulation Plate	E F 0 9 0 3 0 0 0 0 0 0		36	10mm Dia. Joint	E F 0 8 2 6 0 0 0 0 0 0	
7	Felt Packing	E F 0 9 0 4 0 0 0 0 0 0		37	Porcelain Enameled Set Screw	S S 8 2 0 4 0 5 T N. 0 0	
8	Rotary Tension Disk	E F 0 9 0 5 0 0 0 0 0 0		38	No.2 Tension Release Shaft A	E F 0 8 1 1 A 0 0 0 0 0	
9	Tension Collar	E F 0 9 0 6 0 0 0 0 0 0		39	No.2 Tension Release Shaft B	E F 0 8 1 1 B 0 0 0 0 0	
10	Tension Spring	E F 0 9 0 8 0 0 0 0 0 0		40	No.1 Tension Base Foundation Plate	E G 0 9 0 5 A 0 * * * *	
11	Adjusting Screw	E F 0 9 0 9 0 0 0 0 0 0		41	No.2 Tension Base Foundation Plate	E G 0 9 0 5 B 0 * * * *	
12	Spring Hook	E F 0 9 1 0 0 0 0 0 0 0		42	Tension Base Side Bearing Case L	E G 0 9 0 6 0 0 0 0 0 0	
13	Thread Course Tension Spring	E F 0 9 1 5 0 0 0 0 0 0		43	Hexagon Socket Head Cap Screw	S S 6 2 0 4 0 8 C C 0 0	
14	Thread Course Tension Disk	E F 0 9 1 3 0 0 0 0 0 0		44	No.1 Tension Base Cover	E F 0 9 2 7 A 0 * * * *	
15	Thread Course Tension Stud	E F 0 9 1 4 0 0 0 0 0 0		45	No.2 Tension Base Cover	E F 0 9 2 7 B 0 * * * *	
16	Thread Course Thread Guide	E F 0 9 1 2 0 0 0 0 0 0		46	No.3 Tension Base Cover	E F 0 9 2 7 C 0 * * * *	
17	Tension Base Middle Thread Guide	E F 0 9 1 7 0 0 # # # #		47	Contact Point Base	E G 0 9 0 4 0 0 * * * *	
18	Tension Base Lower Thread Guide	E F 0 9 1 6 0 0 # # # #		48	Contact Point Spring	E G 0 9 0 3 0 0 * * * *	
19	Truss Head Screw	S M 0 1 0 9 0 6 S A 0 0		49	Pan Head Screw	S S 4 1 0 3 0 5 C C 0 0	
20	Tension Base Card (PC Board)	E F 7 2 0 1 0 0 0 0 0 0		50	Tension Base Side Cover Bearing Case B	E F 0 9 2 9 B 0 0 0 0 0	
21	Pan Head Screw	S S 4 1 0 3 0 6 M Z 0 0		51	Hexagon Socket Head Cap Screw	S S 6 2 0 5 1 0 C C 0 0	
22	Tension Base Front Cover	E F 0 9 3 0 0 0 * * * *		52	Plain Washer, M5		
23	Tension Release Pin	E F 0 9 1 1 0 0 0 0 0 0		55	Tension Release Driven Pulley	E F 0 9 4 5 0 0 0 0 0 0	
24	Contact Point Spring	E F 0 9 1 9 0 0 0 0 0 0		57	Plain Washer, M4		
25	Hexagon Nut, M3			58	Belt Presser Plate	E F 0 9 3 6 0 0 0 0 0 0	
26	Plain Washer, M3			59	Hexagon Socket Head Cap Screw	S S 6 2 0 3 0 8 C C 0 0	
27	Tension Release Shaft Bearing Case B	E F 0 9 2 1 B 0 0 0 0 0		60	Belt Joint Metal Fittings R	E F 0 9 3 5 R 0 0 0 0 0	
28	10mm Dia. Collar	E F 0 9 2 4 0 0 0 0 0 0		61	Hexagon Nut, M4		
29	Needle Bearing	H K 0 1 0 1 0 0 0 0 0 0		62	Belt Joint Tension Nut	E F 0 9 3 4 0 0 0 0 0 0	
30	Porcelain Enameled Set Screw	S S 8 2 0 4 0 4 T N 0 0		63	Hexagon Nut Counterclockwise, M4		


Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

E G - 12b

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC


**TAJIMA**

(8906)

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(9001)


TMEG EMBROIDERY FRAME

EG-14

Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Frame Sash Lengthwise A	E G 0 3 0 3 0 0 * * * * *					
2	Frame Sash, Rear	E G 0 3 0 1 0 0 * * * * *					
3	Frame Sash, Lengthwise B	E G 0 3 0 4 0 0 * * * * *					
4	Frame Sash, Front	E G 0 3 0 2 0 0 * * * * *					
5	Base Frame Sash Set	E G 0 3 0 0 S 0 * * * * *					
6	Embroidery Space Indicator	E G 0 3 1 0 0 0 0 0 0 0					
7	Embroidery Space Indicator Plate Nut	E G 0 3 1 1 0 0 0 0 0 0					
8	Truss Head Screw	S S 0 1 0 5 0 8 C B 0 0					
9	Screw Ring	E F 0 3 0 3 0 0 0 0 0 0					
10	No.1 Felt	E G 0 3 0 8 0 0 0 0 0 0					
11	No.3 Felt	E G 0 3 0 9 0 0 * * * * *					
12	Countersunk Head Screw	S S 1 1 0 5 1 0 C D 0 0					
13	Border Frame Crosswise Sash	E G 0 3 1 2 0 0 * * * * *					
14	Border Frame Lengthwise Sash	E F 0 3 0 5 0 0 * * * * *					
16	Counter Gear Box—side Corner	E G 0 3 0 6 0 0 0 0 0 0					
17	Truss Head Screw	S S 0 1 0 5 1 2 C B 0 0					
18	Main Gear Box—side Spacer	E G 0 3 0 7 0 0 0 0 0 0					
19	Main Gear Box—side Corner	E G 0 3 0 5 0 0 0 0 0 0					
20	Middle Sash	E G 0 3 1 3 0 0 * * * * *					
21	Truss Head Screw	S S 0 1 0 4 0 5 C B 0 0					
22	Inner Frame Attachment C	E F 0 3 1 1 0 0 0 0 0 0					
23	Pan Head Screw	S S 4 1 0 4 0 5 C D 0 0					
24	Inner Frame Attachment A	E F 0 3 0 9 0 0 0 0 0 0					
25	Inner Frame Attachment B	E F 0 3 1 0 0 0 0 0 0 0					
26	Hexagon Socket Head Cap Screw	S S 6 2 0 4 1 5 C C 0 0					
27	Border Frame Clip (Short)	E F 0 3 0 7 A 0 0 0 0 0					
27	Border Frame Clip (Long)	E F 0 3 0 7 B 0 0 0 0 0					
28	Truss Head Screw	S S 0 1 0 4 0 8 C B 0 0					

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(9002)


TMEG OPERATION PANEL BOX

E G - 15

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(9 0 0 1)

TMEG POWER SUPPLY BOX A

EG-16a


Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Power Supply Box	E G 5 6 0 0 A 4 0 0 0 0					
1	Power Supply Box (G-spec. Machine)	E G 5 6 0 0 B 4 0 0 0 0					
2	No Fuse Breaker, XS30NS3P20AT						
3	Electro-magnetic Switch (with Thermal)						
4	Rectifier, 20G6P44						
5	Rectifier, 15D4B41						
6	Relay, G4F1123TDC12						
7	Spark Killer, CRE 30680						
8	Spark Killer, SQ 52050						
9	Connector, 3191-06P						
10	Connector, 5025-06P						
11	Transformer, TR-0119						
11	Transformer, TR-0120 (G-spec. Machine)						
12	Fuse	P A 5 0 0 2 1 0 0 0 0 0					
13	Fuse	P A 5 0 0 2 A 0 0 0 0 0					
14	Fuse	P A 5 0 0 2 2 0 0 0 0 0					
15	Fuse	P A 5 0 0 2 5 0 0 0 0 0					
16	Fuse	P A 5 0 4 2 A 0 0 0 0 0					
17	6-Joint 21 Card	E G 5 6 0 1 0 1 0 0 0 0					
18	Resistor, RWHOS 15G 0.68ΩK						
19	Resistor, RWHOS 10G 500ΩK						
20	Resistor, RWHOS 30G 10ΩJ						
21	Condenser, HCG7A2A 333YS						
22	Fan, 4715PS 10T B30 B00						
23	Receptacle, AC-G07FB18						
24	Condenser, HCG7A2A682I						

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

TMEG POWER SUPPLY BOX (E-SPEC. MACHINE)

E G - 16b



TAJIMA

(9001)


TMEG POWER SUPPLY BOX (E - SPEC. MACHINE)

EG-16b


Ref.No.	Description	Part No.		Ref.No.	Description	Part No.	
1	Power Supply Box	E G 5 6 0 0 D 3 0 0 0 0					
1	Power Supply Box (G - spec. Machine)	E G 5 6 0 0 E 3 0 0 0 0					
2	No Fuse Breaker, XS30NS3P20AT						
3	Electro-magnetic Switch (with Thermal)						
4	Rectifier, 20G6P44						
5	Rectifier, 15D4B41						
6	Relay, G4F1123T, DC12						
7	Spark Killer, CRE 30680						
8	Spark Killer, SQ52050						
9	Connector, 3191-06P						
10	Connector, 5025-06P						
11	Transformer, TR-0119						
11	Transformer, TR-0120 (G - spec. Machine)						
12	Fuse	P A 5 0 0 2 1 0 0 0 0 0					
13	Fuse	P A 5 0 0 2 A 0 0 0 0 0					
14	Fuse	P A 5 0 0 2 2 0 0 0 0 0					
15	Fuse	P A 5 0 0 2 5 0 0 0 0 0					
16	Fuse	P A 5 0 4 2 A 0 0 0 0 0					
17	6-I/O Mother 2 Card	E G 5 6 0 2 0 2 0 0 0 0					
18	6-UTC 2 Card	G S 5 0 0 2 0 0 0 0 0 0					
19	6-TL 2 Card	A T 5 0 0 2 0 0 0 0 0 0					
20	6-J/S 2 Card	E G 5 6 0 3 0 0 0 0 0 0					
21	Resistor, RWHOS 15G 0.68ΩK						
22	Resistor, RWHOS 10G 500ΩK						
23	Resistor, RWHOS 30G 10ΩJ						
24	Condenser, HCG7A2A333 YS						
25	Fan, 4715PS 10T B30 B00						
26	Receptacle, AC - G07FB18						
27	Condenser, HCG7A2A682I						

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC

**TAJIMA**

(8906)


**TAJIMA**

(9001)

[illegible]

Note: As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC



TAJIMA

(8906)

TMEG MAIN MOTOR CONTROL BOX

E G - 19

[illegible]

Note:As for the parts with marks # or *, please follow our instructions on Table of Contents, in your parts order.

From the library of: Superior Sewing Machine & Supply LLC