
Presser foot pressure should be as light as possible while still sufficient to feed fabric and obtain proper stitch formation. Thumb Screw 1 regulates the pressure of Presser Foot.

Turn nut 1 clockwise for more pressure, and turn it counter-clockwise for less pressure.



From the library of: Superior Sewing Machine & Supply LLC