

Operation Sheet for Knife Sharpener

1. Insert ① micro gauge into hole and fasten it with knob ④-1 from the front.
2. A suitable knife holder ①-1 can be installed on the gauge bracket and fastened by the knob ①-2
3. Put either lower or upper knife on the knife holder ①-1 and fasten the wing nut. Allow the cutting edge of the knife to come close to the stone.
4. Switch on the sharpener, and the stone ⑤ rotates.
5. Hold the handle ①-3 and swing the knife holder with a back & forth motion allowing the knife-edge to swing freely yet close to the stone.
6. Rotate the micro gauge knob ①-4 to push the knife-edge closer to the edge of the stone. Swing the knife holder continuously and the knife-edge will get sharpened.
7. A new and sharp edge can easily be accomplished by slightly rotating the micro gauge closer to the stone.