

PARTS LISTS
FOR
SINGER
MACHINES OF
CLASS 271_K

NUMERICAL LIST OF PARTS FOR MACHINE 271K1
(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
157	Screw	23390	Washer	271665	Spring
161	Screw (2)	23460	Knife Bar	271666	Bracket for 271667
168	Screw (2)	32012	Tension Disc (2)	271667	Thread Check complete, 208, 9544, 9545, 9545-001, 271666 and two 9543 for 271548
190	Screw (2)	32572	Releasing Disc		
191	Screw (2)	39635	Releasing Pin	271691	Spring
200	Set Screw for 271916	39652	Spring for 271658	271692	Thread Guide for 271548
208	Screw for 271667	40043	Collar with 209 (2)	271693	Lower Thread Guide (side of arm)
209	Screw for 40043 (2)	51570	Thumb Nut		
212	Screw	140050	Screw	271700	Take-up Spring Regulator 350060, for 271658
237	Screw for 271700	140490	Set Screw for 271428	271701	Oil Seal Ring (rubber) for 271658
330	Screw for Face Plate (lower)	141087	Set Screw (2)	271744	Thread Eyelet (double)
336	Set Screw for 271835	241189	Oil Packing Wick for 271603	271773	Arm Top Cover Plate
446	Set Screw	249544	Knife Bar Stop	271781	Upper Thread Guide (side of arm)
460	Set Screw	249545	Retainer Plate		
974	Screw	249687	Tension Releaser Rod	271782	Lever Bracket
1019	Set Screw	270200	Oiling Wick for 271603	271835	Needle Bar 271596 with 336 Knife, 1/2"
1043	Screw Stud for 271658	271408	Automatic Knife	271901	Connecting Stud with 1319
1239	Cap Screw		Disengaging Lever	271915	Tension Releaser with 200
1319	Clamping Screw for 271915	271410	Thread Guide for 271408	271916	Knife Holder
1423	Screw for 271548	271428	Balance Weight with 140490	271919	Barring Point
1443	Guide Screw	271440	Needle Bar Frame with 241189, 270200, 271610 and 271611	271929	Automatic Knife Disengaging Lever
1517	Nut		Guide Stud (upper)	271953	Oiling Felt
1547	Nut	271442	Guide Stud (lower)		
1560	Thumb Nut for 271658	271443	Sleeve	271974	Screw Stud
1608	Nut	271444	Collar with two 141087	350399	Socket Screw for 271602
1664	Lock Nut	271445	Thread Guide for 271953	350713	1526 (71x1Y) Needle, Chromium Finish, Size 14
1698	Nut	271472	Spring		
2102	Tension Disc for 271658 (2)	271494	Face Plate for 271548		
8238	Spring for 271658	271547	Face Plate 271547 with 1423, 271667 and 271692		
9543	Disc for 271667 (2)	271548	Needle Bar for 271835		
9544	Cap for 271667		Connecting Stud with 350713		
9545-001	Spring for 271667	271596	Oiling Felt (lower)		
		271602	Oiling Felt (upper)		
		271606	Oiling Felt for 271603		
		271607	Felt Retainer for 271603		
		271610	Tension complete, 1043, 1560, 8238, 39652, 271700, 271701 and two 2102		
		271611			
		271658			


PARTS FOR MACHINE 271K1

(See Numerical List on opposite page)

STYLE OF FINISH:

When ordering screws, nuts and similar parts include new code numbers which follow part numbers on illustrations.

NEW CODE	OLD CODE	FINISH
801	A	Hardened, polished, nickel plated and buffed
802	B	Polished, nickel plated and buffed
803	C	Hardened only
804	D	Polished only
805	E	Soft, not polished
806	F	Hardened and polished
809	J	Nickel plated only
813	R	Phosphate coating formed on surface of iron or steel
819	X	Black oxide for iron and steel
830	A. L.	Heat treated for toughness
831	A. L. D.	Heat treated for toughness and polished
833	A. L. X.	Heat treated for toughness and black oxide
850	X. C.	Hardened and black oxide for iron and steel



NUMERICAL LIST OF PARTS FOR MACHINE 271K1


(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
54	Hinge Screw	249607	Lever Spring	271694	Take-up Crank
90	Hinge Screw (2)	249659	Catch Spring	271696	Take-up Lever for 271699
144	Cap Screw	249660	Lever Spring	271698	Oiling Wick
190	Screw (4)	262058	Screw Stud for 262128	271699	Thread Take-up complete, 1521, 141562, 271696 and 271793
196	Clamping Screw (2)	262128	Knife Bar Disengaging Lever with 262058	271731	Washer
216	Retainer Screw	262133	Hinge Stud for 271608	271733	Bushing (back)
223	Screw (2)	262135	Wick Retainer for 271608	271750	Feed Driving Bevel Pinion with two 453
228	Screw (2)	262138	Hinge Pin	271754	Thrust Washer
430	Stud Screw	262171	Connecting Link	271755	Oiling Felt (lower)
435	Screw	263572	Oil Packing Wick	271756	Felt Retainer
446	Set Screw	267093	Needle Bearing for 271580 (2)	271760	Needle Bar Crank with 858, 1036, 1065 and 1258
448	Set Screw	268425	Needle Bearing for 271794	271764	Oiling Felt
452	Set Screw	271409	Eccentric Stud with 271562	271765	Felt Retainer
453	Set Screw (2)	271423	Oiling Wick	271770	Needle Bar Frame Regulator
704	Screw (2)	271426	Stitch Regulating Gear Retainer	271771	Retainer Clamp
858	Set Screw for 271760	271473	Gear Bracket with Feed Driving Bevel Gear and 141546	271774	Bushing (upper)
898	Screw	271502	Oil Wick	271783	Upper Thread Pull-off
940	Screw (connection, front)	271503	Wick Retainer	271790	Oiling Felt
964	Cap Screw	271504	Spring	271793	Link for 271699
971	Screw (4)	271505	Oiling Felt	271794	Connection Belt Pulley with 268425 and two 140409
974	Screw	271506	Arm Shaft	271796	Barring Slide
1021	Cap Screw	271507	Oiling Felt	271801	Screw Stud
1036	Position Screw for 271760	271508	Oil Pack Wick (2)	271831	Washer
1038	Adjusting Screw	271509	Oiling Felt	271881	Feed Driving Pinion
1042	Hinge Screw	271517	Barring Shaft	271883	Barring Slide Operating Plate (stationary)
1065	Position Screw for 271760	271518	Oiling Felt	271886	Barring Trip Lever
1240	Hinge Screw	271519	Barring Slide Operating Rod	271887	Hinge Pin
1241	Screw Stud	271550	Feed Driving Gear, 64 Teeth	271888	Lever Plate
1242	Screw for 271935	271558	Feed Ratchet Gear (lower), 70 teeth	271889	Tripping Point
1258	Set Screw for 271760	271559	Feed Ratchet Gear (upper), 32 teeth	271890	Tripping Point Spacer
1330	Screw Stud	271560	Compression Spring	271914	Connecting Link
1396	Bracket Screw (2)	271562	Oil Packing Wick for 271409	271917	Pitman (regulator end) for 271966
1521	Nut	271578	Hook Driving Connection Belt (neoprene)	271918	Pitman (hinge screw end) for 271966
1547	Nut (2)	271580	Belt Pulley with 267093	271928	Barring Lever
1607	Nut	271583	Oil Packing Wick for 271979	271930	Stud
1651	Nut	271584	Belt Pulley Gear with 141600	271931	Barring Slide Stop
1698	Nut	271595	Knife Bar Driving Lever	271934	Lever Catch with 1963
1963	Roller and Stud for 271934	271597	Connecting Link	271935	Catch Bracket with 1242 and 238089
7070	Screw Sleeve	271599	Oiling Felt Washer	271936	Knife Bar Driving Lever (intermediate)
7071	Washer (2)	271604	Needle Bar Frame Connection	271943	Adjustable Plate
23681	Spring	271605	Needle Bar Frame Driving Gear	271952	Starting Lever Safety
39504	Washer	271608	Hinge Stud 262133 with 262135 and 271609	271966	Adjustable Pitman complete, 271917, 271918 and two each 190 and 7071
39541	Washer	271609	Oil Wick for 271608	271967	Washer
40025	Position Pin (2)	271631	Bushing (lower)	271975	Oiling Felt
50172	Lock Screw	271641	Stitch Regulating Gear, 45 teeth (2)	271976	Oiling Wick
50416	Hinge Screw	271651	Oil Wick (2)	271978	Eccentric Stud with 263572
51000	Screw (2)	271652	Wick Clamp	271979	Eccentric Stud with 271583
51407	Screw	271661	Releasing Lever	350712	Hinge Screw
53561	Lock Nut (2)	271662	Lever Connection		
53570	Nut				
140409	Socket Screw for 271794 (2)				
140930	Set Screw (2)				
141504	Cap Screw				
141546	Cap Screw for 271473				
141548	Cap Screw				
141549	Hinge Screw				
141562	Screw for 271699				
141564	Adjusting Screw				
141586	Screw Stud				
141600	Lock Screw for 271584				
141649	Hinge Screw				
201732	Nut (2)				
205634	Washer				
210962	Lever Spring				
235706	Oil Wick				
238089	Position Pin for 271935				

NUMERICAL LIST OF PARTS FOR MACHINE 271K1
(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
59	Hinge Screw	39675	Collar with two 191	271727	Belt Shifter Shaft Bracket
61	Hinge Screw	39882	Washer (nylon)	271729	Starting Lever Rod
123	Screw	39988	Washer (nylon)	271730	Washer
124	Stop Screw	40025	Position Pin	271734	Ball Bearing for 271615
158	Screw	51047	Pinch Screw for 249858	271736	Ball Bearing for 271763
161	Screw	58384	Screw Center 564 with	271738	Spacer
191	Screw (3)		1508 (2)	271739	Spiral Pin
229	Screw	140050	Screw (3)	271740	Retaining Ring
237	Screw	140321	Set Screw	271759	Stop Cam Gear
389	Screw (3)	202005	Washer	271763	Positive Drive Pulley
453	Set Screw	202248	Washer		271618 with 271736 and
457	Set Screw for 249713	202330	Oil Packing Wick for		two 271766
564	Screw Center for 58384 (2)		271939 (2)	271766	Retaining Ring for
679	Screw Stud	222616	Lever Spring		271763 (2)
717	Screw	249713	Stop Screw Block	271767	Retaining Ring for
748	Screw (Arm, back) (2)		with 457		271615 (2)
795	Set Screw	249741	Interlocking Rod	271797	Machine Driving Belt
868	Screw (Arm, front) (2)	249858	Bracket Extension with		(endless) 5/16" diameter,
871	Stop Screw		51047		46" long
913	Thumb Screw	249861	Collar with 237	271802	Slow-speed Adjusting
1241	Screw Stud	249864	Trip Stud		Lever
1469	Screw Stud	265672	Retaining Ring	271803	Lever Bracket
1508	Nut (2)	271495	Spring	271925	Crank
1518	Nut	271522	Belt Shifter Operating	271937	Starting Lever Bracket
1520	Nut (2)		Actuator	271938	Starting Lever
1521	Nut	271523	Actuator Block with 350287	271939	Stop Cam with two 202330
1619	Lock Nut for 271940	271524	Belt Shifter Shaft	271940	Guide with 1619 and
1638	Nut	271615	Loose Pulley with 271734		350635, for 271968
1655	Lock Nut		and two 271767	271950	Spring
1959	Roller and Screw Stud	271617	Tight Pulley with 140321	271965	Bracket Stop
	with 229 and 12424 for	271618	Positive Drive Pulley	271968	Interlocking Rod Guide
	271968		for 271763		271940 with 1959
2269	Pin (2)	271619	Gear with Cam Spring	271977	Belt Shifter with 350287
8582	Dowel Pin (4)		Cover and three 389	350235	Hinge Screw (back)
12424	Washer	271650	Gear Stud	350287	Set Screw (3)
21651	Spring	271653	Stop Cam Pinion with 453	350288	Hinge Screw
23520	Tension Releaser Shaft	271654	Releaser Arm	350339	Screw Stud (2)
23554	Spring	271655	Spiral Pin	350635	Set Screw for 271940


PARTS FOR MACHINE 271K1
(See Numerical List on opposite page)



NUMERICAL LIST OF PARTS FOR MACHINE 271K1
(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
32	Hinge Screw	50138	Screw for 271481 (2)	271546	Thumb Screw Rest
52	Hinge Screw	50150	Set Screw for 271792	271678	Cutting Blade Connecting Rod
67	Regulator Screw	50156	Support Screw (2)	271679	Latch with 141575 and 201711
157	Screw	50221	Thumb Screw	271680	Latch Spring
160	Set Screw	50416	Hinge Screw	271684	Adjustable Stop
184	Stop Screw	140071	Hinge Screw	271685	Crank with 906, for 271484
190	Screw	141554	Screw (2)	271687	Cam Follower
203	Screw (2)	141557	Hinge Screw	271688	Cutting Lever
212	Screw	141558	Hinge Screw	271689	Adjustable Connection
219	Screw for 271484	141575	Releasing Screw for 271679	271690	Connection Link
223	Screw (4)	141597	Regulator Screw Stud for 249623	271691	Spring
228	Screw (2)		Cap Screw	271702	Thumb Screw Sleeve
237	Screw	141675	Screw Stud for 271532	271749	Lower Thread Pull-off
240	Screw (3)	201437	Hinge Screw	271780	Cutting Blade Carrier with 40038
337	Adjusting Screw (2)	201476	Lock Nut	271792	Collar with 50150
397	Screw (2)	201624	Nut for 271679	271799	Oil Supply Tube (brass) for Machine Bed
404	Screw (6)	201711	Washer (2)	271800	Lever
435	Screw	202622	Washer	271805	Friction Plate
646	Screw Stud	228026	Crank Pin for 271484	271806	Return Spring
690	Screw (2)	232105	Hinge Stud with 263572	271891	Socket Joint
702	Adjusting Screw	232709	Lever Spring	271892	Connecting Rod
742	Bearing Screw (3)	249534	Clamp Carrier Regulator with 240, 1960 and 39583	271893	Slide Guide (left)
756	Screw (2)	249623	Friction Plate	271894	Slide Guide (right)
889	Set Screw for 271543		Clamp Carrier Plate	271895	Clamp Carrier Slide Lever Regulator
906	Set Screw for 271685	249749	Cutting Blade Shaft for 271484	271896	Bushing
934	Screw (2)	249753	Stop Lever	271920	Left Guide for 271921
1094	Screw (4)	249827	Washer	271921	Clamp Carrier Slide with 1345, 271920 and two 756
1230	Screw (Right Guide) (2)	249922	Oil Packing Wick	271922	Right Guide for Clamp Carrier
1231	Screw (Plate, back) (2)	250444	Mat Housing (with 3/32" rubber) for 271484	271923	Holder (used with 271481)
1234	Regulating Stud	263572	Clamp Check with 271482 and two 50138	271924	Clamp Carrier Block with 40007 and four 404
1235	Screw (4)	271465	Cutting Plate for 271481	271926	Lower Thread Cutting Blade
1241	Screw Stud (2)		Pressure Spring	271932	Slide Lever with 1960
1256	Slide Screw (2)	271481	Clamp Check complete, for 3/8" to 3/4"	271933	Tripping Lever
1296	Screw (3)	271482	buttonholes, 219, 702, 232105, 249827, 271465, 271481, 271483, 271685, 271941, 271942 and two 50093	271941	Upper Thread Clamping Blade for 271484
1345	Screw for 271921	271483	Adjusting Plate	271942	Upper Thread Cutting Blade for 271484
1520	Nut (3)	271484	Clamp Arm	271945	Clamp Carrier with Stay Plate and two 934
1521	Nut		Hinge Block with 201437	271947	Needle Plate
1620	Nut		Pin	271951	Tripping Lever Point
1623	Sleeve Nut		Bearing	350234	Plate Screw (2)
1658	Thumb Nut		Clamp Lifting Arm	350237	Hinge Screw
1671	Nut		Clamp Plate	350265	Hinge Screw (2)
1772	Adjusting Nut		Clamp Plate Block with 889	350459	Screw
1960	Roller and Screw Stud with 1520 (2)		Clamp Plate Block Support		
2273	Position Pin	271487	Clamp Spring		
23390	Washer	271531			
23396	Regulator Cap	271532			
23435	Spring	271533			
39532	Stud Sleeve	271535			
39583	Stud Stop for 249623	271539			
39715	Washer	271542			
40007	Plate for 271924	271543			
40038	Stud for 271780				
40045	Washer (nylon)	271544			
50093	Screw for 271484 (2)	271545			


(See Numerical List on opposite page)



NUMERICAL LIST OF PARTS FOR MACHINE 271K1
(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
157	Screw	210541	Needle Guard for	271591	Oil Tube (brass)
175	Screw for 249869	271575		271592	Screw Stud for 271471
181	Screw (2)	210734	Latch Lever for 271787	271593	Pin for 271575
201	Screw	210735	Fulcrum Pin for 271787	271621	Safety Tripping Lever
202	Collar Screw for 271630	210736	Latch Spring for 271785	271622	Lever Lock
217	Screw	233028	Bobbin	271623	Lock Plate
229	Screw	239515	Spiral Pin (2)	271624	Release Plate
401	Screw	244746	Ring (rubber) for 271585	271625	Sewing Safety Lock
448	Set Screw (2)	249801	Barring Plate (1st)	271626	Actuating Cam
453	Set Screw (3)	249804	Barring Plate (2nd)	271627	Cam Plate
458	Set Screw (2)	249863	Trip Point for 249869	271628	Engaging Plate
460	Set Screw (2)	249869	Collar with 175, 756, 23466,	271629	Hinge Bracket
591	Screw for 271784		249863 and two 448	271630	Collar with 202
592	Stop Screw for 271785	249947	Pitman (front) for 271633	271632	Pitman (rear) for 271633
717	Screw	251170	Lever Spring	271633	Sewing Safety Lock Pitman
756	Screw	265672	Retaining Ring		complete, 249947, 271632,
792	Screw	271417	Adjusting Collar with		two each 914 and 39541
898	Screw		50379	271649	Gear Driver
904	Position Screw for	271456	Adjustable Bushing (front)	271655	Spiral Pin
	271566	271471	Hook Oil Control Screw	271656	Releaser Lever with 140321
914	Screw for 271633 (2)		Stud 271592 with 271808,	271657	Lever Shaft
980	Hinge Screw (2)		for 271575	271670	Lower Thread Cutting
1241	Screw Stud (2)	271474	Oil Chain Guard (lower)		Lever
1351	Ball Screw	271475	Oil Chain Guard (upper)	271671	Cutting Lever Extension
1352	Screw Bushing		with two 350595	271681	Tripping Plate
1520	Nut (2)	271489	Spring	271686	Cutting Cam with two 458
1620	Nut	271515	Cam with two 453	271741	Oil Drip Guide
1901	Roller and Screw Stud	271525	Bobbin Case Base for	271757	Hand Ratchet Lever
	with 229 and 12424		271526	271758	Lever Bracket with 1241
7071	Washer	271526	Bobbin Case complete,	271772	Bracket Spring
9046	Position Pin		271525 and 271785 for	271784	Cap with 591, 141514 and
12424	Washer		271576		271964, for 271785
23466	Tripping Point for	271527	Opener Bracket with	271785	Bobbin Case complete, 592,
	249869		271828, 271829 and		210736, 271784 and 271787,
39541	Washer (5)		271974		for 271526
40025	Position Pin	271530	Bobbin Case Stop	271786	Latch for 271787
40052	Lock Pin	271540	Arm Connection	271787	Latch 271786 with 210734
40053	Spring	271541	Stud Bracket		and 210735 for 271785
50057	Hinge Screw	271565	Driving Shaft	271788	Oil Packing Wick
50379	Set Screw for 271417	271566	Driving Shaft Gear	271789	Hook Gib for 271575
50579	Screw (Guard, lower) (2)		with 904	271795	Tripping Point for 271834
53569	Lock Nut	271567	Driving Shaft Gear	271808	Seal Ring (rubber) for 271471
140321	Set Screw		(intermediate)	271828	Oiling Felt for 271527
140566	Hinge Screw	271568	Stud	271829	Oiling Felt Pin for 271527
141024	Set Screw	271569	Washer	271830	Oil Packing Wick
141507	Screw for 271575	271573	Collar with two 460	271832	Hinge Stud
141514	Screw for 271784	271574	Sewing Hook with 502535,	271833	Oil Regulating Screw Stud
141525	Screw for 271575 (3)		for 271575	271834	Feed Wheel with 271795
141547	Socket Screw (2)	271575	Hook 271574 with 141507,		and two 141563
141556	Hinge Screw		210541, 271471, 271593,	271927	Feed Wheel Shaft
141563	Screw for 271834 (2)		271789 and three 141525	271949	Spring
141602	Position Screw		for 271576	271964	Tension Spring for 271784
141629	Set Screw	271576	Hook and Bobbin Case	271974	Oiling Felt
141659	Screw (Adjustable		complete, 271526 and	350109	Hinge Screw
	Extension)		271575	350114	Lock Screw (2)
201381	Screw	271585	Hook Driving Shaft with	350229	Plate Screw (2)
201474	Stop Screw		244746 and two 141547	350365	Screw
201668	Clamping Nut	271586	Bushing (back)	350595	Set Screw for 271475
206482	Washer (2)	271589	Oil Chain (endless)	502535	Oiling Felt

PARTS FOR MACHINE 271K1
(See Numerical List on opposite page)



NUMERICAL LIST OF PARTS FOR MACHINE 271K1

(illustrated on opposite page)

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
35	Hinge Screw, for 271713	243799	Oil Seal (neoprene) for 271721	271713	Bobbin Winder complete, 35, 1620, 50356, 239241, 249716, 271704, 271706, 271708, 271709, 271712, 271798, two each 161, 171 and 240245 for 271717
161	Screw (2)	249716	Spring for 271713	271714	Guide for 271715
171	Screw for 271713 (2)	249789	Gauge Chain and Ring for 249803	271715	Thread Guide 271714 with 271948, for 271717
176	Screw (2)	249803	Gauge (Buttonhole) with 200137 and 249789	271717	Bobbin Winder with Thread Guide complete, 271713, 271715 and two 792
190	Screw	249820	Wrench for 1352, 1607 and 1772	271718	Belt Guard with 271751, two each 217 and 228661
203	Screw (2)	249883	Oil Tube (brass)	271721	Machine Base with 243798, 243799, 271723, two each 203, 271725, 271778, 271779, four each 50615, 271722, 271762 and two Wood Screws (1-1/2", 12 F. H.) for 271726
217	Screw (2)	249945	Wrench for 1517, 1518, 1520, 1619, 201732 and 350712	271722	Rubber Cushion for 271721 (4)
389	Screw (8)	255513	Tweezers	271723	Oil Reservoir Cover for 271721
418	Screw Stud for 271948	255540	Wrench for 1520, 1620, 1655, 1664, 201624, 201732 and 271684	271725	Bracket for 271721 (2)
792	Screw (2)	255541	Wrench for 1517, 1518, 1619, 271702 and 350712	271726	Machine Base and Belt Guard complete, 271718, 271721, two 271732 and eight 389
934	Screw (8)	259477	Screwdriver (1-3/4" Blade)	271732	Hinge for 271726 (2)
1235	Screw	267242	Wrench (3/32") for 141547	271751	Lock Spring for 271718
1562	Thumb Nut for 271948	271464	Tension Spring	271752	Spring Catch
1620	Nut	271488	Tension Guide	271761	Lock Spring for 271512
2455	Tension Disc for 271948(2)	271510	Side Cover (left) with two 271804	271762	Cushion Cap for 271721 (4)
11831	Screw driver (5" Blade)	271511	Side Cover (right)	271778	Spiral Pin for 271721 (2)
21654	Washer for 1508, 1638 and 53570	271512	Top Cover with 190 and 271761	271779	Pin Sleeve (plastic) for 271721 (2)
23535	Wrench for 1521, 1547, 1671, 1698, 51047, 141575, 201711, 350114 and 350287	271514	Hinge for 271512	271791	Insert Cushion (rubber) (8)
50356	Hinge Screw for 271713	271521	Oil Guard with 249883	271798	Friction Ring (rubber) for 271713
50615	Screw for 271721 (4)	271536	Slide	271804	Position Pin (2)
53564	Lock Nut for 271614	271614	Needle Thread Tension complete, 53564, 141544, 271464 and two 203962	271948	Bobbin Winder complete, 418, 1562, 232515 and two 2455 for 271715
120346	Oiler with 120347	271703	Hinge Connection (2)		1-1/2" Wood Screw No. 12 F. H. (2)
120347	Oiler Spout (8-1/2" long) for 120346	271704	Base for 271713		
141544	Stud for 271614	271705	Frame for 271706		
141572	Cover Screw (3)	271706	Frame 271705 with 225345 and 271711 for 271713		
200137	Screw for 249803	271707	Pulley for 271708		
203962	Tension Disc for 271614 (2)	271708	Pulley 271708 with 271710 for 271713		
225345	Spindle for 271706	271709	Pulley Bracket for 271713		
228476	Screwdriver for Bobbin Case (3" Blade)	271710	Shaft for 271708		
228661	Rubber Cushion (4)	271711	Spindle Pulley for 271706		
232515	Tension Spring for 271948	271712	Stop Latch for 271713		
232935	Wrench for 53561 (2)				
239241	Retaining Ring for 271713				
239353	Wrench (5/32") for 350713				
240245	Retaining Spring for 271713 (2)				
243798	Oil Level Indicator for 271721				

See page 58 for list of Driving Equipment, Special Fittings and other Accessories not illustrated in this Manual.

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K2
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

**OMIT THE FOLLOWING
PARTS LISTED FOR 271K1**

**ADD THE FOLLOWING
271K2 PARTS**

**CHANGE 271K1 LISTINGS
AS INDICATED BELOW**

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
271773	Arm Top Cover Plate	271411	Barring Slide Operating Rod Spring	271837	Arm Side Cover (left) with two 271804, in place of 271510
190	Arm Top Cover Plate Screw (2)	271413	Barring Slide Operating Rod Spring Bracket	271408	Automatic Knife Disengaging Lever, in place of 271953
249607	Barring Lever Spring	201784	Barring Slide Operating Rod Spring Bracket Nut	271410	Automatic Knife Disengaging Lever Thread Guide, in place of 271472
1330	Barring Lever Spring Screw Stud	210805	Barring Slide Operating Rod Spring Bracket Washer	271838	Barring Lever, in place of 271928
271482	Clamp Check Section and Cutting Plate	350287(806)	Barring Slide Operating Rod Spring Screw	271839	Barring Plate (first bar), in place of 249801
50138	Clamp Check Section and Cutting Plate Screw (2)	225734	Barring Slide Operating Rod Spring Washer	271840	Barring Plate (second bar), in place of 249804
1296	Clamp Check Stop Screw	271841	Barring Tension Plate (lower)	271485	Barring Plate Cam with two 453, in place of 271515
271483	Clamp Check Thread Clamping Pressure Spring	40043	Barring Tension Plate (lower) Collar (2) with 209	141644(803)	Barring Plate Screw (2), in place of 350229 (2)
1772	Clamp Check Thread Clamping Pressure Spring Adjusting Nut	209(831)	Barring Tension Plate (lower) Set Screw (2)	271412	Barring Slide Operating Stud, in place of 271930
702	Clamp Check Thread Clamping Pressure Spring Adjusting Screw (2)	271691	Barring Tension Plate (lower) Spring	271460	Barring Slide Stop, in place of 271931
157	Knife Holder Screw	271842	Barring Tension Plate (upper)	141670(803)	Barring Slide Stop Adjusting Screw, in place of 898
1651	Needle Bar Frame Connection Hinge Screw Nut	141628(805)	Barring Tension Screw Stud for 271843	1607(805)	Barring Slide Stop Adjusting Screw Nut, in place of 452
203962	Needle Thread Tension Disc (2)	271414	Barring Tension Spring	271415	Bed Oil Guard with 249883, in place of 271521
53564	Needle Thread Tension Regulating Thumb Nut	12400	Barring Tension Spring Guide	271419	Bobbin Case Base, in place of 271525
271464	Needle Thread Tension Spring	1562(809)	Barring Tension Spring Regulating Nut	271420	Bobbin Case complete 271419 and 271785, in place of 271526
141544	Needle Thread Tension Stud	271843	Barring Tension Support Bracket with 141628	271418	Bobbin Case Stop, in place of 271530
271614	Needle Thread Tension, complete 53564, 141544, 271464 and two 203962	190(804)	Barring Tension Support Bracket Screw (2)	271845	Clamp Arm with 50166, in place of 271531
39675	Starting Lever Spring Collar with two 191	271880	Barring Tie Stitch Plate	271846	Clamp Arm Hinge Block with 141624, in place of 271532
191	Starting Lever Spring Collar Set Screw (2)	141644(803)	Barring Tie Stitch Plate Screw (4)	227224	Clamp Arm Hinge Block Pin Collar with 201052, in place of 271792
271916	Tension (side of arm) Releaser with 200	206482	Barring Tie Stitch Plate Screw Washer (4)	201052(833)	Clamp Arm Hinge Block Pin Collar Set Screw, in place of 50150
271654	Tension (side of arm) Releaser Arm	271844	Bight Stitch Adjusting Point	271416	Clamp Carrier Regulator Slide, in place of 271536
271655	Tension (side of arm) Releaser Arm Pin (spiral)	141623(803)	Bight Stitch Adjusting Point Adjusting Screw	271403	Clamp Check, in place of 271481
200	Tension (side of arm) Releaser Set Screw	1550(803)	Bight Stitch Adjusting Point Adjusting Screw Nut	271849	Clamp Check Holder, in place of 271923
23520	Tension (side of arm) Releaser Shaft	350287(803)	Bight Stitch Adjusting Point Screw		
271925	Tension (side of arm) Releaser Shaft Crank	271807	Hook Driving Shaft Hook Driver Lock Pin		
679	Tension (side of arm) Releaser Shaft Crank Ball Screw Stud	141673(850)	Knife Holder and Needle Thread Pull-off Roller Arm Bracket Screw		
1520	Tension (side of arm) Releaser Shaft Crank Ball Screw Stud Nut	271858	Needle Thread Pull-off with 350287		
2269	Tension (side of arm) Releaser Shaft Crank Pin	350287(803)	Needle Thread Pull-off Hub Screw for 271858		
		271859	Needle Thread Pull-off Latch		
		271860	Latch Spring		

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K2
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

**OMIT THE FOLLOWING
PARTS LISTED FOR 271K1**

**ADD THE FOLLOWING
271K2 PARTS**

**CHANGE 271K1 LISTINGS
AS INDICATED BELOW**

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION		
32012	Tension (top of arm)	201883	Needle Thread Pull-off	271402	Clamp Check Mat Housing
	Disc (2) (Part used on rear		Roller for 351895		with 1/16" Rubber Pad,
	Tension on 271K2)	351895	Needle Thread Pull-off		in place of 271465
51570	Tension (top of arm)		Roller 201883 with 141661	141601(819)	Clamp Check Mat Housing
	Regulating Thumb Nut		for 271980		Screw (2), in place of
249687	Tension (top of arm)	271980	Needle Thread Pull-off		50093 (2)
	Releaser Rod		Roller Arm with 351895	271404	Clamp Check complete
40043	Tension (top of arm)	271981	Needle Thread Pull-off		271402, 271403 and two
	Releaser Rod Collar		Roller Arm Bracket		141601 for 3/8" to 11/16"
209	Tension (top of arm)	203(819)	Needle Thread Pull-off		buttonholes, in place
	Releaser Rod Collar Set		Roller Arm Screw		of 271484
	Set Screw	141661(803)	Needle Thread Pull-off	271486	Face Plate, in place
271691	Tension (top of arm)		Roller Arm Screw Stud		of 271547
	Releaser Rod Spring	271982	Needle Thread Pull-off	271500	Face Plate 271486 with
32572	Tension (top of arm)		Shaft		1423, 271667 and 271692,
	Releasing Disc (Part	271457	Needle Thread Pull-off		in place of 271548
	used on rear Tension		Shaft Collar with 141625	350781(830)	Feed Ratchet Gear Stud
	271K2)	141625(803)	Needle Thread Pull-off		Set Screw, in place
271661	Tension (top of arm)		Shaft Collar Set Screw		of 140930
	Releasing Lever		for 271457	271564	Feed Wheel with 271795
271662	Tension (top of arm)	1423(804)	Needle Thread Pull-off		and two 141563, in place
	Releasing Lever		Shaft Screw (2)		of 271834
	Connection	271983	Needle Thread Pull-off	141602(803)	Feed Wheel Driving Shaft
974	Tension (top of arm)		Shaft Spring		Gear (intermediate) Stud
	Releasing Lever	350229(805)	Needle Thread Pull-off		Set Screw in place
	Connection Screw (back)		Stop Screw		of 141024
940	Tension (top of arm)	1550(805)	Needle Thread Pull-off	249698	Gauge for Setting
	Releasing Lever		Stop Screw Nut		Buttonhole Length, with
	Connection Screw (front)	191(806)	Needle Thread Tension		200137 and 249789, in
90	Tension (top of arm)		Guide Screw		place of 249803
	Releasing Lever Hinge	271984	Needle Thread Tension	271421	Hook and Bobbin Case
	Screw		(rear) Actuator with 336		complete 271420 and
39635	Tension (top of arm)	271985	Needle Thread Tension		271575, in place
	Releasing Pin (Part used		(rear) Bracket for		of 271576
	on rear Tension 271K2)		271988	271470	Knife Holder, in place
350399	Tension (top of arm)	161(804)	Needle Thread Tension		of 271919
	Screw Stud		(rear) Bracket Screw	271992	Starting Lever, in place
1664	Tension (top of arm)	32012	Needle Thread Tension		of 271938
	Screw Stud Lock Nut		(rear) Disc (2), for 271988	271640	Stitch Regulating Gear,
271665	Tension (top of arm)	1560(803)	Needle Thread Tension		40 teeth, in place of
	Spring		(rear) Regulating Thumb		one 271641
271774	Tension (top of arm)		Nut, for 271988	271643	Stitch Regulating Gear,
	Thread Eyelet (double)	32572	Needle Thread Tension		48 teeth, in place of
212	Tension (top of arm)		(rear) Releasing Disc,		one 271641
	Thread Eyelet Screw		for 271988	448(833)	Thread (lower) Cutting
141575	Thread (upper) Cutting	39635	Needle Thread Tension		Blade Carrier Lever Stop
	Blade Connecting Rod		(rear) Releasing Pin,		Screw, in place of 435
	Latch Releasing Screw		for 271988	271993	Thread (lower) Cutting
201711	Thread (upper) Cutting	271986	Needle Thread Tension		Blade (stationary) for
	Blade Connecting Rod		(rear) Rod		271995, in place of 271941
	Latch Releasing Screw Nut	50057(804)	Needle Thread Tension	271994	Thread (lower) Cutting
201437	Thread (upper) Cutting		(rear) Actuator Screw		Blade, for 271995, in
	Blade Connecting Rod		for 271986		place of 271942
	Latch Spring Stop Screw	336(806)	Needle Thread Tension	271995	Thread (lower) Cutting
	Stud		(rear) Rod Set Screw		Blade Arm with 934,
2273	Thread (upper) Cutting	350399(806)	Needle Thread Tension		271993 and 271994 in
	Blade Connecting Rod		(rear) Screw Stud, for		place of 271678
	Position Pin		271988	1423(806)	Blade Arm Screw (2),
271806	Thread (upper) Cutting	271987	Secondary Spring, for		in place of 201476 (2)
	Blade Connecting Rod		271988		
	Return Spring				

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K2
(Same as Complete List for MACHINE 271K1 with the following EXCEP TIONS)

**OMIT THE FOLLOWING
PARTS LISTED FOR 271K1**

**ADD THE FOLLOWING
271K2 PARTS**

**CHANGE 271K1 LISTINGS
AS INDICATED BELOW**

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
271487	Thread (upper) Cutting Blade Connecting Rod Return Spring Adjusting Plate	191(806)	Sewing Safety Lever Extension Screw (2)	271425	Thread (lower) Cutting Blade Connecting Rod Latch with 1698 and 141627, in place of 271679
271684	Thread (upper) Cutting Blade Connecting Rod Stop (Adjustable)	204925	Sewing Safety Lever Extension Screw Washer (2), for 271991	271499	Thread (lower) Cutting Blade Driving Arm Latch Spring, in place of 271680
201624	Rod Stop Lock Nut	271991	Sewing Safety Lever complete, 271989, 271990 two 191 and 204925	271451	Thread (upper) Cutting Cam with 141671, 351894 and two 145, in place of 271686
40045	Thread (upper) Cutting Blade Connecting Rod Stop Washer (nylon)	268072	Tension (Side of Arm) Releaser Lever Shaft Collar with two 200386	271452	Thread (upper) Cutting Cam Follower, in place of 271687
228026	Thread (upper) Cutting Blade Connecting Rod Washer	200386(803)	Tension (Side of Arm) Releaser Lever Shaft Collar Set Screw	271453	Thread (upper) Cutting Cam Follower Link, in place of 271690
219	Thread (upper) Cutting Blade Screw	934(819)	Thread (upper) Cutting Blade Screw for 271995	145(806)	Thread (upper) Cutting Cam Screw (2), in place of 458 (2)
249827	Thread (upper) Cutting Blade Shaft	271996	Thread (upper) Cutting Blade Driving Arm with 141624	23669	Thread Guide (side of arm) (lower), in place of 271693
271685	Thread (upper) Cutting Blade Shaft Crank with 906	271997	Thread (upper) Cutting Blade Driving Arm Actuating Lever	39711	Thread Guide (side of arm) (upper), in place of 271781
232105	Thread (upper) Cutting Blade Shaft Crank Pin	271998	Thread (upper) Cutting Blade Driving Arm Actuating Lever Spring		
906	Thread (upper) Cutting Blade Shaft Crank Set Screw	50166(805)	Thread (upper) Cutting Blade Driving Arm Actuating Lever Spring Screw Eye for 271845		
271688	Thread (upper) Cutting Lever Spring	141624(803)	Thread (upper) Cutting Blade Driving Arm Guide Screw for 271996		
271691	Thread (upper) Pull-off	141627(803)	Thread (upper) Cutting Blade Driving Arm Ratchet Screw for 271425		
271783	Thread (upper) Pull-off	1698(803)	Thread (upper) Cutting Blade Driving Arm Ratchet Screw Nut for 271425		
704	Thread (upper) Pull-off Screw	271401	Thread (upper) Cutting Blade Driving Arm Safety		
39541	Thread (upper) Pull-off Screw Washer	141624(803)	Thread (upper) Cutting Blade Driving Arm Screw, for 271846		
ADD THE FOLLOWING 271K2 PARTS		272000	Thread (upper) Cutting Blade Guide Plate		
271665	Needle Thread Tension (rear) Spring, for 271988	141626(850)	Thread (upper) Cutting Blade Guide Plate Follower Screw		
1664(805)	Needle Thread Tension (rear) Stud Lock Nut, for 271988	51064(803)	Thread (upper) Cutting Blade Guide Plate Screw		
271988	Needle Thread Tension (rear) complete, 1560, 1664, 32572, 39635, 271665, 271985, 271987, 350399 and two 32012	351894	Thread (upper) Cutting Cam Roller for 271451		
271989	Sewing Safety Lever Clamp with 1149	141671(803)	Thread (upper) Cutting Cam Roller Screw Stud for 271451		
1149(830)	Sewing Safety Lever Clamp Pinch Screw for 271989				
271990	Sewing Safety Lever Extension with 1822				
1822	Sewing Safety Lever Extension Roller for 271990				

NOTES: Thread (upper) Pull-off on Machine 271K1 is replaced on Machine 271K2 with "Needle Thread Pull-off".
Tension (top of arm) on Machine 271K1 is replaced on Machine 271K2 with "Needle Thread Tension (rear)".

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K3
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

OMIT THE FOLLOWING PARTS LISTED FOR 271K1		ADD THE FOLLOWING 271K3 PARTS		CHANGE 271K1 LISTINGS AS INDICATED BELOW	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
934	Clamp Carrier Stay Plate Screw (2) (Omit Stay Plate from Chart also)	271852	Clamp Arm Plate	271462	Clamp Check complete for 3/4" to 1-1/2" buttonholes, 219, 232105, 249827, 249976, 249977, 249986 and 271685, in place of 271484
271923	Clamp Check Holder	249958	Clamp Carrier Guard	271853	Clamp Plate, in place of 271542
337	Clamp Check Holder Adjusting Screw (2)	244(804)	Clamp Carrier Guard Screw	271854	Feed Driving Gear, 72 teeth, in place of 271550
249749	Clamp Check Holder Adjusting Screw Friction Plate	1348(805)	Clamp Check Section and Cutting Plate Support Stud for 249986	271855	Feed Ratchet Gear (upper), 24 teeth, in place of 271559
212	Clamp Check Holder Hinge Cap Screw			271856	Feed Wheel with 271795 and two 141563, in place of 271834
237	Clamp Check Holder Stop Screw	CHANGE 271K1 LISTINGS AS INDICATED BELOW		141602(803)	Feed Wheel Driving Shaft Gear (intermediate) Stud Set Screw, in place of 141024
39715	Clamp Check Holder Stop Screw Washer	NUMBER	DESCRIPTION	249984	Gauge, for setting length of buttonhole, with 200137 and 249789, in place of 249803
271465	Clamp Check Mat Housing with 3/32" rubber	249954	Barring Plate (2), in place of 249801 and 249804	235706	Hook Driving Connection Belt Pulley Oiling Wick, in place of 271423
50093	Clamp Check Mat Housing Screw (2)	271851	Clamp Arm, in place of 271531	39558	Knife, 1-1/2", in place of 271901
1296	Clamp Check Stop Screw	1083(803)	Clamp Arm Screw (3), in place of 141554 (2)	271491	Needle Plate, in place of 271947
271483	Clamp Check Thread Clamping Pressure Spring	39541	Clamp Arm Screw Washer (3) in place of 202622 (2)	141666(803)	Needle Plate Screw (2), in place of 350234 (2)
1772	Clamp Check Thread Clamping Pressure Spring Adjusting Nut	249957	Clamp Carrier, in place of 249945 with Stay Plate and two 934	271639	Stitch Regulating Gear, 40 teeth, in place of one 271641
702	Clamp Check Thread Clamping Pressure Spring Adjusting Screw	39591	Clamp Carrier Guide (left), in place of 271920	271644	Stitch Regulating Gear, 50 teeth, in place of one 271641
		271498	Clamp Carrier Plate, in place of 249753	448(833)	Thread Lower Cutting Blade Carrier Lever Stop Screw, in place of 435
		249960	Clamp Carrier Regulator with 240, 1960 and 39583, in place of 249623	249976	Thread (upper) Clamping Blade, in place of 271941
		1480(803)	Clamp Carrier Regulator Cap Screw, in place of 141675	249977	Thread (upper) Cutting Blade, in place of 271942
		39720	Clamp Carrier Slide with 1345, 39591 and two 756, in place of 271921	271857	Thread (upper) Cutting Blade Connecting Rod, in place of 271678
		249986	Clamp Check with 249987, two each 237 and 1348 for 3/4" to 1-1/2" buttonholes, in place of 271481	173(803)	Thread (upper) Cutting Blade Connecting Rod Latch Tripping Plate Screw in place of 201
		1297(806)	Clamp Check Screw (2), in place of 1296 (2)		
		249987	Clamp Check Section and Cutting Plate, in place of 271482		
		237(804)	Clamp Check Section and Cutting Plate Screw, (2) in place of 50138 (2)		

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K4
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

OMIT THE FOLLOWING PARTS LISTED FOR 271K1		ADD THE FOLLOWING 271K4 PARTS		CHANGE 271K1 LISTINGS AS INDICATED BELOW	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
249804	Barring Plate (2nd bar)	262006	Cord Rotating Gear Slide Sleeve	350229(805)	Barring Plate Screw (List 1 not 2)
934	Clamp Carrier Stay Plate Screw (omit Stay Plate from Parts Chart also)	262007	Cord Rotating Gear Slide Sleeve Slide Rod	206482	Barring Plate Screw Washer (List 1 not 2)
271923	Clamp Check Holder	271868	Cord Rotating Gear Slide Sleeve Slide Rod Connection	271862	Bed Oil Guard with 249883, in place of 271521
337	Clamp Check Holder Adjusting Screw	871(806)	Cord Rotating Gear Slide Sleeve Slide Rod Connection Handle Screw	271863	Bobbin Case Cap with 591, 141514 and 271964, in place of 271784
249749	Friction Plate	1200(806)	Cord Rotating Gear Slide Sleeve Slide Rod	271864	Bobbin Case Cap complete, 592, 210736, 271787 and 271863 in place of 271785
212	Clamp Check Holder Hinge Cap Screw	1521(804)	Cord Rotating Gear Slide Sleeve Slide Rod Nut	271865	Bobbin Case complete, 271525 and 271864, in place of 271526
237	Clamp Check Holder Stop Screw	39784	Cord Rotating Gear Slide Sleeve Spring	271851	Clamp Arm, in place of 271531
39715	Clamp Check Holder Stop Screw Washer	39856	Cord Rotating Sector with 7071, 39832 and two 201321	1083(803)	Clamp Arm Screw (3), in place of 141554
271465	Clamp Check Mat Housing	39832	Cord Rotating Sector Adjustable Catch Natch Gib	39541	Clamp Arm Screw Washer (3), in place of 202622
50093	Clamp Check Mat Housing Screw (2)	201321(803)	Cord Rotating Sector Adjustable Catch Natch Gib Screw (2)	249957	Clamp Carrier, in place of 271945
1296	Clamp Check Stop Screw	7071	Cord Rotating Sector Adjustable Catch Natch Gib Screw Washer	271498	Clamp Carrier Plate, in place of 249753
271483	Clamp Check Thread Clamping Pressure Spring	39775	Cord Rotating Sector Catch	249960	Clamp Carrier Regulator with 240, 1960 and 39583 in place of 249623
1772	Clamp Check Thread Clamping Pressure Spring Adjusting Nut	39776	Cord Rotating Sector Catch Connection	1480(803)	Clamp Carrier Regulator Cap Screw, in place of 141675
702	Clamp Check Thread Clamping Pressure Spring Adjusting Screw	240(804)	Cord Rotating Sector Catch Screw (2)	39720	Clamp Carrier Slide with 1345, 271920 and two 756, in place of 271921
271830	Hook Driving Shaft Bushing (back) Oil Packing Wick	271869	Cord Rotating Sector Catch Spring	39914	Clamp Check with 39915, 50354 and two 237, in place of 271481
2269	Tension (side of arm) Releaser Shaft Crank Pin	1034(806)	Cord Rotating Sector Catch Spring Screw	1297(830)	Clamp Check Screw (2) in place of 1296
32012	Tension (top of arm) Disc (2)	440(830)	Cord Rotating Sector Catch Stop Screw	39915	Clamp Check Sector and Cutting Plate, in place of 271482
51570	Tension (top of arm) Regulating Thumb Nut	1547(819)	Cord Rotating Sector Catch Stop Screw Nut	237(819)	Clamp Check Section and Cutting Plate Screw, in place of 50138
249687	Tension (top of arm) Releaser Rod	350342(804)	Cord Rotating Sector Hinge Screw (eccentric)	39916	Clamp Check complete, for 3/8" to 3/4" buttonhole, 219, 2269, 39838, 39867, 39914 and 40050, in place of 271484
40043	Tension (top of arm) Releaser Rod Collar with 209 (2)	1520(809)	Cord Rotating Sector Hinge Screw Nut	271853	Clamp Plate, in place of 271542
209	Tension (top of arm) Releaser Rod Collar Set Screw (2)	213949	Cord Rotating Sector Hinge Screw Washer	271871	Face Plate 271870 with 236, 418, 1562, 18859, 39770, 39789, 39790 and two 2445 in place of 271548
271691	Tension (top of arm) Releaser Rod Spring	262009	Cord Rotating Tripping Cam with two 458		
32572	Tension (top of arm) Releasing Disc	458(803)	Cord Rotating Tripping Cam Set Screw (2)		
271661	Tension (top of arm) Releasing Lever	39750	Cord Take-up Spring		
271662	Tension (top of arm) Releasing Lever Connection	2455	Cord Tension Disc (2)		
974	Tension (top of arm) Releasing Lever Connection Screw (back)	418(804)	Cord Tension Screw Stud		
940	Tension (top of arm) Releasing Lever Connection Screw (front)	39789	Cord Tension Spring		
		1562(819)	Cord Tension Thumb Nut		
		271866	Clamp Arm Plate		

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K4
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

OMIT THE FOLLOWING PARTS LISTED FOR 271K1		ADD THE FOLLOWING 271K4 PARTS		CHANGE 271K1 LISTINGS AS INDICATED BELOW	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
90	Tension (top of arm) Releasing Lever Hinge Screw	141554(830)	Clamp Arm Plate Screw (2)	271870	Face Plate, in place of 271547
39365	Tension (top of arm) Releasing Pin	202622	Clamp Arm Plate Screw Washer (2)	271872	Feed Wheel with 271795 and two 141563, in place of 271834
350399	Tension (top of arm) Screw Stud	249958	Clamp Carrier Guard	141602(803)	Feed Wheel Driving Shaft Gear (intermediate) Stud Set Screw, in place of 141024
1664	Tension (top of arm) Screw Stud Lock Nut	244(804)	Clamp Carrier Guard Screw	262026	Gauge for Setting Buttonhole Length with 200137 and 249789, in place of 249803
271665	Tension (top of arm) Spring	50354(805)	Clamp Check Section and Cutting Plate Support Stud (short)	271873	Hook and Bobbin Case complete, 271575 and 271865, in place of 271576
271744	Tension (top of arm) Thread Eyelet (double)	18859	Cord Guide	235706	Hook Driving Connection Belt Pulley Oiling Wick, in place of 271423
212	Tension (top of arm) Thread Eyelet Screw	39899	Cord Leading Bracket	39829	Knife, 3/4", in place of 271901
271666	Thread Check Bracket	39768	Cord Leading Bracket Dowel Pin	39796	Knife Holder, in place of 271919
9544	Thread Check Cap	389(806)	Cord Leading Bracket Screw	1094(806)	Knife Screw, in place of 191
9543	Thread Check Disc (2)	39770	Cord Leading Eye (double)	39541	Knife Screw Washer, in place of 23390
9545-001	Thread Check Spring	236(804)	Cord Leading Eye Screw	271874	Needle Bar 271596 with 904, in place of 271835
208	Thread Check Screw	271946	Cord Leading Finger (lower)	271441	Needle Bar Frame with 241189, 270200, 271610 and 271611, in place of 271440
271667	Thread Check complete	350067(805)	Cord Leading Finger (lower) Screw	271492	Needle Plate, in place of 271947
271692	Thread Guide (on face plate)	39853	Cord Leading Finger (lower) Screw Washer	141666(803)	Needle Plate Screw (2), in place of 350234 (2)
1423	Thread Guide Screw	39854	Cord Leading Finger (upper)	904(830)	Needle Set Screw, in place of 336
		230(806)	Cord Leading Finger (upper) Screw	271638	Stitch Regulating Gear, 36 teeth, in place of one 271641
		271497	Cord Leading Finger complete, 39853, 39854, 271496 and 350067	271642	Stitch Regulating Gear, 48 teeth, in place of one 271641
		39855	Cord Rotating Gear	271876	Tension (side of arm) Releaser Shaft, in place of 23520
		39773	Cord Rotating Gear Gib (back)	271877	Tension (side of arm) Releaser Shaft Crank with 202, in place of 271925
		39772	Cord Rotating Gear Gib (front)	448(833)	Thread (lower) Cutting Blade Carrier Stop Screw, in place of 435
		1329(804)	Cord Rotating Gear Gib Screw (4)	271490	Thread (lower) Cutting Blade Friction Plate, in place of 271805
		39780	Cord Rotating Gear Slide		
		39781	Cord Rotating Gear Slide Block		
		271867	Cord Rotating Gear Slide Collar with two 141667		
		141667(830)	Cord Rotating Gear Slide Collar Set Screw (2)		
		39788	Cord Rotating Gear Slide Connecting Spring		
		262004	Cord Rotating Gear Slide Connecting Spring Plate		
		1241(804)	Cord Rotating Gear Slide Connecting Spring Screw Eye (front)		
		262005	Cord Rotating Gear Slide Extension		
		185(806)	Cord Rotating Gear Slide Extension Screw (2)		
		40013	Guide		
		1238(806)	Guide Screw		
		202(806)	Tension (side of arm) Releaser Shaft Adjusting Screw		

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K4
 (Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

**CHANGE 271K1 LISTINGS
 AS INDICATED BELOW**

NUMBER	DESCRIPTION
39867	Thread and Cord (upper) Clamping Blade, in place of 271941
39858	Thread and Cord (upper) Cutting Blade, in place of 271942
271878	Thread and Cord (upper) Cutting Blade Connecting Rod, in place of 271678
350265(803)	Hinge Screw, in place of 201476
173(803)	Thread and Cord (upper) Cutting Blade Connecting Rod Latch Tripping Plate Screw, in place of 201
271493	Thread and Cord (upper) Cutting Blade Connecting Rod Return Spring, in place of 271806
39866	Thread and Cord (upper) Cutting Blade Shaft, in place of 249827
40050	Thread and Cord (upper) Cutting Blade Shaft Crank with 906, in place of 271685
2269	Thread and Cord (upper) Cutting Blade Shaft Crank Pin, in place of 232105
271879	Thread and Cord (upper) Cutting Cam with two 458, in place of 271686
222598	Thread and Cord (upper) Cutting Cam Follower Hinge Stud Oil Packing Wick, in place of 263572

NOTE: All parts of Thread (upper) Cutting Device on Machine 271K1 have been changed to read "Thread and Cord (upper) Cutting", when used on Machine 271K4.

SUPPLEMENTARY PARTS LIST FOR MACHINE 271K201
(Same as Complete List for MACHINE 271K1 with the following EXCEPTIONS)

OMIT THE FOLLOWING PARTS LISTED FOR 271K1		ADD THE FOLLOWING 271K201 PARTS		CHANGE 271K1 LISTINGS AS INDICATED BELOW	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
271717	Bobbin Winder with Thread Guide complete	262185	Cloth Plate (front)	262181	Arm Side Cover (left) with two 271804, in place of 271510
249753	Clamp Carrier Plate	140091(804)	Cloth Plate (front) Screw (2)	262103	Clamp Carrier with two 934, in place of 271945
1231	Clamp Carrier Plate	262186	Cloth Plate (lower)	235706	Hook Driving Connection Belt Pulley Oiling Wick, in place of 271423
404	Screw (back) (2)	51946	Cloth Plate (lower) Roller and Screw Stud	271902	Knife, 9/16" in place of 271901
	Clamp Carrier Plate (front) (2)	262187	Cloth Plate (lower) Roller Bearing Plate	262188	Machine Base with 243798, 243799, 271723, 271725, 271778, 271779, two each 203, 50615, four each 271722 and 271762 for 262189, in place of 271721
271536	Clamp Carrier Regulator Slide	930(819)	Cloth Plate (lower Roller Bearing Plate Screw (2)	262189	Machine Base and Belt Guard complete, 262188, 271719, two each 271732 and eight 389, in place of 271726
271801	Knife Bar Driving Lever Screw Stud	756(804)	Cloth Plate (lower) Screw (4)	262183	Needle Plate, in place of 271947
271797	Machine Driving Belt	262144	Cloth Plate (upper) Mounting Bracket	271424	Stop Cam Gear Stud Oiling Wick, in place of 271651
249922	Stop Lever	257237	Cloth Plate (upper) Mounting Bracket Material Retainer	448(833)	Thread (lower) Cutting Blade Carrier Lever Stop Screw, in place of 435
50416	Stop Lever Hinge Screw	1300(804)	Cloth Plate (upper) Mounting Bracket Screw (left)	271671-601	Thread (lower) Cutting Lever Extension, in place of 271671
1-1/2" Wood Screws No. 12 F. H. (2)		1460(804)	Cloth Plate (upper) Mounting Bracket Screw (right)	173(803)	Thread (upper) Cutting Blade Connecting Rod Latch Tripping Plate Screw, in place of 201
		232131	Cloth Plate (upper) Mounting Bracket Screw Washer (2)	222598	Thread (upper) Cutting Cam Follower Hinge Stud Oil Packing Wick, in place of 263572
		262166	Cycling Switch Actuating Lever Driving Stud		
		262182	Machine Starting Lever Push Rod Bracket Mounting Block		
		350654(833)	Machine Starting Lever Push Rod Bracket Mounting Block Screw (2)		
		262118	Machine Starting Lever Rod Trip Lever		
		262119	Machine Starting Lever Rod Trip Lever Bracket		
		350647(833)	Machine Starting Lever Rod Trip Lever Bracket Screw		
		262120	Machine Starting Lever Rod Trip Lever Pin		
		262184	Oil Splash Guard (lower section)		
		1239(804)	Oil Splash Guard Fastening Screw		
		207(804)	Oil Splash Guard Screw		
		259929	Wrench, for 1671		

(Not Illustrated)

271906	Knife, 13/16"
271907	Knife, 7/8"
271908	Knife, 15/16"
271909	Knife, 1"
271458	Stitch Regulating Gear, 40 teeth
271459	Stitch Regulating Gear, 44 teeth
271634	Stitch Regulating Gear, 30 teeth
271635	Stitch Regulating Gear, 32 teeth
271636	Stitch Regulating Gear, 36 teeth
271637	Stitch Regulating Gear, 36 teeth
271638	Stitch Regulating Gear, 36 teeth
271639	Stitch Regulating Gear, 40 teeth
271640	Stitch Regulating Gear, 40 teeth
271642	Stitch Regulating Gear, 48 teeth
271643	Stitch Regulating Gear, 48 teeth
271644	Stitch Regulating Gear, 50 teeth
271645	Stitch Regulating Gear, 54 teeth
271646	Stitch Regulating Gear, 60 teeth
271647	Stitch Regulating Gear, 60 teeth
271648	Stitch Regulating Gear, 60 teeth

271899	Knife, 3/8"
271903	Knife, 5/8"
271905	Knife, 3/4"
228776	Thread Unwinder (two spools) complete, 228766 to 228768, 228770, 228774, two each 150203, 228764, 228769 and three wood screws 7/8" No. 12 R. H. B.
60913	Thread Unwinder Spool Weight with 60914
27739	Thread Unwinder Thread Cone (wood)
225390	Thread Unwinder Thread Cone Holder

MACHINE 271K2
DRIVING EQUIPMENT AND OTHER ACCESSORIES
(Not Illustrated)

DRIVING EQUIPMENT		ACCESSORIES		SPECIAL FITTINGS	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
228909	Clamp Lifting Chain, 36" long, with 39575 and 39576	228776	Thread Unwinder (two spools) complete, 228766 to 228768, 228770, 228774, two each 150203, 228764, 228769 and three wood screws 7/8" No. 12	271905	Knife, 3/4"
250408	Machine Rest (high) with 232982 and two wood screws 1" No. 12			271458	Stitch Regulating Gear, 40 teeth
228349	Starting Chain complete, 228333, 228347, 228348, two each 39575 and 39576	60913	Thread Unwinder Spool Weight with 60914	271459	Stitch Regulating Gear, 44 teeth
228757	Treadle complete, 2718(813), 14372 to 14375, 17881, 50581(813), two each 23250, 51074(813) and 67425 (2)	27739	Thread Unwinder Thread Cone (wood)	271634	Stitch Regulating Gear, 30 teeth
151223	Motor Mount and Belt Tightener complete, 51655(813), 150783, 151066, 151219 to 151222, two each 9281, 151068, four each 50807(813), 151369, eight each 1778(813), 9842, and 126150, for Series 38 continuous running Motor	225390	Thread Unwinder Thread Cone Holder	271635	Stitch Regulating Gear, 32 teeth
	ACCESSORIES		SPECIAL FITTINGS (Available on specific order)	271636	Stitch Regulating Gear, 36 teeth
271899	Knife, 3/8"	271847	Clamp Check for 3/8" to 1 1/16" buttonhole. Use Clamp Check Holder 271850	271637	Stitch Regulating Gear, 36 teeth
271903	Knife, 5/8"	271407	Clamp Check for 3/8" to 1" buttonhole (1/16" thick rubber mat).	271638	Stitch Regulating Gear, 36 teeth
271904	Knife, 1 1/16"	271848	Clamp Check for 3/8" to 1" buttonhole. Use Clamp Check Holder 271850	271639	Stitch Regulating Gear, 40 teeth
		271850	Clamp Check Holder	271641	Stitch Regulating Gear, 45 teeth
		271900	Knife, 7/16"	271642	Stitch Regulating Gear, 48 teeth
		271902	Knife, 9/16"	271644	Stitch Regulating Gear, 50 teeth
				271645	Stitch Regulating Gear, 54 teeth
				271646	Stitch Regulating Gear, 60 teeth
				271647	Stitch Regulating Gear, 60 teeth
				271648	Stitch Regulating Gear, 60 teeth

MACHINE 271K3
DRIVING EQUIPMENT AND OTHER ACCESSORIES
(Not Illustrated)

DRIVING EQUIPMENT		ACCESSORIES		SPECIAL FITTINGS	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
228909	Clamp Lifting Chain, 36" long, with 39575 and 39576	228776	Thread Unwinder (two spools) complete, 228766 to 228768, 228770, 228774, two each 150203, 228764, 228769 and three wood screws 7/8" No. 12	271459	Stitch Regulating Gear, 44 teeth
250408	Machine Rest (high) with 232982 and two wood screws 1" No. 12			271634	Stitch Regulating Gear, 30 teeth
228349	Starting Chain complete, 228333, 228347, 228348, two each 39575 and 39576	60913	Thread Unwinder Spool Weight with 60914	271635	Stitch Regulating Gear, 32 teeth
228757	Treadle complete, 2718(813), 14372 to 14375, 17881, 50581(813), two each 23250, 51074(813) and 67425 (2)	27739	Thread Unwinder Thread Cone (wood)	271636	Stitch Regulating Gear, 36 teeth
151223	Motor Mount and Belt Tightener complete, 51655(813), 150783, 151066, 151219 to 151222, two each 9281, 151068, four each 50807(813), 151369, eight each 1778(813), 9842, and 126150, for Series 38 continuous running Motor	225390	Thread Unwinder Thread Cone Holder	271637	Stitch Regulating Gear, 36 teeth
	ACCESSORIES		SPECIAL FITTINGS (Available on specific order)	271638	Stitch Regulating Gear, 36 teeth
271909	Knife, 1"	271905	Knife, 3/4"	271640	Stitch Regulating Gear, 40 teeth
271911	Knife, 1-1/8"	271906	Knife, 13/16"	271641	Stitch Regulating Gear, 45 teeth
271913	Knife, 1-1/4"	271907	Knife, 7/8"	271642	Stitch Regulating Gear, 48 teeth
		271908	Knife, 15/16"	271643	Stitch Regulating Gear, 48 teeth
		271910	Knife, 1-1/16"	271645	Stitch Regulating Gear, 54 teeth
		271912	Knife, 1-3/16"	271646	Stitch Regulating Gear, 60 teeth
		39555	Knife 1-5/16"	271647	Stitch Regulating Gear, 60 teeth
		39556	Knife, 1-3/8"	271648	Stitch Regulating Gear, 60 teeth
		39557	Knife, 1-7/16"		
		271458	Stitch Regulating Gear, 40 teeth		

MACHINE 271K4
DRIVING EQUIPMENT AND OTHER ACCESSORIES
(Not Illustrated)

DRIVING EQUIPMENT		ACCESSORIES		SPECIAL FITTINGS	
NUMBER	DESCRIPTION	NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
228909	Clamp Lifting Chain, 36" long, with 39575 and 39576	228776	Thread Unwinder (two spools) complete, 228766 to 228768, 228770, 228774, two each 150203, 228764, 228769 and three wood screws 7/8" No. 12	271634	Stitch Regulating Gear, 30 teeth
250408	Machine Rest (high) with 232982 and two wood screws 1" No. 12			271635	Stitch Regulating Gear, 32 teeth
228349	Starting Chain complete, 228333, 228347, 228348, two each 39575 and 39576	60913	R. H. B. Thread Unwinder Spool Weight with 60914	271636	Stitch Regulating Gear, 36 teeth
228757	Treadle complete, 2718(813), 14372 to 14375, 17881, 50581(813), two each 23250, 51074(813) and 67425 (2)	27739	Thread Unwinder Thread Cone (wood)	271637	Stitch Regulating Gear, 36 teeth
151223	Motor Mount and Belt Tightener complete, 51655(813), 150783, 151066, 151219 to 151222, two each 9281, 151068, four each 50807(813), 151369, eight each 1778(813), 9842, and 126150, for Series 38 continuous running Motor	225390	Thread Unwinder Thread Cone Holder	271639	Stitch Regulating Gear, 40 teeth
39799	Knife, 3/8"			271640	Stitch Regulating Gear, 40 teeth
39800	Knife, 1/2"			271641	Stitch Regulating Gear, 45 teeth
39801	Knife, 5/8"			271643	Stitch Regulating Gear, 48 teeth
			SPECIAL FITTINGS (Available on specific order)	271644	Stitch Regulating Gear, 50 teeth
		39923	Clamp Check complete, for 13/16" to 1-1/4" buttonhole	271645	Stitch Regulating Gear, 54 teeth
		39840	Knife, 7/16"	271646	Stitch Regulating Gear, 60 teeth
		39831	Knife, 9/16"	271647	Stitch Regulating Gear, 60 teeth
		39841	Knife, 11/16"	271648	Stitch Regulating Gear, 60 teeth
		271458	Stitch Regulating Gear, 40 teeth		
		271459	Stitch Regulating Gear, 44 teeth		

MACHINE 271K201
SPECIAL FITTINGS
(Available on specific order)

STITCH REGULATING GEARS

NUMBER	DESCRIPTION	NUMBER	DESCRIPTION
271458	Stitch Regulating Gear, 40 teeth	271640	Stitch Regulating Gear, 40 teeth
271459	Stitch Regulating Gear, 44 teeth	271642	Stitch Regulating Gear, 48 teeth
271634	Stitch Regulating Gear, 30 teeth	271643	Stitch Regulating Gear, 48 teeth
271635	Stitch Regulating Gear, 32 teeth	271644	Stitch Regulating Gear, 50 teeth
271636	Stitch Regulating Gear, 36 teeth	271645	Stitch Regulating Gear, 54 teeth
271637	Stitch Regulating Gear, 36 teeth	271646	Stitch Regulating Gear, 60 teeth
271638	Stitch Regulating Gear, 36 teeth	271647	Stitch Regulating Gear, 60 teeth
271639	Stitch Regulating Gear, 40 teeth	271648	Stitch Regulating Gear, 60 teeth